



4. Front Transverse Link

A: REMOVAL


- 1) Set the vehicle on the lift.
- 2) Disconnect the ground terminal from battery.
- 3) Lift-up the vehicle and remove the wheel.
- 4) Remove the sub frame. <Ref. to FS-16, REMOVAL, Sub Frame.>
- 5) Disconnect the stabilizer link from transverse link.
- 6) Remove the bolt securing the ball joint of transverse link to housing.



- 7) Remove the nut (do not remove bolt.) securing the transverse link to crossmember.
- 8) Remove the two bolts securing the bushing bracket of transverse link to vehicle body at rear bushing location.



- 9) Extract the ball joint from housing.
- 10) Remove the bolt securing the transverse link to crossmember and extract the transverse link from crossmember.



B: INSTALLATION

- 1) Temporarily tighten the two bolts used to secure the rear bushing of the transverse link to body.

NOTE:

These bolts should be tightened to such an extent that they can still move back and forth in the oblong shaped hole in the bracket (which holds the bushing).

- 2) Install the bolts used to connect the transverse link to crossmember and temporarily tighten with nut.


CAUTION:

Discard the loosened self-locking nut and replace with a new one.

- 3) Insert the ball joint into housing.
- 4) Connect the stabilizer link to transverse link, and temporarily tighten bolts.

CAUTION:

Discard the loosened self-locking nut and replace with a new one.



- 5) Tighten the following points in the order shown below when the wheels are in full contact with the ground and vehicle is curb weight.

- (1) Transverse link and stabilizer

Tightening torque:

Sedan Turbo model:

45 N·m (4.6 kgf-m, 33 ft-lb)

Except sedan Turbo model:

30 N·m (3.1 kgf-m, 22 ft-lb)

- (2) Transverse link and crossmember

Tightening torque:

100 N·m (10.2 kgf-m, 74 ft-lb)


- (3) Transverse link rear bushing and body

Tightening torque:

250 N·m (25.5 kgf-m, 184 ft-lb)

NOTE:

- Move the rear bushing back and forth until transverse link-to-rear bushing clearance is established (as indicated in figure.) before tightening.



(1) Rear bushing


6) Install the sub frame. <Ref. to FS-16, INSTALLATION, Sub Frame.>

7) Inspect the wheel alignment and adjust if necessary. <Ref. to FS-8, Wheel Alignment.>


C: DISASSEMBLY**1. FRONT BUSHING**

Using ST, press the front bushing out of place.

ST 927680000 INSTALLER & REMOVER SET

**2. REAR BUSHING**


- 1) Scribe an aligning mark on the transverse link and rear bushing.
- 2) Loosen the nut and remove the rear bushing.

**D: ASSEMBLY****1. FRONT BUSHING**

To reassemble, reverse disassembly procedures.

CAUTION:

Install the front bushing in correct direction, as shown in the figure.



(1) Face bushing toward center of ball joint

(2) Ball joint

2. REAR BUSHING

- 1) Install the rear bushing to transverse link and align the aligning marks scribed on the two.

2) Tighten the self-locking nut.

CAUTION:

- Discard the loosened self-locking nut and replace with a new one.
- While holding the rear bushing so as not to change position of aligning marks, tighten the self-locking nut.

Tightening torque:

190 N·m (19.4 kgf-m, 140 ft-lb)

E: INSPECTION

- 1) Check the transverse link for wear, damage and cracks, and correct or replace if defective.
- 2) Check the bushings for cracks, fatigue or damage.
- 3) Check the rear bushing for oil leaks.