


PIPE ASSEMBLY

POWER ASSISTED SYSTEM (POWER STEERING)

6. Pipe Assembly

A: REMOVAL

- 1) Disconnect the battery ground terminal.
- 2) Lift the vehicle and remove the jack-up plate.




(1) Jack-up plate

- 3) Remove one pipe joint at the center of gearbox, and connect a vinyl hose to the pipe and joint. Discharge the fluid by turning steering wheel fully clockwise and counterclockwise. Discharge the fluid similarly from the other pipe.


CAUTION:

Improper removal and installation of parts often causes fluid leak trouble. To prevent this, clean the surrounding portions before disassembly and reassembly, and pay special attention to keep dirt and other foreign matter from mating surfaces.



(1) Pipe A
(2) Pipe B

- 4) Remove the clamp E from pipes C and D.




(1) Return hose
(2) Pressure hose
(3) Clamp E
(4) Pipe C
(5) Pipe D

- 5) Disconnect the pipe C-D from the pipe (on the gearbox side).

CAUTION:

- When disconnecting pipe C-D, use two wrenches to prevent deformities.
- Be careful to keep pipe connections free from foreign matter.




(1) Pipe C
(2) Pipe D

6) Non-TURBO model:

- (1) Remove the air intake duct. <Ref. to IN(H4SO)-7, REMOVAL, Air Intake Duct.>
- (2) Remove the bolt A.
- (3) Disconnect the pipe C from the oil pump.
- (4) Disconnect the pipe D from the return hose.

CAUTION:

- Do not allow fluid from the hose end to come into contact with pulley belt.
- To prevent foreign matter from entering the hose and pipe, cover the open ends of them with a clean cloth.




- (1) Bolt A
- (2) Pipe C
- (3) Pipe D

7) TURBO model:

- (1) Remove the air intake duct, air cleaner upper cover and air intake boot.
<Ref. to IN(H4DOTC)-9, REMOVAL, Air Intake Duct.> and <Ref. to IN(H4DOTC)-7, REMOVAL, Air Cleaner.>
- (2) Remove the two bolts fixing pipe C and D.


(3) Remove the coolant filler tank.



- (4) Disconnect the pipe C from oil pump.
- (5) Disconnect the pipe D from the return hose.

CAUTION:

- Do not allow fluid from the hose end to come into contact with pulley belt.
- To prevent foreign matter from entering the hose and pipe, cover the open ends of them with a clean cloth.



- (1) Pipe C
- (2) Pipe D

PIPE ASSEMBLY

POWER ASSISTED SYSTEM (POWER STEERING)


B: INSTALLATION

- 1) Temporarily tighten the bolts fixing pipe C and D.

CAUTION:


Visually check that hose between tank and pipe D is free from bending or twisting.

- Non-TURBO model



- (1) Bolt A
- (2) Pipe C
- (3) Pipe D

- TURBO model



- (1) Pipe C
- (2) Pipe D

- (1) Connect the pipe D to oil tank.
- (2) Install the pipe C to oil pump.

CAUTION:

Use a new gasket.

Tightening torque:

39 N·m (4.0 kgf-m, 28.9 ft-lb)

- (3) Tighten bolts fixing pipe C and D.

Tightening torque:


13 N·m (1.3 kgf-m, 9.4 ft-lb)

- 2) Install the coolant filler tank. (Turbo model)

Tightening torque:

T1: 19 N·m (1.9 kgf-m, 13.7 ft-lb)


T2: 21 N·m (2.1 kgf-m, 15.2 ft-lb)



PIPE ASSEMBLY

POWER ASSISTED SYSTEM (POWER STEERING)

3) Temporarily connect the pipes C and D to the pipes (on the gearbox side).




- (1) Return hose
- (2) Pressure hose
- (3) Approx. 30 mm (1.18 in)
- (4) Clamp E
- (5) Pipe C
- (6) Pipe D
- (7) Pipe (on gearbox side)

4) Temporarily install the clamp E on the pipes C and D.

CAUTION:

Ensure that the letter "8" on each clamp are diagonally opposite each other as shown in figure.



- (1) Clamp E
- (2) Pipe C

5) Tighten the clamp E firmly.

Tightening torque:

7.4 N·m (0.75 kgf-m, 5.4 ft-lb)

6) Tighten the joint nut.


Tightening torque:

15 N·m (1.5 kgf-m, 10.8 ft-lb)

7) Connect the pipes A and B to the four pipe joints of gearbox. Connect the upper pipe B first, and lower pipe A second.

Tightening torque:

13 N·m (1.3 kgf-m, 9.4 ft-lb)



- (1) Pipe A
- (2) Pipe B

8) Install the jack-up plate.

9) Install the air intake duct. (Non-TURBO model).
<Ref. to IN(H4SO)-7, INSTALLATION, Air Intake Duct.>

10) Install the air intake duct, air intake boot and air cleaner upper cover. (TURBO model)

<Ref. to IN(H4DOTC)-7, INSTALLATION, Air Cleaner.> and <Ref. to IN(H4DOTC)-9, INSTALLATION, Air Intake Duct.>

11) Connect the battery ground terminal.


PIPE ASSEMBLY

POWER ASSISTED SYSTEM (POWER STEERING)

12) Feed the specified fluid.

NOTE:

Never start the engine before feeding the fluid; otherwise vane pump might be seized up.



PS-00179

(1) High-pressure hose

(2) No interference is allowed
between hoses.

(3) Clearance between crossmember

and pipe: 3 — 8 mm (0.12 — 0.31
in)

13) Finally check clearance between pipes and/or hoses, as shown above.

If the clearance between cruise control pump and power steering hose is less than 10 mm (0.39 in), proceed as follows:

(1) Move the clamped section (A) (refer to figure above.) down to a point where the pipe is close to crossmember.

Pipe-to-crossmember clearance:

10 mm (0.39 in), min.

(2) Check that clearance between cruise control pump and power steering hose is at least 10 mm (0.39 in). If it is not, bend section (B) down until a clearance of at least 10 mm (0.39 in) is obtained.

PIPE ASSEMBLY

POWER ASSISTED SYSTEM (POWER STEERING)

C: INSPECTION

Check all disassembled parts for wear, damage or other abnormalities. Repair or replace faulty parts as required.

Part name	Inspection	Remedy
Pipe	<ul style="list-style-type: none"> • O-ring fitting surface for damage • Nut for damage • Pipe for damage 	Replace with a new one.
Clamp	<ul style="list-style-type: none"> • Clamps for weak clamping force 	Replace with a new one.
Hose	<ul style="list-style-type: none"> • Flared surface for damage • Flare nut for damage • Outer surface for cracks • Outer surface for wear • Clip for damage • End coupling or adapter for degradation 	Replace with a new one.

CAUTION:

Although surface layer materials of rubber hoses have excellent weathering resistance, heat resistance and resistance for low temperature brittleness, they are likely to be damaged chemically by brake fluid, battery electrolyte, engine oil and automatic transmission fluid and their service lives are to be very shortened. It is very important to keep the hoses free from before mentioned fluids and to wipe out immediately when the hoses are adhered with the fluids.

Since resistances for heat or low temperature brittleness are gradually declining according to time accumulation of hot or cold conditions for the hoses and their service lives are shortening accordingly, it is necessary to perform careful inspection frequently when the vehicle is used in hot weather areas, cold weather area and/or a driving condition in which many steering operations are required in short time.

Particularly continuous work of relief valve over 5 seconds causes to reduce service lives of the hoses, the oil pump, the fluid, etc. due to over heat.

So, avoid to keep this kind of condition when servicing as well as driving.


Trouble	Possible cause	Corrective action
Pressure hose burst	Excessive holding time of relief status	Instruct customers.
	Malfunction of relief valve	Replace oil pump.
	Poor cold characteristic of fluid	Replace fluid.
Forced out return hose	Poor connection	Correct.
	Poor holding of clip	Retighten.
	Poor cold characteristic of fluid	Replace fluid.
Fluid bleeding out of hose slightly	Wrong layout, tensioned	Replace hose.
	Excessive play of engine due to deterioration of engine mounting rubber	Replace defective parts.
	Improper stop position of pitching stopper	Replace defective parts.
Crack on hose	Excessive holding time of relief status	Replace. Instruct customer.
	Excessive tightening torque for return hose clip	Replace.
	Power steering fluid, brake fluid, engine oil, electrolyte adhere on the hose surface	Replace. Pay attention on service work.
	Too many times use in extremely cold weather	Replace. Instruct customers.

PIPE ASSEMBLY

POWER ASSISTED SYSTEM (POWER STEERING)

CAUTION:

It is likely that although one judges fluid leakage, there is actually no leakage. This is because the fluid spilt during the last maintenance was not completely wiped off. Be sure to wipe off spilt fluid thoroughly after maintenance.



PS-00022

PIPE ASSEMBLY

POWER ASSISTED SYSTEM (POWER STEERING)

Fluid leaking area	Possible cause	Corrective action
Leakage from connecting portions of pipes and hoses, numbered with (1) through (10) in figure	Insufficient tightening of flare nut, catching dirt or the like, damage to flare or flare nut or eye bolt	Loosen and retighten, if ineffective, replace.
	Poor insertion of hose, poor clamping	Retighten or replace the clamp.
	Damaged O-ring or gasket	Replace O-ring or gasket pipe or hose with new one, if ineffective, replace the gearbox also.
Leakage from hose (11), (12) and (13) in figure	Crack or damage in hose	Replace with a new one.
	Crack or damage in hose hardware	Replace with a new one.
Leakage from surrounding of cast iron portion of oil pump (14) and (15) in figure	Damaged O-ring	Replace the oil pump.
	Damaged gasket	Replace the oil pump.
Leakage from oil tank (16) and (17) in figure	Crack in oil tank	Replace the oil tank.
Leakage from filler neck (18)	Damaged cap packing	Replace the cap.
	Crack in root of filler neck	Replace the oil tank.
	High fluid level	Adjust the fluid level.
Leakage from surrounding of power cylinder of gearbox (19) in figure	Damaged oil seal	Replace the oil seal.
Leakage from control valve of gearbox (20) and (21) in figure	Damaged packing or oil seal	Replace the problem parts.
	Damage in control valve	Replace the control valve.

NOTE:

Fluid level is specified at optimum position (range) for ordinary use. Accordingly, if the vehicle is used often under hard conditions such as on very rough roads or in mountainous areas, fluid may bleed out from cap air vent hole. This is not a problem. If a customer complains strongly and is not likely to be satisfied with the leakage, lower the fluid level to the extent that fluid will not bleed out under the conditions described, and have the customer check the fluid level and its quality more frequency than usual.