


8. Radiator Cap

A: INSPECTION

- 1) Attach the radiator cap to the tester.



- 2) Increase pressure until the tester gauge pointer stops. Radiator cap is functioning properly if it holds the service limit pressure for five to six seconds.

Standard pressure:

93 — 123 kPa (0.95 — 1.25 kg/cm², 14 — 18 psi)

Service limit pressure:

83 kPa (0.85 kg/cm², 12 psi)

NOTE:

Be sure to remove foreign matter and rust from the cap in advance otherwise, results of pressure test will be incorrect.