
6. Fuel Level Sensor

A: REMOVAL

For removal procedure, refer to “FU” section. <Ref. to FU(H4SO)-62, REMOVAL, Fuel Level Sensor.>

B: INSTALLATION

For installation procedure, refer to “FU” section. <Ref. to FU(H4SO)-62, INSTALLATION, Fuel Level Sensor.>