

## 16. Engine Malfunction Indicator Lamp (MIL)

### A: PROCEDURE

1. Activation of CHECK ENGINE malfunction indicator lamp (MIL). <Ref. to EN(H4SO)-50, ACTIVATION OF CHECK ENGINE MALFUNCTION INDICATOR LAMP (MIL), Engine Malfunction Indicator Lamp (MIL).>

↓

2. CHECK ENGINE malfunction indicator lamp (MIL) does not come on. <Ref. to EN(H4SO)-51, CHECK ENGINE MALFUNCTION INDICATOR LAMP (MIL) DOES NOT COME ON., Engine Malfunction Indicator Lamp (MIL).>

↓

3. CHECK ENGINE malfunction indicator lamp (MIL) does not go off. <Ref. to EN(H4SO)-54, CHECK ENGINE MALFUNCTION INDICATOR LAMP (MIL) DOES NOT GO OFF., Engine Malfunction Indicator Lamp (MIL).>

↓

4. CHECK ENGINE malfunction indicator lamp (MIL) does not blink at a cycle of 3 Hz. <Ref. to EN(H4SO)-55, CHECK ENGINE MALFUNCTION INDICATOR LAMP (MIL) REMAINS BLINKING AT A CYCLE OF 3 HZ., Engine Malfunction Indicator Lamp (MIL).>

↓

5. Check engine malfunction indicator lamp (MIL) remains blinking at a cycle of 3 Hz. <Ref. to EN(H4SO)-57, CHECK ENGINE MALFUNCTION INDICATOR LAMP (MIL) REMAINS BLINKING AT A CYCLE OF 3 HZ., Engine Malfunction Indicator Lamp (MIL).>

# ENGINE MALFUNCTION INDICATOR LAMP (MIL)

## ENGINE (DIAGNOSTICS)



### B: ACTIVATION OF CHECK ENGINE MALFUNCTION INDICATOR LAMP (MIL)

1) When the ignition switch is turned to ON (engine off), the CHECK ENGINE malfunction indicator lamp (MIL) in the combination meter illuminates.


#### NOTE:

If the MIL does not illuminate, perform diagnostics of the CHECK ENGINE light circuit or the combination meter circuit. <Ref. to EN(H4SO)-51, CHECK ENGINE MALFUNCTION INDICATOR LAMP (MIL) DOES NOT COME ON., Engine Malfunction Indicator Lamp (MIL).>


4) When the ignition switch is turned to ON (engine off) or to "START" with the test mode connector connected, the MIL blinks at a cycle of 3 Hz.



2) After starting the engine, the MIL goes out. If it does not, either the engine or the emission control system is malfunctioning.



3) If the diagnosis system senses a misfire which could damage the catalytic converter, the MIL will blink at a cycle of 1 Hz.



# ENGINE MALFUNCTION INDICATOR LAMP (MIL)

ENGINE (DIAGNOSTICS)

## C: CHECK ENGINE MALFUNCTION INDICATOR LAMP (MIL) DOES NOT COME ON.


### • DIAGNOSIS:

- The CHECK ENGINE malfunction indicator lamp (MIL) circuit is open or shorted.

### • TROUBLE SYMPTOM:

- When the ignition switch is turned ON (engine OFF), MIL does not come on.

### • WIRING DIAGRAM:



EN-01166

Step	Check	Yes	No
1 <b>CHECK OUTPUT SIGNAL FOR ECM.</b> 1) Turn ignition switch to ON. 2) Measure the voltage between ECM connector and chassis ground. <b>Connector &amp; terminal</b> <b>(B137) No. 28 (+) — Chassis ground (-):</b> Is the measured value less than the specified value?	1 V	Go to step 4. Is the measured value less than the specified value?	Go to step 2. Is the measured value less than the specified value?

# ENGINE MALFUNCTION INDICATOR LAMP (MIL)

## ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<b>2 CHECK FOR POOR CONTACT.</b> Does the MIL illuminate when shaking or pulling ECM connector and harness?	Illuminates.	Repair poor contact in ECM connector.	Go to step 3.
<b>3 CHECK ECM CONNECTOR.</b> Is the ECM connector correctly connected?	Correctly connected.	Replace the ECM. <Ref. to FU(H4SO)-48, Engine Control Module.>	Repair connection of ECM connector.
<b>4 CHECK HARNESS BETWEEN COMBINATION METER AND ECM CONNECTOR.</b> 1)Turn ignition switch to OFF. 2)Remove the combination meter. <Ref. to IDI-12, Combination Meter Assembly.> 3)Disconnect the connector from ECM and combination meter. 4)Measure the resistance of harness between ECM and combination meter connector. <b>Connector &amp; terminal</b> <b>(B137) No. 28 — (i12) No. 6:</b> Is the measured value less than the specified value?	1 Ω	Go to step 5.	Repair harness and connector. <b>NOTE:</b> In this case, repair the following: <ul style="list-style-type: none"><li>• Open circuit in harness between ECM and combination meter connector</li><li>• Poor contact in coupling connector</li></ul>
<b>5 CHECK FOR POOR CONTACT.</b> Check for poor contact in combination meter connector. Is there poor contact in combination meter connector?	There is poor contact.	Repair poor contact in combination meter connector.	Go to step 6.
<b>6 CHECK HARNESS BETWEEN COMBINATION METER AND IGNITION SWITCH CONNECTOR.</b> 1)Turn ignition switch to ON. 2)Measure the voltage between combination meter connector and chassis ground. <b>Connector &amp; terminal</b> <b>(i10) No. 7 (+) — Chassis ground (-):</b> Is the measured value more than the specified value?	10 V	Go to step 7.	Check the following and repair if necessary. <b>NOTE:</b> <ul style="list-style-type: none"><li>• Broken down ignition relay.</li><li>• Blown out fuse (No. 13).</li><li>• If replaced fuse (No. 13) blows easily, check the harness for short circuit between fuse (No. 13) and ignition relay connector.</li><li>• Open or short circuit in harness between fuse (No. 13) and battery terminal</li><li>• Open circuit in harness between fuse (No. 13) and ignition relay connector</li><li>• Poor contact in ignition relay connector</li><li>• Poor contact in ignition switch connector</li></ul>

## ENGINE MALFUNCTION INDICATOR LAMP (MIL)

### ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
7 <b>CHECK LAMP BULB.</b> Remove the engine malfunction indicator lamp bulb. Is the lamp bulb condition OK?	OK.	Repair combina-tion meter connec-tor.	Replace the lamp bulb.

# ENGINE MALFUNCTION INDICATOR LAMP (MIL)

## ENGINE (DIAGNOSTICS)

### D: CHECK ENGINE MALFUNCTION INDICATOR LAMP (MIL) DOES NOT GO OFF.


#### • DIAGNOSIS:

- The CHECK ENGINE malfunction indicator lamp (MIL) circuit is shorted.

#### • TROUBLE SYMPTOM:

- Although MIL comes on when the engine runs, a diagnostic trouble code is not shown on the Subaru Select Monitor or OBD-II general scan tool display.

#### • WIRING DIAGRAM:



Step	Check	Yes	No
1 <b>CHECK HARNESS BETWEEN COMBINATION METER AND ECM CONNECTOR.</b> 1) Turn ignition switch to OFF. 2) Disconnect the connector from ECM. 3) Turn ignition switch to ON. Does the MIL illuminate?	Illuminates.	Repair short circuit in harness between combination meter and ECM connector.	Replace the ECM. <Ref. to FU(H4SO)-48, Engine Control Module.>

## ENGINE MALFUNCTION INDICATOR LAMP (MIL)

## ENGINE (DIAGNOSTICS)

**E: CHECK ENGINE MALFUNCTION INDICATOR LAMP (MIL) REMAINS BLINKING AT A CYCLE OF 3 Hz.**


- **DIAGNOSIS:**

- The CHECK ENGINE malfunction indicator lamp (MIL) circuit is open or shorted.
- Test mode connector circuit is in open.

- TROUBLE SYMPTOM:

- When in inspection mode, MIL does not blink at a cycle of 3 Hz.

- **WIRING DIAGRAM:**



# ENGINE MALFUNCTION INDICATOR LAMP (MIL)

## ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
1 <b>CHECK STATUS OF CHECK ENGINE MALFUNCTION INDICATOR LAMP (MIL).</b> 1)Turn ignition switch to OFF. 2)Disconnect the test mode connector. 3)Turn ignition switch to ON. (Engine OFF) Does the MIL illuminate?	Illuminates.	Go to step 2.	Repair the MIL circuit. <Ref. to EN(H4SO)-51, CHECK ENGINE MALFUNCTION INDICATOR LAMP (MIL) DOES NOT COME ON., Engine Malfunction Indicator Lamp (MIL).>
2 <b>CHECK HARNESS BETWEEN COMBINATION METER AND ECM CONNECTOR.</b> 1)Turn ignition switch to OFF. 2)Disconnect the connector from ECM. 3)Turn ignition switch to ON. Does the MIL illuminate?	Illuminates.	Repair short circuit in harness between combination meter and ECM connector.	Go to step 3.
3 <b>CHECK HARNESS BETWEEN TEST MODE CONNECTOR AND CHASSIS GROUND.</b> 1)Turn ignition switch to OFF. 2)Disconnect the connector from ECM. 3)Measure the resistance of harness between test mode connector and chassis ground.  <i>Connector &amp; terminal</i> <i>(B76) No. 1 — Chassis ground:</i> Is the measured value less than the specified value?	1 Ω	Go to step 4.	Repair harness and connector.  NOTE: In this case, repair the following: <ul style="list-style-type: none"><li>• Open circuit in harness between test mode connector and chassis ground</li></ul>
4 <b>CHECK FOR POOR CONTACT.</b> Check for poor contact in ECM connector. Is there poor contact in ECM connector?	There is poor contact.	Repair poor contact in ECM connector.	Go to step 5.
5 <b>CHECK HARNESS BETWEEN ECM AND TEST MODE CONNECTOR.</b> 1)Connect the test mode connector. 2)Measure the resistance of harness between ECM and chassis ground.  <i>Connector &amp; terminal</i> <i>(B136) No. 3 — Chassis ground:</i> Is the measured value less than the specified value?	1 Ω	Go to step 6.	Repair open circuit in harness between ECM and test mode connector.
6 <b>CHECK FOR POOR CONTACT.</b> Check for poor contact in ECM connector. Is there poor contact in ECM connector?	There is poor contact.	Repair poor contact in ECM connector.	Replace the ECM. <Ref. to FU(H4SO)-48, Engine Control Module.>

## ENGINE MALFUNCTION INDICATOR LAMP (MIL)

## ENGINE (DIAGNOSTICS)

**F: CHECK ENGINE MALFUNCTION INDICATOR LAMP (MIL) REMAINS BLINKING AT A CYCLE OF 3 Hz.**


- **DIAGNOSIS:**

- Test mode connector circuit is shorted.

- TROUBLE SYMPTOM:

- MIL blinks at a cycle of 3 Hz when the ignition switch is turned to ON.

- **WIRING DIAGRAM:**



Step	Check	Yes	No
1 <b>CHECK TEST MODE CONNECTOR.</b> 1)Disconnect the test mode connector. 2)Turn ignition switch to ON. Does the MIL blink?	Blinks.	Go to step 2.	System is in good order.  NOTE: MIL blinks at a cycle of 3 Hz when test mode connector is connected.

## ENGINE MALFUNCTION INDICATOR LAMP (MIL)

### ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<b>2</b> <b>CHECK HARNESS BETWEEN ECM CONNECTOR AND ENGINE GROUNDING TERMINAL.</b> 1)Turn ignition switch to OFF. 2)Disconnect the connector from ECM. 3)Measure the resistance of harness between ECM connector and chassis ground. <i>Connector &amp; terminal</i> <i>(B136) No. 3 — Chassis ground:</i> Is the measured value less than the specified value?	5 Ω	Repair short circuit in harness between ECM and test mode connector.	Replace the ECM. <Ref. to FU(H4SO)-48, Engine Control Module.>