


24. Fuel Sub Level Sensor

A: REMOVAL

WARNING:


- Place "NO FIRE" signs near the working area.
- Be careful not to spill fuel on the floor.

1) Disconnect the ground cable from battery.



2) Lift up the vehicle.


3) Drain the fuel from the fuel tank. Set a container under the vehicle and remove the drain plug from the fuel tank.



4) Tighten the fuel drain plug.


Tightening torque:

26 N·m (2.65 kgf-m, 19.2 ft-lb)




5) Remove the rear seat.

6) Remove the service hole cover.




7) Disconnect the connector from the fuel sub meter.


8) Disconnect the fuel jet pump hose.



9) Remove the bolts which install the fuel sub meter unit on the fuel tank.



10) Remove the fuel sub meter unit.



FUEL SUB LEVEL SENSOR

FUEL INJECTION (FUEL SYSTEMS)

B: INSTALLATION

Install in the reverse order of removal.

Tightening torque:

4.4 N·m (0.45 kgf-m, 3.3 ft-lb)

