


IGNITION COIL AND IGNITOR ASSEMBLY

IGNITION


3. Ignition Coil and Ignitor Assembly

A: REMOVAL

- 1) Disconnect the ground cable from battery.




- 2) Disconnect spark plug cords from the ignition coil and ignitor assembly.
- 3) Disconnect connector from the ignition coil and ignitor assembly.



- (A) Spark plug cord
- (B) Connector
- (C) Ignition coil and ignitor assembly

- 4) Remove the ignition coil and ignitor assembly.



B: INSTALLATION

- 1) Install in the reverse order of removal.
For tightening torques, refer to "COMPONENT".
<Ref. to IG(H4SO)-3, COMPONENT, General Description.>

C: INSPECTION

Using a tester, inspect the following items. Replace if defective.

- 1) Primary resistance
- 2) Secondary coil resistance

CAUTION:

If the resistance is extremely low, this indicates the presence of a short-circuit.

Specified resistance:


[Primary side]

Between terminal No. 2 and No. 4

$0.73 \Omega \pm 10\%$

Between terminal No. 1 and No. 2

$0.73 \Omega \pm 10\%$



IG-00029


[Secondary side]

Between (A) and (B)

$12.8 k\Omega \pm 15\%$

Between (C) and (D)

$12.8 k\Omega \pm 15\%$



- 3) Insulation between primary terminal and case:
100 M Ω or more.