

SEAT BELT SYSTEM

SB


	Page
1. Seat Belt	2

1. Seat Belt

A: ADJUSTABLE SHOULDER BELT ANCHOR

1. FRONT

Each front seat belt system has an adjustable shoulder belt anchor which allows the occupant to select the most appropriate anchor height from among the five positions in a 100 mm (3.94 in) range.




SB-00098

(1) Push

2. REAR

The side rear seat belt system has an adjustable shoulder belt anchor which allows the occupant to select the most appropriate anchor height from among the three positions in a 36 mm (1.4 in) range.



SB-00099


(1) Push

SEAT BELT

SEAT BELT SYSTEM

B: REAR CENTER THREE-POINT TYPE SEAT BELT

A three-point type seat belt is available for the center seating position of the rear seat. The retractor is installed inside the right rear quarter panel.




SB-00101

(1) Retractor

C: AUTOMATIC RETRACTOR

When the front passenger's seat belt or any of the rear seat belts is drawn out completely, its retractor is placed in the automatic locking mode which is used when installing a child restraint system. In this mode, the belt can be retracted but cannot be extended. When the belt is retracted to a certain length, this mode is cancelled and normal operation is restored.



- (1) Fully retracted
- (2) Fully extended
- (3) Normal mode (belt can be retracted and pulled out)
- (4) Automatic lock mode (belt can be retracted but cannot be pulled out)
- (5) Automatic locking mode to normal mode changeover
- (6) Normal locking mode to automatic locking mode changeover

D: PRETENSIONER



1. CONSTRUCTION

The driver's and front passenger's seat belts are equipped with seat belt pretensioners. The pretensioners use the front sub sensors and the airbag control module inside sensors to control their operation. If the sensors detect an impact exceeding the predetermined level during a frontal or front-angled collision, the front seat belts are quickly rewound by the retractors to take up slacks for maximum restraining of the seat occupants. If the load placed on a seat belt exceeds the predetermined level, the torsion bar twists to allow the belt to be pulled out, thus lessening the load imposed on the belt wearer's chest. Once the seat belt pretensioner has been activated, the seat belt retractor remains locked and prevents the seat belt from being pulled out.

The gas generator is activated.

The generated gas pushes the steel balls.

Moving steel balls cause the ring gear to rotate.



SB-00103


(1) Tube	(5) Spring
(2) Ring gear	(6) Gas generator
(3) Pinion	(7) Torsion bar
(4) Steel ball	

MEMO

SEAT BELT

SEAT BELT SYSTEM

2. FUNCTION



SB-00105

- (A) • Collision occurs
- (B) • Front sub sensor, electric sensor and safety sensor detect an impact greater than the set level.
 - Operation of pretensioner
 - Airbags start to inflate
- (C) • Load limiter operates
- (D) • Operation complete
 - (1) Safety sensor and electric sensor
 - (2) Front sub sensor
 - (3) Air bag
 - (4) Retractor with pretensioner


SEAT BELT

SEAT BELT SYSTEM

3. PRETENSIONER CONNECTOR


Disconnection:

- 1) Lift the lock button using a thin tipped tool like a miniature screwdriver.



AB-00529

- 2) Pull the connector out from the connection point.



AB-00528

Connection:

Carefully insert the connector into the connection point. Push the connector until a "click" is heard from the lock button.