


# Engine Coolant Temperature Sensor

## FUEL INJECTION (FUEL SYSTEMS)


### 4. Engine Coolant Temperature Sensor

#### A: REMOVAL

- 1) Disconnect the ground cable from battery.



- 2) Remove the generator. <Ref. to SC(H4SO)-16, REMOVAL, Generator.>
- 3) Drain engine coolant. <Ref. to CO(H4DOTC)-14, DRAINING OF ENGINE COOLANT, REPLACEMENT, Engine Coolant.>
- 4) Disconnect the connectors from the engine coolant temperature sensor.



- 5) Remove the engine coolant temperature sensor.

#### B: INSTALLATION

Install in the reverse order of removal.

#### NOTE:

Use a new gasket.

#### Tightening torque:


18 N·m (1.8 kgf·m, 13.3 ft-lb)

#### C: INSPECTION

- 1) Immerse the engine coolant temperature sensor and a thermometer in water.

#### CAUTION:

Take care not to allow water to get into the engine coolant temperature sensor connector. Completely remove any water inside.



(A) Thermometer


(B) Engine coolant temperature sensor

(C) Hexagonal part height: To approx.  $\frac{1}{3}$

- 2) Raise water temperature gradually, measure the resistance between the engine coolant temperature sensor terminals when the temperature is 20°C (68°F) and 80°C (176°F).

#### NOTE:

Agitate the water for even temperature distribution.



Water temperature	Terminal No.	Standard
20°C (68°F)	1 and 2	$2.45 \pm 0.2 \text{ k}\Omega$
80°C (176°F)		$0.318 \pm 0.013 \text{ k}\Omega$