

## 11. Clutch Switch

### A: REMOVAL

- 1) Disconnect the ground cable from battery.
- 2) Remove the instrument panel lower cover.
- 3) Disconnect the connector of clutch switch.
- 4) Remove the clutch switches.

### B: INSTALLATION

#### 1. CLUTCH SWITCH

- 1) Move the clevis pin of push rod to left and right, retain it at the position where it moves smoothly, and measure the clutch pedal stroke.


##### **Clutch pedal full stroke A:**

**130 — 135 mm (5.12 — 5.31 in) (non-turbo model)**

**135 — 140 mm (5.31 — 5.51 in) (turbo model)**

##### **Tightening torque:**

**T: 8 N·m (0.8 kgf-m, 5.9 ft-lb)**




- 2) If the clutch pedal stroke is out of specification, adjust the stroke. <Ref. to CL-24, ADJUSTMENT, Clutch Pedal.>
- 3) Connect the clutch switch connector.

#### 2. CLUTCH START SWITCH

- 1) Fully depress the clutch pedal and hold it.
- 2) Install the clutch pedal plate and clutch switch so that the gap between them is 3 — 3.5 mm (0.12 — 0.14 in), and then tighten the lock nut.

**Tightening torque:**  
**8 N·m (0.8 kgf-m, 5.9 ft-lb)**




(A) Plate  
(B) Clutch switch  
(C) 3 — 3.5 mm (0.12 — 0.14 in)

- 3) Connect the clutch switch connector.
- 4) Make sure that engine does not start with clutch pedal not depressed.
- 5) Make sure that engine starts with clutch pedal fully depressed.

### C: INSPECTION

- 1) If the clutch switch does not operate properly (or if it does not stop at the specified position), replace it with a new part.

**Specified position L:**  
**2+1.5 mm (0.079+0.059 in)**




- 2) Check the clutch switch for continuity. If the resistance is not at the standard value, replace the switch.
  - (1) Disconnect the clutch switch connector.
  - (2) Measure the resistance between terminal 1 and 2 of the switch.

# Clutch Switch

## CLUTCH SYSTEM


- Clutch switch

Condition	Terminal No.	Specified resistance
When clutch pedal is depressed	No. 1 — No. 2	1 MΩ or more
When the clutch pedal is not depressed	No. 1 — No. 2	Less than 1 Ω



- Clutch start switch


Condition	Terminal No.	Specified resistance
When clutch pedal is depressed	No. 1 — No. 2	Less than 1 Ω
When the clutch pedal is not depressed	No. 1 — No. 2	1 MΩ or more



- 3) Make sure that engine does not start with clutch pedal not depressed. If the engine starts, adjust the clutch switch and check the clutch start circuit.
- 4) Make sure that engine starts with clutch pedal fully depressed. If the engine does not start, adjust the clutch switch and check the clutch start circuit.


## D: ADJUSTMENT

- 1) Loosen the lock nut of clutch start switch.



(A) Lock nut  
(B) Clutch start switch

- 2) Fully depress the clutch pedal and hold it.
- 3) Adjust the gap of the clutch pedal plate and the clutch switch to be 3 — 3.5 mm (0.12 — 0.14 in).



(A) Plate  
(B) Clutch start switch  
(C) 3 — 3.5 mm (0.12 — 0.14 in)

- 4) Tighten the lock nut.

**Tightening torque:**  
**8 N·m (0.8 kgf-m, 5.9 ft-lb)**