





### 24. Spot Map Light

#### A: REMOVAL

- 1) Disconnect the ground cable from battery.
- 2) Remove the lens (A) and spot map light mounting screws (B).
- Model without sunroof



- Model with sunroof



- 3) Disconnect the harness connectors and remove the spot map light.

#### B: INSTALLATION

Install each part in the reverse order of removal.


#### C: INSPECTION

##### 1. SPOT MAP LIGHT BULB


- 1) Visually check the bulb for blow out.
- 2) Check the bulb specification. <Ref. to LI-2, SPECIFICATION, General Description.>
- 3) Replace the bulb if it is found defective.

##### 2. SPOT MAP LIGHT SWITCH

- 1) Remove the spot map light.
- 2) Check the resistance of spot map light.
- Model without sunroof



- Model with sunroof



Switch position	Terminal No.	Standard
OFF	1 and 2	1 MΩ or more
ON	1 and 2	18±5.4 Ω

- 3) Replace the spot map light if it is found defective.