

2. VDC Control Module and Hydraulic Control Unit (VDC-CM&H/U)

A: REMOVAL

- 1) Disconnect the ground cable from battery.
- 2) Use compressed air to remove moisture and dust around the VDCCM&H/U.


NOTE:

If the terminals become dirty, it may cause improper contact.

- 3) Lift the lock lever and Disconnect the VDC-CM&H/U connector.

CAUTION:

Do not pull on the harness when disconnecting the connector.



- 4) Disconnect the brake pipes from the VDC-CM&H/U.
- 5) Wrap the brake pipe with a vinyl bag so as not to spill the brake fluid on the vehicle body.

CAUTION:


If brake fluid is spilled on the vehicle body, wash it off immediately with water and wipe clean.

- 6) Remove the nuts and remove the VDCCM&H/U.

CAUTION:

- **Do not drop or bump the VDCCM&H/U.**
- **Do not turn the VDCCM&H/U upside down or place it sideways for storage.**
- **Be careful not to let foreign matter enter the VDCCM&H/U.**

- Be careful that no water enters the connectors.



- 7) Remove the VDCCM&H/U bracket.


B: INSTALLATION

- 1) Install the VDCCM&H/U bracket.

Tightening torque:

33 N·m (3.3 kgf-m, 24.3 ft-lb)


- 2) Install the VDCCM&H/U with a new nut by aligning the damper groove of the VDCCM&H/U to the bracket side claw.



Tightening torque:

7.5 N·m (0.76 kgf-m, 5.5 ft-lb)

- 3) Connect the brake pipes to their correct VDC-CM&H/U positions.



Tightening torque:

T1: 15 N·m (1.5 kgf-m, 11.1 ft-lb)

T2: 19 N·m (1.9 kgf-m, 14 ft-lb)

VDC Control Module and Hydraulic Control Unit (VDCCM&H/U)

VEHICLE DYNAMICS CONTROL (VDC)

4) Connect the VDCCM&H/U connector.

NOTE:

- Be sure to remove all foreign matter from inside the connector before connecting.
- Make sure the VDCCM&H/U connector is securely locked.

5) Bleed air from the brake system.

6) Check the parameter to confirm that the applied models and grades of the relevant vehicle are included. <Ref. to VDC(diag)-19, PARAMETER CHECK, OPERATION, Subaru Select Monitor.>

7) If the applied model and grade of the target vehicle are not included on the {Confirm on parameter} display screen, perform parameter selection and registration. <Ref. to VDC(diag)-19, PARAMETER SELECTION, OPERATION, Subaru Select Monitor.>

NOTE:

- When the VDCCM&H/U is replaced with a new part, be sure to perform the selection · registration operation.
- For the selection and registration of parameter, the Subaru Select Monitor is required.
- When the registration has not been performed, the DTC code "Parameter selection error" is detected together with the ABS/EBD/VDC warning light illumination.


C: INSPECTION

1) Check the condition of connection and settlement of connector.

2) Check the mark used for VDCCM&H/U identification.

Refer to "SPECIFICATION" for identification mark.

<Ref. to VDC-2, SPECIFICATION, General Description.>



(1) Identification mark

1. CHECKING THE HYDRAULIC UNIT ABS OPERATION BY PRESSURE GAUGE

1) Lift up the vehicle, and then remove the wheels.
2) Remove the air bleeder screws from FL and FR caliper bodies.


3) Connect two pressure gauges to FL and FR caliper bodies.

CAUTION:

- Use a pressure gauge used exclusively for brake fluid measurement.
- Do not use the pressure gauge used for the measurement of transmission oil. Doing so will cause the piston seal to expand and deform.

NOTE:

Wrap sealing tape around the pressure gauge.



4) Bleed air from the pressure gauges and the FL and FR caliper bodies.

5) Perform ABS sequence control. <Ref. to VDC-13, ABS Sequence Control.>

6) When the hydraulic unit begins to work, first the FL side performs decompression, hold and compression, and then the FR side performs decompression, hold and compression.

7) Read values indicated on the pressure gauge and check if the fluctuation of the values between decompression and compression meets the standard values. Depress the brake pedal and check that the kick-back is normal, and tightness is normal.

| | Front wheel | Rear wheel |
|--------------------|--|--|
| Initial value | 3,500 kPa (36 kgf/cm ² , 511 psi) | 3,500 kPa (36 kgf/cm ² , 511 psi) |
| When depressurized | 500 kPa (5 kgf/cm ² , 73 psi) or less | 500 kPa (5 kgf/cm ² , 73 psi) or less |
| When pressurized | 3,500 kPa (36 kgf/cm ² , 511 psi) or more | 3,500 kPa (36 kgf/cm ² , 511 psi) or more |



8) Disconnect the pressure gauges from FL and FR caliper bodies.

9) Install the air bleeder screws of FL and FR caliper bodies.

- 10) Remove the air bleeder screws from RL and RR caliper bodies.
- 11) Connect two pressure gauges to RL and RR caliper bodies.
- 12) Bleed air from the brake system.
- 13) Bleed air from RL and RR caliper bodies, and pressure gauge.
- 14) Perform ABS sequence control. <Ref. to VDC-13, ABS Sequence Control.>
- 15) When the hydraulic unit begins to work, first the RR side performs decompression, hold and compression, and then the RL side performs decompression, hold and compression.
- 16) Read values indicated on the pressure gauge and check if the fluctuation of the values between decompression and compression meets specification. Depress the brake pedal and check that the kick-back is normal, and tightness is normal.
- 17) Disconnect the pressure gauge from the RL and RR caliper bodies.
- 18) Install the air bleeder screws of RL and RR caliper bodies.
- 19) Bleed air from the brake system.

2. CHECKING THE HYDRAULIC UNIT ABS OPERATION WITH THE BRAKE TESTER

- 1) Set wheels other than the one to measure on free rollers.
- 2) Prepare for the ABS sequence control operation. <Ref. to VDC-13, ABS Sequence Control.>
- 3) Set the front wheels or rear wheels on the brake tester and set the gear to neutral.



(1) Brake tester

- 4) Operate the brake tester.
- 5) Perform ABS sequence control. <Ref. to VDC-13, ABS Sequence Control.>
- 6) When the hydraulic unit begins to work, check the following work sequence.
 - (1) The FL wheel performs decompression, hold and compression in sequence, and subsequently the FR wheel repeats the cycle.
 - (2) The RR wheel performs decompression, hold and compression in sequence, and subsequently the RL wheel repeats the cycle.
- 7) Read values indicated on the brake tester and check if the fluctuation of the values between decompression and compression meets specification.

| | Front wheel | Rear wheel |
|--------------------|---|---|
| Initial value | 1,000 N (102 kgf, 225 lb) | 1,000 N (102 kgf, 225 lb) |
| When depressurized | 500 N (51 kgf, 112 lb) or less | 500 N (51 kgf, 112 lb) or less |
| When pressurized | 1,000 N (102 kgf, 225 lb) or more | 1,000 N (102 kgf, 225 lb) or more |

- 8) After the inspection, depress the brake pedal and check that it is not abnormally hard, and tightness is normal.

3. CHECKING THE HYDRAULIC UNIT VDC OPERATION USING A PRESSURE GAUGE


- 1) Lift up the vehicle, and then remove the wheels.
- 2) Remove the air bleeder screws from FL and FR caliper bodies.
- 3) Connect two pressure gauges to FL and FR caliper bodies.

CAUTION:

- Use a pressure gauge used exclusively for brake fluid measurement.
- Do not use a pressure gauge used for the measuring transmission oil pressure, as the piston seal may expand and deform.

NOTE:

Wrap sealing tape around the pressure gauge.



VDC Control Module and Hydraulic Control Unit (VDCCM&H/U)

VEHICLE DYNAMICS CONTROL (VDC)



- 4) Bleed air from the pressure gauge.
- 5) Perform VDC sequence control. <Ref. to VDC-16, VDC Sequence Control.>
- 6) When the hydraulic unit begins to work, first the FL side performs compression, hold, and decompression, and then the FR side performs compression, hold, and decompression.
- 7) Read values indicated on the pressure gauge and check if the fluctuation of the values between decompression and compression meets specification. Depress the brake pedal and check that it is not abnormally hard, and tightness is normal.

| | Front wheel | Rear wheel |
|--------------------|--|--|
| When pressurized | 3,000 kPa (31 kgf/cm ² , 441 psi) or more | 3,000 kPa (31 kgf/cm ² , 441 psi) or more |
| When depressurized | 500 kPa (5 kgf/cm ² , 73 psi) or less | 500 kPa (5 kgf/cm ² , 73 psi) or less |

- 8) Disconnect the pressure gauges from FL and FR caliper bodies.
- 9) Install the air bleeder screws of FL and FR caliper bodies.
- 10) Remove the air bleeder screws from RL and RR caliper bodies.
- 11) Connect two pressure gauges to RL and RR caliper bodies.
- 12) Bleed air from RL and RR caliper bodies, and pressure gauge.
- 13) Perform VDC sequence control. <Ref. to VDC-16, VDC Sequence Control.>
- 14) When the hydraulic unit begins to work, first the RR side performs compression, hold, and decompression, and then the RL side performs compression, hold, and decompression.
- 15) Read the values indicated on the pressure gauges and check if it is within specification. Depress the brake pedal and check that it is not abnormally hard, and tightness is normal.
- 16) Disconnect the pressure gauge from the RL and RR caliper bodies.
- 17) Install the air bleeder screws of RL and RR caliper bodies.
- 18) Bleed air from the brake line.

4. CHECK HYDRAULIC UNIT VDC OPERATION WITH BRAKE TESTER

- 1) Set wheels other than the one to measure on free rollers.
- 2) Prepare to operate the VDC sequence control. <Ref. to VDC-16, VDC Sequence Control.>
- 3) Set the front wheels or rear wheels on the brake tester and set the select lever position to the "N" range.



(1) Brake tester

- 4) Operate the brake tester.
- 5) Perform VDC sequence control. <Ref. to VDC-16, VDC Sequence Control.>
- 6) When the hydraulic unit begins to work, check the following work sequence.

- (1) The FL wheel performs compression, hold and decompression in sequence, and subsequently the FR wheel repeats the cycle.
- (2) The RR wheel performs compression, hold and decompression in sequence, and subsequently the RL wheel repeats the cycle.
- 7) Read values indicated on the brake tester and check if the fluctuation of the values between decompression and compression meets specification.

| | Front wheel | Rear wheel |
|--------------------|--|--|
| When pressurized | 2,000 N (204 kgf, 450 lbf) or more | 2,000 N (204 kgf, 450 lbf) or more |
| When depressurized | 500 N (51 kgf, 112 lbf) or less | 500 N (51 kgf, 112 lbf) or less |

8) After the inspection, depress the brake pedal and check that it is not abnormally hard, and tightness is normal.

D: REPLACEMENT

CAUTION:

- Because the pressure sensor built into the H/U is easily damaged by static electricity, start the operation after performing static electricity measures.
- Be careful not to touch the sensors in the H/U to prevent damage.
- Because the seal of the VDCCM cannot be replaced, do not pull or peel it by lifting it up.
- Because the screw of the H/U will become slightly worn in every replacement procedure, 5 times is the maximum number of times for replacement. If a problem is found such as not being able to torque the screw to specifications even before 5 replacement operations are performed, replace the H/U body.
- When installing the VDCCM, always use new screws.
- When the sealing surface of the VDCCM or H/U is dirty or damaged and it cannot be cleaned or repaired, replace with a new part.


1) Remove the VDCCM&H/U. <Ref. to VDC-7, REMOVAL, VDC Control Module and Hydraulic Control Unit (VDCCM&H/U).>

2) To prevent entry of foreign objects and brake fluid leakage, plug the oil pressure port of the VDCCM&H/U using a screw plug, etc.

3) Set the pump motor section of the removed VDCCM&H/U face down on a vise.

NOTE:

Before securing a part in a vise, place cushioning material such as wood blocks, aluminum plate or cloth between the part and the vise.




(1) Aluminum plate, etc.

(2) Vise

4) Using TORX® bit E5, remove the four screws of VDCCM.

CAUTION:

Do not re-use the screws.



ABS00431

5) Slowly pull out the VDCCM upward from the H/U.

CAUTION:

To prevent damaging of coil section, remove the VDCCM straight up from H/U without twisting.

6) Make sure there is no dirt or damage on the sealing surface of the H/U.

CAUTION:

- Do not clean the VDCCM&H/U by applying compressed air.
- Even if damage is found on the H/U seal, do not attempt repair by filing or with a metal scraper. To remove the seal residue, always use a plastic scraper. Do not use chemical such as paint thinner, etc., to clean.


7) Position the coil of the new VDCCM to align with the H/U valve.

8) To prevent deformation of the VDCCM housing cover, hold the corner of VDCCM and install it to the H/U without tilting.

9) Using a TORX® bit E5, attach/tighten new screws in the order of (1) through (4).

CAUTION:

Always use new screws.



ABS00432

Tightening torque:

1.5 N·m (0.15 kgf·m, 1.1 ft-lb)

VDC Control Module and Hydraulic Control Unit (VDCCM&H/U)

VEHICLE DYNAMICS CONTROL (VDC)

- 10) Check that there is no foreign matter in mating surface between the VDCCM&H/U.
- 11) Using a TORX® bit E5, tighten the screws in the order of (1) through (4) again.

Tightening torque:

3 N·m (0.3 kgf·m, 2.2 ft-lb)

- 12) Check that there is no gap in the mating surface between VDCCM&H/U.
- 13) Install the VDCCM&H/U to the vehicle.
- 14) Bleed air from the brake system.
- 15) Perform the selection · registration operation of parameter. <Ref. to VDC(diag)-19, PARAMETER SELECTION, OPERATION, Subaru Select Monitor.>

NOTE:

- After replacing the VDCCM, be sure to perform the selection · registration operation of parameter.
- For the selection and registration of parameter, the Subaru Select Monitor is required.
- When the registration has not been performed, the DTC code “Parameter selection error” is detected together with the ABS/EBD/VDC warning light illumination.

- 16) Check the parameter to confirm that the applied models and grades of the relevant vehicle are included. <Ref. to VDC(diag)-19, PARAMETER CHECK, OPERATION, Subaru Select Monitor.>
- 17) If the applied models and grades of the relevant vehicle are not included, perform the selection · registration operation of parameter with the {Confirm on parameter} screen again. <Ref. to VDC(diag)-19, PARAMETER SELECTION, OPERATION, Subaru Select Monitor.>
- 18) Execute Clear Memory after parameter selection and registration operations because the DTC for “Parameter selection error” is memorized.

E: ADJUSTMENT

When the following replacement, removal and installation are performed, be sure to perform the centering of the steering angle sensor and zero point setting of yaw rate & G sensor.

- VDCCM&H/U
- Steering angle sensor
- Yaw rate & G sensor
- Steering wheel parts (Including airbag)
- Suspension parts
- Wheel alignment adjustment

- 1) Park the vehicle straight on a level surface. (Engine operation in the “P” or “N” range)
- 2) Check that steering wheel is positioned at the center. (When the center position is not correct, adjust the wheel alignment.)

- 3) Set the Subaru Select Monitor to the vehicle, and select the {Set mode Str.A.Sen.N&Lat.GS-en.0p} in the «Function Check Sequence» screen. (Follow the steps on the display.)

- 4) On «Brake Control System» display, select {Current Data Display & Save}, and check that the steering angle sensor shows “0 deg”.
- 5) When the “0 deg” is not displayed, repeat the above steps and check that the “0 deg” is displayed.
- 6) Drive the vehicle for 10 minutes, and check that the ABS and VDC warning light is not illuminated.
- 7) Check that there is no unnecessary VDC operation or steering control loss. If there is a malfunction, repeat the steps above.