


## 7. Switches and Harness

### A: REMOVAL


#### 1. BACK-UP LIGHT AND NEUTRAL POSITION SWITCH

- 1) Disconnect the ground cable from battery.
- 2) Remove the air intake chamber and intake boot. <Ref. to IN(H4SO)-7, REMOVAL, Air Intake Chamber. >
- 3) Disconnect the connector back-up light switch & neutral position switch.



(A) Neutral position switch connector (Brown)  
 (B) Back-up light switch connector (Gray)

- 4) Lift up the vehicle.
- 5) Remove the back-up light switch & neutral position switch with the harness.



(A) Neutral position switch  
 (B) Back-up light switch


### B: INSTALLATION

#### 1. BACK-UP LIGHT AND NEUTRAL POSITION SWITCH

- 1) Install the back-up light switch & neutral position switch with the harness.

##### *Tightening torque:*

32.3 N·m (3.3 kgf·m, 23.8 ft·lb)



(A) Neutral position switch  
 (B) Back-up light switch

- 2) Connect the connectors of back-up light switch & neutral position switch.
- 3) Install the air intake chamber and intake boot. <Ref. to IN(H4SO)-7, INSTALLATION, Air Intake Chamber. >
- 4) Connect the battery ground terminal.


### C: INSPECTION

#### 1. BACK-UP LIGHT SWITCH

Check the back-up light switch. <Ref. to LI-8, INSPECTION, Back-up Light System. >

#### 2. NEUTRAL POSITION SWITCH

- 1) Turn the ignition switch to OFF.
- 2) Disconnect the connector of neutral position switch.
- 3) Measure the resistance between neutral position switch terminals.



Gear shift position	Terminal No.	Specified resistance
Neutral position	1 and 2	Less than 1 Ω
Other positions		1 MΩ or more

- 4) Replace faulty parts.