

13. Heater Core


A: REMOVAL

- 1) Disconnect the ground cable from battery.
- 2) Using the refrigerant recovery system, discharge refrigerant. <Ref. to AC-26, PROCEDURE, Refrigerant Recovery Procedure.>
- 3) Drain the coolant from the radiator. <Ref. to CO(H4DO)-13, DRAINING OF ENGINE COOLANT, REPLACEMENT, Engine Coolant.>
- 4) Remove the intake boot. <Ref. to IN(H4DO)-12, REMOVAL, Air Intake Boot.>

CAUTION:

Move aside the intake boot to perform the operation without disconnecting the PCV hose.

- 5) Remove the bolt, and remove the hose - pressure suction and the pipe - evaporator cooling from the expansion valve - cooling.
- 6) Loosen the heater hose clamps and remove the hoses.




- 7) Remove the instrument panel assembly. <Ref. to EI-70, REMOVAL, Instrument Panel Assembly.>

Heater Core

HVAC SYSTEM (HEATER, VENTILATOR AND A/C)

8) Remove the engine control module (ECM).


- (1) Release the lock and remove the relay holder.
- (2) Remove the nut (a).
- (3) Loosen the bolt (b), and remove the engine control module (ECM).



AC-02682

9) Remove the blower motor unit assembly.

- (1) Disconnect the blower motor relay and each connector.




AC-02683

Heater Core


HVAC SYSTEM (HEATER, VENTILATOR AND A/C)

(2) Remove the bolts and nuts to remove blower motor unit assembly.



10) Remove the heater and cooling unit assembly.


(1) Disconnect each connector and the hose - drain.



Heater Core


HVAC SYSTEM (HEATER, VENTILATOR AND A/C)

(2) Remove the bolt and nuts, and remove the heater & cooling unit assembly.



11) Remove the heater core.


(1) Remove the screw and detach the clamp - pipe.



Heater Core


HVAC SYSTEM (HEATER, VENTILATOR AND A/C)

(2) Remove the screws and detach the cover - heater pipe.



AC-02688

(3) Remove the clamp, and remove the pipe - inlet and outlet.




AC-02689

Heater Core


HVAC SYSTEM (HEATER, VENTILATOR AND A/C)

(4) Remove the screws and detach the plate - heater core.



AC-02690

(5) Pull out the heater core from the case - heater unit.



AC-02691

B: INSTALLATION

CAUTION:

Replace O-rings and clamps with new parts and install securely.

1) Install each part in the reverse order of removal.

NOTE:

Refer to "INSTALLATION" of "Instrument Panel Assembly". <Ref. to EI-87, INSTALLATION, Instrument Panel Assembly.>

Tightening torque:

Heater cooling unit: <Ref. to AC-6, HEATER AND COOLING UNIT, COMPONENT, General Description.>

Blower motor unit: <Ref. to AC-10, BLOWER MOTOR UNIT, COMPONENT, General Description.>

Engine control module (ECM): 7.5 N·m (0.76 kgf·m, 5.5 ft-lb)

2) Fill engine coolant. <Ref. to CO(H4DO)-13, FILLING OF ENGINE COOLANT, REPLACEMENT, Engine Coolant.>

3) Charge refrigerant. <Ref. to AC-27, PROCEDURE, Refrigerant Charging Procedure.>