

15. Diagnostic Procedure with Diagnostic Trouble Code (DTC)

A: DTC B1650 OCCUPANT CLASSIFICATION SYSTEM MALFUNCTION


DTC DETECTING CONDITION:

- Occupant detection sensor is faulty.
- Occupant detection control module is faulty.
- Occupant detection harness is faulty.
- Rear airbag harness is faulty.

CAUTION:

Before performing diagnosis, refer to "CAUTION" in "General Description". <Ref. to AB(diag)-4, CAUTION, General Description.>

WIRING DIAGRAM:



Step	Check	Yes	No
1 CHECK DTC. Read the DTC of the occupant detection system.	Is any of DTC B1760, B1761, B1771 and B1795 detected?	Perform the diagnosis according to DTC.	Go to step 2.
2 CHECK POOR CONTACT OF CONNECTORS. Check for poor contact of the connectors between the occupant detection control module and airbag control module.	Is there poor contact?	Reconnect the connector. If defective is not improved, replace the airbag rear harness along with the body harness or the occupant detection harness (seat harness).	Go to step 3.

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

OCCUPANT DETECTION SYSTEM (DIAGNOSTICS)

Step	Check	Yes	No
3 CHECK AIRBAG REAR HARNESS. 1) Turn the ignition switch to OFF, disconnect the battery ground cable, and wait for 60 seconds or more. 2) Disconnect the connectors (AB59) and (AB53) under the passenger's seat. 3) Disconnect the connectors (AB6, AB17, AB18) from the airbag control module, and connect the connector (1AH) in the test harness AH. 4) Connect the connector (2AH) in the test harness AH and the connector (1AG) in the test harness AG. 5) Connect the connector (1AP) in the test harness AP to the connector (AB53). 6) Measure the resistance between connector (5AG) in the test harness AG and connector (2AP) in the test harness AP. Connector & terminal (5AG) No. 5 — (2AP) No. 2: (5AG) No. 16 — (2AP) No. 1:	Is the resistance less than 10 Ω ?	Go to step 4.	Replace the airbag rear harness along with body harness.
4 CHECK AIRBAG REAR HARNESS. Measure the resistance between connector (5AG) in the test harness AG and chassis ground. Connector & terminal (5AG) No. 5 — Chassis ground: (5AG) No. 16 — Chassis ground: (5AG) No. 5 — (5AG) No. 16:	Is the resistance 1 M Ω or more?	Go to step 5.	Replace the airbag rear harness along with body harness.
5 CHECK OCCUPANT DETECTION HARNESS. 1) Turn the ignition switch to ON. 2) Measure the voltage between connector (2AB) in the test harness AB and chassis ground. Connector & terminal (2AP) No. 3 (+) — Chassis ground (-):	Is the voltage 10 V or more?	Replace the occupant detection harness (seat harness). If defective is not improved, replace the occupant detection system (seat cushion & frame assembly), and then the airbag control module in this order. <Ref. to SE-16, PASSENGER'S SEAT, DISASSEMBLY, Front Seat.>	Check the battery voltage and fuse. If there is no fault, replace the airbag rear harness together with body harness.

Diagnostic Procedure with Diagnostic Trouble Code (DTC)


OCCUPANT DETECTION SYSTEM (DIAGNOSTICS)

B: DTC B1655 FRONT BUCKLE SWITCH RH FAILURE

DTC DETECTING CONDITION:

- Passenger's buckle switch circuit is open, shorted or shorted to ground.
- Seat harness circuit is open, shorted or shorted to ground.
- Occupant detection control module is faulty.

WIRING DIAGRAM:



OD-00092

Step	Check	Yes	No
1 CHECK DTC. Read the DTC of the occupant detection system.	Is any of DTC B1760, B1761, B1771 and B1795 detected?	Perform the diagnosis according to DTC.	Go to step 2.
2 CHECK POOR CONTACT OF CONNECTORS. Check for poor contact of the connectors between the occupant detection control module and buckle switch.	Is there poor contact?	Reconnect the connector. If the fault is not fixed, replace the airbag harness.	Go to step 3.
3 CHECK BUCKLE SWITCH. 1) Turn the ignition switch to OFF, disconnect the battery ground terminal, and wait for 60 seconds. 2) Disconnect the buckle switch connector (AB60). 3) Connect the test harness AE and test harness connector Y to buckle switch connector (AB60). 4) Connect the battery ground terminal and turn the ignition switch to ON.	Does the airbag warning light illuminate for 6 seconds and go off?	Replace the buckle switch. <Ref. to SB-15, SEAT BELT OUTER - FRONT, REMOVAL, Front Seat Belt.>	Check the seat harness, and if any fault is found, replace the seat harness. If the fault is not fixed, replace the occupant detection system. <Ref. to SE-16, PASSENGER'S SEAT, DISASSEMBLY, Front Seat.>

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

OCCUPANT DETECTION SYSTEM (DIAGNOSTICS)

C: DTC B1760 SENSOR MAT ABNORMAL

DTC DETECTING CONDITION:

- Occupant detection sensor circuit is open, shorted between terminals, shorted to power supply or shorted to ground.
- Seat heater circuit is open.
- Occupant detection control module is faulty.

Step	Check	Yes	No
1 CHECK POOR CONTACT OF CONNECTORS. Check for poor contact of connectors between the occupant detection control module and the occupant detection sensor.	Is there poor contact of connector?	Reconnect the connector. If the fault is not fixed, replace the occupant detection harness or replace the occupant detection system (passenger's & frame assembly). <Ref. to SE-16, PASSENGER'S SEAT, DISASSEMBLY, Front Seat. >	Replace the occupant detection system (passenger's & frame assembly). <Ref. to SE-16, PASSENGER'S SEAT, DISASSEMBLY, Front Seat. >

D: DTC B1761 SENSOR MAT LIQUID COATING ABNORMAL

DTC DETECTING CONDITION:

- Occupant detection sensor is spattered with fluid.
- Occupant detection sensor is faulty.
- Occupant detection control module is faulty.

Step	Check	Yes	No
1 DRY THE SEAT. 1) Open the vehicle windows in a well-ventilated place indoors and dry the seat for 24 hours. 2) Read the DTC of the occupant detection system.	Is DTC B1761 detected?	Replace the occupant detection system (passenger's & frame assembly). <Ref. to SE-16, PASSENGER'S SEAT, DISASSEMBLY, Front Seat. >	Clear the memory.

E: DTC B1771 BUCKLE SWITCH ABNORMAL

DTC DETECTING CONDITION:

- Passenger's seat buckle switch is faulty.
- Passenger's buckle switch circuit is open, shorted or shorted to ground.
- Occupant detection system is faulty.
- Occupant detection harness is faulty.

Perform the diagnosis from Step 2 in "DTC B1655 FRONT BUCKLE SWITCH RH FAILURE". <Ref. to OD(diag)-21, DTC B1655 FRONT BUCKLE SWITCH RH FAILURE, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

F: DTC B1795 ECU INTERNAL CIRCUIT FAULT

DTC DETECTING CONDITION:

Occupant detection control module is faulty.

When "DTC B1795 ECU INTERNAL CIRCUIT FAULT" is displayed, the occupant detection control module is faulty. Replace the occupant detection system (passenger's & frame assembly). <Ref. to SE-16, PASSENGER'S SEAT, DISASSEMBLY, Front Seat. >

SEAT BELT SYSTEM

SB

	Page
1. General Description	2
2. Pretensioner Connector	10
3. Inspection Locations after a Collision	11
4. Seat Belt Warning System	12
5. Front Seat Belt	15
6. Rear Seat Belt	29