

## 15. Malfunction Indicator Light

### A: PROCEDURE


1. Activation of malfunction indicator light <Ref. to EN(H4DO)(diag)-58, ACTIVATION OF MALFUNCTION INDICATOR LIGHT, Malfunction Indicator Light.>	↓
2. Malfunction indicator light does not come on <Ref. to EN(H4DO)(diag)-60, MALFUNCTION INDICATOR LIGHT DOES NOT COME ON, Malfunction Indicator Light.>	↓
3. Malfunction indicator light does not go off <Ref. to EN(H4DO)(diag)-60, MALFUNCTION INDICATOR LIGHT DOES NOT GO OFF, Malfunction Indicator Light.>	↓
4. Malfunction indicator light does not blink <Ref. to EN(H4DO)(diag)-61, MALFUNCTION INDICATOR LIGHT DOES NOT BLINK, Malfunction Indicator Light.>	↓
5. Malfunction indicator light remains blinking <Ref. to EN(H4DO)(diag)-63, MALFUNCTION INDICATOR LIGHT REMAINS BLINKING, Malfunction Indicator Light.>	

### B: ACTIVATION OF MALFUNCTION INDICATOR LIGHT

1) When the ignition switch is turned to ON (engine OFF), the malfunction indicator light (A) in the combination meter illuminates.

NOTE:


If the malfunction indicator light does not illuminate, perform diagnostics of the malfunction indicator light circuit or the combination meter circuit. <Ref. to EN(H4DO)(diag)-60, MALFUNCTION INDICATOR LIGHT DOES NOT COME ON, Malfunction Indicator Light.>



# Malfunction Indicator Light


## ENGINE (DIAGNOSTICS)

2) After starting the engine, the malfunction indicator light goes out. If it does not go off, any of the engine and emission control system has malfunction.



- (1) No fault
- (2) Trouble occurs
- (3) ON
- (4) OFF
- (5) Ignition switch ON
- (6) Engine start

3) If the diagnostic system detects a misfire which could damage the catalyst, the malfunction indicator light will blink at a cycle of 1 Hz.




- (1) ON
- (2) OFF
- (3) Ignition switch ON
- (4) Engine start
- (5) Misfire start
- (6) 1 second


4) Install the delivery (test) mode fuse (A) of main fuse box with ignition switch to OFF.

### CAUTION:

**Do not use any fuses that are installed on the vehicle.**



- (1) When the ignition switch is turned to ON (engine OFF), the malfunction indicator light illuminates.
- (2) After the engine starts, malfunction indicator light blinks in a cycle of 0.5 Hz. (During diagnosis)
- (3) Malfunction indicator light blinks at a cycle of 3 Hz after diagnosis if there is no trouble. Malfunction indicator light illuminates if faulty.



- (1) ON
- (2) OFF
- (3) Ignition switch ON
- (4) 1 second

# Malfunction Indicator Light

## ENGINE (DIAGNOSTICS)

### C: MALFUNCTION INDICATOR LIGHT DOES NOT COME ON

#### TROUBLE SYMPTOM:

When the ignition switch is turned to ON (engine OFF), malfunction indicator light does not illuminate.

#### NOTE:

Refer to IDI section for diagnostic procedure. <Ref. to IDI(diag)-2, Basic Diagnostic Procedure.>

### D: MALFUNCTION INDICATOR LIGHT DOES NOT GO OFF

#### TROUBLE SYMPTOM:

Although malfunction indicator light comes on when the engine runs, DTC is not shown on the Subaru Select Monitor or general scan tool display.

Step	Check	Yes	No
1 <b>CHECK DTC.</b>	Is DTC of engine or LAN system displayed? <Ref. to EN(H4DO)(diag)-43, OPERATION, Read Diagnostic Trouble Code (DTC).>	Check the appropriate DTC using the "List of Diagnostic Trouble Code (DTC)". <Ref. to EN(H4DO)(diag)-79, List of Diagnostic Trouble Code (DTC).> <Ref. to LAN(diag)-43, List of Diagnostic Trouble Code (DTC).>	Check the combination meter system. <Ref. to IDI(diag)-2, Basic Diagnostic Procedure.>

### E: MALFUNCTION INDICATOR LIGHT DOES NOT BLINK



#### DIAGNOSIS:

- The malfunction indicator light circuit is open or shorted.
- The delivery (test) mode fuse circuit is open.

#### TROUBLE SYMPTOM:

Malfunction indicator light does not blink during Inspection Mode.

#### WIRING DIAGRAM:



EN-09222

Step	Check	Yes	No
1 <b>CHECK STATUS OF MALFUNCTION INDICATOR LIGHT.</b> 1) Turn the ignition switch to OFF. 2) Check the delivery (test) mode fuse is removed. 3) Turn the ignition switch to ON. (engine OFF)	Does the malfunction indicator light illuminate?	Go to step 2.	Repair the malfunction indicator light circuit. <Ref. to EN(H4DO)(diag)-60, MALFUNCTION INDICATOR LIGHT DOES NOT COME ON, Malfunction Indicator Light.>
2 <b>CHECK HARNESS BETWEEN ECM AND DELIVERY (TEST) MODE FUSE.</b> 1) Turn the ignition switch to OFF. 2) Disconnect the connector from ECM. 3) Install the delivery (test) mode fuse. <b>CAUTION:</b> <b>Do not use any fuses that are installed on the vehicle.</b> 4) Measure the resistance of harness between ECM connectors. <b>Connector &amp; terminal</b> <b>(B136) No. 34 — (B136) No. 4:</b>	Is the resistance less than 1 Ω?	Go to step 3.	Repair the harness and connector. <b>NOTE:</b> In this case, repair the following item: <ul style="list-style-type: none"> <li>• Open circuit in harness between ECM connector</li> <li>• Poor contact of each connector between ECM connector</li> </ul>

## Malfunction Indicator Light

### ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<b>3 CHECK FOR POOR CONTACT.</b> Check for poor contact of ECM connector.	Is there poor contact of ECM connector?	Repair the poor contact of ECM connector.	Replace the ECM. <Ref. to FU(H4DO)-101, Engine Control Module (ECM).>

### F: MALFUNCTION INDICATOR LIGHT REMAINS BLINKING



#### DIAGNOSIS:

The delivery (test) mode fuse circuit is short to ground.

#### TROUBLE SYMPTOM:

Malfunction indicator light blinks when delivery (test) mode fuse is not connected.

#### WIRING DIAGRAM:



EN-09222

Step	Check	Yes	No
1 <b>CHECK DELIVERY (TEST) MODE CONNECTOR.</b> 1) Check the delivery (test) mode fuse is removed. 2) Turn the ignition switch to ON.	Does the malfunction indicator light blink?	Go to step 2.	System is normal. NOTE: Malfunction indicator light blinks at a cycle of 3 Hz when delivery (test) mode fuse is attached.
2 <b>CHECK HARNESS BETWEEN ECM AND DELIVERY (TEST) MODE FUSE.</b> 1) Turn the ignition switch to OFF. 2) Disconnect the connector from ECM. 3) Measure the resistance between ECM and chassis ground. <i>Connector &amp; terminal (B136) No. 34 — Chassis ground:</i>	Is the resistance 1 MΩ or more?	Replace the ECM. <Ref. to FU(H4DO)-101, Engine Control Module (ECM).>	Repair the short circuit to ground in harness between ECM and delivery (test) mode fuse.