

# Drive Pinion Shaft Assembly

CONTINUOUSLY VARIABLE TRANSMISSION

## 41. Drive Pinion Shaft Assembly

### A: REMOVAL

#### CAUTION:

The specifications of drive pinion retainer parts vary depending on transmission serial No.. When replacing the following parts, be sure to check the serial number before replacing.

- Drive pinion retainer

|                         |                                            |                             |
|-------------------------|--------------------------------------------|-----------------------------|
| Transmission serial No. | 96892 earlier<br>334608 earlier            | 96893 later<br>334609 later |
| Drive pinion retainer   | 32290AA020<br>32290AA021 can also be used. | 32290AA021                  |


|                         |                                            |             |
|-------------------------|--------------------------------------------|-------------|
| Transmission serial No. | 96735 earlier                              | 96736 later |
| Drive pinion retainer   | 32290AA030<br>32290AA031 can also be used. | 32290AA031  |

- 1) Remove the transmission assembly from the vehicle. <Ref. to CVT-58, REMOVAL, Automatic Transmission Assembly.>
- 2) Remove the air breather hose. <Ref. to CVT-148, REMOVAL, Air Breather Hose.>
- 3) Remove the control valve body. <Ref. to CVT-112, REMOVAL, Control Valve Body.>
- 4) Remove the transmission harness. <Ref. to CVT-124, REMOVAL, Transmission Harness.>
- 5) Remove the turbine speed sensor. <Ref. to CVT-99, REMOVAL, Turbine Speed Sensor.>
- 6) Remove the secondary speed sensor. <Ref. to CVT-101, REMOVAL, Secondary Speed Sensor.>
- 7) Remove the primary speed sensor. <Ref. to CVT-103, REMOVAL, Primary Speed Sensor.>
- 8) Remove the inhibitor switch. <Ref. to CVT-94, REMOVAL, Inhibitor Switch.>
- 9) Remove the extension case. <Ref. to CVT-156, REMOVAL, Extension Case.>
- 10) Remove the transfer clutch assembly. <Ref. to CVT-160, REMOVAL, Transfer Clutch.>
- 11) Remove the transfer driven gear assembly. <Ref. to CVT-174, REMOVAL, Transfer Driven Gear.>
- 12) Remove the parking pawl. <Ref. to CVT-177, REMOVAL, Parking Pawl.>
- 13) Remove the reduction driven gear assembly. <Ref. to CVT-179, REMOVAL, Reduction Driven Gear.>
- 14) Remove the oil pan and oil strainer. <Ref. to CVT-108, REMOVAL, Oil Pan and Strainer.>
- 15) Remove the transmission control device. <Ref. to CVT-187, REMOVAL, Transmission Control Device.>
- 16) Remove the transmission case. <Ref. to CVT-193, REMOVAL, Transmission Case.>
- 17) Remove the reduction drive gear. <Ref. to CVT-209, REMOVAL, Reduction Drive Gear.>
- 18) Remove the primary pulley, secondary pulley and variator chain. <Ref. to CVT-213, REMOVAL, Primary Pulley and Secondary Pulley.>
- 19) Remove the reverse brake assembly. <Ref. to CVT-234, REMOVAL, Reverse Brake Assembly.>
- 20) Remove the forward clutch assembly. <Ref. to CVT-249, REMOVAL, Forward Clutch Assembly.>


## Drive Pinion Shaft Assembly

CONTINUOUSLY VARIABLE TRANSMISSION

- 21) Using the ST, remove the drive pinion retainer.  
ST 18270KA020 SOCKET (E20)



- 22) Remove the O-ring.



# Drive Pinion Shaft Assembly


CONTINUOUSLY VARIABLE TRANSMISSION

## B: INSTALLATION

- 1) Clean the mating surface of drive pinion retainer and converter case.
- 2) Adjust the backlash and tooth contact between drive pinion shaft assembly and the front differential side gear. <Ref. to CVT-291, ADJUSTMENT, Drive Pinion Shaft Assembly.>
- 3) Install O-rings in two locations to the converter case.

### NOTE:


- Use new O-rings.
- Apply CVTF to the O-ring.



- 4) Apply liquid gasket seamlessly to the mating surface of drive pinion retainer.

### **Liquid gasket:**

**THREE BOND 1215 (Part No. 004403007) or equivalent**



## Drive Pinion Shaft Assembly

CONTINUOUSLY VARIABLE TRANSMISSION


- 5) Install the drive pinion retainer to converter case, and tighten the bolt using the ST.  
ST 18270KA020 SOCKET (E20)

**NOTE:**

Do not confuse the three different-length bolts when installing.

**Tightening torque:**

**43 N·m (4.4 kgf-m, 31.7 ft-lb)**



AT-06495

- 6) Install the forward clutch assembly. <Ref. to CVT-252, INSTALLATION, Forward Clutch Assembly.>  
7) Install the reverse brake assembly. <Ref. to CVT-237, INSTALLATION, Reverse Brake Assembly.>  
8) Install the primary pulley, secondary pulley and variator chain. <Ref. to CVT-220, INSTALLATION, Primary Pulley and Secondary Pulley.>  
9) Install the reduction drive gear. <Ref. to CVT-210, INSTALLATION, Reduction Drive Gear.>  
10) Install the transmission case. <Ref. to CVT-196, INSTALLATION, Transmission Case.>  
11) Install the transmission control device. <Ref. to CVT-190, INSTALLATION, Transmission Control Device.>  
12) Install the oil strainer and oil pan. <Ref. to CVT-109, INSTALLATION, Oil Pan and Strainer.>  
13) Install the reduction driven gear assembly. <Ref. to CVT-179, INSTALLATION, Reduction Driven Gear.>  
14) Install the transfer driven gear assembly. <Ref. to CVT-175, INSTALLATION, Transfer Driven Gear.>  
15) Install the transfer clutch assembly. <Ref. to CVT-162, INSTALLATION, Transfer Clutch.>  
16) Install the parking pawl. <Ref. to CVT-178, INSTALLATION, Parking Pawl.>  
17) Install the extension case. <Ref. to CVT-157, INSTALLATION, Extension Case.>  
18) Install the inhibitor switch. <Ref. to CVT-96, INSTALLATION, Inhibitor Switch.>  
19) Install the secondary speed sensor. <Ref. to CVT-101, INSTALLATION, Secondary Speed Sensor.>  
20) Install the primary speed sensor. <Ref. to CVT-104, INSTALLATION, Primary Speed Sensor.>  
21) Install the turbine speed sensor. <Ref. to CVT-99, INSTALLATION, Turbine Speed Sensor.>  
22) Install the transmission harness. <Ref. to CVT-130, INSTALLATION, Transmission Harness.>  
23) Install the control valve body. <Ref. to CVT-117, INSTALLATION, Control Valve Body.>  
24) Install the air breather hose. <Ref. to CVT-149, INSTALLATION, Air Breather Hose.>  
25) Install the transmission assembly to the vehicle. <Ref. to CVT-69, INSTALLATION, Automatic Transmission Assembly.>

# Drive Pinion Shaft Assembly

CONTINUOUSLY VARIABLE TRANSMISSION


## C: DISASSEMBLY

- 1) Flatten the tab of the lock nut.
- 2) Using ST1, ST2 and ST3, fix at the spline portion of drive pinion shaft to remove the lock nut.


ST1 499787500 ADAPTER

ST2 499787700 WRENCH

ST3 498937110 HOLDER




- 3) Remove the drive pinion shaft from the drive pinion retainer.




## Drive Pinion Shaft Assembly

CONTINUOUSLY VARIABLE TRANSMISSION

- 4) Using the round bar with diameter of 36 mm (1.42 in) or 37 mm (1.46 in), remove the bearing inner race and plug.



- 5) Remove the drive pinion washer.  
6) Remove the drive pinion spacer.




## Drive Pinion Shaft Assembly

### CONTINUOUSLY VARIABLE TRANSMISSION

---


7) Remove the O-ring.



AT-06763

8) Remove the inner race and drive pinion shim from drive pinion shaft using ST.

ST 498515500 REMOVER




AT-06772

## Drive Pinion Shaft Assembly

CONTINUOUSLY VARIABLE TRANSMISSION


- 9) Using the ST, remove the outer race.  
ST 398527700 PULLER ASSY



- 10) Remove the two oil seals using a screwdriver wrapped with cloth etc.

**CAUTION:**

**Do not damage the fitting surface of oil seal.**




# Drive Pinion Shaft Assembly

## CONTINUOUSLY VARIABLE TRANSMISSION

---

11) Remove the plug from drive pinion retainer.



### D: ASSEMBLY


1) Install the plug to drive pinion retainer.

#### NOTE:

- Use new O-rings.
- Apply CVTF to the O-ring.

#### **Tightening torque:**

**25 N·m (2.5 kgf-m, 18.4 ft-lb)**



# Drive Pinion Shaft Assembly


CONTINUOUSLY VARIABLE TRANSMISSION

2) Using the ST, install the oil seal to drive pinion retainer.

**NOTE:**

- Apply CVTF to the oil seal press-fitting surface and lip.
- Install the oil seal in the correct direction.

ST 927720000 HOUSING BUSHING INSTALLER AND REMOVER



(A) 2.8 mm (0.11 in)

(B) 18.7 mm (0.74 in)


# Drive Pinion Shaft Assembly

## CONTINUOUSLY VARIABLE TRANSMISSION


---

3) Select the drive pinion washer.

(1) Measure the roller bearing inner race width "A" on the front side.




(2) Measure the roller bearing inner race width "B" on the rear side.



# Drive Pinion Shaft Assembly

CONTINUOUSLY VARIABLE TRANSMISSION


(3) Measure the spacer width "C".



(4) Using the ST, install the front roller bearing outer race to the drive pinion retainer.

ST1 28499TC010 INSTALLER


ST2 398177700 INSTALLER



## Drive Pinion Shaft Assembly

### CONTINUOUSLY VARIABLE TRANSMISSION

- (5) Using the ST, install the rear roller bearing outer race to the drive pinion retainer.  
ST 20099AE020 INSTALLER




- (6) Place the drive pinion retainer on the surface plate, and install the inner race to the rear roller bearing outer race.

#### NOTE:

Place the drive pinion retainer so that the mating surface of the drive pinion retainer (mating surface with the converter case) contacts the surface plate.

- (7) Measure the height "D" from the end face of the rear roller bearing inner race to the surface plate.




- (8) Install the inner race to the front roller bearing outer race.

# Drive Pinion Shaft Assembly

CONTINUOUSLY VARIABLE TRANSMISSION

- (9) Measure the depth "E" from the end face of the front roller bearing inner race to the end face of the ST.  
ST 499575400 GAUGE



AT-06768

- (10) Using following formula, select one to three drive pinion washers.

$$T \text{ (mm)} = D - (A + B + C + E - 15) - (0 \pm 0.0125)$$

$$[T \text{ (in)} = D - (A + B + C + E - 0.591) - (0 \pm 0.0005)]$$

A: Front roller bearing width

B: Rear roller bearing width

C: Spacer width

D: Height from end face of rear roller bearing inner race to surface plate

E: Depth from end face of front roller bearing inner race to end face of ST

15 mm (0.591 in): Thickness of ST

T: Drive pinion washer thickness

0 ± 0.0125 mm (0 ± 0.0005 in): Clearance

| Drive pinion washer |                   |
|---------------------|-------------------|
| Part No.            | Thickness mm (in) |
| 38336AA750          | 0.150 (0.0059)    |
| 38336AA760          | 0.175 (0.0069)    |
| 38336AA770          | 0.200 (0.0079)    |
| 38336AA780          | 0.225 (0.0089)    |
| 38336AA790          | 0.250 (0.0098)    |
| 38336AA800          | 0.275 (0.0108)    |
| 38336AA810          | 0.300 (0.0118)    |
| 38336AA820          | 0.400 (0.0157)    |

- 4) Measure and record the drive pinion shim thickness to be reused.  
5) Install the drive pinion shim that is reused for the drive pinion shaft.

## Drive Pinion Shaft Assembly


### CONTINUOUSLY VARIABLE TRANSMISSION

---

6) Using the ST1 and ST2, press-fit the inner race to the drive pinion shaft.

ST1 899580100 INSTALLER


ST2 927130000 EXTENSION DRIVE SHAFT



7) Install the drive pinion spacer.

#### NOTE:


Replace the O-ring with a new part after tooth contact inspection.



## Drive Pinion Shaft Assembly

CONTINUOUSLY VARIABLE TRANSMISSION

8) Install the selected drive pinion washer.



9) Insert the drive pinion shaft into the drive pinion retainer.


**CAUTION:**

**Be careful not to damage the oil seal.**

10) Install the inner bearing and lock nut.

**NOTE:**

Use a new lock nut.



## Drive Pinion Shaft Assembly

### CONTINUOUSLY VARIABLE TRANSMISSION

11) Using the ST, tighten the lock nut to the specified torque so that the starting torque of the drive pinion shaft is within the specified range.

#### CAUTION:

**Before inspecting the starting torque, apply differential gear oil to roller of bearing and rotate the bearing several times.**

#### NOTE:

- Tighten the lock nut while directly aligning ST2 and torque wrench.
- If the starting torque is not within the specified range, select the drive pinion washer, and repeat the step until the starting torque is within the specified range.
- When a thicker drive pinion washer is selected, the starting torque decreases. When a thinner drive pinion washer is selected, the starting torque increases.

#### Starting torque:

**5.1 — 17.1 N (0.5 — 1.7 kgf, 1.1 — 3.8 lbf)**

ST1 499787500 ADAPTER

ST2 499787700 WRENCH

ST3 498937110 HOLDER

Using the following formula, calculate the tightening torque for a torque wrench.

$$T2 = L2 / (L1 + L2) \times T1$$

T1: 170 — 250 N·m (17.3 — 25.5 kgf·m, 125.4 — 184.4 ft·lb) [Specified tightening torque range]


T2: Tightening torque

L1: ST1 length 0.072 m (2.83 in)

L2: Torque wrench length


Example:

| Torque wrench length<br>m (in) | Tightening torque<br>N·m (kgf·m, ft·lb) |
|--------------------------------|-----------------------------------------|
| 0.4 (15.75)                    | 144 — 211 (14.7 — 21.5, 106.2 — 155.6)  |
| 0.45 (17.72)                   | 147 — 215 (15.0 — 21.9, 108.4 — 158.6)  |
| 0.5 (19.69)                    | 149 — 218 (15.2 — 22.2, 109.9 — 160.8)  |
| 0.55 (21.65)                   | 150 — 221 (15.3 — 22.5, 110.6 — 163.0)  |



# Drive Pinion Shaft Assembly

CONTINUOUSLY VARIABLE TRANSMISSION



12) Install the drive pinion retainer to the converter case, and check the backlash and tooth contact. <Ref. to CVT-291, ADJUSTMENT, Drive Pinion Shaft Assembly.> <Ref. to CVT-312, ADJUSTMENT, Front Differential Assembly.>


13) Remove the drive pinion retainer from converter case. <Ref. to CVT-268, REMOVAL, Drive Pinion Shaft Assembly.>

14) Remove the drive pinion spacer from the drive pinion shaft. <Ref. to CVT-272, DISASSEMBLY, Drive Pinion Shaft Assembly.>

15) Install the O-ring to the drive pinion shaft.

## NOTE:

- Use new O-rings.
- Apply CVTF to the O-ring.




## Drive Pinion Shaft Assembly

### CONTINUOUSLY VARIABLE TRANSMISSION


---

- 16) Install the drive pinion spacer to the drive pinion shaft.



AT-06762

- 17) Install the drive pinion washer.



AT-06774


## Drive Pinion Shaft Assembly

CONTINUOUSLY VARIABLE TRANSMISSION


18) Insert the drive pinion shaft into the drive pinion retainer.

**CAUTION:**

**Be careful not to damage the oil seal.**



19) Install the inner bearing and lock nut.



## Drive Pinion Shaft Assembly

### CONTINUOUSLY VARIABLE TRANSMISSION

20) Using the ST, tighten the lock nut to the specified torque so that the starting torque of the drive pinion shaft is within the specified range.

#### CAUTION:

**Before inspecting the starting torque, apply differential gear oil to roller of bearing and rotate the bearing several times.**

#### NOTE:

- Tighten the lock nut while directly aligning ST2 and torque wrench.
- If the starting torque is not within the specified range, select the drive pinion washer, and repeat the step until the starting torque is within the specified range.
- When a thicker drive pinion washer is selected, the starting torque decreases. When a thinner drive pinion washer is selected, the starting torque increases.

#### Starting torque:

**5.1 — 17.1 N (0.5 — 1.7 kgf, 1.1 — 3.8 lbf)**

ST1 499787500 ADAPTER

ST2 499787700 WRENCH

ST3 498937110 HOLDER

Using the following formula, calculate the tightening torque for a torque wrench.

$$T2 = L2 / (L1 + L2) \times T1$$

T1: 170 — 250 N·m (17.3 — 25.5 kgf·m, 125.4 — 184.4 ft·lb) [Specified tightening torque range]


T2: Tightening torque

L1: ST1 length 0.072 m (2.83 in)

L2: Torque wrench length


Example:

| Torque wrench length<br>m (in) | Tightening torque<br>N·m (kgf·m, ft·lb) |
|--------------------------------|-----------------------------------------|
| 0.4 (15.75)                    | 144 — 211 (14.7 — 21.5, 106.2 — 155.6)  |
| 0.45 (17.72)                   | 147 — 215 (15.0 — 21.9, 108.4 — 158.6)  |
| 0.5 (19.69)                    | 149 — 218 (15.2 — 22.2, 109.9 — 160.8)  |
| 0.55 (21.65)                   | 150 — 221 (15.3 — 22.5, 110.6 — 163.0)  |



# Drive Pinion Shaft Assembly

CONTINUOUSLY VARIABLE TRANSMISSION




21) Crimp the lock nut in 2 locations.

22) Using the ST, install the plug.

ST1 499755602 PRESS SNAP RING

ST2 398177700 INSTALLER



# Drive Pinion Shaft Assembly

CONTINUOUSLY VARIABLE TRANSMISSION

## E: INSPECTION

- Make sure that all component parts are free of scratches, holes and other faults.
- Check the tooth contact. <Ref. to CVT-291, ADJUSTMENT, Drive Pinion Shaft Assembly.>
- Apply CVTF to bearing and rotate the bearing to check for noise or dragging etc.
- Check the starting torque of drive pinion shaft.

### CAUTION:


**Before measuring, apply differential gear oil to roller of bearing and rotate the bearing several times.**

ST1 498937110 HOLDER

ST2 499787700 WRENCH

### Starting torque:

**5.1 — 17.1 N (0.5 — 1.7 kgf, 1.1 — 3.8 lbf)**



# Drive Pinion Shaft Assembly

CONTINUOUSLY VARIABLE TRANSMISSION

## F: ADJUSTMENT


- 1) Remove the liquid gasket from the mating surface completely.
- 2) Using the ST, install the drive pinion retainer to converter case.  
ST 18270KA020 SOCKET (E20)

NOTE:

Do not confuse the three different-length bolts when installing.

**Tightening torque:**


**43 N·m (4.4 kgf-m, 31.7 ft-lb)**



- 3) Rotate the drive pinion several times using ST1 and ST2.

ST1 498937110 HOLDER

ST2 499787700 WRENCH



- 4) Adjust the drive pinion and hypoid driven gear backlash. <Ref. to CVT-312, ADJUSTMENT, Front Differential Assembly.>

- 5) Using the ST, remove the drive pinion retainer from converter case.

ST 18270KA020 SOCKET (E20)

## Drive Pinion Shaft Assembly

### CONTINUOUSLY VARIABLE TRANSMISSION

6) Apply lead-free red dye evenly on the both sides of three to four teeth of the hypoid driven gear. Then install the drive pinion retainer and rotate the drive pinion in both directions several times. Remove the drive pinion retainer and check the tooth contact pattern.


If the teeth contact is inappropriate, adjust the backlash or thickness of the shim. <Ref. to CVT-312, ADJUSTMENT, Front Differential Assembly.>

#### NOTE:

After correction, wipe off the lead-free red dye.

- Correct tooth contact

**Check item: Tooth contact surface is slightly shifted toward the toe side under a no-load condition. (When driving, it moves towards the heel side.)**



(A) Toe side

(B) Heel side


# Drive Pinion Shaft Assembly

CONTINUOUSLY VARIABLE TRANSMISSION


- Face contact

**Check item: Backlash is too large.**

Contact pattern



Corrective action: Increase thickness of drive pinion shim according to the procedures for moving the drive pinion close to hypoid driven gear.




# Drive Pinion Shaft Assembly

## CONTINUOUSLY VARIABLE TRANSMISSION


- Flank contact

**Check item: Backlash is too small.**

Contact pattern



Corrective action: Reduce the thickness of the drive pinion shim according to the procedures for moving the drive pinion away from the hypoid driven gear.




# Drive Pinion Shaft Assembly

CONTINUOUSLY VARIABLE TRANSMISSION


- Toe contact (inside contact)

**Check item: Teeth contact area is too small.**

Contact pattern



Corrective action: Reduce the thickness of the drive pinion shim according to the procedures for moving the drive pinion away from the hypoid driven gear side.




## Drive Pinion Shaft Assembly

### CONTINUOUSLY VARIABLE TRANSMISSION


- Heel contact (outside end contact)

**Check item: Teeth contact area is too small.**

Contact pattern



Corrective action: Increase the thickness of the drive pinion shim according to the procedures for moving the drive pinion closer to the hypoid driven gear.



7) Using the ST, loosen the differential side retainer until the mounting groove of the O-ring appears, and then install the O-ring.

NOTE:

- When loosening the differential side retainer, record the number of the turns made.
- Perform this for both left and right differential side retainers.
- Use new O-rings.
- Apply the differential gear oil to O-ring.

ST 18658AA020 WRENCH COMPL RETAINER

8) Using the ST, tighten the retainer to the position before it is loosened.

ST 18658AA020 WRENCH COMPL RETAINER

9) Replace the differential side retainer oil seal with a new part. <Ref. to CVT-87, Differential Side Retainer Oil Seal.>


# Drive Pinion Shaft Assembly

CONTINUOUSLY VARIABLE TRANSMISSION

10) Install the lock plate.

**Tightening torque:**

**25 N·m (2.5 kgf-m, 18.4 ft-lb)**



(A) Lock plate