

General Description


DRIVE SHAFT SYSTEM

1. General Description

A: SPECIFICATION

1. PROPELLER SHAFT


Car line	All models	
Propeller shaft type	EDJ	
Front propeller shaft Joint-to-Joint length: L_1	CVT	675.5 mm (26.59 in)
	5MT	735.5 mm (28.96 in)
Rear propeller shaft Joint-to-Joint length: L_2		723 mm (28.46 in)
Outer diameter of tube:	D_1	63.5 mm (2.50 in)
	D_2	57.5 mm (2.26 in)



DS-00430

2. FRONT AXLE SHAFT ASSEMBLY

Model	Axle shaft type	Axle diameter ϕ mm (in)	Axle length mm (in)
Except for XV model	AC + AAR	22 (0.87)	351.5 (13.84)
XV model	EBJ + PTJ	22 (0.87)	361.4 (14.23)



DS-00478

(A) Axle diameter

(B) Axle length

General Description

DRIVE SHAFT SYSTEM


3. REAR AXLE SHAFT ASSEMBLY

- Except for XV model

T/M type	Axle shaft type	Axle diameter ϕ mm (in)	Axle length mm (in)
CVT	BJ + DOJ	22 (0.87)	357.45 (14.07)
MT	EBJ + DOJ	22 (0.87)	372.5 (14.67)

- XV model

T/M type	Axle shaft type	Axle diameter ϕ mm (in)	Axle length mm (in)
CVT	BJ + DOJ	22 (0.87)	388.6 (15.30)
MT	EBJ + DOJ	22 (0.87)	388.5 (15.30)




(A) Axle diameter

(B) Axle length

B: COMPONENT

1. PROPELLER SHAFT



- (1) Propeller shaft
- (2) Rear differential (VA1-type)
- (3) Rear differential (T-type)

Tightening torque: N·m (kgf·m, ft·lb)

T1: 31 (3.16, 22.9)


T2: 52 (5.30, 38.4)

General Description

DRIVE SHAFT SYSTEM

2. FRONT AXLE

- AC + AAR type




(1) Circlip	(8) Band - drive shaft D	(15) Nut - axle
(2) Baffle plate	(9) Axle shaft ASSY	
(3) Outer race (AAR)	(10) Boot (AC)	
(4) Snap ring	(11) Housing ASSY - front axle	Tightening torque: N·m (kgf·m, ft·lb)
(5) Trunnion	(12) Back plate - front brake	T1: 65 (6.63, 47.9)
(6) Boot (AAR)	(13) Bolt - hub	T2: 220 (22.43, 162.3)
(7) Band - drive shaft A	(14) Hub unit COMPL - front axle	

General Description

DRIVE SHAFT SYSTEM

- EBJ + PTJ type



(1) Circlip

(2) Baffle plate

(3) Outer race (PTJ)

(4) Snap ring

(5) Trunnion

(6) Snap ring

(7) Boot band

(8) Boot (PTJ)

(9) O-ring

(10) EBJ shaft ASSY

(11) Housing ASSY - front axle

(12) Back plate - front brake

(13) Bolt - hub

(14) Hub unit COMPL - front axle

(15) Nut - axle

Tightening torque: N·m (kgf·m, ft-lb)


T1: 220 (22.43, 162.3)

T2: 65 (6.63, 47.9)

General Description

DRIVE SHAFT SYSTEM

3. REAR AXLE




(1) Circlip A	(9) Inner race	(17) Bolt - hub
(2) Baffle plate -	(10) Boot - drive shaft (DOJ)	(18) Hub unit COMPL - rear axle
(3) Outer race (DOJ)	(11) Band - drive shaft B	(19) Nut - axle
(4) Snap ring	(12) Boot - drive shaft (BJ) Boot - drive shaft (EBJ)	
(5) Ball	(13) Shaft ASSY (EBJ) (CVT model) Shaft ASSY (EBJ) (MT model)	
(6) Cage	(14) Housing ASSY - rear axle	Tightening torque: N·m (kgf·m, ft·lb)
(7) Circlip B	(15) Bushing - trailing link	T1: 65 (6.63, 47.9)
(8) Band - drive shaft A	(16) Back plate - rear brake	T2: 190 (19.37, 140.1)

C: CAUTION

- Wear appropriate work clothing, including a helmet, protective goggles and protective shoes when performing any work.
- Remove contamination including dirt and corrosion before removal, installation or disassembly.
- Keep the disassembled parts in order and protect them from dust and dirt.
- Before removal, installation or disassembly, be sure to clarify the failure. Avoid unnecessary removal, installation, disassembly and replacement.
- Vehicle components are extremely hot after driving. Be wary of receiving burns from heated parts.
- Use SUBARU genuine grease etc. or equivalent. Do not mix grease etc. of different grades or manufacturers.
- Be sure to tighten fasteners including bolts and nuts to the specified torque.
- Place shop jacks or rigid racks at the specified points.
- Apply grease onto sliding or revolving surfaces before installation.
- Before installing snap rings, apply sufficient amount of grease to avoid damage and deformation.
- Before securing a part on a vise, place cushioning materials such as wood blocks, aluminum plates, or waste cloth between the part and the vise.
 - When the suspension-related components have been removed and installed, be sure to adjust the steering sensor. <Ref. to VDC-19, VDC SENSOR MIDPOINT SETTING MODE, ADJUSTMENT, VDC Control Module and Hydraulic Control Unit (VDCCM&H/U).>






D: PREPARATION TOOL

1. SPECIAL TOOL

ILLUSTRATION	Part No.	DESCRIPTION	REMARKS
 ST20099PA010	20099PA010	INSTALLER & REMOVER	<ul style="list-style-type: none">• Used for replacing the bushing - trailing link of the housing assembly - rear axle.• Used together with BUSHING REMOVER (20099FG000).
 ST20099FG000	20099FG000	BUSHING REMOVER	<ul style="list-style-type: none">• Used for replacing the bushing - trailing link of the housing assembly - rear axle.• Used together with base part of INSTALLER & REMOVER (20099PA010).





General Description

DRIVE SHAFT SYSTEM

ILLUSTRATION	Part No.	DESCRIPTION	REMARKS
	28099AC000	BOOT BAND PLIER	Used for tightening the band - boot. (for front axle shaft)
	925091000	BAND TIGHTENING TOOL	Used for tightening the band - boot. (A) Jig for the band (B) Ratchet wrench
	18675AA000	DIFFERENTIAL SIDE OIL SEAL INSTALLER	Used for installing the differential side retainer oil seal.
	926470000	AXLE SHAFT PULLER	<ul style="list-style-type: none"> Used for removing the axle shaft. Used together with AXLE SHAFT PULLER PLATE (28099PA110).
	28099PA110	AXLE SHAFT PULLER PLATE	Exchange with the plate of the AXLE SHAFT PULLER (926470000) to use.

General Description

DRIVE SHAFT SYSTEM

ILLUSTRATION	Part No.	DESCRIPTION	REMARKS
 ST-927080000	927080000	HUB STAND	Used for assembling the bolt - hub of the hub.
 ST28399AG000	28399AG000	HUB STAND	Used for extracting the bolt - hub.
 ST28399SA010	28399SA010	OIL SEAL PROTECTOR	<ul style="list-style-type: none"> Used for installing the front axle shaft into the front differential. For protecting the oil seal.
 ST28099PA090	28099PA090	OIL SEAL PROTECTOR	<ul style="list-style-type: none"> Used for installing the rear axle shaft into the rear differential. For protecting the oil seal.

2. GENERAL TOOL

TOOL NAME	REMARKS
Tie-rod ball joint puller	Used for disconnecting joints.
Dial gauge	Used for inspecting the propeller shaft run-out.
Extension cap	Used for preventing leakage of gear oil or ATF.
Crowbar	Used for extracting the axle shaft.
Needle nose pliers	Used for tightening the band - boot of the rear axle shaft. <ul style="list-style-type: none"> Snap-on 96BCP Or equivalent.