

18. Evaporator


A: REMOVAL

- 1) Disconnect the ground cable from battery.
- 2) Using the refrigerant recovery system, discharge refrigerant. <Ref. to AC-26, PROCEDURE, Refrigerant Recovery Procedure.>
- 3) Remove the intake boot. <Ref. to IN(H4DO)-12, REMOVAL, Air Intake Boot.>

CAUTION:

Move aside the intake boot to perform the operation without disconnecting the PCV hose.


- 4) Remove the expansion valve - cooling.
 - (1) Remove the bolt, and detach the hose - pressure suction and the pipe - evaporator cooling.



- (2) Remove the bolt, and remove the expansion valve - cooling.

PREPARATION TOOL:

Hexagon wrench: 4 mm (0.16 in)




- 5) Remove the glove box. <Ref. to EI-67, REMOVAL, Glove Box.>

Evaporator

HVAC SYSTEM (HEATER, VENTILATOR AND A/C)


6) Remove the engine control module (ECM).

- (1) Release the lock and remove the relay holder.
- (2) Remove the harness clip, and disconnect the connector.



(3) Remove the nut (a).

(4) Loosen the bolt (b), and remove the engine control module (ECM).




Evaporator

HVAC SYSTEM (HEATER, VENTILATOR AND A/C)

7) Remove the blower motor unit assembly.

(1) Release the claws, and then remove the grille assembly - ventilation RH.


(2) Disconnect the blower motor relay and each connector.



(3) Remove the bolts and nuts to remove blower motor unit assembly.

NOTE:

Remove the RH upper nut from the mounting portion of the grille assembly - ventilation RH.




Evaporator

HVAC SYSTEM (HEATER, VENTILATOR AND A/C)

8) Remove the evaporator assembly - cooling.

(1) Disconnect the connector and lock of the thermostat - cooling.


(2) Remove the screws and detach the cover.



(3) Remove the cover - heater unit.

a) Disconnect the connector for the power transistor or resistor.

b) Remove the screws and clips to remove the cover - heater unit.




Evaporator

HVAC SYSTEM (HEATER, VENTILATOR AND A/C)

(4) Remove the bolt, and detach the pipe - evaporator core.


PREPARATION TOOL:

Hexagon wrench: 4 mm (0.16 in)



AC-02703

(5) Pull out the evaporator assembly - cooling from the case - heater unit.




AC-02704

Evaporator

HVAC SYSTEM (HEATER, VENTILATOR AND A/C)

(6) Remove the thermostat - cooling from the evaporator assembly - cooling.



B: INSTALLATION

CAUTION:

- If the evaporator assembly - cooling has been replaced, add an appropriate amount of compressor oil. <Ref. to AC-34, ADJUSTMENT, Compressor Oil.>
- When the evaporator assembly - cooling has been replaced, replace the packing of the expansion valve - cooling with a new one, and then apply compressor oil.
- Make sure that the water seal packing on the cover attachment area is securely attached.
- Replace the O-rings with new parts, and then apply compressor oil.
- After installing the grille assembly - ventilation RH, check that the air vent grille of the grille assembly - ventilation RH is inserted correctly into the air vent duct.

1) Install the thermostat - cooling to the specified position. <Ref. to AC-82, INSTALLATION, Evaporator Sensor.>

2) Install each part in the reverse order of removal.

Tightening torque:

Blower motor unit: <Ref. to AC-10, BLOWER MOTOR UNIT, COMPONENT, General Description.>

Engine control module (ECM): 7.5 N·m (0.76 kgf·m, 5.5 ft-lb)

3) Charge refrigerant. <Ref. to AC-27, PROCEDURE, Refrigerant Charging Procedure.>

C: INSPECTION

- 1) Check the evaporator fin for dust. Blow with compressed air or flush fins with water as needed.
- 2) If any oil leak is found, replace the evaporator assembly - cooling.