

## Refrigerant Leak Check

HVAC SYSTEM (HEATER, VENTILATOR AND A/C)

---

### 6. Refrigerant Leak Check

#### A: INSPECTION

##### **PREPARATION TOOL:**

*Manifold gauge set*

*Electronic leak detector*

- 1) Attach the manifold gauge set.
  - (1) Confirm that all valves are fully closed.
  - (2) Install the low/high pressure hoses to the service ports on the low/high pressure sides of the vehicle respectively.

##### **CAUTION:**

**Confirm that the connections are secure.**

- (3) Start the engine to operate the A/C system for approx. 10 minutes, and check that the high-pressure side shows at least 0.69 MPa (7.0 kgf/cm<sup>2</sup>, 100 psi).

2) Stop the engine to start the leak test.

# Refrigerant Leak Check

HVAC SYSTEM (HEATER, VENTILATOR AND A/C)

| Inspection parts        | Condition  | Corrective action  |
|-------------------------|--|--|
| Pipe                    | Check the connection between pipe and expansion valve.   | Check the O-ring and tightening torque on the connection. If necessary, replace each part. |
|                         | Check the connection between pressure switch or pressure sensor and high-pressure pipe.  | Replace the pressure switch or pressure sensor.  |
|                         | Check the connection between pipe and condenser.   | Check the O-ring and tightening torque on the connection. If necessary, replace each part. |
| Condenser               | Check the welded spot of condenser and the core.   | Replace the condenser.   |
| Hose<br>(high-pressure) | Check the connection between hose (high-pressure) and compressor.  | Check the O-ring and tightening torque on the connection. If necessary, replace each part. |
|                         | Check the connection between hose (high-pressure) and condenser.   | Check the O-ring and tightening torque on the connection. If necessary, replace each part. |
|                         | Check the rubber part of the flexible hose and the seam between hose and pipe.<br><b>CAUTION:</b><br><b>Carefully check the external surface of flexible hose and pipe at approx. 25 mm (0.98 in) per second.</b>  | Replace the hose (high-pressure).  |
|                         | Check the valve and cap in the service port.   | Check the rubber seal of the valve and cap. If necessary, replace valve or cap.            |
| Compressor              | Check the compressor pulley and the vicinity of shaft seal.<br><b>CAUTION:</b><br><b>Some shaft seals will show a slight amount of leakage, about 3 g (0.1 oz) per year. This is not a problem.</b>  | Replace the compressor.  |
| Hose<br>(low-pressure)  | Check the connection between hose (low-pressure) and expansion valve.  | Check the O-ring and tightening torque on the connection. If necessary, replace each part. |
|                         | Check the connection between hose (low-pressure) and compressor.   | Check the O-ring and tightening torque on the connection. If necessary, replace each part. |
|                         | Check the rubber part of the flexible hose and the seam between hose and pipe.<br><b>CAUTION:</b><br><b>Carefully check the external surface of flexible hose and pipe at approx. 25 mm (0.98 in) per second.</b>  | Replace the hose (low-pressure).   |
|                         | Check the valve and cap in the service port.   | Check the rubber seal of the valve and cap. If necessary, replace valve or cap.            |
|                         | Remove the drain hose from the heater case, and check the end portion for 10 seconds or more.  | Replace the evaporator.  |
| Evaporator              | Check the air vent grille.<br><b>NOTE:</b><br>Turn the ignition switch to ON, and run the blower at high speed for approx. 1 minute. Stop the blower to check the air vent grille on the instrument panel. While moving the tester closer to the grille, run the blower for 1 or 2 seconds, then stop it. Check the grille at that position for at least 10 seconds. | Replace the evaporator.  |