

4. Multi-function Display (MFD) System


A: WIRING DIAGRAM

Refer to “Multi-function Display (MFD) System” in WI section. <Ref. to WI-108, WIRING DIAGRAM, Multi-function Display (MFD) System.>

B: ELECTRICAL SPECIFICATION

1. MULTI FUNCTION DISPLAY

- Standard type



Terminal No.	Item	Measuring condition	Standard
1 (+B) \leftrightarrow Chassis ground	Voltage	Always	10 — 14 V
2 (GND) \leftrightarrow Chassis ground	Resistance	Always	Less than 1 Ω
3 (IG) \leftrightarrow Chassis ground	Voltage	IG OFF \rightarrow ON	0 V \rightarrow 10 — 14 V
9 (U-ART com.)	—	Cannot be measured	—
10 \leftrightarrow Chassis ground	Voltage	Passenger's airbag ON indicator light OFF \rightarrow ON	0 V \rightarrow 1.5 V
11 \leftrightarrow Chassis ground	Voltage	Passenger's airbag OFF indicator light OFF \rightarrow ON	0 V \rightarrow 1.5 V

- High grade type

Refer to “Control Module I/O Signal” of “INSTRUMENTATION/DRIVER INFO (DIAGNOSTICS)” section. <Ref. to IDI(diag)-6, ELECTRICAL SPECIFICATION, Control Module I/O Signal.>

Multi-function Display (MFD) System

INSTRUMENTATION/DRIVER INFO

C: OPERATION

1. DIAGNOSTIC MODE (HIGH GRADE TYPE ONLY)

The settings of the multi-function display can be changed by performing the following procedures to display the diagnostic mode.

CAUTION:

- Perform the work with IG-ON while charging the battery.
- While performing the work, close the front hood and all doors, and do not operate any electrical parts.
- Display can not be switched to diagnostic mode if the illumination control dial is set to the position for the dimming cancel function (maximum brightness).

1) Procedure

CAUTION:

Perform the steps described in (2) through (4) within 10 seconds.

- (1) Within 3 seconds after turning the IG-ON, turn the lighting switch to Switch 1 (TAIL) or Switch 2 (HEAD).
- (2) While keeping the lighting switch to Switch 1 (TAIL) or Switch 2 (HEAD) position, press the i/SET switch three times.
- (3) Turn the lighting switch to OFF, and press the i/SET switch three times.
- (4) Turn the lighting switch to Switch 1 (TAIL) or Switch 2 (HEAD) position again, press the i/SET switch three times.

NOTE:

- Except for the demonstration display setting of the diagnostic mode, the display will terminate with IG-OFF or by selecting "Back" from the menu screen.
- The demonstration display setting of the diagnostic mode will terminate by starting the engine or removing the battery. Even if it becomes IG-OFF then IG-ON again, the diagnostic mode will not terminate.
- To select other menus from the demonstration display setting, terminate the diagnostic mode by starting the engine or removing the battery, then access to the diagnostic mode again.

2) Display menu

Change the display and settings from each menu.

Menu	Item	Contents
Demonstration display setting	—	Shows demonstration display.
Vehicle status confirmation	• CAN communication	Displays the connection status of input signals.
	• U-ART communication	
	• Camera connection	
Rear camera settings	• Guide line adjustment	Adjust the guide line in the order of up/down, left/right and rotate, then select "Set" to determine.
	• Guide line display	Select "ON" or "OFF", then select "Set" to determine.
	• Guide line reset	Select "Yes" or "No" to determine whether to restore to the default settings.
Customize	• Key operation sound	Select "ON" or "OFF", then select "Set" to determine.
	• Correction of lifetime fuel economy value*	Adjust the fuel economy value within the range of -10 — +10 km/l, then determine the value with i/SET switch.
Back	—	Finish the diagnostic mode.

*: Correction of lifetime fuel economy value is used only when the multi-function display has been replaced. This function is provided as a compensation feature to bring the current lifetime fuel economy value to the one before the replacement of multi-function display.

D: INSPECTION

- Standard type

Refer to the following inspection steps. <Ref. to IDI-13, SYMPTOM CHART, INSPECTION, Multi-function Display (MFD) System.>

- High grade type

Refer to "Basic Diagnostic Procedure" of "INSTRUMENTATION/DRIVER INFO (DIAGNOSTICS)" section. <Ref. to IDI(diag)-2, Basic Diagnostic Procedure.>

1. SYMPTOM CHART

Symptoms	Repair order	Note
No display is shown.	1. Power supply 2. Ground circuit 3. Communication circuit harness 4. MFD	<Ref. to IDI-13, CHECK POWER SUPPLY AND GROUND CIRCUIT AND COMMUNICATION CIRCUIT, INSPECTION, Multi-function Display (MFD) System.>
Ambient air temperature/fuel economy displays do not appear.	1. Power supply 2. Ground circuit 3. Communication circuit harness 4. MFD	<Ref. to IDI-14, CHECK CLOCK SYSTEM COMMUNICATION CIRCUIT, INSPECTION, Multi-function Display (MFD) System.>
Only ambient air temperature display is not displayed.	1. Power supply 2. Harness 3. Ambient sensor 4. Communication circuit 5. MFD	<Ref. to IDI-15, CHECK AMBIENT TEMPERATURE METER SYSTEM COMMUNICATION CIRCUIT, INSPECTION, Multi-function Display (MFD) System.>
Only fuel economy display is not displayed.	1. Setting 2. Communication circuit 3. MFD	<Ref. to IDI-16, CHECK COMMUNICATION CIRCUIT OF FUEL ECONOMY SYSTEM, INSPECTION, Multi-function Display (MFD) System.>

2. CHECK POWER SUPPLY AND GROUND CIRCUIT AND COMMUNICATION CIRCUIT

Step	Check	Yes	No
1 CHECK POWER SUPPLY. 1) Disconnect the MFD connector. 2) Measure the voltage between MFD connector and chassis ground. <i>Connector & terminal (i122) No. 1 (+) — Chassis ground (-):</i>	Is the voltage 10 V or more?	Go to step 2.	Check the harness for open or short between the fuse and MFD.
2 CHECK GROUND CIRCUIT. Measure the resistance between MFD connector and chassis ground. <i>Connector & terminal (i122) No. 2 — Chassis ground:</i>	Is the resistance less than 10 Ω ?	Go to step 3.	Repair or replace the harness.
3 CHECK HARNESS BETWEEN MFD AND COMBINATION METER ASSEMBLY. 1) Disconnect the connector of combination meter assembly. 2) Check harness between MFD and combination meter assembly. <i>Connector & terminal (i122) No. 9 — (i10) No. 28:</i>	Is harness normal?	Go to step 4.	Repair or replace the harness.
4 CHECK MFD. 1) Remove the MFD. 2) Attach the clock to another vehicle on which the clock display operates normally, and check its operation.	Is the MFD normal?	Replace the meter - main assembly.	Replace the MFD.

Multi-function Display (MFD) System

INSTRUMENTATION/DRIVER INFO

3. CHECK CLOCK SYSTEM COMMUNICATION CIRCUIT

Step	Check	Yes	No
1 CHECK POWER SUPPLY. 1) Disconnect the MFD connector. 2) Turn the ignition switch to ON. 3) Measure the voltage between MFD connector and chassis ground. <i>Connector & terminal</i> <i>(i122) No. 3 (+) — Chassis ground (-):</i>	Is the voltage 10 V or more?	Go to step 2 .	Repair or replace the harness.
2 CHECK GROUND CIRCUIT. Measure the resistance between MFD connector and chassis ground. <i>Connector & terminal</i> <i>(i122) No. 2 — Chassis ground:</i>	Is the resistance less than 10 Ω ?	Go to step 3 .	Repair or replace the harness.
3 CHECK HARNESS BETWEEN MFD AND COMBINATION METER ASSEMBLY. 1) Disconnect the connector of combination meter assembly. 2) Check harness between MFD and combination meter assembly. <i>Connector & terminal</i> <i>(i122) No. 9 — (i10) No. 28:</i>	Is harness normal?	Go to step 4 .	Repair or replace the harness.
4 CHECK MFD. 1) Remove the MFD. 2) Attach the clock to another vehicle on which the clock display operates normally, and check its operation.	Is the MFD normal?	Replace the meter - main assembly.	Replace the MFD.

Multi-function Display (MFD) System

INSTRUMENTATION/DRIVER INFO

4. CHECK AMBIENT TEMPERATURE METER SYSTEM COMMUNICATION CIRCUIT

Step	Check	Yes	No
1 CHECK AMBIENT SENSOR POWER SUPPLY. 1) Disconnect the ambient sensor connector. 2) Turn the ignition switch to ON. 3) Measure the voltage between the ambient sensor connector and chassis ground. <i>Connector & terminal</i> (F78) No. 1 (+) — Chassis ground (-):	Is the voltage 4 V or more?	Go to step 2.	Check the harness for open or short between the fuse and MFD.
2 CHECK HARNESS BETWEEN AMBIENT SENSOR AND COMBINATION METER ASSEMBLY. 1) Disconnect the connector of combination meter assembly. 2) Check harness between ambient sensor and combination meter assembly. <i>Connector & terminal</i> (F78) No. 1 — (i10) No. 27: (F78) No. 2 — (i10) No. 36:	Is harness normal?	Go to step 3.	Repair or replace the harness.
3 CHECK AMBIENT SENSOR. Check the ambient sensor. <Ref. to AC-75, INSPECTION, Ambient Sensor.>	Is the ambient sensor operating properly?	Go to step 4.	Replace the ambient sensor.
4 CHECK AMBIENT TEMPERATURE DISPLAY. 1) Connect the combination meter assembly connector. 2) Install the 3 kΩ resistance between connector terminals of the ambient sensor. 3) Turn the ignition switch to ON. <i>Connector & terminal</i> (F78) No. 1 — No. 2:	Does the ambient temperature display 25°C (77°F)?	Repair the poor contact between the ambient sensor and harness connector.	Go to step 5.
5 CHECK CURRENT DATA. Using the Subaru Select Monitor, display the data of «Ambient Air Temperature». NOTE: For detailed procedures, refer to "PC application help for Subaru Select Monitor".	Is the ambient temperature of 25°C (77°F) output?	Go to step 6.	Replace the meter - main assembly. <Ref. to IDI-17, Combination Meter.>
6 CHECK MFD. 1) Remove the MFD. 2) Attach the ambient temperature display to another vehicle on which the ambient temperature display operates normally to check its operation.	Does the ambient temperature display 25°C (77°F)?	Replace the MFD.	Replace the meter - main assembly. <Ref. to IDI-17, Combination Meter.>

Multi-function Display (MFD) System

INSTRUMENTATION/DRIVER INFO

5. CHECK COMMUNICATION CIRCUIT OF FUEL ECONOMY SYSTEM

Step	Check	Yes	No
1 CHECK FUEL ECONOMY DISPLAY OFF MODE. Check that the mode display changes when the MFD changeover knob is operated. (Display changes in the following order: cruising distance → average fuel economy → instantaneous fuel economy → continuous driving time → average vehicle speed → blank display)	Is fuel economy displayed?	MFD is normal.	Go to step 2 .
2 CHECK BODY INTEGRATED UNIT. Read the DTC using Subaru Select Monitor. NOTE: For detailed procedures, refer to "PC application help for Subaru Select Monitor".	Is DTC detected?	Go to step 3 .	Replace the meter - main assembly. <Ref. to IDI-17, Combination Meter.>
3 CHECK MFD. 1) Remove the MFD. 2) Attach the fuel economy display to another vehicle on which the fuel economy display operates normally to check its operation.	Is the fuel economy display correct?	Replace the MFD.	Replace the meter - main assembly. <Ref. to IDI-17, Combination Meter.>

E: NOTE

For procedure of each component in the clock system, refer to the respective section.

- Multi-function display: <Ref. to IDI-24, Multi-function Display (MFD).>