

Basic Diagnostic Procedure

INSTRUMENTATION/DRIVER INFO (DIAGNOSTICS)

1. Basic Diagnostic Procedure

A: PROCEDURE

1. COMBINATION METER

Step	Check	Yes	No
1 PERFORM CUSTOMER INTERVIEW. Using the Check List for Interview, ask the customer the condition of how trouble occurs. <Ref. to IDI(diag)-3, CHECK, Check List for Interview.>	Did you interview the customer?	Go to step 2.	Interview the customer. <Ref. to IDI(diag)-3, CHECK, Check List for Interview.>
2 CHECK CAN COMMUNICATION. Read the DTC of the CAN system using the Subaru Select Monitor. <Ref. to LAN(diag)-22, OPERATION, Read Diagnostic Trouble Code (DTC).>	Is DTC displayed?	Perform the diagnosis according to DTC. <Ref. to LAN(diag)-51, LIST, List of Diagnostic Trouble Code (DTC).>	Go to step 3.
3 CHECK COMBINATION METER. Using the Subaru Select Monitor, read DTC of combination meter. <Ref. to BC(diag)-9, OPERATION, Read Diagnostic Trouble Code (DTC).>	Is DTC displayed?	Perform the diagnosis according to DTC. <Ref. to BC(diag)-22, LIST, List of Diagnostic Trouble Code (DTC).>	Go to step 4.
4 CHECK COMBINATION METER. Check the operation of combination meter. <Ref. to IDI(diag)-17, System Operation Check Mode.>	Is it operating normally?	System is normal.	Replace the combination meter. <Ref. to IDI-17, Combination Meter.>

2. MFD

Step	Check	Yes	No
1 PERFORM CUSTOMER INTERVIEW. Using the Check List for Interview, ask the customer the condition of how trouble occurs. <Ref. to IDI(diag)-3, CHECK, Check List for Interview.>	Did you interview the customer?	Go to step 2.	Interview the customer. <Ref. to IDI(diag)-3, CHECK, Check List for Interview.>
2 CHECK CAN COMMUNICATION. Read the DTC of the CAN system using the Subaru Select Monitor. <Ref. to LAN(diag)-22, OPERATION, Read Diagnostic Trouble Code (DTC).>	Is DTC displayed?	Perform the diagnosis according to DTC. <Ref. to LAN(diag)-51, LIST, List of Diagnostic Trouble Code (DTC).>	Go to step 3.
3 CHECK MFD. Read the DTC relating the MFD using the Subaru Select Monitor. <Ref. to BC(diag)-9, OPERATION, Read Diagnostic Trouble Code (DTC).>	Is DTC displayed?	Perform the diagnosis according to DTC. <Ref. to BC(diag)-22, LIST, List of Diagnostic Trouble Code (DTC).>	Go to step 4.
4 CHECK MFD. Check the MFD display using the system operation check mode of combination meter. <Ref. to IDI(diag)-17, System Operation Check Mode.>	Is the display normal?	System is normal.	Replace the MFD. <Ref. to IDI-24, Multi-function Display (MFD).>