


## 25.Sun Visor


### A: REMOVAL

1) Remove the screws and detach the sun visor.



2) Disconnect the connector. (Model with vanity mirror light)

3) While pressing the (A) on the both side using flat tip screwdriver, pull the sun visor hook to remove it.



### B: INSTALLATION

Install each part in the reverse order of removal.