


### 3. Front Axle

#### A: REMOVAL

- 1) Lift up the vehicle, and then remove the front wheels.
- 2) Lift the crimped section of axle nut.




DS-00038

- 3) Remove the axle nut using a socket wrench while depressing the brake pedal.

#### CAUTION:

**Do not loosen the axle nut while the front axle is loaded. Doing so may damage the hub bearing.**

- 4) Remove the stabilizer link.




DS-00262

- 5) Remove the disc brake caliper from the housing, and suspend it from strut using a wire.

- 6) Remove the disc rotor from the hub.


#### NOTE:

If it is difficult to remove the disc rotor from the hub, drive the 8 mm bolt into the threaded end of rotor, and then remove the rotor.



DS-00041

- 7) Remove the cotter pin and castle nut securing the tie-rod end to the housing knuckle arm.




DS-00042

(A) Cotter pin

(B) Castle nut


(C) Tie-rod

- 8) Using a puller, remove the tie-rod ball joint from knuckle arm.




DS-00043

- 9) Remove the ABS wheel speed sensor assembly and harness.



DS-00249

- 10) Remove the bolts which secure the sensor harness to the strut.




DS-00144



# Front Axle

## DRIVE SHAFT SYSTEM

10) Tighten the castle nut to specified torque and tighten further within  $60^\circ$  until the pin hole is aligned with the slot in the nut. Bend the cotter pin to lock.



(A) Cotter pin  
(B) Castle nut  
(C) Tie-rod

11) While depressing the brake pedal, tighten a new axle nut to the specified torque and lock it securely.


### CAUTION:

**Do not apply weight to the front axle before tightening the axle nut. Doing so may damage the hub bearing.**

### Tightening torque:

**220 N·m (22.43 kgf-m, 162.3 ft-lb)**

12) After tightening the axle nut, lock it securely.



13) Install the wheel.


### Tightening torque:

**100 N·m (10.20 kgf-m, 73.8 ft-lb)**

14) Connect the battery ground terminal.  
15) Inspect the wheel alignment and adjust if necessary.


## C: DISASSEMBLY

1) Remove the four bolts from the housing (A), and remove the front hub unit bearing and disc cover.



### CAUTION:

- Do not get closer the tool which charged magnetism to magnetic encoder.
- Be careful not to damage the magnetic encoder.




(1) Magnetic encoder  
(2) Front hub unit bearing

2) Disassemble the front hub unit bearing. <Ref. to DS-19, DISASSEMBLY, Front Hub Unit Bearing.>

**D: ASSEMBLY**


1) Assemble the front hub unit bearing. <Ref. to DS-19, ASSEMBLY, Front Hub Unit Bearing.>  
 2) Place the disc cover between housing (A) and front hub unit, and tighten the four bolts.

**Tightening torque:**

65 N·m (6.63 kgf·m, 47.9 ft-lb)

**CAUTION:**

- Do not get closer the tool which charged magnetism to magnetic encoder.
- Be careful not to damage the magnetic encoder.




(1) Magnetic encoder

(2) Front hub unit bearing

**E: INSPECTION**

1) Moving the front tire up and down by hand, check there is no play in bearing, and check the wheel rotates smoothly.



2) Inspect the lean of axis direction using a dial gauge. Replace the bearing if the load range exceeds the limitation.

**Service limit:**

**Maximum: 0.05 mm (0.0020 in)**

