

6. Fuel Level Sensor

A: REMOVAL

For removal procedures, refer to the “FU(w/o STI)” section. <Ref. to FU(w/o STI)-80, REMOVAL, Fuel Level Sensor.>

B: INSTALLATION

For installation procedures, refer to the “FU(w/o STI)” section. <Ref. to FU(w/o STI)-80, INSTALLATION, Fuel Level Sensor.>

C: INSPECTION

For inspection procedures, refer to the “FU(w/o STI)” section. <Ref. to FU(w/o STI)-80, INSPECTION, Fuel Level Sensor.>