



5. Crankshaft Position Sensor

A: REMOVAL


- 1) Remove the collector cover.
- 2) Disconnect the ground cable from battery.



- 3) Remove the bolt which secures crankshaft position sensor to oil pump.



- 4) Remove the crankshaft position sensor, and disconnect the connector from the crankshaft position sensor.



B: INSTALLATION

Install in the reverse order of removal.


Tightening torque:

6.4 N·m (0.7 kgf-m, 4.7 ft-lb)

C: INSPECTION

1. CRANKSHAFT POSITION SENSOR (METHOD WITH CIRCUIT TESTER)


Measure the resistance between crankshaft position sensor terminals.




Terminal No.	Standard
1 and 2	2.04±0.204 kΩ

2. CRANKSHAFT POSITION SENSOR (METHOD WITH OSCILLOSCOPE)

- 1) Prepare an oscilloscope.
- 2) Remove the lower inner trim of passenger's side. <Ref. to EI-57, REMOVAL, Lower Inner Trim.>
- 3) Turn over the floor mat of passenger's seat.
- 4) Remove the protect cover.




- 5) Remove the nuts and bolts which hold the ECM to the bracket.



Crankshaft Position Sensor

FUEL INJECTION (FUEL SYSTEMS)

6) Connect the probe to ECM connector.




(A) To ECM connector

Terminal No.	Probe
17	+
25	-

7) Start the engine and let it idle.

8) Check the pattern is the same as the waveform and voltage shown below.



(A) One crankshaft rotation

9) After inspection, install the related parts in the reverse order of removal.

Tightening torque:

7.5 N·m (0.8 kgf-m, 5.5 ft-lb)

3. OTHER INSPECTIONS

Check that the crankshaft position sensor has no deformation, cracks or other damages.