


Diagnostic Procedure without Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

1. SI-DRIVE MODE INDICATION DOES NOT CHANGE AND MODES DO NOT SWITCH AFTER SWITCHING SI-DRIVE MODES

WIRING DIAGRAM:

- Engine electrical system, without SI-DRIVE <Ref. to WI-32, WITHOUT SI-DRIVE, WIRING DIAGRAM, Engine Electrical System.>
- Engine electrical system, with SI-DRIVE <Ref. to WI-48, WITH SI-DRIVE, WIRING DIAGRAM, Engine Electrical System.>



EN-06527

Step	Check	Yes	No
1 CHECK SI-DRIVE SELECTOR. 1) Turn the ignition switch to OFF. 2) Disconnect the connector from the combination meter. 3) Measure the resistance between connectors when the SI-DRIVE selector is operated. Connector & terminal (i10) No. 33 — (i10) No. 35:	Does the resistance change as below? S#: 3.48 — 3.85 kΩ I: 0.95 — 1.05 kΩ S: less than 1 Ω	Go to step 4.	Go to step 2.

Diagnostic Procedure without Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
2 CHECK HARNESS BETWEEN COMBINATION METER AND MULTI-SELECT SWITCH CONNECTOR. 1) Disconnect the connector from multi-select switch. 2) Measure the resistance of harness between combination meter and multi-select switch connector. Connector & terminal (i10) No. 33 — (R33) No. 8: (i10) No. 35 — (R33) No. 5:	Is the resistance less than 1 Ω ?	Go to step 3.	Repair the harness and connector. NOTE: In this case, repair the following item: <ul style="list-style-type: none">• Open circuit in harness between combination meter and multi-select switch connector• Poor contact of coupling connector
3 CHECK HARNESS BETWEEN COMBINATION METER AND MULTI-SELECT SWITCH CONNECTOR. Measure the resistance between multi-select switch connector and chassis ground. Connector & terminal (R33) No. 8 — Chassis ground: (R33) No. 5 — Chassis ground:	Is the resistance 1 $M\Omega$ or more?	Repair the poor contact of multi-select switch connector. Replace the multi-select switch if defective. <Ref. to FU(STI)-58, SI-DRIVE (SUBARU Intelligent Drive) Selector.>	Repair the ground short circuit in harness between combination meter and multi-select switch connector.
4 CHECK HARNESS BETWEEN COMBINATION METER AND CHASSIS GROUND. Measure the resistance of harness between combination meter and chassis ground. Connector & terminal (i10) No. 21 — Chassis ground: (i10) No. 22 — Chassis ground:	Is the resistance less than 5 Ω ?	Go to step 5.	Repair the harness and connector. NOTE: In this case, repair the following item: <ul style="list-style-type: none">• Open circuit in harness between combination meter and chassis ground• Poor contact of coupling connector
5 RECHECK FAULT. 1) Connect all connectors. 2) Switch SI-DRIVE modes.	Is there any fault?	Repair the poor contact of combination meter connector. Replace the combination meter if defective. <Ref. to IDI-16, Combination Meter.>	The circuit has returned to a normal condition at this time. Reproduce the failure, and then perform the diagnosis again. NOTE: In this case, temporary poor contact of connector, temporary open or short circuit of harness may be the cause.

Diagnostic Procedure without Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

2. "S" BLINKS ON SI-DRIVE MODE DISPLAY IN THE COMBINATION METER APPROX. 5 SECONDS AFTER SWITCHING SI-DRIVE MODES

Step	Check	Yes	No
1 CHECK DTC.	Is DTC displayed?	Check the appropriate DTC using the "List of Diagnostic Trouble Code (DTC)" concerning the respective units.	Go to step 2.
2 CHECK COMBINATION METER AND CLOCK DISPLAY. Check for abnormal indication other than "S" blinking. Examples: <ul style="list-style-type: none">• Malfunction indicator light illuminates.• "Err" is displayed on fuel efficiency display part.• Engine coolant temperature gauge does not move.	Is there any abnormal indication other than "S" blinking?	For the diagnostic procedure, refer to LAN section. <Ref. to LAN(diag)-2, Basic Diagnostic Procedure.>	Go to step 3.
3 CHECK COMBINATION METER, ECM AND BODY INTEGRATED UNIT.	Are the part numbers of combination meter, ECM and body integrated unit correct?	Replace the combination meter. <Ref. to IDI-16, Combination Meter.>	Replace the combination meter, ECM or body integrated unit with parts of proper part number. <Ref. to IDI-16, Combination Meter.> <Ref. to FU(STI)-59, Engine Control Module (ECM).> or <Ref. to SL-48, Body Integrated Unit.>

Diagnostic Procedure without Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

3. “S#”, “I” OR “S” BLINKS ON SI-DRIVE MODE DISPLAY IN THE COMBINATION METER AFTER SWITCHING SI-DRIVE MODES

NOTE:

In this case, there is a fault other than in SI-DRIVE system.

Step	Check	Yes	No
1 CHECK MALFUNCTION INDICATOR LIGHT. 1) Start the engine. 2) Check if malfunction indicator light illuminates.	Does the malfunction indicator light illuminate?	Read the DTC using Subaru Select Monitor and check the indicated DTC. <Ref. to EN(H4DOTC)(diag)-87, List of Diagnostic Trouble Code (DTC).>	Go to step 2.
2 CHECK ENGINE COOLANT TEMPERATURE GAUGE. 1) Turn the ignition switch to ON. 2) Check the engine coolant temperature gauge.	Does it indicate overheating?	Inspect for the cause of overheating and repair.	Go to step 3.
3 CHECK COMBINATION METER INDICATION. 1) Turn the ignition switch to ON. 2) Switch SI-DRIVE modes. 3) Check the SI-DRIVE mode display in the combination meter.	Does “S#”, “I” or “S” of the SI-DRIVE mode blink in combination meter?	Replace the combination meter. <Ref. to IDI-16, Combination Meter.>	Perform test driving to check the malfunction indicator light and engine coolant temperature gauge. Complete the diagnosis if they are normal.