


16.Oil Control Solenoid

A: REMOVAL


1. INTAKE SIDE

- 1) Disconnect the ground terminal from battery sensor. <Ref. to NT-5, BATTERY, NOTE, Note.>
- 2) Remove the air intake duct. (RH side only) <Ref. to IN(w/o STI)-22, REMOVAL, Air Intake Duct.>
- 3) Disconnect the connector (A) from the oil control solenoid, and remove the oil control solenoid from the chain cover.

- RH side




- LH side




2. EXHAUST SIDE

- 1) Disconnect the ground terminal from battery sensor. <Ref. to NT-5, BATTERY, NOTE, Note.>
 - 2) Remove the air intake duct. (RH side only) <Ref. to IN(w/o STI)-22, REMOVAL, Air Intake Duct.>
 - 3) Disconnect the connector (A) from the oil control solenoid, and remove the oil control solenoid from the chain cover.
- RH side



- LH side



B: INSTALLATION

Install in the reverse order of removal.

NOTE:

- Use new O-rings.
- Apply engine oil to O-ring.

Tightening torque:


6.4 N·m (0.7 kgf·m, 4.7 ft-lb)

Oil Control Solenoid

FUEL INJECTION (FUEL SYSTEMS)

C: INSPECTION

- 1) Check that the oil control solenoid has no deformation, cracks or other damages.
- 2) Measure the resistance between the oil control solenoid terminals.



FU-05950

Terminal No.	Standard
1 and 2	$7.25 \pm 0.4 \Omega$ (when 20°C (68°F))