

10. Fuel Sub Level Sensor

A: REMOVAL

Refer to "Fuel Sub Level Sensor" for removal procedure of the fuel sub level sensor. <Ref. to FU(w/o STI)-176, REMOVAL, Fuel Sub Level Sensor.>

B: INSTALLATION

Refer to "Fuel Sub Level Sensor" for installation procedure of the fuel sub level sensor. <Ref. to FU(w/o STI)-180, INSTALLATION, Fuel Sub Level Sensor.>

C: INSPECTION

Refer to "Fuel Sub Level Sensor" for the fuel sub level sensor inspection procedure. <Ref. to FU(w/o STI)-182, INSPECTION, Fuel Sub Level Sensor.>