

10. Clutch Pedal

A: REMOVAL

1) Disconnect the ground cable from battery. <Ref. to NT-5, BATTERY, NOTE, Note.>

NOTE:


For models other than STI model, disconnect the ground terminal from battery sensor.

2) Remove the steering column. <Ref. to PS-25, REMOVAL, Steering Column.>

3) Disconnect the connector from the stop light switch and clutch switch.

4) Remove the snap pins from clevis pins which secure the lever to the push rod and operating rod.

5) Pull out the clevis pins which secures the lever to the push rod and operating rod.




(A) Operating rod
(B) Push rod
(C) Snap pin
(D) Clevis pin

6) Remove the intercooler.

<Ref. to IN(STI)-13, REMOVAL, Intercooler.>
<Ref. to IN(w/o STI)-38, REMOVAL, Intercooler.>

7) Remove the nut which secures the clutch master cylinder.



8) Remove the bolts and nuts which secure the brake pedal and clutch pedal, and remove the pedal assembly.

B: INSTALLATION

1) Install in the reverse order of removal.

CAUTION:

Always use a new clevis pin.


2) Adjust the clutch pedal after installation. <Ref. to CL-33, ADJUSTMENT, Clutch Pedal.>

3) Adjust the clutch start switch. <Ref. to CL-37, ADJUSTMENT, Clutch Switch.>

C: DISASSEMBLY


1) Remove the clutch switches.

2) Remove the clip, assist spring, rod and bushing.



(A) Clip
(B) Assist spring
(C) Assist rod A
(D) Assist rod B
(E) Assist bushing
(F) Clutch clevis pin
(G) Bushing

3) Remove the spring pin and lever.




(A) Spring pin
(B) Lever

Clutch Pedal

CLUTCH SYSTEM


4) Remove the clutch pedal and bushings.



(A) Clutch pedal

(B) Bushing


5) Remove the stopper and clutch pedal pad from the clutch pedal.



(A) Stopper

(B) Clutch pedal pad

6) Remove the stopper from the clutch pedal bracket.



(A) Stopper

D: ASSEMBLY

- 1) Attach the stopper and clutch pedal pad to the clutch pedal.
- 2) Install the clutch switch to the pedal bracket.
- 3) Clean the pedal bushing holes of the clutch pedal and the brake pedal, apply grease, and install the pedal bushings.
- 4) Install the clutch pedal, brake pedal and lever to the pedal bracket, and fix with a spring pin.
- 5) Install the assist rod A, assist rod B, assist bushing and assist spring to the clutch pedal and pedal bracket.

E: INSPECTION

- 1) Check the free play of the clutch pedal.

NOTE:

Check by pressing the pedal.

Clutch pedal free play:

5 — 11 mm (0.2 — 0.43 in)

- 2) Move the clutch pedal pads in the lateral direction with a force of approximately 10 N (1 kgf, 2 lbf) to check that the clutch pedal deflection is within the service limit.


CAUTION:

If the play exceeds the service limit, replace the bushing with a new part.

Deflection of the clutch pedal:

Service limit

4.0 mm (0.157 in) or less



(A) Clutch pedal

(B) Brake pedal

F: ADJUSTMENT

1) Turn the lock nut until the full stroke of clutch pedal becomes within the specification.

CAUTION:

When adjusting the full stroke of clutch pedal, do not turn the clutch switch.

NOTE:

If the lock nut cannot adjust the full stroke of clutch pedal to the specified value, adjust it by turning the master cylinder push rod.

Clutch pedal full stroke A:

STI model


130 — 135 mm (5.12 — 5.31 in)

Except for STI model

135 — 140 mm (5.31 — 5.51 in)

Tightening torque (clutch switch lock nut):

T: 8 N·m (0.8 kgf-m, 5.9 ft-lb)




2) If the full stroke is not within the specified value, loosen the clutch switch lock nut to adjust.

Tightening torque:

8 N·m (0.8 kgf-m, 5.9 ft-lb)

3) Loosen the push rod lock nuts.



(A) Clevis pin

(B) Snap pin


(C) Push rod

(D) Push rod lock nut

4) Rotate the push rod to adjust.

(1) Make sure that the clutch pedal contacts the clutch switch side when the pedal is released.

(2) Make sure that the clutch pedal contacts the clutch pedal bracket stopper when the clutch pedal is at the maximum stroke position.



CL-00080

(A) Clevis hole

(B) Push rod lock nut


(C) In the shorter direction

(D) In the longer direction

(E) Push rod

(F) Clevis

5) Turn the push rod to shorten until a clearance is gained on the clutch switch side.



CL-00605


(A) Clutch switch

(B) Stopper

Clutch Pedal

CLUTCH SYSTEM

- 6) Turn the push rod to lengthen until clutch pedal contacts the clutch switch.
- 7) Turn further in the direction that will shorten the push rod (arrow direction shown in figure) by 270°.



CL-00600


(A) Accelerator pedal
(B) Clevis

- 8) Check that the clevis pin moves smoothly by moving it in the left and right directions.

- 9) Tighten the push rod lock nut.

Tightening torque (push rod lock nut):

T: 10 N·m (1.0 kgf·m, 7.4 ft-lb)



CL-00226

(A) Clevis pin
(B) Snap pin
(C) Push rod

- 10) Depress and release the clutch pedal two or three times to ensure that the clutch pedal and release lever operate smoothly. If the clutch pedal and release lever do not operate smoothly, bleed air from the clutch hydraulic system. <Ref. to CL-29, Clutch Fluid Air Bleeding.>

- 11) Measure the clutch pedal full stroke length again to ensure that it is within specifications. If it is not within specifications, repeat adjustment procedures again from the beginning.

Clutch pedal full stroke:


STI model

130 — 135 mm (5.12 — 5.31 in)

Except for STI model

135 — 140 mm (5.31 — 5.51 in)


- 12) Push the release lever until the operating cylinder push rod retracts. Make sure that the clutch fluid level in the reservoir tank increases. If the clutch fluid level increases, the hydraulic clutch is properly adjusted. If the fluid level does not increase or the push rod does not retract, replace the master cylinder with a new part. <Ref. to CL-24, Master Cylinder.>



CL-00663

(A) Push rod
(B) Release lever
(C) Operating cylinder

- 13) Push the release lever until the operating cylinder push rod retracts. Check that the clutch fluid level in the reservoir tank increases.



CL-00663

(A) Push rod
(B) Release lever
(C) Operating cylinder

- 14) If the clutch fluid level increases, hydraulic clutch play is correct.

- 15) If the clutch fluid level does not increase or push rod does not retract, readjust the clutch pedal.

- 16) Check the fluid level using the scale on the outside of the reservoir tank. <Ref. to CL-28, INSPECTION, Clutch Fluid.>