

### 8. Front Strut

#### A: REMOVAL

1) Disconnect the ground cable from battery. <Ref. to NT-5, BATTERY, NOTE, Note.>

NOTE:

For models other than STI model, disconnect the ground terminal from battery sensor.


2) Lift up the vehicle, and then remove the front wheels.

3) Remove the strut assembly.


- (1) Place an alignment mark (a) on the adjusting bolt and the strut.
- (2) Remove the brake hose bracket.
- (3) Remove the clamp of ABS wheel speed sensor harness.
- (4) Remove the adjusting bolts and flange bolts for the strut assembly.

**CAUTION:**

**While holding the adjusting bolt side, tighten the nut side.**



(5) Remove the three nuts securing strut mount to body.



### B: INSTALLATION

#### CAUTION:

**For parts which are not reusable, always use new parts.**

- 1) Install the strut mount - front at the upper side of the strut to the vehicle body.

#### *Tightening torque:*

**20 N·m (2.0 kgf·m, 14.8 ft-lb)**

- 2) Align alignment marks on the camber adjusting bolt and the strut, and install the strut to the housing assembly - front axle.

#### NOTE:

While holding the bolt head of adjusting bolt, tighten the nut.

#### *Tightening torque:*

**155 N·m (15.8 kgf·m, 114.3 ft-lb)**

- 3) Secure the ABS wheel speed sensor harness bracket to the strut.

#### CAUTION:

**During the installation, make sure that the marking of ABS wheel speed sensor harness does not twist.**

- 4) Install the brake hose bracket.

#### *Tightening torque:*

**33 N·m (3.4 kgf·m, 24.3 ft-lb)**

- 5) Install the front wheels.

#### *Tightening torque:*

**120 N·m (12.2 kgf·m, 88.5 ft-lb)**

- 6) Connect the battery ground terminal. <Ref. to NT-5, BATTERY, NOTE, Note.>

#### NOTE:

For models other than STI model, connect the ground terminal to battery sensor.

- 7) Inspect the wheel alignment and adjust if necessary.

- Inspection: <Ref. to FS-10, INSPECTION, Wheel Alignment.>
- Adjustment: <Ref. to FS-15, ADJUSTMENT, Wheel Alignment.>

#### CAUTION:

**When the wheel alignment has been adjusted, perform “VDC sensor midpoint setting mode” of the VDC. <Ref. to VDC-16, ADJUSTMENT, VDC Control Module and Hydraulic Control Unit (VDCCM&H/U).>**

- 8) Perform reinitialization of the auto headlight beam leveler system. (Model with auto headlight beam leveler) <Ref. to LI-16, PROCEDURE, Auto Headlight Beam Leveler System.>

# Front Strut


## FRONT SUSPENSION

### C: DISASSEMBLY

- 1) Using a coil spring compressor, compress the coil spring.
- 2) Using a hexagon wrench to prevent strut rod from turning, remove the self-locking nut with ST.

*Preparation tool:*

**ST: STRUT MOUNT SOCKET (20399AG000)**




- 3) Remove the strut mount - front, spacer - front strut, dust cover - front strut and spring seat - front strut UPR from the strut COMPL.
- 4) Gradually decrease the compression force of compressor, and remove the coil spring.
- 5) Remove the dust cover - inner and the helper - front strut.

### D: ASSEMBLY

- 1) Before assembly, check each part. <Ref. to FS-49, INSPECTION, Front Strut.>
- 2) Using a coil spring compressor, compress the coil spring.


NOTE:

Make sure that the vertical install direction of the coil spring is as shown in the figure.



- (1) Diameter is small (upper part)
- (2) Identification paint
- (3) Diameter is large (bottom part)

- 3) Set the coil spring correctly so that its end face (a) contacts the vertical surface (b) of the spring seat - front strut LWR as shown in the figure.



- 4) Install the dust cover - inner and the helper - front strut to the piston rod.


# Front Strut

## FRONT SUSPENSION

5) Pull the piston rod fully upward, and install the spring seat and the dust cover - front strut.

NOTE:

Position the spring seat - front strut UPR as shown in the figure.



(1) Outside of body

6) Install the spacer - front strut and the strut mount - front to the piston rod, and temporarily tighten a new self-locking nut.


7) Using a hexagon wrench to prevent strut rod from turning, tighten the new self-locking nut with ST.

**CAUTION:**

**Make sure that the strut mount - front turns smoothly after tightening.**

*Preparation tool:*

**ST: STRUT MOUNT SOCKET (20399AG000)**



**Tightening torque:**

**55 N·m (5.6 kgf·m, 40.6 ft-lb)**


8) Loosen the coil spring compressor carefully.

### E: INSPECTION

Check the removed part for wear, damage and cracks, and then repair or replace it if defective.

#### 1. STRUT

- 1) Check for oil leaks.
- 2) Move the piston rod up and down to check that it operates smoothly without any hitch.
- 3) Check the piston rod for play.
  - (1) Fix the outer shell in place and fully extend the rod.
  - (2) Set the dial gauge on the end of the rod L [10 mm (0.39 in)].
  - (3) While applying a force of W [20 N (2 kgf, 4 lbf)] to the threaded part, read the dial gauge indication  $P_1$ .
  - (4) Apply a force of 20 N (2 kgf, 4 lbf) from the opposite direction of "W", and then read the dial gauge indication  $P_2$ .



FS-00046

**Play limit ( $P_1 + P_2$ ): 0.8 mm (0.031 in)**

- 4) Replace the strut if faulty is found in the inspection or limit value is exceeded.

#### 2. STRUT MOUNT - FRONT

Check the rubber part for deformation, cracks or deterioration, and then replace it with a new part if defective.

#### 3. DUST COVER - INNER

If cracks or damage are found, replace it with a new part.

#### 4. COIL SPRING - FRONT

If cracks, damage or deformation are found, replace it with a new part.

#### 5. HELPER - FRONT STRUT

If major cracks or damage are found, replace it with a new part.

#### 6. DUST COVER - FRONT

If major cracks or damage are found, replace it with a new part.


### F: DISPOSAL

#### CAUTION:

- Before handling struts, be sure to wear goggles to protect eyes from gas, oil and cutting powder.
- Do not disassemble the strut damper or throw into flames.
- When discarding gas filled struts, drill holes in them to purge the gas.


1) Place the strut on a level surface with the piston rod fully expanded.

2) Using a 2 — 3 mm (0.08 — 0.12 in) dia. drill, make holes in areas shown in the figure. (standard damper model)



(1) 40 mm (1.57 in)

3) Using a 2 — 3 mm (0.08 — 0.12 in) dia. drill, make a hole into the position (1) first, and then (2). (inverted damper model)



(1) 20 mm (0.78 in)

(2) 10 mm (0.39 in)

(3) Strut

(4) Damping tube