

General Description

REAR SUSPENSION

1. General Description

A: SPECIFICATION

1. WRX MODEL


| | | |
|--|-----------|---|
| Tire size | 235/45R17 | |
| Wheel arch height (Tolerance: +12 mm -24 mm (+0.47 in -0.94 in)) | mm (in) | 367 (14.45) |
| Camber (tolerance: $\pm 0^\circ 45'$ Differences between RH and LH: 45' or less) | | -1°30' |
| Toe-in | mm (in) | IN3±3 (IN0.12±0.12) |
| | | Toe angle (sum of both wheels): IN0°16'±16' |
| Thrust angle (tolerance: 0°00'±30') | 0°00' | |

2. STI MODEL

| | | |
|--|-----------|---|
| Tire size | 245/40R18 | |
| Wheel arch height (Tolerance: +12 mm -24 mm (+0.47 in -0.94 in)) | mm (in) | 362 (14.25) |
| Camber (tolerance: $\pm 0^\circ 45'$ Differences between RH and LH: 45' or less) | | -1°40' |
| Toe-in | mm (in) | IN3±3 (IN0.12±0.12) |
| | | Toe angle (sum of both wheels): IN0°16'±16' |
| Thrust angle (tolerance: 0°00'±30') | 0°00' | |

NOTE:

- Front toe-in, rear toe-in and front camber can be adjusted. Adjust if the value of toe-in or camber exceeds the tolerance range of the specification chart.
- Other items except for front toe-in, rear toe-in and front camber that are described in the specification chart cannot be adjusted.
- If other items exceed the tolerance range of the specification chart, check the suspension parts and connections for deformation. If defective, replace with new parts.




RS-00537

A - B = Positive: Toe-in, Negative: Toe-out

α = Individual toe angles

B: COMPONENT

1. REAR SUSPENSION



RS-00539

| | | |
|------------------------------------|----------------------------------|------------------------------|
| (1) Rear sub frame ASSY | (11) Rear support sub frame | (21) Bushing - trailing link |
| (2) Stopper UPR | (12) Flange nut | |
| (3) Support - sub frame | (13) Rear stabilizer | |
| (4) Flange bolt A | (14) Bushing - stabilizer | |
| (5) Bushing A - trailing link | (15) Clamp - stabilizer bushing | |
| (6) Trailing link | (16) Stabilizer link ASSY | |
| (7) Flange bolt B | (17) Rear shock absorber ASSY | |
| (8) Self-locking nut | (18) Rear lateral link ASSY | |
| (9) Flange bolt C | (19) Bushing - rear axle housing | |
| (10) Bushing C - lateral link rear | (20) Housing ASSY - rear axle | |

Tightening torque: N·m (kgf·m, ft·lb)

T1: 30 (3.1, 22.1)

T2: 38 (3.9, 28.0)

T3: 70 (7.1, 51.6)

T4: 80 (8.2, 59.0)


T5: 85 (8.7, 62.7)

T6: 110 (11.2, 81.1)

T7: 145 (14.8, 106.9)

General Description

REAR SUSPENSION



RS-00538

(1) Rear sub frame ASSY

(2) Self-locking nut

(3) Rear upper arm ASSY

(4) Snap pin

(5) Lateral link ASSY - front

(6) Bushing B - lateral link

(7) Adjusting washer

(8) Adjusting bolt

(9) Sensor ASSY - headlight beam leveler (models with auto headlight beam leveler only)

(10) Lateral link ASSY - rear

(11) Housing ASSY - rear axle

(12) Bushing - rear axle housing

(13) Bushing - trailing link

(14) Flange nut

(15) Trailing link

(16) Flange bolt

Tightening torque: N·m (kgf-m, ft-lb)

T1: 7.5 (0.8, 5.5)

T2: 60 (6.1, 44.3)


T3: 80 (8.2, 59.0)

T4: 90 (9.2, 66.4)

T5: 100 (10.2, 73.8)

T6: 110 (11.2, 81.1)

2. REAR SHOCK ABSORBER



| | |
|-----------------------------|---------------------------------|
| (1) Flange nut | (5) Dust cover - rear shock |
| (2) Self-locking nut | (6) Helper - rear |
| (3) Shock mount - rear | (7) Coil spring - rear |
| (4) Rubber seat - shock UPR | (8) Shock absorber COMPL - rear |

Tightening torque: N·m (kgf·m, ft-lb)

T1: 25 (2.5, 18.4)

T2: 30 (3.1, 22.1)

General Description


REAR SUSPENSION

C: CAUTION

- When performing any work, always wear work clothes, a work cap and protective shoes. Additionally, wear a helmet, protective goggles, etc. if necessary.
- When disposing of shock absorbers, be sure to bleed the oil or gas out completely. Also, do not expose to flames or fire.
- When performing a repair, identify the cause of trouble and avoid unnecessary removal, disassembly and replacement.
- Use SUBARU genuine grease, the recommended or equivalent. Do not mix grease etc. of different grades or manufacturers.
- Do not secure a part in a vise directly. Place cushioning materials such as wood blocks, aluminum plates, or waste cloth between the part and the vise.
- Be sure to tighten fasteners including bolts and nuts to the specified torque.
- Always use the jack-up point when the shop jacks or rigid racks are used to support the vehicle.
- When the suspension-related components have been removed/installed or replaced, perform "VDC sensor midpoint setting mode" of the VDC. <Ref. to VDC-16, ADJUSTMENT, VDC Control Module and Hydraulic Control Unit (VDCCM&H/U).>
- For parts which are not reusable, always use new parts. Other parts should be replaced with new parts as required.
- When handling oil or fuel, adhere to the following to prevent unexpected accident.
 - Be careful with fire.
 - Prepare a container to catch grease or oil, etc. If any grease or oil spills, wipe it off and clean immediately to prevent from penetrating into floor or flowing outside.
 - Follow all government and local regulations concerning disposal of refuse when disposing.
- Be sure that the surface of brake disc or brake pad is free from grease or oil.
- Before disconnecting connectors of sensors or units, be sure to disconnect the ground cable from battery.
- Some vehicle components are extremely hot immediately after driving. Be wary of receiving burns from heated parts.




D: PREPARATION TOOL

1. SPECIAL TOOL

| ILLUSTRATION | TOOL NUMBER | DESCRIPTION | REMARKS |
|---|-------------|---------------------|---|
|  | 20099PA010 | INSTALLER & REMOVER | <ul style="list-style-type: none">• Used for replacing the bushing A - trailing link of the housing assembly - rear axle.• Used together with BUSHING REMOVER (20099FG000). |
|  | 20099FG000 | BUSHING REMOVER | <ul style="list-style-type: none">• Used for replacing the bushing A - trailing link of the housing assembly - rear axle.• Used together with base part of INSTALLER & REMOVER (20099PA000). |

General Description

REAR SUSPENSION

| ILLUSTRATION | TOOL NUMBER | DESCRIPTION | REMARKS |
|--|-------------|---------------------|---|
|  ST20099AE000 | 20099AE000 | INSTALLER & REMOVER | Used for replacing the bushing B - lateral link. |
|  ST20099AE010 | 20099AE010 | INSTALLER & REMOVER | Used for replacing the bushing C - lateral link. |
|  ST20399FG000 | 20399FG000 | STRUT MOUNT SOCKET | <ul style="list-style-type: none"> Used for disassembling and assembling strut assembly and shock absorber assembly. Used for checking center nut torque of strut assembly and shock absorber assembly. |

2. GENERAL TOOL

| TOOL NAME | REMARKS |
|---------------------------|---|
| Alignment tester | Used for measuring wheel alignment. |
| Toe-in gauge | Used for toe-in measurement. |
| Jack | Used for removing and installing suspension. |
| Bearing puller | Used for removing bushings. |
| Tie-rod ball joint puller | Used for disconnecting the lateral link assembly - front. |
| Coil spring compressor | Used for disassembling and assembling strut assembly and shock absorber assembly. |