

4. Tire Pressure Monitoring System

A: REMOVAL

1. TRANSMITTER (TIRE INFLATION PRESSURE SENSOR)

- 1) Remove the wheels from the vehicle. <Ref. to WT-5, REMOVAL, Tire and Wheel.>
- 2) Remove the tires from wheels.

CAUTION:


Use a tire changer when removing the tire from the wheel.

- 3) Loosen the screw to remove the transmitter from the valve stem.

CAUTION:

Do not reuse the valve and screw.

Replace the valve and screw with a new part even when reusing transmitter.



- (1) Wheel
- (2) Transmitter
- (3) Screw
- (4) Valve

- 4) Remove the valve from the wheel.

2. TPMS & KEYLESS CONTROL MODULE

NOTE:

TPMS control module for keyless entry model is integrated with the keyless entry control module. For removal procedures, refer to "SECURITY AND LOCKS" section. <Ref. to SL-76, REMOVAL, Keyless Entry Control Module.>

Tire Pressure Monitoring System

WHEEL AND TIRE SYSTEM

3. TPMS CM

NOTE:


TPMS control module for keyless access model is separated from the keyless access control module.

- 1) Disconnect the ground cable from battery. <Ref. to NT-5, BATTERY, NOTE, Note.>

NOTE:

For models other than STI model, disconnect the ground terminal from battery sensor.


- 2) Remove the trunk room mat.
- 3) Remove the trim panel - trunk rear.
 - (1) Remove the clip.
 - (2) Release the claws, and remove the trim panel - trunk rear.



- 4) Remove the trim panel - trunk side LH. <Ref. to EI-95, REMOVAL, Trunk Room Trim.>
- 5) Remove the TPMS CM.

(1) Disconnect the connector.

(2) Remove the nuts to remove the TPMS CM.




B: INSTALLATION

1. TRANSMITTER (TIRE INFLATION PRESSURE SENSOR)

CAUTION:

Use the new transmitter assembly or replace the new valve and screw, when installing.

- 1) Replace the valve and screw with a new part when reusing transmitter.



- (1) Screw
- (2) Transmitter
- (3) Valve

Tightening torque:

1.4 N·m (0.1 kgf·m, 1.0 ft·lb)

- 2) Install the transmitter to the wheel by aligning it with valve hole.


NOTE:

When using the jig that pulls the valve cap by hooking its neck part, use another short-type cap.

- 3) Install the tires to wheels.

CAUTION:

- Use a tire changer when installing tire to wheel.
- To prevent damaging the transmitter, set the tire changer boom in the position as shown in the figure.



- (1) Transmitter
- (2) Direction of turn table rotation
- (3) 135°
- (4) Tire changer boom
- (5) 90°
- (6) Starting point for fitting the bead to the rim

- 4) Install the wheels to vehicle. <Ref. to WT-5, INSTALLATION, Tire and Wheel.>

- 5) Register the transmitter ID to the TPMS & keyless control module. <Ref. to TPM(diag)-14, Register Transmitter (ID).>

Tire Pressure Monitoring System

WHEEL AND TIRE SYSTEM

2. TPMS & KEYLESS CONTROL MODULE

NOTE:

TPMS control module for keyless entry model is integrated with the keyless entry control module. For installation procedures, refer to "SECURITY AND LOCKS" section. <Ref. to SL-76, INSTALLATION, Keyless Entry Control Module.>

3. TPMS CM

NOTE:

TPMS control module for keyless access model is separated from the keyless access control module.

- 1) Install the TPMS CM.

Tightening torque:

7.5 N·m (0.8 kgf·m, 5.5 ft-lb)

- 2) Install the trim panel - trunk side LH.
- 3) Install the trim panel - trunk rear.
- 4) Connect the battery ground terminal. <Ref. to NT-5, BATTERY, NOTE, Note.>

NOTE:

For models other than STI model, connect the ground terminal to battery sensor.

C: ADJUSTMENT

Re-register the transmitter ID when transmitter has been replaced. <Ref. to TPM(diag)-14, Register Transmitter (ID).>