


24. Fuel Pump Control Unit

A: REMOVAL

- 1) Disconnect the ground cable from battery.
- 2) Remove the right side trunk side trim. <Ref. to EI-95, REMOVAL, Trunk Room Trim.>
- 3) Disconnect the connector (A) from the fuel pump control unit, and remove the fuel pump control unit.



B: INSTALLATION

Install in the reverse order of removal.

Tightening torque:

5 N·m (0.5 kgf·m, 3.7 ft-lb)

C: INSPECTION

Check that the fuel pump control unit has no deformation, cracks or other damages.