


Control Module I/O Signal

POWER ASSISTED SYSTEM (POWER STEERING) (DIAGNOSTICS)

5. Control Module I/O Signal

A: ELECTRICAL SPECIFICATION



PS-01741

NOTE:


The terminal numbers of the power steering control module connectors are as indicated in the figure.

| Contents | Terminal No. | Input/output signal |
|----------------------------|--------------|---|
| | | Measured value and measuring conditions |
| Power supply (IG SW) | A1 | Battery voltage is detected with the ignition switch ON when measuring between A1 — B1. |
| Shield GND | A3 | 0 V is constantly detected. |
| Main torque sensor | A4 | The voltage changes when the steering is operated to the right or left with the ignition switch ON. |
| Sub torque sensor | A5 | The voltage changes when the steering is operated to the right or left with the ignition switch ON. |
| CAN communication | A6 | Digital signal; can not be measured |
| CAN communication | A7 | Digital signal; can not be measured |
| Torque sensor ground | A9 | 0 V is constantly detected. |
| Torque sensor power supply | A10 | Approximately 5 V is detected with ignition switch ON. |
| Ground | B1 | Battery voltage is constantly detected when measuring between B1 — B2. |
| Power supply | B2 | |
| Resolver S1 | C1 | Varies depending on the operational status of the motor. |
| Resolver S3 | C2 | |
| Resolver S2 | C3 | |
| Resolver S4 | C4 | |
| Resolver R1 | C5 | |
| Resolver R2 | C6 | Varies depending on the motor output. |
| Motor W phase | D1 | |
| Motor V phase | D2 | |
| Motor U phase | D3 | |

Control Module I/O Signal

POWER ASSISTED SYSTEM (POWER STEERING) (DIAGNOSTICS)

B: WIRING DIAGRAM



PS-01748

| | | |
|---|-----------------------------------|--------------------------------|
| (1) Battery | (5) Engine control module (ECM) | (9) Torque sensor (main & sub) |
| (2) Ignition switch | (6) Power steering control module | (10) CAN communication |
| (3) STEERING warning light (combination meter) | (7) Motor | (11) VDC CM |
| (4) Data link connector (for Subaru Select Monitor) | (8) Resolver sensor | (12) Steering gearbox |