

## 3. Inspection Locations after a Collision

### A: REPLACEMENT

Replace the following parts if the airbag system has been activated.

#### 1. FRONT COLLISION

- 1) Driver's airbag module
- 2) Knee airbag module
- 3) Passenger's airbag module
- 4) Curtain airbag module (both sides / if deployed)
- 5) Driver's seat belt (pretensioner)
- 6) Passenger's seat belt (pretensioner)
- 7) Lap seat belt pretensioner (passenger's side only)
- 8) Airbag control module
- 9) Front sub sensor (right and left)
- 10) Roll connector
- 11) Instrument panel (for integrating with passenger's airbag module)
- 12) Trim panel - roof assembly (if the curtain airbag is deployed)
- 13) Trim panel of each pillar (if the curtain airbag is deployed)

#### 2. SIDE COLLISION

- 1) Airbag control module
- 2) Satellite safing sensor
- 3) Cover - satellite safing
- 4) Side airbag module (operating side)
- 5) Side airbag sensor (operating side)
- 6) Front door impact sensor (operating side)
- 7) Seat belt pretensioner (collision side / if deployed)
- 8) Curtain airbag module (operating side)
- 9) Curtain airbag sensor (operating side)
- 10) Pad assembly - front seat backrest (operating side)
- 11) Cover COMPL - front backrest (operating side)
- 12) Trim panel - roof assembly
- 13) Trim panel for each pillar (operating side)

#### 3. INSPECTION OF OTHER PARTS

Check for the following parts, and replace the damaged parts with new parts.

- 1) Steering wheel and column assembly - steering

Check the column assembly - steering for mounting conditions, and deflection of front and rear direction with tilt lever released. (After a collision, absorbing part of the column assembly - steering may have been operated.)

- 2) Check the direct type connector of driver's airbag module, knee airbag module, curtain airbag module, and pretensioner for damage, and also check each harness for pinching and connector damage. Replace the main harness as an assembly if damage is found.

- 3) Check the seat cushion, backrest, slide rail and headrest for installation condition and looseness.

- 4) If any break or fray is found in the cover COMPL - front backrest of the driver's seat or passenger's seat, the side airbag system may not operate normally. In this case, replace the cover COMPL - front backrest with a new part.

- 5) For the passenger's seat, replace the frame assembly - front cushion with a new part if the frame assembly - front cushion is deformed or cracked.

- 6) If there are tears or loosening in the seat cover - front cushion on the passenger's side, it may interfere with the proper operation of the occupant detection system. Replace the cover - front cushion with a new part.

- 7) When the passenger seat cushion cover has been removed or replaced, make sure that the occupant detection system operates normally.

- 8) Use the Subaru Select Monitor to check whether the passenger's seat belt buckle switch is operating normally.

## B: INSPECTION

If the vehicle is involved in a collision, even if it is a slight collision, be sure to check the following systems.

### 1. DRIVER'S AIRBAG MODULE ASSEMBLY

1) Frontal collision (driver's airbag module assembly activated)

1. Replace the following parts with new ones.

- Airbag control module
- Driver's airbag module
- Knee airbag module
- Passenger's airbag module
- Curtain airbag module (both sides / if deployed)
- Seat belt pretensioner (right and left)
- Lap seat belt pretensioner (passenger's side only)
- Front sub sensor (right and left)
- Column assembly - steering
- Trim panel - roof assembly (if the curtain airbag is deployed)
- Trim panel of each pillar (if the curtain airbag is deployed)

2. Visually inspect the following items and replace any damaged part with a new one.

- Steering wheel
- Beam COMPL - steering
- Instrument panel harness and connector on body side

2) Frontal collision (driver's airbag module not activated)

Visually inspect the following items and replace any damaged or cracked part with a new one.

Specially inspect the damage of airbag module body, mounting bracket and harness connector.

- Driver's airbag module
- Knee airbag module
- Passenger's airbag module
- Seat belt pretensioner (right and left)
- Lap seat belt pretensioner (passenger's side only)
- Front sub sensor (right and left)
- Instrument panel assembly (because it is integrated with passenger's airbag module)

3) No frontal collision

Visually inspect the airbag modules for damage or contamination and replace any faulty part with a new one.

### 2. KNEE AIRBAG MODULE

1) Frontal collision (knee airbag module activated)

1. Replace the following parts with new ones.

- Airbag control module
- Driver's airbag module
- Knee airbag module
- Passenger's airbag module
- Curtain airbag module (both sides / if deployed)
- Seat belt pretensioner (right and left)
- Lap seat belt pretensioner (passenger's side only)
- Front sub sensor (right and left)
- Column assembly - steering
- Trim panel - roof assembly (if the curtain airbag is deployed)
- Trim panel of each pillar (if the curtain airbag is deployed)

2. Visually inspect the following items and replace any damaged part with a new one.

- Steering wheel
- Beam COMPL - steering
- Instrument panel harness and connector on body side

# Inspection Locations after a Collision

## AIRBAG SYSTEM

---

### 2) Frontal collision (knee airbag module not activated)

Visually inspect the following items and replace any damaged or cracked part with a new one.

Specially inspect the damage of airbag module body, mounting bracket and harness connector.

- Driver's airbag module
- Knee airbag module
- Passenger's airbag module
- Seat belt pretensioner (right and left)
- Lap seat belt pretensioner (passenger's side only)
- Front sub sensor (right and left)
- Instrument panel assembly (because it is integrated with passenger's airbag module)

### 3) No frontal collision

Visually inspect the airbag modules for damage or contamination and replace any faulty part with a new one.

## 3. PASSENGER'S AIRBAG MODULE

### 1) Frontal collision (passenger's airbag module activated)

#### 1. Replace the following parts with new ones.

- Airbag control module
- Driver's airbag module
- Knee airbag module
- Passenger's airbag module
- Curtain airbag module (both sides / if deployed)
- Seat belt pretensioner (right and left)
- Lap seat belt pretensioner (passenger's side only)
- Front sub sensor (right and left)
- Instrument panel assembly (because it is integrated with passenger's airbag module)
- Trim panel - roof assembly (if the curtain airbag is deployed)
- Trim panel of each pillar (if the curtain airbag is deployed)

#### 2. Visually inspect the following items and replace any damaged part with a new one.

- Beam COMPL - steering
- Instrument panel harness and connector on body side

### 2) Frontal collision (passenger's airbag module not activated)

Visually inspect the following items and replace any damaged or cracked part with a new one.

Specially inspect the damage of airbag module body, mounting bracket and harness connector.

- Driver's airbag module
- Knee airbag module
- Passenger's airbag module
- Seat belt pretensioner (right and left)
- Lap seat belt pretensioner (passenger's side only)
- Front sub sensor (right and left)
- Instrument panel assembly (because it is integrated with passenger's airbag module)

### 3) No frontal collision

Visually inspect the airbag modules for damage or contamination and replace any faulty part with a new one.

## 4. SIDE AIRBAG MODULE

1) Side impact (side airbag module activated)

1. Replace the following parts with new ones.

- Airbag control module
- Satellite safing sensor
- Cover - satellite safing
- Front door impact sensor
- Seat belt pretensioner (collision side / if deployed)
- Side airbag module (collision side)
- Side airbag sensor (collision side)
- Curtain airbag module (collision side)
- Curtain airbag sensor (collision side)
- Pad assembly - front seat backrest (collision side)
- Frame assembly - front backrest (collision side)
- Cover COMPL - front backrest (collision side)
- Trim panel - roof assembly (collision side)
- Trim panel for each pillar (collision side)

2. Visually inspect the following items and replace any damaged part (collision side) with a new one.

- Headrest assembly
- Bushing - lock headrest
- Slide rail assembly - OUT
- Slide rail assembly - INN
- Cover - hinge front seat
- Knob - lifter
- Lever - reclining
- Side airbag harness and connector on body side

2) Side impact (side airbag module not activated)

Visually inspect the following items and replace any damaged or cracked part (collision side) with a new one.

Specially inspect the damage of airbag module body, mounting bracket and harness connector.

- Pad assembly - front seat backrest
- Frame assembly - front backrest
- Cover COMPL - front backrest
- Satellite safing sensor
- Cover - satellite safing
- Front door impact sensor
- Side airbag module
- Side airbag sensor
- Curtain airbag module
- Curtain airbag sensor

3) No side impact

Visually inspect the airbag modules for contamination and replace any faulty part with a new one.

# Inspection Locations after a Collision

## AIRBAG SYSTEM

---

### 5. CURTAIN AIRBAG MODULE

1) Side impact or roll over (curtain airbag module activated)

1. Replace the following parts with new ones.

- Airbag control module
- Satellite safing sensor
- Cover - satellite safing
- Curtain airbag module (collision side)
- Seat belt pretensioner (if deployed)
- Front door impact sensor (collision side)
- Side airbag sensor (collision side)
- Curtain airbag sensor (collision side)
- Pad assembly - front seat backrest (collision side)
- Frame assembly - front backrest (collision side)
- Cover COMPL - front backrest (collision side)
- Trim panel - roof assembly (collision side)
- Trim panel for each pillar (collision side)
- Airbag bracket (model with sunroof) (collision side)

2. Visually inspect the following items and replace any damaged part (collision side) with a new one.

- Assist rail - front and rear
- Bracket - assist rail front and rear
- Curtain airbag harness and connector on body side

2) Side impact (curtain airbag module not activated)

Visually inspect the following items and replace any damaged or cracked part (collision side) with a new one.

Specially inspect the damage of airbag module body, mounting bracket and harness connector.

- Trim panel - roof assembly
- Trim panel for each pillar
- Curtain airbag module
- Satellite safing sensor
- Cover - satellite safing
- Front door impact sensor
- Side airbag sensor
- Curtain airbag sensor

3) No side impact

Visually inspect the airbag covers for damage or contamination and replace any faulty part with a new one.


### 6. AIRBAG CONTROL MODULE

Check for the following, and replace the damaged parts with new parts.

- Control module is cracked or deformed.
- Mounting bracket is cracked or deformed.
- Connector is scratched, cracked or deformed.
- Driver's airbag module has been activated.
- Knee airbag module has been activated.
- Passenger's airbag module has been activated.
- Side airbag module has been activated.
- Curtain airbag module has been activated.
- Seat belt pretensioner has been activated.
- Lap seat belt pretensioner has been activated.

### 7. FRONT SUB SENSOR


If the section of vehicle as shown in the figure is damaged, check the following items and replace the damaged parts with new parts.



AB-03548

- Front sub sensor is cracked or deformed.
- Connector is scratched, cracked or deformed.
- Driver's airbag module, knee airbag module or passenger's airbag module has been activated.

### 8. FRONT DOOR IMPACT SENSOR, SATELLITE SAFING SENSOR, SIDE AIRBAG SENSOR AND CURTAIN AIRBAG SENSOR



AB-03549

- Front door impact sensor, satellite safing sensor, side airbag sensor and curtain airbag sensor are cracked or deformed.
- Mounting bracket is cracked or deformed.
- Connector is scratched, cracked or deformed.
- Side airbag module or curtain airbag module has been activated. (Operating side)

## Inspection Locations after a Collision

### AIRBAG SYSTEM

---

#### 9. ROLL CONNECTOR

Check the following items and replace any damaged, cracked, or deformed parts with new parts.

- Combination switch
- Steering roll connector

#### 10. COLUMN ASSEMBLY - STEERING & STEERING WHEEL

Check the following items, and if there is anything out of standard value, it is considered to be damaged. If so, replace it with a new part. <Ref. to PS-29, INSPECTION, Steering Column.>

#### 11. PASSENGER'S SEAT

Check for the following, and replace the damaged parts with new parts.

- Body or bracket of the seat belt inner - front is scratched, cracked or deformed.
- Frame assembly - front backrest is cracked or deformed.
- Headrest assembly for deformation or play
- If the cover - front cushion and the cover COMPL - front backrest is damaged or frayed, replace the cover with a new part.

#### CAUTION:

**If any of the following applies, replace the pad assembly - front seat cushion & frame assembly - front cushion as a unit. Do not disassemble.**

- The frame assembly - front cushion or the pad assembly - front seat cushion is cracked or deformed.
- Scratches, cracks, or deformation found on the occupant detection system sensor mat or occupant detection control module, or attachment brackets of the control module.
- Harness and/or connector is cracked, deformed or open. Harness wire is exposed.