


## 26. Evaporator Sensor

### A: REMOVAL

- 1) Remove the evaporator assembly - cooling. <Ref. to AC-63, REMOVAL, Evaporator.>
- 2) Remove the thermostat - cooling from the evaporator assembly - cooling.




### B: INSTALLATION

#### CAUTION:

- Make sure that the water seal packing on the cover attachment area is securely attached.
- Replace the O-rings with new parts, and then apply compressor oil.

- 1) Install the thermostat - cooling at the position shown in the figure below.



(1) Evaporator ASSY - cooling	(3) Thermostat - cooling	(5) Fifth row fin from the left end
(2) Center	(4) 130 mm (5.12 in) from the upper end of the fins	

- 2) Install each part in the reverse order of removal.
- 3) Charge refrigerant. <Ref. to AC-30, PROCEDURE, Refrigerant Charging Procedure.>

# Evaporator Sensor

HVAC SYSTEM (HEATER, VENTILATOR AND A/C)

## C: INSPECTION


### 1. MANUAL A/C MODEL

**Preparation tool:**

**Circuit tester**

**Thermometer and hygrometer**

**WIRING DIAGRAM:**



1) Prepare the vehicle.

**NOTE:**

Check that the ambient temperature is 25 — 40°C (77 — 104°F) and that the humidity is 30% — 80%.

- Place the vehicle in the workshop or in the shade and windless condition.
- Open all windows.

2) Set the vehicle to the following conditions and idle the engine for 15 minutes.

Item	Condition
Engine	Idling
Air vent grille	Shutter is fully open.
A/C switch	OFF
Temperature adjustment dial	LO (MAX COOL)
FRESH/RECIRC switch	RECIRC
Air flow control dial	VENT
Fan dial	3/4 level

3) Check evaporator sensor power supply input

- (1) Turn the ignition to OFF.
- (2) Disconnect the evaporator sensor connector.
- (3) Turn the ignition to ON.
- (4) Measure the voltage between evaporator sensor connector and chassis ground.

**Connector & terminal**

**(B88) No. 3 (+) — Chassis ground (-):**

- (5) Is the voltage approx. 12 V?

- **Yes** → Go to step 4.
- **No** → Repair or replace the harness.

- 4) Check evaporator sensor ground circuit
  - (1) Turn the ignition to OFF.
  - (2) Check continuity between evaporator sensor connector and chassis ground.

### **Connector & terminal**

#### **(B88) No. 2 — Chassis ground:**

(3) Is there continuity?

- **Yes** → Go to step 6).
- **No** → Go to step 5).

- 5) Check open circuit in evaporator sensor ground circuit
  - (1) Disconnect the control panel connector.
  - (2) Check continuity between evaporator sensor connector and control panel connector.

### **Connector & terminal**

#### **(B88) No. 2 — (i16) No. 2:**

(3) Is there continuity?

- **Yes** → Replace the control panel.
- **No** → Repair or replace the harness.

- 6) Check evaporator sensor signal output
  - (1) Connect the evaporator sensor connector and the control panel connector.
  - (2) Disconnect the engine control module (ECM) connector.
  - (3) Turn the ignition to ON.
  - (4) Turn the A/C switch to ON.
  - (5) Measure the voltage between engine control module (ECM) connector and chassis ground.

### **Connector & terminal**

#### **(B137) No. 26 — Chassis ground (-):**

(6) Is the voltage approx. 8 V or more?

- **Yes** → Evaporator sensor is normal.
- **No** → Go to step 7).

- 7) Check open circuit in evaporator sensor signal output circuit
  - (1) Turn the ignition to OFF.
  - (2) Disconnect the evaporator sensor connector.
  - (3) Check continuity between evaporator sensor connector and engine control module (ECM) connector.

### **Connector & terminal**

#### **(B88) No. 1 — (B137) No. 26:**

(4) Is there continuity?

- **Yes** → Replace the evaporator sensor.
- **No** → Repair or replace the harness.

# Evaporator Sensor

HVAC SYSTEM (HEATER, VENTILATOR AND A/C)

## 2. AUTO A/C MODEL

**Preparation tool:**

**Subaru Select Monitor III kit**

**Circuit tester**

**Thermometer and hygrometer**

1) Prepare the vehicle.

**NOTE:**

Check that the ambient temperature is 25 — 40°C (77 — 104°F) and that the humidity is 30% — 80%.

- Place the vehicle in the workshop or in the shade and windless condition.
- Open all windows.

2) Set the vehicle to the following conditions.

Item	Condition
Engine	Idling
Air vent grille	Shutter is fully open.
A/C switch	OFF
Temperature adjustment dial	LO (MAX COOL)
FRESH/RECIRC switch	RECIRC
Air flow control dial or switch	VENT
Fan dial	5/7 level

3) Using the Subaru Select Monitor, check «Evaporator Temperature».

**NOTE:**

For detailed procedures, refer to “PC application help for Subaru Select Monitor”.

(1) Idle the engine for 15 minutes, and then compare the air flow outlet temperature with «Evaporator Temperature».

**NOTE:**

For outlet opening temperature, measure the average temperature of center grille assembly and side grille assembly.

(2) Do the air flow outlet temperature and «Evaporator Temperature» differ by 3°C (5.4°F) or more?

- **Yes** → Go to step 4).
- **No** → Evaporator sensor is normal.


# Evaporator Sensor

HVAC SYSTEM (HEATER, VENTILATOR AND A/C)

4) Check the evaporator sensor.

(1) Disconnect the evaporator sensor connector.

(2) Is the resistance between terminals of evaporator sensor within standard value?



Terminal No.	Inspection conditions	Standard
1 — 2	-20°C	15.37 — 16.62 kΩ
	-15°C	12.09 — 12.87 kΩ
	-10°C	9.576 — 10.05 kΩ
	-5°C	7.636 — 7.899 kΩ
	0°C	6.132 — 6.256 kΩ
	5°C	4.891 — 5.057 kΩ
	10°C	3.928 — 4.113 kΩ
	15°C	3.174 — 3.366 kΩ
	20°C	2.581 — 2.77 kΩ
	25°C	2.111 — 2.292 kΩ
	30°C	1.737 — 1.907 kΩ
	35°C	1.437 — 1.595 kΩ
	40°C	1.195 — 1.34 kΩ

- **Yes** → Evaporator sensor is normal.
- **No** → Replace the evaporator sensor.