

7. Turn Signal Light and Hazard Light System

A: WIRING DIAGRAM

Refer to "Turn Signal Light and Hazard Light System" in the wiring diagram.

- Gasoline engine model: <Ref. to WI(w/o HEV)-219, WIRING DIAGRAM, Turn Signal Light and Hazard Light System.>
- HEV model: <Ref. to WI(HEV)-213, WIRING DIAGRAM, Turn Signal Light and Hazard Light System.>

Turn Signal Light and Hazard Light System

LIGHTING SYSTEM

B: INSPECTION

1. CHECK TURN SIGNAL SWITCH

Refer to the "INSPECTION" of the "Combination Switch (Light)". <Ref. to LI-24, INSPECTION, Combination Switch (Light).>

2. CHECK HAZARD SWITCH

Refer to the "INSPECTION" of the "Hazard Switch". <Ref. to LI-44, INSPECTION, Hazard Switch.>

3. CHECK TURN SIGNAL AND HAZARD MODULE

Refer to "INSPECTION" of the "Turn Signal Light and Hazard Light System". <Ref. to LI-45, INSPECTION, Turn Signal Light & Hazard Light Module.>

4. CHECK ONE-TOUCH TURN SIGNAL SYSTEM

Step	Check	Yes	No
1 CHECK CUSTOMIZATION. Display the data of «Lane change signal setting» and «One-touch Turn Signal System Setup» using Subaru Select Monitor. NOTE: For detailed procedures, refer to "PC application help for Subaru Select Monitor".	Is the setting "Support" and "ON"?	Go to step 2.	Change the setting to "Support" and "ON".
2 CHECK CURRENT DATA. 1) Turn the ignition to ON. 2) Display the data of «Left turn signal input» and «Right turn signal input» using Subaru Select Monitor.	Does the display change to OFF \longleftrightarrow ON, when the combination switch is operated?	Replace the body integrated unit. <Ref. to SL-87, Body Integrated Unit.>	Go to step 3.
3 CHECK HARNESS. 1) Turn the ignition to OFF. 2) Disconnect the connectors of the body integrated unit and turn signal & hazard unit. 3) Check the harness between body integrated unit and turn signal & hazard unit. <i>Connector & terminal</i> (B281) No. 21 — (B32) No. 5: (B281) No. 9 — (B32) No. 6:	Is the resistance less than 1 Ω ?	Go to step 4.	Repair or replace the harness.
4 CHECK HARNESS. Measure the resistance between the body integrated unit connector and chassis ground. <i>Connector & terminal</i> (B281) No. 21 — Chassis ground: (B281) No. 9 — Chassis ground: NOTE: Check with the combination switch in the OFF position.	Is the resistance 1 $M\Omega$ or more?	Go to step 5.	Repair or replace the harness.
5 CHECK HARNESS. 1) Disconnect the connector of the combination switch. 2) Measure the resistance between the combination switch connector and chassis ground. <i>Connector & terminal</i> (B71) No. 12 — Chassis ground:	Is the resistance less than 1 Ω ?	Replace the body integrated unit. <Ref. to SL-87, Body Integrated Unit.>	Repair or replace the harness.

C: NOTE

For operation procedures of each component of the turn signal and hazard light system, refer to the respective sections.

- Combination switch (light): <Ref. to LI-21, Combination Switch (Light).>
- Front turn signal light bulb: <Ref. to LI-47, Front Turn Signal Light Bulb.>
- Side turn signal light assembly: <Ref. to LI-59, Side Turn Signal Light Assembly.>
- Rear combination light assembly: <Ref. to LI-60, Rear Combination Light Assembly.>
- Rear turn signal light bulb: <Ref. to LI-66, Rear Turn Signal Light Bulb.>
- Hazard switch: <Ref. to LI-44, Hazard Switch.>
- Turn signal and hazard module: <Ref. to LI-45, Turn Signal Light & Hazard Light Module.>