

## Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

---

### 18. Diagnostic Procedure with Diagnostic Trouble Code (DTC)

#### **A: DTC P000A A CAMSHAFT POSITION SLOW RESPONSE (BANK 1)**

NOTE:

For the diagnostic procedure, refer to DTC P0011. <Ref. to EN(H4DO HEV)(diag)-105, DTC P0011 INTAKE CAMSHAFT POSITION - TIMING OVER-ADVANCED OR SYSTEM PERFORMANCE (BANK 1), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

#### **B: DTC P000B B CAMSHAFT POSITION SLOW RESPONSE (BANK 1)**

NOTE:

For the diagnostic procedure, refer to DTC P0014. <Ref. to EN(H4DO HEV)(diag)-109, DTC P0014 EXHAUST AVCS SYSTEM 1 (RANGE/PERFORMANCE), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

#### **C: DTC P000C A CAMSHAFT POSITION SLOW RESPONSE (BANK 2)**

NOTE:

For the diagnostic procedure, refer to DTC P0021. <Ref. to EN(H4DO HEV)(diag)-120, DTC P0021 INTAKE CAMSHAFT POSITION - TIMING OVER-ADVANCED OR SYSTEM PERFORMANCE (BANK 2), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

#### **D: DTC P000D B CAMSHAFT POSITION SLOW RESPONSE (BANK 2)**

NOTE:

For the diagnostic procedure, refer to DTC P0024. <Ref. to EN(H4DO HEV)(diag)-124, DTC P0024 EXHAUST AVCS SYSTEM 2 (RANGE/PERFORMANCE), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

## E: DTC P0010 "A" CAMSHAFT POSITION ACTUATOR CIRCUIT/OPEN (BANK 1)

### DTC DETECTING CONDITION:

- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-15, DTC P0010 "A" CAMSHAFT POSITION ACTUATOR CIRCUIT/OPEN (BANK 1), Diagnostic Trouble Code (DTC) Detecting Criteria.>

### TROUBLE SYMPTOM:


Improper idling

### CAUTION:

After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.

### WIRING DIAGRAM:

- Engine electrical system (without push button start) <Ref. to WI(HEV)-100, WITHOUT PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>
- Engine electrical system (with push button start) <Ref. to WI(HEV)-114, WITH PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>



EN-10737

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

## ENGINE (DIAGNOSTICS)

| Step  | Check                                    | Yes  | No   |
|---|--|--|--|
| <b>1</b><br><b>CHECK OUTPUT SIGNAL OF ECM.</b><br>1) Turn the ignition switch to ON.<br>2) Measure the voltage between ECM connector and chassis ground.<br><b>Connector &amp; terminal</b><br><b>(B134) No. 17 (+) — Chassis ground (-):</b>   | Is the voltage 10 V or more?             | Go to step 2.  | Go to step 3.  |
| <b>2</b><br><b>CHECK FOR POOR CONTACT.</b><br>Check for poor contact of ECM connector.  | Is there poor contact of ECM connector?  | Repair the poor contact of ECM connector.                            | Even if DTC is detected, the circuit has returned to a normal condition at this time. Reproduce the failure, and then perform the diagnosis again.<br><br><b>NOTE:</b><br>In this case, temporary poor contact of connector, temporary open or short circuit of harness may be the cause.      |
| <b>3</b><br><b>CHECK POWER SUPPLY TO THE INTAKE OIL CONTROL SOLENOID RH.</b><br>Measure the voltage between intake oil control solenoid RH connector and engine ground.<br><b>Connector &amp; terminal</b><br><b>(E38) No. 1 (+) — Engine ground (-):</b>   | Is the voltage 10 V or more?             | Go to step 4.  | Repair the power supply circuit.   |
| <b>4</b><br><b>CHECK HARNESS BETWEEN ECM AND INTAKE OIL CONTROL SOLENOID RH CONNECTOR.</b><br>1) Turn the ignition switch to OFF.<br>2) Disconnect the connectors from the ECM and intake oil control solenoid RH.<br>3) Measure the resistance between intake oil control solenoid RH connector and engine ground.<br><b>Connector &amp; terminal</b><br><b>(E38) No. 2 — Engine ground:</b> | Is the resistance 1 M $\Omega$ or more?  | Go to step 5.  | Repair the short circuit to ground in harness between ECM connector and intake oil control solenoid RH connector.  |
| <b>5</b><br><b>CHECK HARNESS BETWEEN ECM AND INTAKE OIL CONTROL SOLENOID RH CONNECTOR.</b><br>Measure the resistance of harness between ECM connector and intake oil control solenoid RH.<br><b>Connector &amp; terminal</b><br><b>(B134) No. 17 — (E38) No. 2:</b>   | Is the resistance less than 1 $\Omega$ ? | Go to step 6.  | Repair the harness and connector.<br><br><b>NOTE:</b><br>In this case, repair the following item: <ul style="list-style-type: none"> <li>• Open circuit in harness between ECM connector and intake oil control solenoid RH connector</li> <li>• Poor contact of coupling connector</li> </ul> |
| <b>6</b><br><b>CHECK INTAKE OIL CONTROL SOLENOID RH.</b><br>Measure the resistance between intake oil control solenoid RH terminals.<br><b>Terminals</b><br><b>No. 1 — No. 2:</b>   | Is the resistance 6 — 12 $\Omega$ ?      | Repair the poor contact of intake oil control solenoid RH connector. | Replace the intake oil control solenoid RH. <Ref. to FU(H4DO(HEV))-56, Oil Control Solenoid.>  |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

## F: DTC P0011 INTAKE CAMSHAFT POSITION - TIMING OVER-ADVANCED OR SYSTEM PERFORMANCE (BANK 1)

### DTC DETECTING CONDITION:

- Detected when two consecutive driving cycles with fault occur.
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-16, DTC P0011 INTAKE CAMSHAFT POSITION - TIMING OVER-ADVANCED OR SYSTEM PERFORMANCE (BANK 1), Diagnostic Trouble Code (DTC) Detecting Criteria.>

### TROUBLE SYMPTOM:

- Engine stalls.
- Improper idling

### CAUTION:

After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.

|   | Step   | Check   | Yes  | No  |
|---|--|---|--|---|
| 1 | <p><b>CHECK CURRENT DATA.</b></p> <p>1) Start the engine and let it idle.</p> <p>2) Read the value of «VVT Adv. Ang. Amount R» using the Subaru Select Monitor.</p> <p>NOTE:<br/>For detailed operation procedures, refer to “Current Data Display For Engine”. &lt;Ref. to EN(H4DO HEV)(diag)-36, Subaru Select Monitor.&gt;</p>  | Is the value of «VVT Adv. Ang. Amount R» approx. 0 deg?   | Go to step 2.  | <p>Check the following item and repair or replace if necessary.</p> <ul style="list-style-type: none"> <li>• Intake cam sprocket (clog or dirt of oil routing, setting of spring)</li> <li>• Intake camshaft (dirt, damage of camshaft)</li> </ul>  |
| 2 | <p><b>CHECK CURRENT DATA.</b></p> <p>1) Drive with acceleration and deceleration at 80 km/h (50 MPH) or less.</p> <p>NOTE:<br/>Drive to an extent that the duty output of oil flow control solenoid valve increases.</p> <p>2) Read the values of «OCV Duty R» and «VVT Adv. Ang. Amount R» using the Subaru Select Monitor.</p> <p>NOTE:<br/>For detailed operation procedures, refer to “Current Data Display For Engine”. &lt;Ref. to EN(H4DO HEV)(diag)-36, Subaru Select Monitor.&gt;</p> | When the value of «OCV Duty R» increases more than 10%, is the value of «VVT Adv. Ang. Amount R» approx. 0 deg? | <p>Check the following item and repair or replace if necessary.</p> <ul style="list-style-type: none"> <li>• Intake cam sprocket (clog or dirt of oil routing, setting of spring)</li> <li>• Intake camshaft (dirt, damage of camshaft)</li> </ul> | <p>Perform the following procedures, and clean the oil routing.</p> <p>Replace the engine oil and idle the engine for 5 minutes, and then replace the oil filter and engine oil.</p> <p>&lt;Ref. to LU(H4DO(w/o HEV))-13, REPLACEMENT, Engine Oil.&gt; &lt;Ref. to LU(H4DO(w/o HEV))-29, Engine Oil Filter.&gt;</p> |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

## G: DTC P0013 B CAMSHAFT POSITION ACTUATOR CIRCUIT/OPEN (BANK 1)

### DTC DETECTING CONDITION:

- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-17, DTC P0013 B CAMSHAFT POSITION ACTUATOR CIRCUIT/OPEN (BANK 1), Diagnostic Trouble Code (DTC) Detecting Criteria.>

### TROUBLE SYMPTOM:


Improper idling

### CAUTION:

After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.

### WIRING DIAGRAM:

- Engine electrical system (without push button start) <Ref. to WI(HEV)-100, WITHOUT PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>
- Engine electrical system (with push button start) <Ref. to WI(HEV)-114, WITH PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>



EN-10738

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

|   | Step  | Check                                    | Yes                                       | No   |
|---|---|--|---|--|
| 1 | <p><b>CHECK OUTPUT SIGNAL OF ECM.</b><br/>                     1) Turn the ignition switch to ON.<br/>                     2) Measure the voltage between ECM connector and chassis ground.<br/> <i>Connector &amp; terminal</i><br/> <i>(B134) No. 7 (+) — Chassis ground (-):</i></p>   | Is the voltage 10 V or more?             | Go to step 2.                             | Go to step 3.  |
| 2 | <p><b>CHECK FOR POOR CONTACT.</b><br/>                     Check for poor contact of ECM connector.</p>   | Is there poor contact of ECM connector?  | Repair the poor contact of ECM connector. | Even if DTC is detected, the circuit has returned to a normal condition at this time. Reproduce the failure, and then perform the diagnosis again.<br>NOTE:<br>In this case, temporary poor contact of connector, temporary open or short circuit of harness may be the cause.       |
| 3 | <p><b>CHECK POWER SUPPLY TO THE EXHAUST OIL CONTROL SOLENOID RH.</b><br/>                     Measure the voltage between exhaust oil control solenoid RH connector and engine ground.<br/> <i>Connector &amp; terminal</i><br/> <i>(E63) No. 1 (+) — Engine ground (-):</i></p>  | Is the voltage 10 V or more?             | Go to step 4.                             | Repair the power supply circuit.   |
| 4 | <p><b>CHECK HARNESS BETWEEN ECM AND EXHAUST OIL CONTROL SOLENOID RH CONNECTOR.</b><br/>                     1) Turn the ignition switch to OFF.<br/>                     2) Disconnect the connectors from ECM and exhaust oil control solenoid RH.<br/>                     3) Measure the resistance between exhaust oil control solenoid RH connector and engine ground.<br/> <i>Connector &amp; terminal</i><br/> <i>(E63) No. 2 — Engine ground:</i></p> | Is the resistance 1 M $\Omega$ or more?  | Go to step 5.                             | Repair the short circuit to ground in harness between ECM connector and exhaust oil control solenoid RH connector.   |
| 5 | <p><b>CHECK HARNESS BETWEEN ECM AND EXHAUST OIL CONTROL SOLENOID RH CONNECTOR.</b><br/>                     Measure the resistance of harness between ECM connector and exhaust oil control solenoid RH.<br/> <i>Connector &amp; terminal</i><br/> <i>(B134) No. 7 — (E63) No. 2:</i></p>   | Is the resistance less than 1 $\Omega$ ? | Go to step 6.                             | Repair the harness and connector.<br>NOTE:<br>In this case, repair the following item: <ul style="list-style-type: none"> <li>• Open circuit in harness between ECM connector and exhaust oil control solenoid RH connector</li> <li>• Poor contact of coupling connector</li> </ul> |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step  | Check                               | Yes   | No   |
|---|-------------------------------------|---|--|
| <b>6</b><br><b>CHECK EXHAUST OIL CONTROL SOLENOID RH.</b><br>Measure the resistance between exhaust oil control solenoid RH terminals.<br><b>Terminals</b><br><b>No. 1 — No. 2:</b> | Is the resistance 6 — 12 $\Omega$ ? | Repair the poor contact of exhaust oil control solenoid RH connector. | Replace the exhaust oil control solenoid RH. <Ref. to FU(H4DO(HEV))-56, Oil Control Solenoid.> |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

## H: DTC P0014 EXHAUST AVCS SYSTEM 1 (RANGE/PERFORMANCE)

### DTC DETECTING CONDITION:

- Detected when two consecutive driving cycles with fault occur.
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-18, DTC P0014 EXHAUST AVCS SYSTEM 1 (RANGE/PERFORMANCE), Diagnostic Trouble Code (DTC) Detecting Criteria.>

### TROUBLE SYMPTOM:

- Engine stalls.
- Improper idling

### CAUTION:

After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.

| Step   | Check  | Yes  | No   |
|--|--|--|--|
| <b>1</b><br><b>CHECK CURRENT DATA.</b><br>1) Start the engine and let it idle.<br>2) Read the value of «Exh. VVT Retard Ang. R» using the Subaru Select Monitor.<br><br>NOTE:<br>For detailed operation procedures, refer to “Current Data Display For Engine”. <Ref. to EN(H4DO HEV)(diag)-36, Subaru Select Monitor.>  | Is the value of «Exh. VVT Retard Ang. R» approx. 0 deg?  | Go to step 2.  | Check the following item and repair or replace if necessary.<br>• Exhaust cam sprocket (clog or dirt of oil routing, setting of spring)<br>• Exhaust camshaft (dirt, damage of camshaft)   |
| <b>2</b><br><b>CHECK CURRENT DATA.</b><br>1) Drive with acceleration and deceleration at 80 km/h (50 MPH) or less.<br><br>NOTE:<br>Drive to an extent that the duty output of oil flow control solenoid valve increases.<br>2) Read the values of «Exh. OCV Duty R» and «Exh. VVT Retard Ang. R» using the Subaru Select Monitor.<br><br>NOTE:<br>For detailed operation procedures, refer to “Current Data Display For Engine”. <Ref. to EN(H4DO HEV)(diag)-36, Subaru Select Monitor.> | When the value of «Exh. OCV Duty R» increases more than 10%, is the value of «Exh. VVT Retard Ang. R» approx. 0 deg? | Check the following item and repair or replace if necessary.<br>• Exhaust cam sprocket (clog or dirt of oil routing, setting of spring)<br>• Exhaust camshaft (dirt, damage of camshaft) | Perform the following procedures, and clean the oil routing.<br>Replace the engine oil and idle the engine for 5 minutes, and then replace the oil filter and engine oil.<br><Ref. to LU(H4DO(w/o HEV))-13, REPLACEMENT, Engine Oil.> <Ref. to LU(H4DO(w/o HEV))-29, Engine Oil Filter.> |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

## I: DTC P0016 CRANKSHAFT POSITION - CAMSHAFT POSITION CORRELATION (BANK1)

### DTC DETECTING CONDITION:

- Detected when two consecutive driving cycles with fault occur.
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-19, DTC P0016 CRANKSHAFT POSITION - CAMSHAFT POSITION CORRELATION (BANK1), Diagnostic Trouble Code (DTC) Detecting Criteria.>

### TROUBLE SYMPTOM:

- Engine stalls.
- Improper idling

### CAUTION:

After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.

| Step | Check   | Yes  | No  |
|------|---|--|---|
| 1    | <b>CHECK FOR ANY OTHER DTC ON DISPLAY.</b><br>Are DTCs other than P0016, P0017, P0018 or P0019 displayed?   | Check the appropriate DTC using the "List of Diagnostic Trouble Code (DTC)". <Ref. to EN(H4DO HEV)(diag)-92, List of Diagnostic Trouble Code (DTC).>   | Go to step 2.   |
| 2    | <b>CHECK INTAKE OIL CONTROL SOLENOID RH.</b><br>Check the intake oil control solenoid RH. <Ref. to FU(H4DO(HEV))-58, INSPECTION, Oil Control Solenoid.>   | Go to step 3.  | Replace the intake oil control solenoid RH. <Ref. to FU(H4DO(HEV))-56, Oil Control Solenoid.>               |
| 3    | <b>CHECK INSTALLATION CONDITION OF TIMING CHAIN.</b><br>Using ST and by turning the crankshaft, align the alignment marks of crank sprocket, intake cam sprocket and exhaust cam sprocket. <Ref. to ME(H4DO(w/o HEV))-169, Timing Chain Assembly.><br>ST 18252AA000 CRANKSHAFT SOCKET | Go to step 4.  | Correct the installation condition of timing chain. <Ref. to ME(H4DO(w/o HEV))-169, Timing Chain Assembly.> |
| 4    | <b>CHECK CAM CARRIER FILTER.</b><br>Check the filter installed to cam carrier. <Ref. to ME(H4DO(w/o HEV))-257, INSPECTION, Cam Carrier.>  | Replace the intake cam sprocket RH. <Ref. to ME(H4DO(w/o HEV))-191, Cam Sprocket.> After the operation is complete, go to the next step. Go to step 5. | Replace the filter of cam carrier. <Ref. to ME(H4DO(w/o HEV))-220, Cam Carrier.>                            |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step   | Check  | Yes   | No  |
|--|--|---|---|
| <p><b>5</b>      <b>CHECK CURRENT DATA.</b><br/>                     1) Clear the memory using the Subaru Select Monitor or general scan tool. &lt;Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.&gt;<br/>                     2) Start the engine and warm up completely.<br/>                     3) Using Subaru Select Monitor, read the value of «VVT Initial Position Learning Value #1» and «VVT Adv. Ang. Amount R» when idling condition is stable for 30 seconds or more.<br/>                     NOTE:<br/>                     For detailed operation procedures, refer to “Current Data Display For Engine”. &lt;Ref. to EN(H4DO HEV)(diag)-36, Subaru Select Monitor.&gt;<br/>                     4) Calculate the read value according to the following formula. At this time, ignore the unit.<br/>                      «VVT Initial Position Learning Value #1» – (60 + «VVT Adv. Ang. Amount R») </p> | <p>Is the calculation result less than 10?</p>         | <p>Go to step 6.</p>  | <p>Replace the ECM.<br/>                     &lt;Ref. to FU(H4DO(HEV))-85, Engine Control Module (ECM).&gt;</p> |
| <p><b>6</b>      <b>CHECK DTC.</b><br/>                     1) Clear the memory using the Subaru Select Monitor or general scan tool. &lt;Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.&gt;<br/>                     2) Perform drive cycle N. &lt;Ref. to EN(H4DO HEV)(diag)-64, DRIVE CYCLE N, PROCEDURE, Drive Cycle.&gt;</p>  | <p>Is the same DTC as current diagnosis displayed?</p> | <p>Replace the ECM.<br/>                     &lt;Ref. to FU(H4DO(HEV))-85, Engine Control Module (ECM).&gt;</p> | <p>End.</p>   |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

## J: DTC P0017 CRANK AND CAM TIMING B SYSTEM FAILURE (BANK 1)

### DTC DETECTING CONDITION:

- Detected when two consecutive driving cycles with fault occur.
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-20, DTC P0017 CRANK AND CAM TIMING B SYSTEM FAILURE (BANK 1), Diagnostic Trouble Code (DTC) Detecting Criteria.>

### TROUBLE SYMPTOM:

- Engine stalls.
- Improper idling

### CAUTION:

After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.

| Step     | Check  | Yes   | No  |
|----------|--|---|---|
| <b>1</b> | <b>CHECK FOR ANY OTHER DTC ON DISPLAY.</b><br>Are DTCs other than P0016, P0017, P0018 or P0019 displayed?  | Check the appropriate DTC using the "List of Diagnostic Trouble Code (DTC)". <Ref. to EN(H4DO HEV)(diag)-92, List of Diagnostic Trouble Code (DTC).>    | Go to step 2.   |
| <b>2</b> | <b>CHECK EXHAUST OIL CONTROL SOLENOID RH.</b><br>Check the exhaust oil control solenoid RH. <Ref. to FU(H4DO(HEV))-58, INSPECTION, Oil Control Solenoid.>  | Go to step 3.   | Replace the exhaust oil control solenoid RH. <Ref. to FU(H4DO(HEV))-56, Oil Control Solenoid.>              |
| <b>3</b> | <b>CHECK INSTALLATION CONDITION OF TIMING CHAIN.</b><br>Using ST and by turning the crankshaft, align the alignment marks of crank sprocket, intake cam sprocket and exhaust cam sprocket. <Ref. to ME(H4DO(w/o HEV))-169, Timing Chain Assembly.><br>ST 18252AA000      CRANKSHAFT SOCKET | Go to step 4.   | Correct the installation condition of timing chain. <Ref. to ME(H4DO(w/o HEV))-169, Timing Chain Assembly.> |
| <b>4</b> | <b>CHECK CAM CARRIER FILTER.</b><br>Check the filter installed to cam carrier. <Ref. to ME(H4DO(w/o HEV))-257, INSPECTION, Cam Carrier.>   | Replace the exhaust cam sprocket RH. <Ref. to ME(H4DO(w/o HEV))-191, Cam Sprocket.> After the operation is complete, go to the next step. Go to step 5. | Replace the filter of cam carrier. <Ref. to ME(H4DO(w/o HEV))-220, Cam Carrier.>                            |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step   | Check  | Yes   | No  |
|--|--|---|---|
| <p><b>5</b>      <b>CHECK CURRENT DATA.</b><br/>                     1) Clear the memory using the Subaru Select Monitor or general scan tool. &lt;Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.&gt;<br/>                     2) Start the engine and warm up completely.<br/>                     3) Using Subaru Select Monitor, read the value of «VVT Ex Initial Position Learning Value #1» and «Exh. VVT Retard Ang. R» when idling condition is stable for 30 seconds or more.<br/>                     NOTE:<br/>                     For detailed operation procedures, refer to "Current Data Display For Engine". &lt;Ref. to EN(H4DO HEV)(diag)-36, Subaru Select Monitor.&gt;<br/>                     4) Calculate the read value according to the following formula. At this time, ignore the unit.<br/>                      «VVT Ex Initial Position Learning Value #1» – (90 – «Exh. VVT Retard Ang. R») </p> | <p>Is the calculation result less than 10?</p>         | <p>Go to step 6.</p>  | <p>Replace the ECM.<br/>                     &lt;Ref. to FU(H4DO(HEV))-85, Engine Control Module (ECM).&gt;</p> |
| <p><b>6</b>      <b>CHECK DTC.</b><br/>                     1) Clear the memory using the Subaru Select Monitor or general scan tool. &lt;Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.&gt;<br/>                     2) Perform drive cycle N. &lt;Ref. to EN(H4DO HEV)(diag)-64, DRIVE CYCLE N, PROCEDURE, Drive Cycle.&gt;</p>  | <p>Is the same DTC as current diagnosis displayed?</p> | <p>Replace the ECM.<br/>                     &lt;Ref. to FU(H4DO(HEV))-85, Engine Control Module (ECM).&gt;</p> | <p>End.</p>   |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

## K: DTC P0018 CRANKSHAFT POSITION - CAMSHAFT POSITION CORRELATION (BANK2)

### DTC DETECTING CONDITION:

- Detected when two consecutive driving cycles with fault occur.
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-21, DTC P0018 CRANKSHAFT POSITION - CAMSHAFT POSITION CORRELATION (BANK2), Diagnostic Trouble Code (DTC) Detecting Criteria.>

### TROUBLE SYMPTOM:

- Engine stalls.
- Improper idling

### CAUTION:

After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.

|   | Step  | Check   | Yes  | No  |
|---|---|---|--|---|
| 1 | <b>CHECK FOR ANY OTHER DTC ON DISPLAY.</b>  | Are DTCs other than P0016, P0017, P0018 or P0019 displayed? | Check the appropriate DTC using the "List of Diagnostic Trouble Code (DTC)". <Ref. to EN(H4DO HEV)(diag)-92, List of Diagnostic Trouble Code (DTC).>   | Go to step 2.   |
| 2 | <b>CHECK INTAKE OIL CONTROL SOLENOID LH.</b><br>Check the intake oil control solenoid LH. <Ref. to FU(H4DO(HEV))-58, INSPECTION, Oil Control Solenoid.>   | Is intake oil control solenoid LH normal?                   | Go to step 3.  | Replace the intake oil control solenoid LH. <Ref. to FU(H4DO(HEV))-56, Oil Control Solenoid.>               |
| 3 | <b>CHECK INSTALLATION CONDITION OF TIMING CHAIN.</b><br>Using ST and by turning the crankshaft, align the alignment marks of crank sprocket, intake cam sprocket and exhaust cam sprocket. <Ref. to ME(H4DO(w/o HEV))-169, Timing Chain Assembly.><br>ST 18252AA000 CRANKSHAFT SOCKET | Is timing chain installed to the appropriate position?      | Go to step 4.  | Correct the installation condition of timing chain. <Ref. to ME(H4DO(w/o HEV))-169, Timing Chain Assembly.> |
| 4 | <b>CHECK CAM CARRIER FILTER.</b><br>Check the filter installed to cam carrier. <Ref. to ME(H4DO(w/o HEV))-257, INSPECTION, Cam Carrier.>  | Is filter of cam carrier normal?                            | Replace the intake cam sprocket LH. <Ref. to ME(H4DO(w/o HEV))-191, Cam Sprocket.> After the operation is complete, go to the next step. Go to step 5. | Replace the filter of cam carrier. <Ref. to ME(H4DO(w/o HEV))-220, Cam Carrier.>                            |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step   | Check  | Yes   | No  |
|--|--|---|---|
| <p><b>5</b>      <b>CHECK CURRENT DATA.</b><br/>                     1) Clear the memory using the Subaru Select Monitor or general scan tool. &lt;Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.&gt;<br/>                     2) Start the engine and warm up completely.<br/>                     3) Using Subaru Select Monitor, read the value of «VVT Initial Position Learning Value #2» and «VVT Adv. Ang. Amount L» when idling condition is stable for 30 seconds or more.<br/>                     NOTE:<br/>                     For detailed operation procedures, refer to “Current Data Display For Engine”. &lt;Ref. to EN(H4DO HEV)(diag)-36, Subaru Select Monitor.&gt;<br/>                     4) Calculate the read value according to the following formula. At this time, ignore the unit.<br/> <math> \llcorner\text{VVT Initial Position Learning Value \#2}\llcorner - (60 + \llcorner\text{VVT Adv. Ang. Amount L}\llcorner) </math></p> | <p>Is the calculation result less than 10?</p>         | <p>Go to step 6.</p>  | <p>Replace the ECM.<br/>                     &lt;Ref. to FU(H4DO(HEV))-85, Engine Control Module (ECM).&gt;</p> |
| <p><b>6</b>      <b>CHECK DTC.</b><br/>                     1) Clear the memory using the Subaru Select Monitor or general scan tool. &lt;Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.&gt;<br/>                     2) Perform drive cycle N. &lt;Ref. to EN(H4DO HEV)(diag)-64, DRIVE CYCLE N, PROCEDURE, Drive Cycle.&gt;</p>  | <p>Is the same DTC as current diagnosis displayed?</p> | <p>Replace the ECM.<br/>                     &lt;Ref. to FU(H4DO(HEV))-85, Engine Control Module (ECM).&gt;</p> | <p>End.</p>   |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

## L: DTC P0019 CRANK AND CAM TIMING B SYSTEM FAILURE (BANK 2)

### DTC DETECTING CONDITION:

- Detected when two consecutive driving cycles with fault occur.
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-21, DTC P0019 CRANK AND CAM TIMING B SYSTEM FAILURE (BANK 2), Diagnostic Trouble Code (DTC) Detecting Criteria.>

### TROUBLE SYMPTOM:

- Engine stalls.
- Improper idling

### CAUTION:

After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.

| Step | Check  | Yes   | No  |
|------|--|---|---|
| 1    | <b>CHECK FOR ANY OTHER DTC ON DISPLAY.</b><br>Are DTCs other than P0016, P0017, P0018 or P0019 displayed?  | Check the appropriate DTC using the "List of Diagnostic Trouble Code (DTC)". <Ref. to EN(H4DO HEV)(diag)-92, List of Diagnostic Trouble Code (DTC).>    | Go to step 2.   |
| 2    | <b>CHECK EXHAUST OIL CONTROL SOLENOID LH.</b><br>Check the exhaust oil control solenoid LH. <Ref. to FU(H4DO(HEV))-58, INSPECTION, Oil Control Solenoid.>  | Go to step 3.   | Replace the exhaust oil control solenoid LH. <Ref. to FU(H4DO(HEV))-56, Oil Control Solenoid.>              |
| 3    | <b>CHECK INSTALLATION CONDITION OF TIMING CHAIN.</b><br>Using ST and by turning the crankshaft, align the alignment marks of crank sprocket, intake cam sprocket and exhaust cam sprocket. <Ref. to ME(H4DO(w/o HEV))-169, Timing Chain Assembly.><br>ST 18252AA000      CRANKSHAFT SOCKET | Go to step 4.   | Correct the installation condition of timing chain. <Ref. to ME(H4DO(w/o HEV))-169, Timing Chain Assembly.> |
| 4    | <b>CHECK CAM CARRIER FILTER.</b><br>Check the filter installed to cam carrier. <Ref. to ME(H4DO(w/o HEV))-257, INSPECTION, Cam Carrier.>   | Replace the exhaust cam sprocket LH. <Ref. to ME(H4DO(w/o HEV))-191, Cam Sprocket.> After the operation is complete, go to the next step. Go to step 5. | Replace the filter of cam carrier. <Ref. to ME(H4DO(w/o HEV))-220, Cam Carrier.>                            |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step   | Check  | Yes   | No  |
|--|--|---|---|
| <p><b>5</b>      <b>CHECK CURRENT DATA.</b><br/>                     1) Clear the memory using the Subaru Select Monitor or general scan tool. &lt;Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.&gt;<br/>                     2) Start the engine and warm up completely.<br/>                     3) Using Subaru Select Monitor, read the value of «VVT Ex Initial Position Learning Value #2» and «Exh. VVT Retard Ang. L» when idling condition is stable for 30 seconds or more.<br/>                     NOTE:<br/>                     For detailed operation procedures, refer to "Current Data Display For Engine". &lt;Ref. to EN(H4DO HEV)(diag)-36, Subaru Select Monitor.&gt;<br/>                     4) Calculate the read value according to the following formula. At this time, ignore the unit.<br/>                      «VVT Ex Initial Position Learning Value #2» – (90 – «Exh. VVT Retard Ang. L») </p> | <p>Is the calculation result less than 10?</p>         | <p>Go to step 6.</p>  | <p>Replace the ECM.<br/>                     &lt;Ref. to FU(H4DO(HEV))-85, Engine Control Module (ECM).&gt;</p> |
| <p><b>6</b>      <b>CHECK DTC.</b><br/>                     1) Clear the memory using the Subaru Select Monitor or general scan tool. &lt;Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.&gt;<br/>                     2) Perform drive cycle N. &lt;Ref. to EN(H4DO HEV)(diag)-64, DRIVE CYCLE N, PROCEDURE, Drive Cycle.&gt;</p>  | <p>Is the same DTC as current diagnosis displayed?</p> | <p>Replace the ECM.<br/>                     &lt;Ref. to FU(H4DO(HEV))-85, Engine Control Module (ECM).&gt;</p> | <p>End.</p>   |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

## M: DTC P0020 "A" CAMSHAFT POSITION ACTUATOR CIRCUIT/OPEN (BANK 2)

### DTC DETECTING CONDITION:

- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-21, DTC P0020 "A" CAMSHAFT POSITION ACTUATOR CIRCUIT/OPEN (BANK 2), Diagnostic Trouble Code (DTC) Detecting Criteria.>

### TROUBLE SYMPTOM:


Improper idling

### CAUTION:

After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.

### WIRING DIAGRAM:

- Engine electrical system (without push button start) <Ref. to WI(HEV)-100, WITHOUT PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>
- Engine electrical system (with push button start) <Ref. to WI(HEV)-114, WITH PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>



EN-10737

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step  | Check                                    | Yes  | No   |
|---|--|--|--|
| <b>1</b><br><b>CHECK OUTPUT SIGNAL OF ECM.</b><br>1) Turn the ignition switch to ON.<br>2) Measure the voltage between ECM connector and chassis ground.<br><b>Connector &amp; terminal</b><br><b>(B134) No. 16 (+) — Chassis ground (-):</b>   | Is the voltage 10 V or more?             | Go to step 2.  | Go to step 3.  |
| <b>2</b><br><b>CHECK FOR POOR CONTACT.</b><br>Check for poor contact of ECM connector.  | Is there poor contact of ECM connector?  | Repair the poor contact of ECM connector.                            | Even if DTC is detected, the circuit has returned to a normal condition at this time. Reproduce the failure, and then perform the diagnosis again.<br><br><b>NOTE:</b><br>In this case, temporary poor contact of connector, temporary open or short circuit of harness may be the cause.      |
| <b>3</b><br><b>CHECK POWER SUPPLY TO THE INTAKE OIL CONTROL SOLENOID LH.</b><br>Measure the voltage between intake oil control solenoid LH connector and engine ground.<br><b>Connector &amp; terminal</b><br><b>(E37) No. 1 (+) — Engine ground (-):</b>   | Is the voltage 10 V or more?             | Go to step 4.  | Repair the power supply circuit.   |
| <b>4</b><br><b>CHECK HARNESS BETWEEN ECM AND INTAKE OIL CONTROL SOLENOID LH CONNECTOR.</b><br>1) Turn the ignition switch to OFF.<br>2) Disconnect the connectors from ECM and intake oil control solenoid LH.<br>3) Measure the resistance between intake oil control solenoid LH connector and engine ground.<br><b>Connector &amp; terminal</b><br><b>(E37) No. 2 — Engine ground:</b> | Is the resistance 1 M $\Omega$ or more?  | Go to step 5.  | Repair the short circuit to ground in harness between ECM connector and intake oil control solenoid LH connector.  |
| <b>5</b><br><b>CHECK HARNESS BETWEEN ECM AND INTAKE OIL CONTROL SOLENOID LH CONNECTOR.</b><br>Measure the resistance of harness between ECM connector and intake oil control solenoid LH.<br><b>Connector &amp; terminal</b><br><b>(B134) No. 16 — (E37) No. 2:</b>   | Is the resistance less than 1 $\Omega$ ? | Go to step 6.  | Repair the harness and connector.<br><br><b>NOTE:</b><br>In this case, repair the following item: <ul style="list-style-type: none"> <li>• Open circuit in harness between ECM connector and intake oil control solenoid LH connector</li> <li>• Poor contact of coupling connector</li> </ul> |
| <b>6</b><br><b>CHECK INTAKE OIL CONTROL SOLENOID LH.</b><br>Measure the resistance between intake oil control solenoid LH terminals.<br><b>Terminals</b><br><b>No. 1 — No. 2:</b>   | Is the resistance 6 — 12 $\Omega$ ?      | Repair the poor contact of intake oil control solenoid LH connector. | Replace the intake oil control solenoid LH. <Ref. to FU(H4DO(HEV))-56, Oil Control Solenoid.>  |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

## N: DTC P0021 INTAKE CAMSHAFT POSITION - TIMING OVER-ADVANCED OR SYSTEM PERFORMANCE (BANK 2)

### DTC DETECTING CONDITION:

- Detected when two consecutive driving cycles with fault occur.
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-21, DTC P0021 INTAKE CAMSHAFT POSITION - TIMING OVER-ADVANCED OR SYSTEM PERFORMANCE (BANK 2), Diagnostic Trouble Code (DTC) Detecting Criteria.>

### TROUBLE SYMPTOM:

- Engine stalls.
- Improper idling

### CAUTION:

After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.

|   | Step   | Check   | Yes  | No  |
|---|--|---|--|---|
| 1 | <p><b>CHECK CURRENT DATA.</b></p> <p>1) Start the engine and let it idle.</p> <p>2) Read the value of «VVT Adv. Ang. Amount L» using the Subaru Select Monitor.</p> <p>NOTE:<br/>For detailed operation procedures, refer to “Current Data Display For Engine”. &lt;Ref. to EN(H4DO HEV)(diag)-36, Subaru Select Monitor.&gt;</p>  | Is the value of «VVT Adv. Ang. Amount L» approx. 0 deg?   | Go to step 2.  | <p>Check the following item and repair or replace if necessary.</p> <ul style="list-style-type: none"> <li>• Intake cam sprocket (clog or dirt of oil routing, setting of spring)</li> <li>• Intake camshaft (dirt, damage of camshaft)</li> </ul>  |
| 2 | <p><b>CHECK CURRENT DATA.</b></p> <p>1) Drive with acceleration and deceleration at 80 km/h (50 MPH) or less.</p> <p>NOTE:<br/>Drive to an extent that the duty output of oil flow control solenoid valve increases.</p> <p>2) Read the values of «OCV Duty L» and «VVT Adv. Ang. Amount L» using the Subaru Select Monitor.</p> <p>NOTE:<br/>For detailed operation procedures, refer to “Current Data Display For Engine”. &lt;Ref. to EN(H4DO HEV)(diag)-36, Subaru Select Monitor.&gt;</p> | When the value of «OCV Duty L» increases more than 10%, is the value of «VVT Adv. Ang. Amount L» approx. 0 deg? | <p>Check the following item and repair or replace if necessary.</p> <ul style="list-style-type: none"> <li>• Intake cam sprocket (clog or dirt of oil routing, setting of spring)</li> <li>• Intake camshaft (dirt, damage of camshaft)</li> </ul> | <p>Perform the following procedures, and clean the oil routing.</p> <p>Replace the engine oil and idle the engine for 5 minutes, and then replace the oil filter and engine oil.</p> <p>&lt;Ref. to LU(H4DO(w/o HEV))-13, REPLACEMENT, Engine Oil.&gt; &lt;Ref. to LU(H4DO(w/o HEV))-29, Engine Oil Filter.&gt;</p> |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

## O: DTC P0023 B CAMSHAFT POSITION ACTUATOR CIRCUIT/OPEN (BANK 2)

### DTC DETECTING CONDITION:

- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-21, DTC P0023 B CAMSHAFT POSITION ACTUATOR CIRCUIT/OPEN (BANK 2), Diagnostic Trouble Code (DTC) Detecting Criteria.>

### TROUBLE SYMPTOM:


Improper idling

### CAUTION:

After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.

### WIRING DIAGRAM:

- Engine electrical system (without push button start) <Ref. to WI(HEV)-100, WITHOUT PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>
- Engine electrical system (with push button start) <Ref. to WI(HEV)-114, WITH PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>



EN-10738

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

## ENGINE (DIAGNOSTICS)

| Step   | Check                                    | Yes                                       | No  |
|--|--|---|---|
| <b>1</b><br><b>CHECK OUTPUT SIGNAL OF ECM.</b><br>1) Turn the ignition switch to ON.<br>2) Measure the voltage between ECM connector and chassis ground.<br><b>Connector &amp; terminal</b><br><b>(B134) No. 5 (+) — Chassis ground (-):</b>   | Is the voltage 10 V or more?             | Go to step 2.                             | Go to step 3.   |
| <b>2</b><br><b>CHECK FOR POOR CONTACT.</b><br>Check for poor contact of ECM connector.   | Is there poor contact of ECM connector?  | Repair the poor contact of ECM connector. | Even if DTC is detected, the circuit has returned to a normal condition at this time. Reproduce the failure, and then perform the diagnosis again.<br><br><b>NOTE:</b><br>In this case, temporary poor contact of connector, temporary open or short circuit of harness may be the cause.       |
| <b>3</b><br><b>CHECK POWER SUPPLY TO THE EXHAUST OIL CONTROL SOLENOID LH.</b><br>Measure the voltage between exhaust oil control solenoid LH connector and engine ground.<br><b>Connector &amp; terminal</b><br><b>(E66) No. 1 (+) — Engine ground (-):</b>  | Is the voltage 10 V or more?             | Go to step 4.                             | Repair the power supply circuit.  |
| <b>4</b><br><b>CHECK HARNESS BETWEEN ECM AND EXHAUST OIL CONTROL SOLENOID LH CONNECTOR.</b><br>1) Turn the ignition switch to OFF.<br>2) Disconnect the connectors from ECM and exhaust oil control solenoid LH.<br>3) Measure the resistance between exhaust oil control solenoid LH connector and engine ground.<br><b>Connector &amp; terminal</b><br><b>(E66) No. 2 — Engine ground:</b> | Is the resistance 1 M $\Omega$ or more?  | Go to step 5.                             | Repair the short circuit to ground in harness between ECM connector and exhaust oil control solenoid LH connector.  |
| <b>5</b><br><b>CHECK HARNESS BETWEEN ECM AND EXHAUST OIL CONTROL SOLENOID LH CONNECTOR.</b><br>Measure the resistance of harness between ECM connector and exhaust oil control solenoid LH.<br><b>Connector &amp; terminal</b><br><b>(B134) No. 5 — (E66) No. 2:</b>   | Is the resistance less than 1 $\Omega$ ? | Go to step 6.                             | Repair the harness and connector.<br><br><b>NOTE:</b><br>In this case, repair the following item: <ul style="list-style-type: none"> <li>• Open circuit in harness between ECM connector and exhaust oil control solenoid LH connector</li> <li>• Poor contact of coupling connector</li> </ul> |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step  | Check                               | Yes   | No   |
|---|-------------------------------------|---|--|
| <b>6</b><br><b>CHECK EXHAUST OIL CONTROL SOLENOID LH.</b><br>Measure the resistance between exhaust oil control solenoid LH terminals.<br><b>Terminals</b><br><b>No. 1 — No. 2:</b> | Is the resistance 6 — 12 $\Omega$ ? | Repair the poor contact of exhaust oil control solenoid LH connector. | Replace the exhaust oil control solenoid LH. <Ref. to FU(H4DO(HEV))-56, Oil Control Solenoid.> |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

## P: DTC P0024 EXHAUST AVCS SYSTEM 2 (RANGE/PERFORMANCE)

### DTC DETECTING CONDITION:

- Detected when two consecutive driving cycles with fault occur.
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-21, DTC P0024 EXHAUST AVCS SYSTEM 2 (RANGE/PERFORMANCE), Diagnostic Trouble Code (DTC) Detecting Criteria.>

### TROUBLE SYMPTOM:

- Engine stalls.
- Improper idling

### CAUTION:

After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.

| Step   | Check  | Yes  | No   |
|--|--|--|--|
| <b>1</b><br><b>CHECK CURRENT DATA.</b><br>1) Start the engine and let it idle.<br>2) Read the value of «Exh. VVT Retard Ang. L» using the Subaru Select Monitor.<br><br>NOTE:<br>For detailed operation procedures, refer to "Current Data Display For Engine". <Ref. to EN(H4DO HEV)(diag)-36, Subaru Select Monitor.>  | Is the value of «Exh. VVT Retard Ang. L» approx. 0 deg?  | Go to step 2.  | Check the following item and repair or replace if necessary.<br><ul style="list-style-type: none"> <li>• Exhaust cam sprocket (clog or dirt of oil routing, setting of spring)</li> <li>• Exhaust camshaft (dirt, damage of camshaft)</li> </ul>   |
| <b>2</b><br><b>CHECK CURRENT DATA.</b><br>1) Drive with acceleration and deceleration at 80 km/h (50 MPH) or less.<br><br>NOTE:<br>Drive to an extent that the duty output of oil flow control solenoid valve increases.<br>2) Read the values of «Exh. OCV Duty L» and «Exh. VVT Retard Ang. L» using the Subaru Select Monitor.<br><br>NOTE:<br>For detailed operation procedures, refer to "Current Data Display For Engine". <Ref. to EN(H4DO HEV)(diag)-36, Subaru Select Monitor.> | When the value of «Exh. OCV Duty L» increases more than 10%, is the value of «Exh. VVT Retard Ang. L» approx. 0 deg? | Check the following item and repair or replace if necessary.<br><ul style="list-style-type: none"> <li>• Exhaust cam sprocket (clog or dirt of oil routing, setting of spring)</li> <li>• Exhaust camshaft (dirt, damage of camshaft)</li> </ul> | Perform the following procedures, and clean the oil routing.<br>Replace the engine oil and idle the engine for 5 minutes, and then replace the oil filter and engine oil.<br><Ref. to LU(H4DO(w/o HEV))-13, REPLACEMENT, Engine Oil.> <Ref. to LU(H4DO(w/o HEV))-29, Engine Oil Filter.> |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

## Q: DTC P0030 HO2S HEATER CONTROL CIRCUIT (BANK 1 SENSOR 1)

### DTC DETECTING CONDITION:


- Detected when two consecutive driving cycles with fault occur.
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-22, DTC P0030 HO2S HEATER CONTROL CIRCUIT (BANK 1 SENSOR 1), Diagnostic Trouble Code (DTC) Detecting Criteria.>

### CAUTION:

After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.

### WIRING DIAGRAM:

- Engine electrical system (without push button start) <Ref. to WI(HEV)-100, WITHOUT PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>
- Engine electrical system (with push button start) <Ref. to WI(HEV)-114, WITH PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>



EN-10739

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

## ENGINE (DIAGNOSTICS)

| Step   | Check   | Yes   | No  |
|--|---|---|---|
| <p><b>1</b>     <b>CHECK HARNESS BETWEEN ECM AND FRONT OXYGEN (A/F) SENSOR CONNECTOR.</b></p> <p>1) Start and warm up the engine.<br/>           2) Turn the ignition switch to OFF.<br/>           3) Disconnect the connectors from ECM and front oxygen (A/F) sensor.<br/>           4) Measure the resistance of harness between ECM connector and front oxygen (A/F) sensor connector.</p> <p><b>Connector &amp; terminal</b><br/> <b>(B136) No. 5 — (E24) No. 1:</b><br/> <b>(B136) No. 19 — (E24) No. 3:</b><br/> <b>(B136) No. 18 — (E24) No. 4:</b></p> | <p>Is the resistance less than 1 Ω?</p>                                     | <p>Go to step 2.</p>  | <p>Repair the harness and connector.</p> <p>NOTE:<br/>           In this case, repair the following item:</p> <ul style="list-style-type: none"> <li>• Open circuit in harness between ECM connector and front oxygen (A/F) sensor connector</li> <li>• Poor contact of coupling connector</li> </ul> |
| <p><b>2</b>     <b>CHECK FRONT OXYGEN (A/F) SENSOR.</b><br/>           Measure the resistance between front oxygen (A/F) sensor terminals.</p> <p><b>Terminals</b><br/> <b>No. 1 — No. 2:</b></p>  | <p>Is the resistance 1.8 — 2.2 Ω?</p>                                       | <p>Go to step 3.</p>  | <p>Replace the front oxygen (A/F) sensor. &lt;Ref. to FU(H4DO(HEV))-78, Front Oxygen (A/F) Sensor.&gt;</p>  |
| <p><b>3</b>     <b>CHECK FOR POOR CONTACT.</b><br/>           Check for poor contact of ECM and front oxygen (A/F) sensor connector.</p>   | <p>Is there poor contact of ECM or front oxygen (A/F) sensor connector?</p> | <p>Repair the poor contact of ECM or front oxygen (A/F) sensor connector.</p> | <p>Replace the front oxygen (A/F) sensor. &lt;Ref. to FU(H4DO(HEV))-78, Front Oxygen (A/F) Sensor.&gt;</p>  |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

## R: DTC P0031 HO2S HEATER CONTROL CIRCUIT LOW (BANK 1 SENSOR 1)

### DTC DETECTING CONDITION:


- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-23, DTC P0031 HO2S HEATER CONTROL CIRCUIT LOW (BANK 1 SENSOR 1), Diagnostic Trouble Code (DTC) Detecting Criteria.>

### CAUTION:

After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.

### WIRING DIAGRAM:

- Engine electrical system (without push button start) <Ref. to WI(HEV)-100, WITHOUT PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>
- Engine electrical system (with push button start) <Ref. to WI(HEV)-114, WITH PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>



EN-10739

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

## ENGINE (DIAGNOSTICS)

|   | Step   | Check                                    | Yes                                       | No   |
|---|--|--|---|--|
| 1 | <p><b>CHECK POWER SUPPLY TO FRONT OXYGEN (A/F) SENSOR.</b></p> <ol style="list-style-type: none"> <li>1) Turn the ignition switch to OFF.</li> <li>2) Disconnect the connectors from front oxygen (A/F) sensor.</li> <li>3) Turn the ignition switch to ON.</li> <li>4) Measure the voltage between front oxygen (A/F) sensor connector and engine ground.</li> </ol> <p><b>Connector &amp; terminal</b><br/><b>(E24) No. 2 (+) — Engine ground (-):</b></p> | Is the voltage 10 V or more?             | Go to step 2.                             | <p>Repair the power supply line.</p> <p>NOTE:<br/>In this case, repair the following item:</p> <ul style="list-style-type: none"> <li>• Open circuit in harness between A/F, oxygen sensor relay connector and front oxygen (A/F) sensor connector</li> <li>• Poor contact of A/F, oxygen sensor relay connector</li> <li>• Poor contact of coupling connector</li> <li>• Malfunction of A/F, oxygen sensor relay</li> </ul> |
| 2 | <p><b>CHECK HARNESS BETWEEN ECM AND FRONT OXYGEN (A/F) SENSOR CONNECTOR.</b></p> <ol style="list-style-type: none"> <li>1) Turn the ignition switch to OFF.</li> <li>2) Disconnect the connector from ECM.</li> <li>3) Measure the resistance between ECM connector and front oxygen (A/F) sensor connector.</li> </ol> <p><b>Connector &amp; terminal</b><br/><b>(B136) No. 5 — (E24) No. 1:</b></p>  | Is the resistance less than 1 $\Omega$ ? | Go to step 3.                             | <p>Repair the harness and connector.</p> <p>NOTE:<br/>In this case, repair the following item:</p> <ul style="list-style-type: none"> <li>• Open circuit in harness between ECM connector and front oxygen (A/F) sensor connector</li> <li>• Poor contact of coupling connector</li> </ul>   |
| 3 | <p><b>CHECK GROUND CIRCUIT FOR ECM.</b></p> <p>Measure the resistance of harness between ECM connector and chassis ground.</p> <p><b>Connector &amp; terminal</b><br/><b>(B134) No. 3 — Chassis ground:</b><br/><b>(B134) No. 4 — Chassis ground:</b><br/><b>(B136) No. 1 — Chassis ground:</b><br/><b>(B136) No. 2 — Chassis ground:</b><br/><b>(B136) No. 3 — Chassis ground:</b></p>  | Is the resistance less than 5 $\Omega$ ? | Go to step 4.                             | <p>Repair the harness and connector.</p> <p>NOTE:<br/>In this case, repair the following item:</p> <ul style="list-style-type: none"> <li>• Open circuit of harness between ECM connector and engine ground</li> <li>• Poor contact of coupling connector</li> </ul>   |
| 4 | <p><b>CHECK FRONT OXYGEN (A/F) SENSOR.</b></p> <p>Measure the resistance between front oxygen (A/F) sensor terminals.</p> <p><b>Terminals</b><br/><b>No. 1 — No. 2:</b></p>  | Is the resistance 1.8 — 2.2 $\Omega$ ?   | Repair the poor contact of ECM connector. | <p>Replace the front oxygen (A/F) sensor. &lt;Ref. to FU(H4DO(HEV))-78, Front Oxygen (A/F) Sensor.&gt;</p>   |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

## S: DTC P0032 HO2S HEATER CONTROL CIRCUIT HIGH (BANK 1 SENSOR 1)

### DTC DETECTING CONDITION:


- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-24, DTC P0032 HO2S HEATER CONTROL CIRCUIT HIGH (BANK 1 SENSOR 1), Diagnostic Trouble Code (DTC) Detecting Criteria.>

### CAUTION:

After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.

### WIRING DIAGRAM:

- Engine electrical system (without push button start) <Ref. to WI(HEV)-100, WITHOUT PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>
- Engine electrical system (with push button start) <Ref. to WI(HEV)-114, WITH PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>



EN-10739

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step   | Check                                   | Yes  | No  |
|--|---|--|---|
| <p><b>1</b>     <b>CHECK HARNESS BETWEEN ECM AND FRONT OXYGEN (A/F) SENSOR CONNECTOR.</b></p> <p>1) Turn the ignition switch to OFF.<br/>2) Measure the voltage between ECM connector and chassis ground.</p> <p><b>Connector &amp; terminal</b><br/><b>(B136) No. 5 (+) — Chassis ground (-):</b></p>   | <p>Is the voltage 10 V or more?</p>     | <p>Repair the short circuit to power in the harness between ECM connector and front oxygen (A/F) sensor connector.</p> | <p>Go to step 2.</p>  |
| <p><b>2</b>     <b>CHECK GROUND CIRCUIT FOR ECM.</b></p> <p>1) Disconnect the connector from ECM.<br/>2) Measure the resistance between ECM connector and chassis ground.</p> <p><b>Connector &amp; terminal</b><br/><b>(B134) No. 3 — Chassis ground:</b><br/><b>(B134) No. 4 — Chassis ground:</b><br/><b>(B136) No. 1 — Chassis ground:</b><br/><b>(B136) No. 2 — Chassis ground:</b><br/><b>(B136) No. 3 — Chassis ground:</b></p> | <p>Is the resistance less than 5 Ω?</p> | <p>Repair the poor contact of ECM connector.</p>   | <p>Repair the harness and connector.</p> <p><b>NOTE:</b><br/>In this case, repair the following item:</p> <ul style="list-style-type: none"> <li>• Open circuit of harness between ECM connector and engine ground</li> <li>• Poor contact of coupling connector</li> </ul> |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

## T: DTC P0037 HO2S HEATER CONTROL CIRCUIT LOW (BANK 1 SENSOR 2)

### DTC DETECTING CONDITION:


- Detected when two consecutive driving cycles with fault occur.
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-25, DTC P0037 HO2S HEATER CONTROL CIRCUIT LOW (BANK 1 SENSOR 2), Diagnostic Trouble Code (DTC) Detecting Criteria.>

### CAUTION:

After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.

### WIRING DIAGRAM:

- Engine electrical system (without push button start) <Ref. to WI(HEV)-100, WITHOUT PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>
- Engine electrical system (with push button start) <Ref. to WI(HEV)-114, WITH PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>



EN-10740

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

## ENGINE (DIAGNOSTICS)

| Step   | Check                                    | Yes                                       | No  |
|--|--|---|---|
| <p><b>1</b>      <b>CHECK POWER SUPPLY TO REAR OXYGEN SENSOR.</b><br/>                     1) Turn the ignition switch to OFF.<br/>                     2) Disconnect the connector from rear oxygen sensor.<br/>                     3) Turn the ignition switch to ON.<br/>                     4) Measure the voltage between rear oxygen sensor connector and engine ground.<br/> <b>Connector &amp; terminal</b><br/> <b>(E25) No. 1 (+) — Engine ground (-):</b></p> | Is the voltage 10 V or more?             | Go to step 2.                             | Repair the power supply line. Or replace the main relay.<br><br>NOTE:<br>In this case, repair the following item:<br>• Open circuit in harness between A/F, oxygen sensor relay connector and rear oxygen sensor connector<br>• Poor contact of A/F, oxygen sensor relay connector<br>• Poor contact of coupling connector<br>• Malfunction of A/F, oxygen sensor relay |
| <p><b>2</b>      <b>CHECK HARNESS BETWEEN ECM AND REAR OXYGEN SENSOR CONNECTOR.</b><br/>                     1) Turn the ignition switch to OFF.<br/>                     2) Disconnect the connector from ECM.<br/>                     3) Measure the resistance between ECM connector and oxygen sensor connector.<br/> <b>Connector &amp; terminal</b><br/> <b>(B134) No. 6 — (E25) No. 2:</b></p>   | Is the resistance less than 1 $\Omega$ ? | Go to step 3.                             | Repair the harness and connector.<br><br>NOTE:<br>In this case, repair the following item:<br>• Open circuit in harness between ECM connector and rear oxygen sensor connector<br>• Poor contact of coupling connector  |
| <p><b>3</b>      <b>CHECK GROUND CIRCUIT FOR ECM.</b><br/>                     Measure the resistance of harness between ECM connector and chassis ground.<br/> <b>Connector &amp; terminal</b><br/> <b>(B134) No. 3 — Chassis ground:</b><br/> <b>(B134) No. 4 — Chassis ground:</b><br/> <b>(B136) No. 1 — Chassis ground:</b><br/> <b>(B136) No. 2 — Chassis ground:</b><br/> <b>(B136) No. 3 — Chassis ground:</b></p>   | Is the resistance less than 5 $\Omega$ ? | Go to step 4.                             | Repair the harness and connector.<br><br>NOTE:<br>In this case, repair the following item:<br>• Open circuit of harness between ECM connector and engine ground<br>• Poor contact of coupling connector   |
| <p><b>4</b>      <b>CHECK REAR OXYGEN SENSOR.</b><br/>                     Measure the resistance between rear oxygen sensor terminals.<br/> <b>Terminals</b><br/> <b>No. 2 — No. 1:</b></p>   | Is the resistance 5 — 6.4 $\Omega$ ?     | Repair the poor contact of ECM connector. | Replace the rear oxygen sensor.<br><Ref. to FU(H4DO(HEV))-82, Rear Oxygen Sensor.>  |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

## U: DTC P0038 HO2S HEATER CONTROL CIRCUIT HIGH (BANK 1 SENSOR 2)

### DTC DETECTING CONDITION:


- Detected when two consecutive driving cycles with fault occur.
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-26, DTC P0038 HO2S HEATER CONTROL CIRCUIT HIGH (BANK 1 SENSOR 2), Diagnostic Trouble Code (DTC) Detecting Criteria.>

### CAUTION:

After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.

### WIRING DIAGRAM:

- Engine electrical system (without push button start) <Ref. to WI(HEV)-100, WITHOUT PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>
- Engine electrical system (with push button start) <Ref. to WI(HEV)-114, WITH PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>



EN-10740

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step   | Check                                   | Yes   | No  |
|--|---|---|---|
| <p><b>1</b>     <b>CHECK HARNESS BETWEEN ECM AND REAR OXYGEN SENSOR CONNECTOR.</b><br/>           1) Turn the ignition switch to OFF.<br/>           2) Measure the voltage between ECM connector and chassis ground.<br/> <b>Connector &amp; terminal</b><br/> <b>(B134) No. 6 (+) — Chassis ground (-):</b></p>  | <p>Is the voltage 10 V or more?</p>     | <p>Repair the short circuit to power in the harness between ECM connector and rear oxygen sensor connector.</p> | <p>Go to step 2.</p>  |
| <p><b>2</b>     <b>CHECK GROUND CIRCUIT FOR ECM.</b><br/>           1) Disconnect the connector from ECM.<br/>           2) Measure the resistance between ECM connector and chassis ground.<br/> <b>Connector &amp; terminal</b><br/> <b>(B134) No. 3 — Chassis ground:</b><br/> <b>(B134) No. 4 — Chassis ground:</b><br/> <b>(B136) No. 1 — Chassis ground:</b><br/> <b>(B136) No. 2 — Chassis ground:</b><br/> <b>(B136) No. 3 — Chassis ground:</b></p> | <p>Is the resistance less than 5 Ω?</p> | <p>Repair the poor contact of ECM connector.</p>  | <p>Repair the harness and connector.<br/> <b>NOTE:</b><br/>           In this case, repair the following item:<br/>           • Open circuit of harness between ECM connector and engine ground<br/>           • Poor contact of coupling connector</p> |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

## V: DTC P0068 MAP/MAF - THROTTLE POSITION CORRELATION

### DTC DETECTING CONDITION:

- Detected when two consecutive driving cycles with fault occur.
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-27, DTC P0068 MAP/MAF - THROTTLE POSITION CORRELATION, Diagnostic Trouble Code (DTC) Detecting Criteria.>

### CAUTION:

After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.

| Step   | Check  | Yes   | No  |
|--|--|---|---|
| 1<br><b>CHECK AIR INTAKE SYSTEM.</b>   | Are there holes, loose bolts or disconnection of hose on air intake system?  | Repair the air intake system.   | Go to step 2.   |
| 2<br><b>CHECK MANIFOLD ABSOLUTE PRESSURE SENSOR.</b><br>1) Start the engine and warm up engine until coolant temperature is higher than 75°C (167°F).<br>2) Place the select lever in "P" range or "N" range.<br>3) Turn the A/C switch to OFF.<br>4) Turn all the accessory switches to OFF.<br>5) Read the value of «Mani. Absolute Pressure» using the Subaru Select Monitor or a general scan tool.<br><b>NOTE:</b><br>• Subaru Select Monitor<br>For detailed operation procedures, refer to "Current Data Display For Engine". <Ref. to EN(H4DO HEV)(diag)-36, Subaru Select Monitor.><br>• General scan tool<br>For detailed operation procedures, refer to the "General Scan Tool Instruction Manual". | Is the value in «Mani. Absolute Pressure» 73.3 — 106.6 kPa (550 — 800 mmHg, 21.65 — 31.50 inHg) when the ignition is turned ON, and 20.0 — 46.7 kPa (150 — 350 mmHg, 5.91 — 13.78 inHg) during idling? | Go to step 3.   | Replace the manifold absolute pressure sensor. <Ref. to FU(H4DO(HEV))-66, Manifold Absolute Pressure Sensor.> |
| 3<br><b>CHECK THROTTLE OPENING ANGLE.</b><br>Using the Subaru Select Monitor or a general scan tool, read the value in «Throttle Opening Angle».<br><b>NOTE:</b><br>• Subaru Select Monitor<br>For detailed operation procedures, refer to "Current Data Display For Engine". <Ref. to EN(H4DO HEV)(diag)-36, Subaru Select Monitor.><br>• General scan tool<br>For detailed operation procedures, refer to the "General Scan Tool Instruction Manual".  | Is the value in «Throttle Opening Angle» with the throttle fully closed less than 5%?  | Go to step 4.   | Replace the electronic throttle control. <Ref. to FU(H4DO(HEV))-14, Throttle Body.>                           |
| 4<br><b>CHECK THROTTLE OPENING ANGLE.</b>  | Is the value in «Throttle Opening Angle» with the throttle fully open 85% or more?   | Replace the manifold absolute pressure sensor. <Ref. to FU(H4DO(HEV))-66, Manifold Absolute Pressure Sensor.> | Replace the electronic throttle control. <Ref. to FU(H4DO(HEV))-14, Throttle Body.>                           |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

## W: DTC P0071 AMBIENT TEMPERATURE SENSOR CIRCUIT "A" RANGE/PERFORMANCE

### DTC DETECTING CONDITION:


- Detected when two consecutive driving cycles with fault occur.
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-29, DTC P0071 AMBIENT TEMPERATURE SENSOR CIRCUIT "A" RANGE/PERFORMANCE, Diagnostic Trouble Code (DTC) Detecting Criteria.>

### CAUTION:

After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.

### WIRING DIAGRAM:

Air conditioning system <Ref. to WI(HEV)-56, WIRING DIAGRAM, Air Conditioning System.>



EN-10741

| Step | Check   | Yes   | No            |
|------|---|---|---------------|
| 1    | <b>CHECK FOR ANY OTHER DTC ON DISPLAY.</b><br>Is any other DTC displayed? | Check the appropriate DTC using the "List of Diagnostic Trouble Code (DTC)".<br><Ref. to EN(H4DO HEV)(diag)-92, List of Diagnostic Trouble Code (DTC).> | Go to step 2. |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step  | Check   | Yes  | No  |
|---|---|--|---|
| <p><b>2</b></p> <p><b>CHECK AMBIENT SENSOR.</b></p> <p>1) Turn the ignition switch to OFF.</p> <p>2) Disconnect the connector from ambient sensor.</p> <p>3) Measure the resistance between ambient sensor terminals while heating and cooling the ambient sensor using a hair drier.</p> <p><b>CAUTION:</b><br/>Do not heat the part to the temperature where you cannot touch it with your bare hand in order to prevent burning yourself and protect the part.</p> <p><i>Terminals</i><br/><i>No. 1 — No. 2:</i></p> | <p>Is the resistance of ambient sensor different between during heating and during cooling?</p> | <p>Repair the poor contact of ECM connector.</p> | <p>Replace the ambient sensor. &lt;Ref. to AC-77, Ambient Sensor.&gt;</p> |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

## X: DTC P0072 AMBIENT TEMPERATURE SENSOR CIRCUIT "A" LOW

### DTC DETECTING CONDITION:

- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-31, DTC P0072 AMBIENT TEMPERATURE SENSOR CIRCUIT "A" LOW, Diagnostic Trouble Code (DTC) Detecting Criteria.>

### CAUTION:

After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.

| Step   | Check   | Yes  | No   |
|--|---|--|--|
| 1<br><b>CHECK DTC.</b><br>Check for DTC. <Ref. to EN(H4DO HEV)(diag)-51, Read Diagnostic Trouble Code (DTC).>                  | Is DTC P0072 or P0073 displayed in «Present fault»? | Go to step 2.  | Even if DTC is detected, the circuit has returned to a normal condition at this time. Reproduce the failure, and then perform the diagnosis again.<br><br>NOTE:<br>In this case, temporary poor contact of connector, temporary open or short circuit of harness may be the cause. |
| 2<br><b>CHECK COMBINATION METER.</b><br>Check the combination meter system. <Ref. to IDI(diag)-2, Basic Diagnostic Procedure.> | Is combination meter system OK?                     | Replace the ambient sensor. <Ref. to AC-77, Ambient Sensor.> | Repair the combination meter system. <Ref. to IDI(diag)-2, Basic Diagnostic Procedure.>  |

## Y: DTC P0073 AMBIENT TEMPERATURE SENSOR CIRCUIT "A" HIGH

### NOTE:

For the diagnostic procedure, refer to DTC P0072. <Ref. to EN(H4DO HEV)(diag)-138, DTC P0072 AMBIENT TEMPERATURE SENSOR CIRCUIT "A" LOW, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

## Z: DTC P0101 MASS OR VOLUME AIR FLOW CIRCUIT RANGE/PERFORMANCE

### DTC DETECTING CONDITION:

- Detected when two consecutive driving cycles with fault occur.
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-33, DTC P0101 MASS OR VOLUME AIR FLOW CIRCUIT RANGE/PERFORMANCE, Diagnostic Trouble Code (DTC) Detecting Criteria.>

### TROUBLE SYMPTOM:

- Improper idling
- Engine stalls.
- Poor driving performance

### CAUTION:

After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.

| Step                                     | Check                       | Yes  | No  |
|--|-----------------------------|--|---|
| 1<br>CHECK FOR ANY OTHER DTC ON DISPLAY. | Is any other DTC displayed? | Check the appropriate DTC using the "List of Diagnostic Trouble Code (DTC)". <Ref. to EN(H4DO HEV)(diag)-92, List of Diagnostic Trouble Code (DTC).> | Replace the mass air flow and intake air temperature sensor. <Ref. to FU(H4DO(HEV))-63, Mass Air Flow and Intake Air Temperature Sensor.> |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

## AA:DTC P0102 MASS OR VOLUME AIR FLOW CIRCUIT LOW INPUT

### DTC DETECTING CONDITION:

- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-35, DTC P0102 MASS OR VOLUME AIR FLOW CIRCUIT LOW INPUT, Diagnostic Trouble Code (DTC) Detecting Criteria.>

### TROUBLE SYMPTOM:



- Improper idling
- Engine stalls.
- Poor driving performance

### CAUTION:

After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.

### WIRING DIAGRAM:

- Engine electrical system (without push button start) <Ref. to WI(HEV)-100, WITHOUT PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>
- Engine electrical system (with push button start) <Ref. to WI(HEV)-114, WITH PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>



EN-10742

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step   | Check   | Yes   | No  |
|--|---|---|---|
| <p><b>1</b></p> <p><b>CHECK CURRENT DATA.</b></p> <p>1) Start the engine.</p> <p>2) Read the value of «Air Flow Sensor Voltage» using Subaru Select Monitor.</p> <p>NOTE:<br/>For detailed operation procedures, refer to “Current Data Display For Engine”. &lt;Ref. to EN(H4DO HEV)(diag)-36, Subaru Select Monitor.&gt;</p>   | <p>Is the value of «Air Flow Sensor Voltage» less than 0.2 V?</p>                                 | <p>Go to step 2.</p>  | <p>Even if DTC is detected, the circuit has returned to a normal condition at this time. Reproduce the failure, and then perform the diagnosis again.</p> <p>NOTE:<br/>In this case, temporary poor contact of connector, temporary open or short circuit of harness may be the cause.</p>                      |
| <p><b>2</b></p> <p><b>CHECK POWER SUPPLY OF MASS AIR FLOW AND INTAKE AIR TEMPERATURE SENSOR.</b></p> <p>1) Turn the ignition switch to OFF.</p> <p>2) Disconnect the connectors from the mass air flow and intake air temperature sensor.</p> <p>3) Turn the ignition switch to ON.</p> <p>4) Measure the voltage between mass air flow and intake air temperature sensor connector and engine ground.</p> <p><b>Connector &amp; terminal</b><br/><b>(B3) No. 3 (+) — Engine ground (-):</b></p> | <p>Is the voltage 10 V or more?</p>   | <p>Go to step 3.</p>  | <p>Repair the harness and connector.</p> <p>NOTE:<br/>In this case, repair the following item:</p> <ul style="list-style-type: none"> <li>• Open circuit in harness between main relay and mass air flow and intake air temperature sensor connector</li> <li>• Poor contact of main relay connector</li> </ul> |
| <p><b>3</b></p> <p><b>CHECK HARNESS BETWEEN ECM AND MASS AIR FLOW AND INTAKE AIR TEMPERATURE SENSOR CONNECTOR.</b></p> <p>1) Turn the ignition switch to OFF.</p> <p>2) Disconnect the connector from ECM.</p> <p>3) Measure the resistance of harness between ECM connector and the mass air flow and intake air temperature sensor connector.</p> <p><b>Connector &amp; terminal</b><br/><b>(B137) No. 22 — (B3) No. 5:</b></p>  | <p>Is the resistance less than 1 Ω?</p>   | <p>Go to step 4.</p>  | <p>Repair the open circuit of harness between ECM connector and the mass air flow and intake air temperature sensor connector.</p>  |
| <p><b>4</b></p> <p><b>CHECK HARNESS BETWEEN ECM AND MASS AIR FLOW AND INTAKE AIR TEMPERATURE SENSOR CONNECTOR.</b></p> <p>Measure the resistance between ECM connector and chassis ground.</p> <p><b>Connector &amp; terminal</b><br/><b>(B137) No. 22 — Chassis ground:</b></p>   | <p>Is the resistance 1 MΩ or more?</p>  | <p>Go to step 5.</p>  | <p>Repair the ground short circuit of harness between ECM connector and the mass air flow and intake air temperature sensor connector.</p>  |
| <p><b>5</b></p> <p><b>CHECK FOR POOR CONTACT.</b></p> <p>Check for poor contact of ECM and mass air flow and intake air temperature sensor connector.</p>  | <p>Is there poor contact of ECM or mass air flow and intake air temperature sensor connector?</p> | <p>Repair the poor contact of ECM or mass air flow and intake air temperature sensor connector.</p> | <p>Replace the mass air flow and intake air temperature sensor. &lt;Ref. to FU(H4DO(HEV))-63, Mass Air Flow and Intake Air Temperature Sensor.&gt;</p>  |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

## AB:DTC P0103 MASS OR VOLUME AIR FLOW CIRCUIT HIGH INPUT

### DTC DETECTING CONDITION:

- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-36, DTC P0103 MASS OR VOLUME AIR FLOW CIRCUIT HIGH INPUT, Diagnostic Trouble Code (DTC) Detecting Criteria.>

### TROUBLE SYMPTOM:



- Improper idling
- Engine stalls.
- Poor driving performance

### CAUTION:

After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.

### WIRING DIAGRAM:

- Engine electrical system (without push button start) <Ref. to WI(HEV)-100, WITHOUT PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>
- Engine electrical system (with push button start) <Ref. to WI(HEV)-114, WITH PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>



EN-10742

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

|   | Step   | Check   | Yes  | No  |
|---|--|---|--|---|
| 1 | <p><b>CHECK CURRENT DATA.</b></p> <p>1) Start the engine.</p> <p>2) Read the value of «Air Flow Sensor Voltage» using Subaru Select Monitor.</p> <p>NOTE:<br/>For detailed operation procedures, refer to “Current Data Display For Engine”. &lt;Ref. to EN(H4DO HEV)(diag)-36, Subaru Select Monitor.&gt;</p>   | Is the value of «Air Flow Sensor Voltage» 5 V or more?                              | Go to step 2.  | <p>Even if DTC is detected, the circuit has returned to a normal condition at this time. Reproduce the failure, and then perform the diagnosis again.</p> <p>NOTE:<br/>In this case, temporary poor contact of connector, temporary open or short circuit of harness may be the cause.</p>                      |
| 2 | <p><b>CHECK HARNESS BETWEEN ECM AND MASS AIR FLOW AND INTAKE AIR TEMPERATURE SENSOR CONNECTOR.</b></p> <p>1) Turn the ignition switch to OFF.</p> <p>2) Disconnect the connectors from the mass air flow and intake air temperature sensor.</p> <p>3) Start the engine.</p> <p>4) Read the value of «Air Flow Sensor Voltage» using Subaru Select Monitor.</p> <p>NOTE:<br/>For detailed operation procedures, refer to “Current Data Display For Engine”. &lt;Ref. to EN(H4DO HEV)(diag)-36, Subaru Select Monitor.&gt;</p> | Is the value of «Air Flow Sensor Voltage» 5 V or more?                              | Repair the short circuit of harness to power supply between ECM connector and the mass air flow and intake air temperature sensor connector. | Go to step 3.   |
| 3 | <p><b>CHECK HARNESS BETWEEN ECM AND MASS AIR FLOW AND INTAKE AIR TEMPERATURE SENSOR CONNECTOR.</b></p> <p>1) Turn the ignition switch to OFF.</p> <p>2) Measure the resistance of harness between mass air flow and intake air temperature sensor connector and engine ground.</p> <p><b>Connector &amp; terminal</b><br/><b>(B3) No. 4 — Engine ground:</b></p>   | Is the resistance less than 5 Ω?  | Go to step 4.  | <p>Repair the harness and connector.</p> <p>NOTE:<br/>In this case, repair the following item:</p> <ul style="list-style-type: none"> <li>• Open circuit in harness between ECM connector and the mass air flow and intake air temperature sensor connector</li> <li>• Poor contact of ECM connector</li> </ul> |
| 4 | <p><b>CHECK FOR POOR CONTACT.</b></p> <p>Check for poor contact of mass air flow and intake air temperature sensor connector.</p>  | Is there poor contact of mass air flow and intake air temperature sensor connector? | Repair the poor contact of mass air flow and intake air temperature sensor connector.  | Replace the mass air flow and intake air temperature sensor. <Ref. to FU(H4DO(HEV))-63, Mass Air Flow and Intake Air Temperature Sensor.>   |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

## AC:DTC P0107 MANIFOLD ABSOLUTE PRESSURE/BAROMETRIC PRESSURE CIRCUIT LOW INPUT

### DTC DETECTING CONDITION:


- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-37, DTC P0107 MANIFOLD ABSOLUTE PRESSURE/BAROMETRIC PRESSURE CIRCUIT LOW INPUT, Diagnostic Trouble Code (DTC) Detecting Criteria.>

### CAUTION:

After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.

### WIRING DIAGRAM:

- Engine electrical system (without push button start) <Ref. to WI(HEV)-100, WITHOUT PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>
- Engine electrical system (with push button start) <Ref. to WI(HEV)-114, WITH PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>



EN-09670

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step  | Check  | Yes   | No   |
|---|--|---|--|
| <p><b>1</b></p> <p><b>CHECK CURRENT DATA.</b></p> <p>1) Start the engine.</p> <p>2) Read the value of «Mani. Absolute Pressure» using the Subaru Select Monitor or a general scan tool.</p> <p>NOTE:</p> <ul style="list-style-type: none"> <li>• Subaru Select Monitor</li> </ul> <p>For detailed operation procedures, refer to “Current Data Display For Engine”. &lt;Ref. to EN(H4DO HEV)(diag)-36, Subaru Select Monitor.&gt;</p> <ul style="list-style-type: none"> <li>• General scan tool</li> </ul> <p>For detailed operation procedures, refer to the “General Scan Tool Instruction Manual”.</p> | <p>Is the value of «Mani. Absolute Pressure» less than 13.3 kPa (100 mmHg, 3.94 inHg)?</p> | <p>Go to step 2.</p>  | <p>Even if DTC is detected, the circuit has returned to a normal condition at this time. Reproduce the failure, and then perform the diagnosis again.</p> <p>NOTE:</p> <p>In this case, temporary poor contact of connector, temporary open or short circuit of harness may be the cause.</p>  |
| <p><b>2</b></p> <p><b>CHECK POWER SUPPLY OF MANIFOLD ABSOLUTE PRESSURE SENSOR.</b></p> <p>1) Turn the ignition switch to OFF.</p> <p>2) Disconnect the connector from manifold absolute pressure sensor.</p> <p>3) Turn the ignition switch to ON.</p> <p>4) Measure the voltage between manifold absolute pressure sensor connector and engine ground.</p> <p><b>Connector &amp; terminal</b><br/><b>(E21) No. 3 (+) — Engine ground (-):</b></p>  | <p>Is the voltage 4.5 V or more?</p>   | <p>Go to step 3.</p>  | <p>Repair the harness and connector.</p> <p>NOTE:</p> <p>In this case, repair the following item:</p> <ul style="list-style-type: none"> <li>• Open circuit of harness between ECM connector and manifold absolute pressure sensor connector</li> <li>• Poor contact of ECM connector</li> <li>• Poor contact of coupling connector</li> </ul> |
| <p><b>3</b></p> <p><b>CHECK HARNESS BETWEEN ECM AND MANIFOLD ABSOLUTE PRESSURE SENSOR CONNECTOR.</b></p> <p>1) Turn the ignition switch to OFF.</p> <p>2) Disconnect the connector from ECM.</p> <p>3) Measure the resistance of harness between ECM connector and manifold absolute pressure sensor connector.</p> <p><b>Connector &amp; terminal</b><br/><b>(B136) No. 20 — (E21) No. 2:</b></p>  | <p>Is the resistance less than 1 Ω?</p>  | <p>Go to step 4.</p>  | <p>Repair the harness and connector.</p> <p>NOTE:</p> <p>In this case, repair the following item:</p> <ul style="list-style-type: none"> <li>• Open circuit of harness between ECM connector and manifold absolute pressure sensor connector</li> <li>• Poor contact of coupling connector</li> </ul>  |
| <p><b>4</b></p> <p><b>CHECK HARNESS BETWEEN ECM AND MANIFOLD ABSOLUTE PRESSURE SENSOR CONNECTOR.</b></p> <p>Measure the resistance between ECM connector and chassis ground.</p> <p><b>Connector &amp; terminal</b><br/><b>(B136) No. 20 — Chassis ground:</b></p>  | <p>Is the resistance 1 MΩ or more?</p>   | <p>Go to step 5.</p>  | <p>Repair short circuit to ground in harness between ECM connector and manifold absolute pressure sensor connector.</p>  |
| <p><b>5</b></p> <p><b>CHECK FOR POOR CONTACT.</b></p> <p>Check for poor contact of ECM and manifold absolute pressure sensor connector.</p>   | <p>Is there poor contact of ECM or manifold absolute pressure sensor connector?</p>        | <p>Repair the poor contact of ECM or manifold absolute pressure sensor connector.</p> | <p>Replace the manifold absolute pressure sensor. &lt;Ref. to FU(H4DO(HEV))-66, Manifold Absolute Pressure Sensor.&gt;</p>   |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

## AD:DTC P0108 MANIFOLD ABSOLUTE PRESSURE/BAROMETRIC PRESSURE CIRCUIT HIGH INPUT

### DTC DETECTING CONDITION:


- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-38, DTC P0108 MANIFOLD ABSOLUTE PRESSURE/BAROMETRIC PRESSURE CIRCUIT HIGH INPUT, Diagnostic Trouble Code (DTC) Detecting Criteria.>

### CAUTION:

After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.

### WIRING DIAGRAM:

- Engine electrical system (without push button start) <Ref. to WI(HEV)-100, WITHOUT PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>
- Engine electrical system (with push button start) <Ref. to WI(HEV)-114, WITH PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>



EN-09670

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step   | Check  | Yes  | No   |
|--|--|--|--|
| <p><b>1</b></p> <p><b>CHECK CURRENT DATA.</b></p> <p>1) Start the engine.</p> <p>2) Read the value of «Mani. Absolute Pressure» using the Subaru Select Monitor or a general scan tool.</p> <p>NOTE:</p> <ul style="list-style-type: none"> <li>• Subaru Select Monitor</li> </ul> <p>For detailed operation procedures, refer to “Current Data Display For Engine”. &lt;Ref. to EN(H4DO HEV)(diag)-36, Subaru Select Monitor.&gt;</p> <ul style="list-style-type: none"> <li>• General scan tool</li> </ul> <p>For detailed operation procedures, refer to the “General Scan Tool Instruction Manual”.</p>  | <p>Is the value of «Mani. Absolute Pressure» 119.5 kPa (896.5 mmHg, 35.29 inHg) or more?</p> | <p>Go to step 2.</p>   | <p>Even if DTC is detected, the circuit has returned to a normal condition at this time. Reproduce the failure, and then perform the diagnosis again.</p> <p>NOTE:</p> <p>In this case, temporary poor contact of connector, temporary open or short circuit of harness may be the cause.</p>  |
| <p><b>2</b></p> <p><b>CHECK HARNESS BETWEEN ECM AND MANIFOLD ABSOLUTE PRESSURE SENSOR CONNECTOR.</b></p> <p>1) Turn the ignition switch to OFF.</p> <p>2) Disconnect the connector from manifold absolute pressure sensor.</p> <p>3) Start the engine.</p> <p>4) Read the value of «Mani. Absolute Pressure» using the Subaru Select Monitor or a general scan tool.</p> <p>NOTE:</p> <ul style="list-style-type: none"> <li>• Subaru Select Monitor</li> </ul> <p>For detailed operation procedures, refer to “Current Data Display For Engine”. &lt;Ref. to EN(H4DO HEV)(diag)-36, Subaru Select Monitor.&gt;</p> <ul style="list-style-type: none"> <li>• General scan tool</li> </ul> <p>For detailed operation procedures, refer to the “General Scan Tool Instruction Manual”.</p> | <p>Is the value of «Mani. Absolute Pressure» 119.5 kPa (896.5 mmHg, 35.29 inHg) or more?</p> | <p>Repair the short circuit to power in harness between ECM connector and manifold absolute pressure sensor connector.</p> | <p>Go to step 3.</p>   |
| <p><b>3</b></p> <p><b>CHECK HARNESS BETWEEN ECM AND MANIFOLD ABSOLUTE PRESSURE SENSOR CONNECTOR.</b></p> <p>1) Turn the ignition switch to OFF.</p> <p>2) Measure the resistance of harness between manifold absolute pressure sensor connector and engine ground.</p> <p><b>Connector &amp; terminal</b><br/><b>(E21) No. 1 — Engine ground:</b></p>  | <p>Is the resistance less than 5 Ω?</p>  | <p>Go to step 4.</p>   | <p>Repair the harness and connector.</p> <p>NOTE:</p> <p>In this case, repair the following item:</p> <ul style="list-style-type: none"> <li>• Open circuit of harness between ECM connector and manifold absolute pressure sensor connector</li> <li>• Poor contact of ECM connector</li> <li>• Poor contact of coupling connector</li> </ul> |
| <p><b>4</b></p> <p><b>CHECK FOR POOR CONTACT.</b></p> <p>Check for poor contact of manifold absolute pressure sensor connector.</p>  | <p>Is there poor contact of manifold absolute pressure sensor connector?</p>                 | <p>Repair the poor contact of manifold absolute pressure sensor connector.</p>   | <p>Replace the manifold absolute pressure sensor. &lt;Ref. to FU(H4DO(HEV))-66, Manifold Absolute Pressure Sensor.&gt;</p>   |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

## AE:DTC P0111 INTAKE AIR TEMPERATURE SENSOR RANGE/PERFORMANCE PROBLEM

### DTC DETECTING CONDITION:

- Detected when two consecutive driving cycles with fault occur.
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-39, DTC P0111 INTAKE AIR TEMPERATURE SENSOR RANGE/PERFORMANCE PROBLEM, Diagnostic Trouble Code (DTC) Detecting Criteria.>

### TROUBLE SYMPTOM:



- Improper idling
- Poor driving performance

### CAUTION:

After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.

### WIRING DIAGRAM:

- Engine electrical system (without push button start) <Ref. to WI(HEV)-100, WITHOUT PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>
- Engine electrical system (with push button start) <Ref. to WI(HEV)-114, WITH PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>



EN-10742

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step   | Check   | Yes   | No  |
|--|---|---|---|
| <b>1</b><br><b>CHECK FOR ANY OTHER DTC ON DISPLAY.</b>   | Is any other DTC displayed?   | Check the appropriate DTC using the "List of Diagnostic Trouble Code (DTC)".<br><Ref. to EN(H4DO HEV)(diag)-92, List of Diagnostic Trouble Code (DTC).> | Go to step 2.   |
| <b>2</b><br><b>CHECK MASS AIR FLOW AND INTAKE AIR TEMPERATURE SENSOR.</b><br>1) Disconnect the connectors from the mass air flow and intake air temperature sensor.<br>2) Measure the resistance between mass air flow and intake air temperature sensor terminals when the engine coolant is cold and after warmed up.<br><b>Terminals</b><br><b>No. 1 — No. 2:</b> | Is the resistance of mass air flow and intake air temperature sensor different between when engine coolant is cold and after warmed up? | Repair the poor contact of ECM connector.   | Replace the mass air flow and intake air temperature sensor. <Ref. to FU(H4DO(HEV))-63, Mass Air Flow and Intake Air Temperature Sensor.> |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

## AF:DTC P0112 INTAKE AIR TEMPERATURE SENSOR 1 CIRCUIT LOW

### DTC DETECTING CONDITION:

- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-42, DTC P0112 INTAKE AIR TEMPERATURE SENSOR 1 CIRCUIT LOW, Diagnostic Trouble Code (DTC) Detecting Criteria.>

### TROUBLE SYMPTOM:


- Improper idling
- Poor driving performance

### CAUTION:

After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.

### WIRING DIAGRAM:

- Engine electrical system (without push button start) <Ref. to WI(HEV)-100, WITHOUT PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>
- Engine electrical system (with push button start) <Ref. to WI(HEV)-114, WITH PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>



EN-10742

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step   | Check  | Yes  | No  |
|--|--|--|---|
| <p><b>1</b></p> <p><b>CHECK CURRENT DATA.</b></p> <p>1) Start the engine.</p> <p>2) Read the value of «Intake Air Temp.» using the Subaru Select Monitor or a general scan tool.</p> <p>NOTE:</p> <ul style="list-style-type: none"> <li>• Subaru Select Monitor</li> </ul> <p>For detailed operation procedures, refer to “Current Data Display For Engine”. &lt;Ref. to EN(H4DO HEV)(diag)-36, Subaru Select Monitor.&gt;</p> <ul style="list-style-type: none"> <li>• General scan tool</li> </ul> <p>For detailed operation procedures, refer to the general scan tool operation manual.</p> | <p>Is the value of «Intake Air Temp.» 120°C (248°F) or more?</p> | <p>Go to step 2.</p>   | <p>Even if DTC is detected, the circuit has returned to a normal condition at this time. Reproduce the failure, and then perform the diagnosis again.</p> <p>NOTE:</p> <p>In this case, temporary poor contact of connector, temporary open or short circuit of harness may be the cause.</p> |
| <p><b>2</b></p> <p><b>CHECK HARNESS BETWEEN ECM AND MASS AIR FLOW AND INTAKE AIR TEMPERATURE SENSOR CONNECTOR.</b></p> <p>1) Turn the ignition switch to OFF.</p> <p>2) Disconnect the connector from ECM and the mass air flow and intake air temperature sensor.</p> <p>3) Measure the resistance between ECM connector and chassis ground.</p> <p><b>Connector &amp; terminal</b><br/><b>(B137) No. 12 — Chassis ground:</b></p>  | <p>Is the resistance 1 MΩ or more?</p>                           | <p>Replace the mass air flow and intake air temperature sensor. &lt;Ref. to FU(H4DO(HEV))-63, Mass Air Flow and Intake Air Temperature Sensor.&gt;</p> | <p>Repair the ground short circuit of harness between ECM connector and the mass air flow and intake air temperature sensor connector.</p>  |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

## AG:DTC P0113 INTAKE AIR TEMPERATURE SENSOR 1 CIRCUIT HIGH

### DTC DETECTING CONDITION:

- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-43, DTC P0113 INTAKE AIR TEMPERATURE SENSOR 1 CIRCUIT HIGH, Diagnostic Trouble Code (DTC) Detecting Criteria.>

### TROUBLE SYMPTOM:



- Improper idling
- Poor driving performance

### CAUTION:

After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.

### WIRING DIAGRAM:

- Engine electrical system (without push button start) <Ref. to WI(HEV)-100, WITHOUT PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>
- Engine electrical system (with push button start) <Ref. to WI(HEV)-114, WITH PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>



EN-10742

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

|   | Step   | Check  | Yes  | No   |
|---|--|--|--|--|
| 1 | <p><b>CHECK CURRENT DATA.</b></p> <p>1) Start the engine.</p> <p>2) Read the value of «Intake Air Temp.» using the Subaru Select Monitor or a general scan tool.</p> <p>NOTE:</p> <ul style="list-style-type: none"> <li>Subaru Select Monitor</li> </ul> <p>For detailed operation procedures, refer to “Current Data Display For Engine”. &lt;Ref. to EN(H4DO HEV)(diag)-36, Subaru Select Monitor.&gt;</p> <ul style="list-style-type: none"> <li>General scan tool</li> </ul> <p>For detailed operation procedures, refer to the general scan tool operation manual.</p> | Is the value of «Intake Air Temp.» -40°C (-40°F) or less?                                  | Go to step 2.  | <p>Even if DTC is detected, the circuit has returned to a normal condition at this time. Reproduce the failure, and then perform the diagnosis again.</p> <p>NOTE:</p> <p>In this case, temporary poor contact of connector, temporary open or short circuit of harness may be the cause.</p>                    |
| 2 | <p><b>CHECK FOR POOR CONTACT.</b></p> <p>Check for poor contact of ECM and mass air flow and intake air temperature sensor connector.</p>  | Is there poor contact of ECM or mass air flow and intake air temperature sensor connector? | Repair the poor contact of ECM or mass air flow and intake air temperature sensor connector.   | Go to step 3.  |
| 3 | <p><b>CHECK HARNESS BETWEEN ECM AND MASS AIR FLOW AND INTAKE AIR TEMPERATURE SENSOR CONNECTOR.</b></p> <p>1) Turn the ignition switch to OFF.</p> <p>2) Disconnect the connector from ECM and the mass air flow and intake air temperature sensor.</p> <p>3) Measure the resistance of harness between ECM connector and the mass air flow and intake air temperature sensor connector.</p> <p><b>Connector &amp; terminal</b></p> <p><b>(B137) No. 12 — (B3) No. 1:</b></p> <p><b>(B135) No. 30 — (B3) No. 2:</b></p>   | Is the resistance less than 1 Ω?   | Go to step 4.  | <p>Repair the harness and connector.</p> <p>NOTE:</p> <p>In this case, repair the following item:</p> <ul style="list-style-type: none"> <li>Open circuit in harness between ECM connector and the mass air flow and intake air temperature sensor connector</li> <li>Poor contact of joint connector</li> </ul> |
| 4 | <p><b>CHECK HARNESS BETWEEN ECM AND MASS AIR FLOW AND INTAKE AIR TEMPERATURE SENSOR CONNECTOR.</b></p> <p>1) Connect all connectors.</p> <p>2) Turn the ignition switch to ON.</p> <p>3) Measure the voltage between ECM connector and chassis ground.</p> <p><b>Connector &amp; terminal</b></p> <p><b>(B137) No. 12 (+) — Chassis ground (-):</b></p>  | Is the voltage 5 V or more?  | Repair the short circuit of harness to power supply between ECM connector and the mass air flow and intake air temperature sensor connector. | Replace the mass air flow and intake air temperature sensor. <Ref. to FU(H4DO(HEV))-63, Mass Air Flow and Intake Air Temperature Sensor.>  |

## Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

---

### **AH:DTC P0116 ENGINE COOLANT TEMPERATURE SENSOR 1 CIRCUIT RANGE/PERFORMANCE**

#### **DTC DETECTING CONDITION:**

- Detected when two consecutive driving cycles with fault occur.
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-44, DTC P0116 ENGINE COOLANT TEMPERATURE SENSOR 1 CIRCUIT RANGE/PERFORMANCE, Diagnostic Trouble Code (DTC) Detecting Criteria.>

#### **TROUBLE SYMPTOM:**

- Hard to start
- Improper idling
- Poor driving performance

#### **CAUTION:**


After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

## WIRING DIAGRAM:

- Engine electrical system (without push button start) <Ref. to WI(HEV)-100, WITHOUT PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>
- Engine electrical system (with push button start) <Ref. to WI(HEV)-114, WITH PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>



|   | Step                                       | Check                       | Yes   | No            |
|---|--|-----------------------------|---|---------------|
| 1 | <b>CHECK FOR ANY OTHER DTC ON DISPLAY.</b> | Is any other DTC displayed? | Check the appropriate DTC using the "List of Diagnostic Trouble Code (DTC)".<br><Ref. to EN(H4DO HEV)(diag)-92, List of Diagnostic Trouble Code (DTC).> | Go to step 2. |

## Diagnostic Procedure with Diagnostic Trouble Code (DTC)

### ENGINE (DIAGNOSTICS)

| Step   | Check   | Yes                                       | No  |
|--|---|---|---|
| <b>2</b><br><b>CHECK ENGINE COOLANT TEMPERATURE SENSOR.</b><br>1) Disconnect the connectors from the engine coolant temperature sensor.<br>2) Measure the resistance between engine coolant temperature sensor terminals when the engine coolant is cold and after warmed up.<br><b>Terminals</b><br><b>No. 1 — No. 2:</b> | Is the resistance of engine coolant temperature sensor different between when engine coolant is cold and after warmed up? | Repair the poor contact of ECM connector. | Replace the engine coolant temperature sensor. <Ref. to FU(H4DO(HEV))-41, Engine Coolant Temperature Sensor.> |

## AI: DTC P0117 ENGINE COOLANT TEMPERATURE CIRCUIT LOW

### DTC DETECTING CONDITION:

- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-46, DTC P0117 ENGINE COOLANT TEMPERATURE CIRCUIT LOW, Diagnostic Trouble Code (DTC) Detecting Criteria.>

### TROUBLE SYMPTOM:




- Hard to start
- Improper idling
- Poor driving performance

### CAUTION:

After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.

### WIRING DIAGRAM:

- Engine electrical system (without push button start) <Ref. to WI(HEV)-100, WITHOUT PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>
- Engine electrical system (with push button start) <Ref. to WI(HEV)-114, WITH PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>



# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

## ENGINE (DIAGNOSTICS)

|   | Step  | Check  | Yes   | No  |
|---|---|--|---|---|
| 1 | <p><b>CHECK CURRENT DATA.</b></p> <p>1) Start the engine.</p> <p>2) Read the value of «Coolant Temp.» using the Subaru Select Monitor or a general scan tool.</p> <p>NOTE:</p> <ul style="list-style-type: none"> <li>• Subaru Select Monitor</li> </ul> <p>For detailed operation procedures, refer to “Current Data Display For Engine”. &lt;Ref. to EN(H4DO HEV)(diag)-36, Subaru Select Monitor.&gt;</p> <ul style="list-style-type: none"> <li>• General scan tool</li> </ul> <p>For detailed operation procedures, refer to the general scan tool operation manual.</p> | Is the value of «Coolant Temp.» 120°C (248°F) or more? | Go to step 2.   | <p>Even if DTC is detected, the circuit has returned to a normal condition at this time. Reproduce the failure, and then perform the diagnosis again.</p> <p>NOTE:</p> <p>In this case, temporary poor contact of connector, temporary open or short circuit of harness may be the cause.</p> |
| 2 | <p><b>CHECK HARNESS BETWEEN ECM AND ENGINE COOLANT TEMPERATURE SENSOR CONNECTOR.</b></p> <p>1) Turn the ignition switch to OFF.</p> <p>2) Disconnect the connectors from ECM and engine coolant temperature sensor.</p> <p>3) Measure the resistance between ECM connector and chassis ground.</p> <p><b>Connector &amp; terminal</b><br/><b>(B134) No. 30 — Chassis ground:</b></p>  | Is the resistance 1 MΩ or more?                        | Replace the engine coolant temperature sensor. <Ref. to FU(H4DO(HEV))-41, Engine Coolant Temperature Sensor.> | Repair the short circuit to ground in harness between ECM connector and engine coolant temperature sensor connector.  |

## AJ:DTC P0118 ENGINE COOLANT TEMPERATURE CIRCUIT HIGH

### DTC DETECTING CONDITION:

- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-47, DTC P0118 ENGINE COOLANT TEMPERATURE CIRCUIT HIGH, Diagnostic Trouble Code (DTC) Detecting Criteria.>

### TROUBLE SYMPTOM:


- Hard to start
- Improper idling
- Poor driving performance

### CAUTION:

**After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.**

### WIRING DIAGRAM:

- Engine electrical system (without push button start) <Ref. to WI(HEV)-100, WITHOUT PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>
- Engine electrical system (with push button start) <Ref. to WI(HEV)-114, WITH PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>



# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

## ENGINE (DIAGNOSTICS)

| Step  | Check   | Yes   | No  |
|---|---|---|---|
| <p><b>1 CHECK CURRENT DATA.</b></p> <p>1) Start the engine.</p> <p>2) Read the value of «Coolant Temp.» using the Subaru Select Monitor or a general scan tool.</p> <p>NOTE:</p> <ul style="list-style-type: none"> <li>Subaru Select Monitor</li> </ul> <p>For detailed operation procedures, refer to “Current Data Display For Engine”. &lt;Ref. to EN(H4DO HEV)(diag)-36, Subaru Select Monitor.&gt;</p> <ul style="list-style-type: none"> <li>General scan tool</li> </ul> <p>For detailed operation procedures, refer to the general scan tool operation manual.</p> | <p>Is the value of «Coolant Temp.» -40°C (-40°F) or less?</p>                       | <p>Go to step 2.</p>  | <p>Even if DTC is detected, the circuit has returned to a normal condition at this time. Reproduce the failure, and then perform the diagnosis again.</p> <p>NOTE:</p> <p>In this case, temporary poor contact of connector, temporary open or short circuit of harness may be the cause.</p>     |
| <p><b>2 CHECK FOR POOR CONTACT.</b></p> <p>Check for poor contact of ECM and engine coolant temperature sensor connector.</p>   | <p>Is there poor contact of ECM or engine coolant temperature sensor connector?</p> | <p>Repair the poor contact of ECM or engine coolant temperature sensor connector.</p>   | <p>Go to step 3.</p>  |
| <p><b>3 CHECK HARNESS BETWEEN ECM AND ENGINE COOLANT TEMPERATURE SENSOR CONNECTOR.</b></p> <p>1) Turn the ignition switch to OFF.</p> <p>2) Disconnect the connectors from ECM and engine coolant temperature sensor.</p> <p>3) Measure the resistance of harness between ECM connector and engine coolant temperature sensor connector.</p> <p><b>Connector &amp; terminal</b></p> <p><b>(B134) No. 29 — (E8) No. 1:</b></p> <p><b>(B134) No. 30 — (E8) No. 2:</b></p>   | <p>Is the resistance less than 1 Ω?</p>   | <p>Go to step 4.</p>  | <p>Repair the harness and connector.</p> <p>NOTE:</p> <p>In this case, repair the following item:</p> <ul style="list-style-type: none"> <li>Open circuit in harness between ECM connector and engine coolant temperature sensor connector</li> <li>Poor contact of coupling connector</li> </ul> |
| <p><b>4 CHECK HARNESS BETWEEN ECM AND ENGINE COOLANT TEMPERATURE SENSOR CONNECTOR.</b></p> <p>1) Connect all connectors.</p> <p>2) Turn the ignition switch to ON.</p> <p>3) Measure the voltage between ECM connector and chassis ground.</p> <p><b>Connector &amp; terminal</b></p> <p><b>(B134) No. 30 (+) — Chassis ground (-):</b></p>   | <p>Is the voltage 5 V or more?</p>  | <p>Repair the short circuit of harness to power supply between ECM connector and engine coolant temperature sensor connector.</p> | <p>Replace the engine coolant temperature sensor. &lt;Ref. to FU(H4DO(HEV))-41, Engine Coolant Temperature Sensor.&gt;</p>  |

## **AK:DTC P0122 THROTTLE/PEDAL POSITION SENSOR/SWITCH “A” CIRCUIT LOW**

### **DTC DETECTING CONDITION:**

- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-48, DTC P0122 THROTTLE/PEDAL POSITION SENSOR/SWITCH “A” CIRCUIT LOW, Diagnostic Trouble Code (DTC) Detecting Criteria.>

### **TROUBLE SYMPTOM:**

- Improper idling
- Engine stalls.
- Poor driving performance

### **CAUTION:**


**After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.**

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

## ENGINE (DIAGNOSTICS)

### WIRING DIAGRAM:

- Engine electrical system (without push button start) <Ref. to WI(HEV)-100, WITHOUT PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>
- Engine electrical system (with push button start) <Ref. to WI(HEV)-114, WITH PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>



| Step  | Check                                  | Yes                  | No   |
|---|--|----------------------|--|
| <p><b>1</b></p> <p><b>CHECK HARNESS BETWEEN ECM AND ELECTRONIC THROTTLE CONTROL CONNECTOR.</b></p> <p>1) Turn the ignition switch to OFF.</p> <p>2) Disconnect the connectors from ECM and electronic throttle control.</p> <p>3) Measure the resistance between ECM connector and chassis ground.</p> <p><b>Connector &amp; terminal</b></p> <p><b>(B134) No. 19 — Chassis ground:</b></p> <p><b>(B134) No. 18 — Chassis ground:</b></p> <p><b>(B134) No. 18 — (B137) No. 4:</b></p> | <p>Is the resistance 1 MΩ or more?</p> | <p>Go to step 2.</p> | <p>Repair the ground short circuit of harness between ECM connector and electronic throttle control connector.</p> |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step   | Check                                   | Yes   | No  |
|--|---|---|---|
| <b>2</b><br><b>CHECK SHORT CIRCUIT INSIDE THE ECM.</b><br>1) Connect the connector to ECM.<br>2) Measure the resistance between electronic throttle control connector and engine ground.<br><b>Connector &amp; terminal</b><br><b>(E57) No. 6 — Engine ground:</b> | Is the resistance 1 M $\Omega$ or more? | Replace the electronic throttle control. <Ref. to FU(H4DO(HEV))-14, Throttle Body.> | Repair the ground short circuit of harness between ECM connector and electronic throttle control connector.<br>Replace the ECM if defective. <Ref. to FU(H4DO(HEV))-85, Engine Control Module (ECM).> |

## Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

---

### **AL:DTC P0123 THROTTLE/PEDAL POSITION SENSOR/SWITCH “A” CIRCUIT HIGH**

#### **DTC DETECTING CONDITION:**

- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-49, DTC P0123 THROTTLE/PEDAL POSITION SENSOR/SWITCH “A” CIRCUIT HIGH, Diagnostic Trouble Code (DTC) Detecting Criteria.>

#### **TROUBLE SYMPTOM:**

- Improper idling
- Engine stalls.
- Poor driving performance

#### **CAUTION:**


After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)


ENGINE (DIAGNOSTICS)

## WIRING DIAGRAM:

- Engine electrical system (without push button start) <Ref. to WI(HEV)-100, WITHOUT PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>
- Engine electrical system (with push button start) <Ref. to WI(HEV)-114, WITH PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>



\* : TERMINAL No. OPTIONAL ARRANGEMENT



EN-10744

| Step  | Check                                   | Yes                  | No   |
|---|---|----------------------|--|
| <p><b>1</b></p> <p><b>CHECK HARNESS BETWEEN ECM AND ELECTRONIC THROTTLE CONTROL CONNECTOR.</b></p> <p>1) Turn the ignition switch to OFF.<br/>                 2) Disconnect the connectors from ECM and electronic throttle control.<br/>                 3) Measure the resistance of harness between ECM connector and electronic throttle control connector.</p> <p><b>Connector &amp; terminal</b><br/> <b>(B134) No. 18 — (E57) No. 6:</b><br/> <b>(B134) No. 29 — (E57) No. 3:</b></p> | <p>Is the resistance less than 1 Ω?</p> | <p>Go to step 2.</p> | <p>Repair the harness and connector.</p> <p><b>NOTE:</b><br/>                 In this case, repair the following item:</p> <ul style="list-style-type: none"> <li>• Open circuit in harness between ECM connector and electronic throttle control connector</li> <li>• Poor contact of coupling connector</li> </ul> |

## Diagnostic Procedure with Diagnostic Trouble Code (DTC)

### ENGINE (DIAGNOSTICS)

| Step   | Check                                    | Yes  | No   |
|--|--|--|--|
| <b>2</b><br><b>CHECK HARNESS BETWEEN ECM AND ELECTRONIC THROTTLE CONTROL CONNECTOR.</b><br>1) Connect the connector to ECM.<br>2) Measure the resistance between electronic throttle control connector and engine ground.<br><b>Connector &amp; terminal</b><br><b>(E57) No. 3 — Engine ground:</b>        | Is the resistance less than 5 $\Omega$ ? | Go to step 3.  | Repair the harness and connector.<br>NOTE:<br>In this case, repair the following item:<br>• Open circuit of harness between ECM connector and engine ground<br>• Poor contact of ECM connector<br>• Poor contact of coupling connector |
| <b>3</b><br><b>CHECK HARNESS BETWEEN ECM AND ELECTRONIC THROTTLE CONTROL CONNECTOR.</b><br>1) Turn the ignition switch to ON.<br>2) Measure the voltage between electronic throttle control connector and engine ground.<br><b>Connector &amp; terminal</b><br><b>(E57) No. 6 (+) — Engine ground (-):</b> | Is the voltage 5 V or more?              | Repair the short circuit to power in the harness between ECM connector and electronic throttle control connector.  | Go to step 4.  |
| <b>4</b><br><b>CHECK HARNESS BETWEEN ECM AND ELECTRONIC THROTTLE CONTROL CONNECTOR.</b><br>1) Turn the ignition switch to OFF.<br>2) Disconnect the connector from ECM.<br>3) Measure the resistance between ECM connectors.<br><b>Connector &amp; terminal</b><br><b>(B134) No. 19 — (B134) No. 18:</b>   | Is the resistance 1 M $\Omega$ or more?  | Repair the poor contact of electronic throttle control connector.<br>Replace the electronic throttle control if defective.<br><Ref. to FU(H4DO(HEV))-14, Throttle Body.> | Repair the short circuit to power in the harness between ECM connector and electronic throttle control connector.  |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

## AM:DTC P0125 INSUFFICIENT COOLANT TEMPERATURE FOR CLOSED LOOP FUEL CONTROL

### DTC DETECTING CONDITION:

- Detected when two consecutive driving cycles with fault occur.
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-50, DTC P0125 INSUFFICIENT COOLANT TEMPERATURE FOR CLOSED LOOP FUEL CONTROL, Diagnostic Trouble Code (DTC) Detecting Criteria.>

### TROUBLE SYMPTOM:

Engine does not return to idle.

### CAUTION:

After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.

| Step   | Check  | Yes   | No  |
|--|--|---|---|
| 1<br><b>CHECK TIRE SIZE.</b>   | Is the tire size as specified and the same size as three other wheels? | Go to step 2.   | Replace the tire.   |
| 2<br><b>CHECK ENGINE COOLANT.</b><br>Check the following items: <ul style="list-style-type: none"><li>• Amount of engine coolant</li><li>• Engine coolant freeze</li><li>• Contamination of engine coolant</li></ul> | Is the engine coolant normal?  | Go to step 3.   | Fill or replace the engine coolant. <Ref. to CO(H4DO(w/o HEV))-16, REPLACEMENT, Engine Coolant.>              |
| 3<br><b>CHECK THERMOSTAT.</b>  | Does the thermostat remain opened?                                     | Replace the thermostat. <Ref. to CO(H4DO(w/o HEV))-64, Thermostat.> | Replace the engine coolant temperature sensor. <Ref. to FU(H4DO(HEV))-41, Engine Coolant Temperature Sensor.> |

## Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

### AN:DTC P0128 COOLANT THERMOSTAT (ENGINE COOLANT TEMPERATURE BELOW THERMOSTAT REGULATING TEMPERATURE)

**DTC DETECTING CONDITION:**

- Detected when two consecutive driving cycles with fault occur.
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-51, DTC P0128 COOLANT THERMOSTAT (ENGINE COOLANT TEMPERATURE BELOW THERMOSTAT REGULATING TEMPERATURE), Diagnostic Trouble Code (DTC) Detecting Criteria.>

**TROUBLE SYMPTOM:**

Thermostat remains open.

**CAUTION:**

After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.

| Step   | Check  | Yes   | No   |
|--|--|---|--|
| <b>1</b><br><b>CHECK FOR ANY OTHER DTC ON DISPLAY.</b>   | Is any other DTC displayed?  | Check the appropriate DTC using the "List of Diagnostic Trouble Code (DTC)". <Ref. to EN(H4DO HEV)(diag)-92, List of Diagnostic Trouble Code (DTC).>              | Go to step 2.  |
| <b>2</b><br><b>CHECK ENGINE COOLANT.</b>   | Is the engine coolant amount normal?   | Go to step 3.   | Refill the engine coolant. <Ref. to CO(H4DO(w/o HEV))-16, Engine Coolant.> |
| <b>3</b><br><b>CHECK RADIATOR FAN.</b><br>1) Start the engine.<br>2) Check the radiator fan operation. | Does the radiator fan continuously rotate for 3 minutes or more during idling? | Repair radiator fan circuit. <Ref. to CO(H4DO(w/o HEV))-89, Radiator Main Fan and Fan Motor.> and <Ref. to CO(H4DO(w/o HEV))-93, Radiator Sub Fan and Fan Motor.> | Replace the thermostat. <Ref. to CO(H4DO(w/o HEV))-64, Thermostat.>        |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

## AO:DTC P0131 O2 SENSOR CIRCUIT LOW VOLTAGE (BANK 1 SENSOR 1)

### DTC DETECTING CONDITION:


- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-54, DTC P0131 O2 SENSOR CIRCUIT LOW VOLTAGE (BANK 1 SENSOR 1), Diagnostic Trouble Code (DTC) Detecting Criteria.>

### CAUTION:

After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.

### WIRING DIAGRAM:

- Engine electrical system (without push button start) <Ref. to WI(HEV)-100, WITHOUT PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>
- Engine electrical system (with push button start) <Ref. to WI(HEV)-114, WITH PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>



EN-10739

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step   | Check   | Yes   | No   |
|--|---|---|--|
| <b>1</b><br><b>CHECK FRONT OXYGEN (A/F) SENSOR CONNECTOR AND COUPLING CONNECTOR.</b>   | Has water entered the connector?                              | Completely remove any water inside.                             | Go to step 2.  |
| <b>2</b><br><b>CHECK HARNESS BETWEEN ECM AND FRONT OXYGEN (A/F) SENSOR CONNECTOR.</b><br>1) Turn the ignition switch to OFF.<br>2) Disconnect the connectors from ECM and front oxygen (A/F) sensor.<br>3) Measure the resistance between ECM connector and chassis ground.<br><b>Connector &amp; terminal</b><br><b>(B136) No. 18 — Chassis ground:</b><br><b>(B136) No. 19 — Chassis ground:</b> | Is the resistance 1 MΩ or more?                               | Go to step 3.   | Repair the short circuit to ground in harness between ECM connector and front oxygen (A/F) sensor connector. |
| <b>3</b><br><b>CHECK FOR POOR CONTACT.</b><br>Check for poor contact of the front oxygen (A/F) sensor connector.   | Is there poor contact of front oxygen (A/F) sensor connector? | Repair the poor contact of front oxygen (A/F) sensor connector. | Replace the front oxygen (A/F) sensor. <Ref. to FU(H4DO(HEV))-78, Front Oxygen (A/F) Sensor.>                |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

## AP:DTC P0132 O2 SENSOR CIRCUIT HIGH VOLTAGE (BANK 1 SENSOR 1)

### DTC DETECTING CONDITION:


- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-55, DTC P0132 O2 SENSOR CIRCUIT HIGH VOLTAGE (BANK 1 SENSOR 1), Diagnostic Trouble Code (DTC) Detecting Criteria.>

### CAUTION:

After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.

### WIRING DIAGRAM:

- Engine electrical system (without push button start) <Ref. to WI(HEV)-100, WITHOUT PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>
- Engine electrical system (with push button start) <Ref. to WI(HEV)-114, WITH PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>



EN-10739

## Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step  | Check                            | Yes   | No  |
|---|----------------------------------|---|---|
| <b>1</b><br><b>CHECK FRONT OXYGEN (A/F) SENSOR CONNECTOR AND COUPLING CONNECTOR.</b>  | Has water entered the connector? | Completely remove any water inside.   | Go to step 2.   |
| <b>2</b><br><b>CHECK HARNESS BETWEEN ECM AND FRONT OXYGEN (A/F) SENSOR CONNECTOR.</b><br>1) Turn the ignition switch to OFF.<br>2) Disconnect the connectors from front oxygen (A/F) sensor.<br>3) Turn the ignition switch to ON.<br>4) Measure the voltage between ECM connector and chassis ground.<br><b>Connector &amp; terminal</b><br><b>(B136) No. 18 (+) — Chassis ground (-):</b><br><b>(B136) No. 19 (+) — Chassis ground (-):</b> | Is the voltage 8 V or more?      | Repair the short circuit to power in the harness between ECM connector and front oxygen (A/F) sensor connector. | Replace the front oxygen (A/F) sensor. <Ref. to FU(H4DO(HEV))-78, Front Oxygen (A/F) Sensor.> |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

## AQ:DTC P0134 O2 SENSOR CIRCUIT NO ACTIVITY DETECTED (BANK 1 SENSOR 1)

### DTC DETECTING CONDITION:


- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-56, DTC P0134 O2 SENSOR CIRCUIT NO ACTIVITY DETECTED (BANK 1 SENSOR 1), Diagnostic Trouble Code (DTC) Detecting Criteria.>

### CAUTION:

After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.

### WIRING DIAGRAM:

- Engine electrical system (without push button start) <Ref. to WI(HEV)-100, WITHOUT PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>
- Engine electrical system (with push button start) <Ref. to WI(HEV)-114, WITH PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>



EN-10739

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step   | Check   | Yes   | No  |
|--|---|---|---|
| <p><b>1</b>     <b>CHECK HARNESS BETWEEN ECM AND FRONT OXYGEN (A/F) SENSOR CONNECTOR.</b></p> <p>1) Turn the ignition switch to OFF.<br/>           2) Disconnect the connectors from ECM and front oxygen (A/F) sensor.<br/>           3) Measure the resistance of harness between ECM connector and front oxygen (A/F) sensor connector.</p> <p><b>Connector &amp; terminal</b><br/> <b>(B136) No. 19 — (E24) No. 3:</b><br/> <b>(B136) No. 18 — (E24) No. 4:</b></p> | <p>Is the resistance less than 1 Ω?</p>                                     | <p>Go to step 2.</p>  | <p>Repair the harness and connector.</p> <p>NOTE:<br/>           In this case, repair the following item:</p> <ul style="list-style-type: none"> <li>• Open circuit in harness between ECM connector and front oxygen (A/F) sensor connector</li> <li>• Poor contact of coupling connector</li> </ul> |
| <p><b>2</b>     <b>CHECK FOR POOR CONTACT.</b><br/>           Check for poor contact of ECM and front oxygen (A/F) sensor connector.</p>   | <p>Is there poor contact of ECM or front oxygen (A/F) sensor connector?</p> | <p>Repair the poor contact of ECM or front oxygen (A/F) sensor connector.</p> | <p>Replace the front oxygen (A/F) sensor. &lt;Ref. to FU(H4DO(HEV))-78, Front Oxygen (A/F) Sensor.&gt;</p>  |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

## AR:DTC P0137 O2 SENSOR CIRCUIT LOW VOLTAGE (BANK 1 SENSOR 2)

### DTC DETECTING CONDITION:


- Detected when two consecutive driving cycles with fault occur.
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-57, DTC P0137 O2 SENSOR CIRCUIT LOW VOLTAGE (BANK 1 SENSOR 2), Diagnostic Trouble Code (DTC) Detecting Criteria.>

### CAUTION:

After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.

### WIRING DIAGRAM:

- Engine electrical system (without push button start) <Ref. to WI(HEV)-100, WITHOUT PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>
- Engine electrical system (with push button start) <Ref. to WI(HEV)-114, WITH PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>



EN-10740

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

## ENGINE (DIAGNOSTICS)

| Step  | Check   | Yes   | No   |
|---|---|---|--|
| <p><b>1 CHECK REAR OXYGEN SENSOR DATA.</b><br/>                     1) Warm up the engine until engine coolant temperature is higher than 75°C (167°F), and keep the engine speed at 3,000 rpm. (2 minutes maximum)<br/>                     2) Read the value of «Oxygen sensor #12» using the Subaru Select Monitor or a general scan tool.<br/>                     NOTE:<br/>                     • Subaru Select Monitor<br/>                     For detailed operation procedures, refer to “Current Data Display For Engine”. &lt;Ref. to EN(H4DO HEV)(diag)-36, Subaru Select Monitor.&gt;<br/>                     • General scan tool<br/>                     For detailed operation procedures, refer to the general scan tool operation manual.</p> | <p>Is the value of «Oxygen sensor #12» 0.490 V or more?</p> | <p>Go to step 5.</p>  | <p>Go to step 2.</p>   |
| <p><b>2 CHECK REAR OXYGEN SENSOR CONNECTOR AND COUPLING CONNECTOR.</b></p>  | <p>Has water entered the connector?</p>                     | <p>Completely remove any water inside.</p>  | <p>Go to step 3.</p>   |
| <p><b>3 CHECK HARNESS BETWEEN ECM AND REAR OXYGEN SENSOR CONNECTOR.</b><br/>                     1) Turn the ignition switch to OFF.<br/>                     2) Disconnect the connector from ECM and rear oxygen sensor.<br/>                     3) Measure the resistance of harness between ECM connector and rear oxygen sensor connector.<br/> <i>Connector &amp; terminal</i><br/> <i>(B136) No. 21 — (E25) No. 3:</i><br/> <i>(B135) No. 30 — (E25) No. 4:</i></p>   | <p>Is the resistance less than 1 Ω?</p>                     | <p>Go to step 4.</p>  | <p>Repair the harness and connector.<br/>                     NOTE:<br/>                     In this case, repair the following item:<br/>                     • Open circuit in harness between ECM connector and rear oxygen sensor connector<br/>                     • Poor contact of coupling connector</p>  |
| <p><b>4 CHECK HARNESS BETWEEN ECM AND REAR OXYGEN SENSOR CONNECTOR.</b><br/>                     1) Connect the connector to ECM.<br/>                     2) Turn the ignition switch to ON.<br/>                     3) Measure the voltage between rear oxygen sensor connector and chassis ground.<br/> <i>Connector &amp; terminal</i><br/> <i>(E25) No. 3 (+) — Chassis ground (-):</i></p>   | <p>Is the voltage 0.2 — 0.5 V?</p>                          | <p>Replace the rear oxygen sensor.<br/>                     &lt;Ref. to FU(H4DO(HEV))-82, Rear Oxygen Sensor.&gt;</p> | <p>Repair the harness and connector.<br/>                     NOTE:<br/>                     In this case, repair the following item:<br/>                     • Open circuit in harness between ECM connector and rear oxygen sensor connector<br/>                     • Poor contact of coupling connector<br/>                     • Poor contact of ECM connector</p> |
| <p><b>5 CHECK EXHAUST SYSTEM.</b><br/>                     Check exhaust system parts.<br/>                     NOTE:<br/>                     Check the following items.<br/>                     • Looseness and improper fitting of exhaust system parts<br/>                     • Damage (crack, hole etc.) of parts<br/>                     • Loose part and improper installation between front oxygen (A/F) sensor and rear oxygen sensor</p>  | <p>Is there any fault in exhaust system?</p>                | <p>Repair or replace faulty parts.</p>  | <p>Replace the rear oxygen sensor.<br/>                     &lt;Ref. to FU(H4DO(HEV))-82, Rear Oxygen Sensor.&gt;</p>  |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

## AS:DTC P0138 O2 SENSOR CIRCUIT HIGH VOLTAGE (BANK 1 SENSOR 2)

### DTC DETECTING CONDITION:


- Detected when two consecutive driving cycles with fault occur.
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-58, DTC P0138 O2 SENSOR CIRCUIT HIGH VOLTAGE (BANK 1 SENSOR 2), Diagnostic Trouble Code (DTC) Detecting Criteria.>

### CAUTION:

After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.

### WIRING DIAGRAM:

- Engine electrical system (without push button start) <Ref. to WI(HEV)-100, WITHOUT PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>
- Engine electrical system (with push button start) <Ref. to WI(HEV)-114, WITH PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>



EN-10740

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

## ENGINE (DIAGNOSTICS)

| Step  | Check   | Yes   | No   |
|---|---|---|--|
| <p><b>1 CHECK REAR OXYGEN SENSOR DATA.</b><br/>                     1) Warm up the engine until engine coolant temperature is higher than 75°C (167°F), and rapidly reduce the engine speed from 3,000 rpm.<br/>                     2) Read the value of «Oxygen sensor #12» using the Subaru Select Monitor or a general scan tool.<br/>                     NOTE:<br/>                     • Subaru Select Monitor<br/>                     For detailed operation procedures, refer to “Current Data Display For Engine”. &lt;Ref. to EN(H4DO HEV)(diag)-36, Subaru Select Monitor.&gt;<br/>                     • General scan tool<br/>                     For detailed operation procedures, refer to the general scan tool operation manual.</p> | <p>Is the value of «Oxygen sensor #12» 0.250 V or less?</p> | <p>Go to step 5.</p>  | <p>Go to step 2.</p>   |
| <p><b>2 CHECK REAR OXYGEN SENSOR CONNECTOR AND COUPLING CONNECTOR.</b></p>  | <p>Has water entered the connector?</p>                     | <p>Completely remove any water inside.</p>  | <p>Go to step 3.</p>   |
| <p><b>3 CHECK HARNESS BETWEEN ECM AND REAR OXYGEN SENSOR CONNECTOR.</b><br/>                     1) Turn the ignition switch to OFF.<br/>                     2) Disconnect the connector from ECM and rear oxygen sensor.<br/>                     3) Measure the resistance of harness between ECM connector and rear oxygen sensor connector.<br/> <i>Connector &amp; terminal</i><br/> <i>(B136) No. 21 — (E25) No. 3:</i><br/> <i>(B135) No. 30 — (E25) No. 4:</i></p>   | <p>Is the resistance less than 1 Ω?</p>                     | <p>Go to step 4.</p>  | <p>Repair the harness and connector.<br/>                     NOTE:<br/>                     In this case, repair the following item:<br/>                     • Open circuit in harness between ECM connector and rear oxygen sensor connector<br/>                     • Poor contact of coupling connector</p>  |
| <p><b>4 CHECK HARNESS BETWEEN ECM AND REAR OXYGEN SENSOR CONNECTOR.</b><br/>                     1) Connect the connector to ECM.<br/>                     2) Turn the ignition switch to ON.<br/>                     3) Measure the voltage between rear oxygen sensor connector and chassis ground.<br/> <i>Connector &amp; terminal</i><br/> <i>(E25) No. 3 (+) — Chassis ground (-):</i></p>   | <p>Is the voltage 0.2 — 0.5 V?</p>                          | <p>Replace the rear oxygen sensor.<br/>                     &lt;Ref. to FU(H4DO(HEV))-82, Rear Oxygen Sensor.&gt;</p> | <p>Repair the harness and connector.<br/>                     NOTE:<br/>                     In this case, repair the following item:<br/>                     • Open circuit in harness between ECM connector and rear oxygen sensor connector<br/>                     • Poor contact of coupling connector<br/>                     • Poor contact of ECM connector</p> |
| <p><b>5 CHECK EXHAUST SYSTEM.</b><br/>                     Check exhaust system parts.<br/>                     NOTE:<br/>                     Check the following items.<br/>                     • Looseness and improper fitting of exhaust system parts<br/>                     • Damage (crack, hole etc.) of parts<br/>                     • Loose part and improper installation between front oxygen (A/F) sensor and rear oxygen sensor</p>  | <p>Is there any fault in exhaust system?</p>                | <p>Repair or replace faulty parts.</p>  | <p>Replace the rear oxygen sensor.<br/>                     &lt;Ref. to FU(H4DO(HEV))-82, Rear Oxygen Sensor.&gt;</p>  |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

## AT:DTC P013A O2 SENSOR SLOW RESPONSE - RICH TO LEAN (BANK 1 SENSOR 2)

### DTC DETECTING CONDITION:


- Detected when two consecutive driving cycles with fault occur.
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-59, DTC P013A O2 SENSOR SLOW RESPONSE - RICH TO LEAN (BANK 1 SENSOR 2), Diagnostic Trouble Code (DTC) Detecting Criteria.>

### CAUTION:

After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.

### WIRING DIAGRAM:

- Engine electrical system (without push button start) <Ref. to WI(HEV)-100, WITHOUT PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>
- Engine electrical system (with push button start) <Ref. to WI(HEV)-114, WITH PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>



EN-10740

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step  | Check                                   | Yes  | No  |
|---|---|--|---|
| <p><b>1</b></p> <p><b>CHECK HARNESS BETWEEN ECM AND REAR OXYGEN SENSOR CONNECTOR.</b></p> <p>1) Turn the ignition switch to OFF.<br/>2) Disconnect the connector from ECM and rear oxygen sensor.<br/>3) Measure the resistance of harness between ECM connector and rear oxygen sensor connector.</p> <p><b>Connector &amp; terminal</b><br/><b>(B136) No. 21 — (E25) No. 3:</b></p> | <p>Is the resistance less than 1 Ω?</p> | <p>Go to step 2.</p>   | <p>Repair the harness and connector.</p> <p><b>NOTE:</b><br/>In this case, repair the following item:</p> <ul style="list-style-type: none"> <li>• Open circuit in harness between ECM connector and rear oxygen sensor connector</li> <li>• Poor contact of coupling connector</li> </ul>        |
| <p><b>2</b></p> <p><b>CHECK HARNESS BETWEEN ECM AND REAR OXYGEN SENSOR CONNECTOR.</b></p> <p>Measure the resistance between rear oxygen sensor connector and chassis ground.</p> <p><b>Connector &amp; terminal</b><br/><b>(E25) No. 3 — Chassis ground:</b></p>  | <p>Is the resistance 1 MΩ or more?</p>  | <p>Go to step 3.</p>   | <p>Repair the short circuit to ground in harness between ECM connector and rear oxygen sensor connector.</p>  |
| <p><b>3</b></p> <p><b>CHECK REAR OXYGEN SENSOR.</b></p> <p>Measure the resistance between rear oxygen sensor terminals.</p> <p><b>Terminals</b><br/><b>No. 3 — No. 4</b></p>  | <p>Is the resistance less than 1 Ω?</p> | <p>Replace the rear oxygen sensor.<br/>&lt;Ref. to FU(H4DO(HEV))-82, Rear Oxygen Sensor.&gt;</p> | <p>Even if DTC is detected, the circuit has returned to a normal condition at this time. Reproduce the failure, and then perform the diagnosis again.</p> <p><b>NOTE:</b><br/>In this case, temporary poor contact of connector, temporary open or short circuit of harness may be the cause.</p> |

## **AU:DTC P013B O2 SENSOR SLOW RESPONSE - LEAN TO RICH (BANK 1 SENSOR 2)**

**NOTE:**

For the diagnostic procedure, refer to DTC P013A. <Ref. to EN(H4DO HEV)(diag)-179, DTC P013A O2 SENSOR SLOW RESPONSE - RICH TO LEAN (BANK 1 SENSOR 2), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

## **AV:DTC P013E O2 SENSOR DELAYED RESPONSE - RICH TO LEAN (BANK 1 SENSOR 2)**

**NOTE:**

For the diagnostic procedure, refer to DTC P013A. <Ref. to EN(H4DO HEV)(diag)-179, DTC P013A O2 SENSOR SLOW RESPONSE - RICH TO LEAN (BANK 1 SENSOR 2), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

## **AW:DTC P013F O2 SENSOR DELAYED RESPONSE - LEAN TO RICH (BANK 1 SENSOR 2)**

**NOTE:**

For the diagnostic procedure, refer to DTC P013A. <Ref. to EN(H4DO HEV)(diag)-179, DTC P013A O2 SENSOR SLOW RESPONSE - RICH TO LEAN (BANK 1 SENSOR 2), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

## **AX:DTC P0141 O2 SENSOR HEATER CIRCUIT (BANK1 SENSOR2)**

Refer to DTC P0037 for diagnostic procedure. <Ref. to EN(H4DO HEV)(diag)-131, DTC P0037 HO2S HEATER CONTROL CIRCUIT LOW (BANK 1 SENSOR 2), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

## AY:DTC P014C O2 SENSOR SLOW RESPONSE - RICH TO LEAN (BANK 1 SENSOR 1)

### DTC DETECTING CONDITION:

- Detected when two consecutive driving cycles with fault occur.
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-68, DTC P014C O2 SENSOR SLOW RESPONSE - RICH TO LEAN (BANK 1 SENSOR 1), Diagnostic Trouble Code (DTC) Detecting Criteria.>

### CAUTION:

After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.

| Step  | Check                                 | Yes                        | No  |
|---|---------------------------------------|----------------------------|---|
| 1<br><b>CHECK EXHAUST SYSTEM.</b><br>NOTE:<br>Check the following items. <ul style="list-style-type: none"><li>• Loose installation of front portion of exhaust pipe onto cylinder heads</li><li>• Loose connection between front exhaust pipe and front catalytic converter</li><li>• Damage of exhaust pipe resulting in a hole</li></ul> | Is there any fault in exhaust system? | Repair the exhaust system. | Replace the front oxygen (A/F) sensor. <Ref. to FU(H4DO(HEV))-78, Front Oxygen (A/F) Sensor.> |

## AZ:DTC P014D O2 SENSOR SLOW RESPONSE - LEAN TO RICH (BANK 1 SENSOR 1)

### NOTE:

For the diagnostic procedure, refer to DTC P014C. <Ref. to EN(H4DO HEV)(diag)-182, DTC P014C O2 SENSOR SLOW RESPONSE - RICH TO LEAN (BANK 1 SENSOR 1), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

## BA:DTC P015A O2 SENSOR DELAYED RESPONSE - RICH TO LEAN (BANK 1 SENSOR 1)

### NOTE:

For the diagnostic procedure, refer to DTC P014C. <Ref. to EN(H4DO HEV)(diag)-182, DTC P014C O2 SENSOR SLOW RESPONSE - RICH TO LEAN (BANK 1 SENSOR 1), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

## BB:DTC P015B O2 SENSOR DELAYED RESPONSE - LEAN TO RICH (BANK 1 SENSOR 1)

### NOTE:

For the diagnostic procedure, refer to DTC P014C. <Ref. to EN(H4DO HEV)(diag)-182, DTC P014C O2 SENSOR SLOW RESPONSE - RICH TO LEAN (BANK 1 SENSOR 1), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

## BC:DTC P0171 SYSTEM TOO LEAN (BANK 1)

Refer to DTC P0172 for diagnostic procedure. <Ref. to EN(H4DO HEV)(diag)-183, DTC P0172 SYSTEM TOO RICH (BANK 1), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

## BD:DTC P0172 SYSTEM TOO RICH (BANK 1)

### DTC DETECTING CONDITION:

- Detected when two consecutive driving cycles with fault occur.
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-75, DTC P0172 SYSTEM TOO RICH (BANK 1), Diagnostic Trouble Code (DTC) Detecting Criteria.>

### TROUBLE SYMPTOM:

- Improper idling
- Engine stalls.
- Poor driving performance

### CAUTION:

After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.

| Step | Check   | Yes   | No   |
|------|---|---|--|
| 1    | <b>CHECK EXHAUST SYSTEM.</b>  | Are there holes or loose bolts on exhaust system?                                 | Repair the exhaust system.<br>Go to step 2.  |
| 2    | <b>CHECK AIR INTAKE SYSTEM.</b>   | Are there holes, loose bolts or disconnection of hose on air intake system?       | Repair the air intake system.<br>Go to step 3.   |
| 3    | <b>CHECK FUEL PRESSURE.</b><br><b>WARNING:</b><br>Place "NO OPEN FLAMES" signs near the working area.<br><b>CAUTION:</b><br>Be careful not to spill fuel.<br>Measure the fuel pressure. <Ref. to ME(H4DO(w/o HEV))-35, INSPECTION, Fuel Pressure.><br><b>CAUTION:</b><br>Release fuel pressure before removing the fuel pressure gauge.   | Is the measured value 340 — 400 kPa (3.5 — 4.1 kg/cm <sup>2</sup> , 49 — 58 psi)? | Go to step 4.<br>Check the fuel pump and fuel delivery line. <Ref. to FU(H4DO(HEV))-127, INSPECTION, Fuel Pump.> <Ref. to FU(H4DO(HEV))-157, INSPECTION, Fuel Delivery and Evaporation Lines.> |
| 4    | <b>CHECK ENGINE COOLANT TEMPERATURE SENSOR.</b><br>1) Start the engine and warm up completely.<br>2) Read the value of «Coolant Temp.» using the Subaru Select Monitor or a general scan tool.<br><b>NOTE:</b><br>• Subaru Select Monitor<br>For detailed operation procedures, refer to "Current Data Display For Engine". <Ref. to EN(H4DO HEV)(diag)-36, Subaru Select Monitor.><br>• General scan tool<br>For detailed operation procedures, refer to the general scan tool operation manual. | Is the value of «Coolant Temp.» 75°C (167°F) or more?                             | Go to step 5.<br>Replace the engine coolant temperature sensor. <Ref. to FU(H4DO(HEV))-41, Engine Coolant Temperature Sensor.>   |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

## ENGINE (DIAGNOSTICS)

| Step  | Check   | Yes  | No   |
|---|---|--|--|
| <p><b>5</b>     <b>CHECK MASS AIR FLOW AND INTAKE AIR TEMPERATURE SENSOR.</b></p> <p>1) Start the engine and warm up engine until coolant temperature is higher than 75°C (167°F).</p> <p>2) Place the select lever in “P” range or “N” range.</p> <p>3) Turn the A/C switch to OFF.</p> <p>4) Turn all the accessory switches to OFF.</p> <p>5) Read the value of «Mass Air Flow» using the Subaru Select Monitor or a general scan tool.</p> <p>NOTE:</p> <ul style="list-style-type: none"> <li>• Subaru Select Monitor</li> </ul> <p>For detailed operation procedures, refer to “Current Data Display For Engine”. &lt;Ref. to EN(H4DO HEV)(diag)-36, Subaru Select Monitor.&gt;</p> <ul style="list-style-type: none"> <li>• General scan tool</li> </ul> <p>For detailed operation procedures, refer to the general scan tool operation manual.</p>  | <p>Is the value of «Mass Air Flow» 1.0 — 5.0 g/s (0.13 — 0.66 lb/m)?</p>                                    | <p>Go to step 6.</p>                             | <p>Replace the mass air flow and intake air temperature sensor. &lt;Ref. to FU(H4DO(HEV))-63, Mass Air Flow and Intake Air Temperature Sensor.&gt;</p> |
| <p><b>6</b>     <b>CHECK MASS AIR FLOW AND INTAKE AIR TEMPERATURE SENSOR.</b></p> <p>1) Start the engine and warm up engine until coolant temperature is higher than 75°C (167°F).</p> <p>2) Place the select lever in “P” range or “N” range.</p> <p>3) Turn the A/C switch to OFF.</p> <p>4) Turn all the accessory switches to OFF.</p> <p>5) Open the front hood.</p> <p>6) Measure the ambient temperature.</p> <p>7) Read the value of «Intake Air Temp.» using the Subaru Select Monitor or a general scan tool.</p> <p>NOTE:</p> <ul style="list-style-type: none"> <li>• Subaru Select Monitor</li> </ul> <p>For detailed operation procedures, refer to “Current Data Display For Engine”. &lt;Ref. to EN(H4DO HEV)(diag)-36, Subaru Select Monitor.&gt;</p> <ul style="list-style-type: none"> <li>• General scan tool</li> </ul> <p>For detailed operation procedures, refer to the general scan tool operation manual.</p> | <p>Subtract ambient temperature from «Intake Air Temp.». Is the obtained value -10 — 50°C (-18 — 90°F)?</p> | <p>Repair the poor contact of ECM connector.</p> | <p>Check the mass air flow and intake air temperature sensor. &lt;Ref. to FU(H4DO(HEV))-63, Mass Air Flow and Intake Air Temperature Sensor.&gt;</p>   |

## **BE:DTC P0196 ENGINE OIL TEMPERATURE SENSOR CIRCUIT RANGE/PERFORMANCE**

### **DTC DETECTING CONDITION:**

- Detected when two consecutive driving cycles with fault occur.
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-76, DTC P0196 ENGINE OIL TEMPERATURE SENSOR CIRCUIT RANGE/PERFORMANCE, Diagnostic Trouble Code (DTC) Detecting Criteria.>

### **TROUBLE SYMPTOM:**

- Hard to start
- Improper idling
- Poor driving performance

### **CAUTION:**


**After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.**

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

## ENGINE (DIAGNOSTICS)

### WIRING DIAGRAM:

- Engine electrical system (without push button start) <Ref. to WI(HEV)-100, WITHOUT PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>
- Engine electrical system (with push button start) <Ref. to WI(HEV)-114, WITH PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>



| Step | Check  | Yes  | No            |
|------|--|--|---------------|
| 1    | <b>CHECK FOR ANY OTHER DTC ON DISPLAY.</b> Is any other DTC displayed? | Check the appropriate DTC using the "List of Diagnostic Trouble Code (DTC)". <Ref. to EN(H4DO HEV)(diag)-92, List of Diagnostic Trouble Code (DTC).> | Go to step 2. |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step   | Check  | Yes  | No   |
|--|--|--|--|
| <p><b>2</b></p> <p><b>CHECK ENGINE OIL TEMPERATURE SENSOR.</b></p> <p>1) Disconnect the connectors from the engine oil temperature sensor.</p> <p>2) Measure the resistance between engine oil temperature sensor terminals when the engine coolant is cold and after warmed up.</p> <p><b>Terminals</b><br/><b>No. 1 — No. 2:</b></p> | <p>Is the resistance of engine oil temperature sensor different between when engine coolant is cold and after warmed up?</p> | <p>Repair the poor contact of ECM connector.</p> | <p>Replace the engine oil temperature sensor. &lt;Ref. to FU(H4DO(HEV))-44, Engine Oil Temperature Sensor.&gt;</p> |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

## BF:DTC P0197 ENGINE OIL TEMPERATURE SENSOR LOW

### DTC DETECTING CONDITION:

- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-78, DTC P0197 ENGINE OIL TEMPERATURE SENSOR LOW, Diagnostic Trouble Code (DTC) Detecting Criteria.>

### TROUBLE SYMPTOM:


- Hard to start
- Improper idling
- Poor driving performance

### CAUTION:

After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.

### WIRING DIAGRAM:

- Engine electrical system (without push button start) <Ref. to WI(HEV)-100, WITHOUT PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>
- Engine electrical system (with push button start) <Ref. to WI(HEV)-114, WITH PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>



EN-10745

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

|   | Step  | Check   | Yes  | No  |
|---|---|---|--|---|
| 1 | <p><b>CHECK CURRENT DATA.</b></p> <p>1) Start the engine.</p> <p>2) Read the value of «Oil Temperature» using the Subaru Select Monitor or a general scan tool.</p> <p>NOTE:</p> <ul style="list-style-type: none"> <li>Subaru Select Monitor</li> </ul> <p>For detailed operation procedures, refer to “Current Data Display For Engine”. &lt;Ref. to EN(H4DO HEV)(diag)-36, Subaru Select Monitor.&gt;</p> <ul style="list-style-type: none"> <li>General scan tool</li> </ul> <p>For detailed operation procedures, refer to the general scan tool operation manual.</p> | <p>Is the value of «Oil Temperature» 150°C (302°F) or more?</p> | <p>Go to step 2.</p>   | <p>Even if DTC is detected, the circuit has returned to a normal condition at this time. Reproduce the failure, and then perform the diagnosis again.</p> <p>NOTE:</p> <p>In this case, temporary poor contact of connector, temporary open or short circuit of harness may be the cause.</p> |
| 2 | <p><b>CHECK HARNESS BETWEEN ECM AND ENGINE OIL TEMPERATURE SENSOR CONNECTOR.</b></p> <p>1) Turn the ignition switch to OFF.</p> <p>2) Disconnect the connectors from the ECM and engine oil temperature sensor.</p> <p>3) Measure the resistance between ECM connector and chassis ground.</p> <p><b>Connector &amp; terminal</b><br/><b>(B134) No. 20 — Chassis ground:</b></p>  | <p>Is the resistance 1 MΩ or more?</p>                          | <p>Replace the engine oil temperature sensor. &lt;Ref. to FU(H4DO(HEV))-44, Engine Oil Temperature Sensor.&gt;</p> | <p>Repair the short circuit to ground in the harness between the ECM connector and engine oil temperature sensor connector.</p>   |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

## BG:DTC P0198 ENGINE OIL TEMPERATURE SENSOR HIGH

### DTC DETECTING CONDITION:

- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-79, DTC P0198 ENGINE OIL TEMPERATURE SENSOR HIGH, Diagnostic Trouble Code (DTC) Detecting Criteria.>

### TROUBLE SYMPTOM:



- Hard to start
- Improper idling
- Poor driving performance

### CAUTION:

After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.

### WIRING DIAGRAM:

- Engine electrical system (without push button start) <Ref. to WI(HEV)-100, WITHOUT PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>
- Engine electrical system (with push button start) <Ref. to WI(HEV)-114, WITH PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>



EN-10745

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

|   | Step  | Check  | Yes   | No  |
|---|---|--|---|---|
| 1 | <p><b>CHECK CURRENT DATA.</b></p> <p>1) Start the engine.</p> <p>2) Read the value of «Oil Temperature» using the Subaru Select Monitor or a general scan tool.</p> <p>NOTE:</p> <ul style="list-style-type: none"> <li>Subaru Select Monitor</li> </ul> <p>For detailed operation procedures, refer to “Current Data Display For Engine”. &lt;Ref. to EN(H4DO HEV)(diag)-36, Subaru Select Monitor.&gt;</p> <ul style="list-style-type: none"> <li>General scan tool</li> </ul> <p>For detailed operation procedures, refer to the general scan tool operation manual.</p> | Is the value of «Oil Temperature» $-40^{\circ}\text{C}$ ( $-40^{\circ}\text{F}$ ) or less? | Go to step 2.   | <p>Even if DTC is detected, the circuit has returned to a normal condition at this time. Reproduce the failure, and then perform the diagnosis again.</p> <p>NOTE:</p> <p>In this case, temporary poor contact of connector, temporary open or short circuit of harness may be the cause.</p> |
| 2 | <p><b>CHECK FOR POOR CONTACT.</b></p> <p>Check for poor contact between the ECM and engine oil temperature sensor connectors.</p>   | Is there poor contact of the ECM or engine oil temperature sensor connectors?              | Repair the poor contact of ECM or engine oil temperature sensor connector.                                      | Go to step 3.   |
| 3 | <p><b>CHECK HARNESS BETWEEN ECM AND ENGINE OIL TEMPERATURE SENSOR CONNECTOR.</b></p> <p>1) Turn the ignition switch to OFF.</p> <p>2) Disconnect the connectors from the ECM and engine oil temperature sensor.</p> <p>3) Measure the resistance of the harness between the ECM connector and engine oil temperature sensor connector.</p> <p><b>Connector &amp; terminal</b></p> <p><b>(B134) No. 29 — (E75) No. 1:</b></p> <p><b>(B134) No. 20 — (E75) No. 2:</b></p>   | Is the resistance less than $1\ \Omega$ ?  | Go to step 4.   | <p>Repair the harness and connector.</p> <p>NOTE:</p> <p>In this case, repair the following item:</p> <ul style="list-style-type: none"> <li>Open circuit in harness between ECM connector and engine oil temperature sensor connector</li> <li>Poor contact of coupling connector</li> </ul> |
| 4 | <p><b>CHECK HARNESS BETWEEN ECM AND ENGINE OIL TEMPERATURE SENSOR CONNECTOR.</b></p> <p>1) Connect all connectors.</p> <p>2) Turn the ignition switch to ON.</p> <p>3) Measure the voltage between ECM connector and chassis ground.</p> <p><b>Connector &amp; terminal</b></p> <p><b>(B134) No. 20 (+) — Chassis ground (-):</b></p>   | Is the voltage 5 V or more?  | Repair the short circuit to power in harness between ECM connector and engine oil temperature sensor connector. | Replace the engine oil temperature sensor. <Ref. to FU(H4DO(HEV))-44, Engine Oil Temperature Sensor.>   |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

## BH:DTC P0201 INJECTOR #1

### DTC DETECTING CONDITION:

- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-80, DTC P0201 INJECTOR #1, Diagnostic Trouble Code (DTC) Detecting Criteria.>

### TROUBLE SYMPTOM:


- Improper idling
- Poor driving performance

### CAUTION:

After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.

### WIRING DIAGRAM:

- Engine electrical system (without push button start) <Ref. to WI(HEV)-100, WITHOUT PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>
- Engine electrical system (with push button start) <Ref. to WI(HEV)-114, WITH PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>



EN-10736

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step   | Check                                   | Yes                                       | No   |
|--|---|---|--|
| <p><b>1</b>      <b>CHECK POWER SUPPLY TO FUEL INJECTOR.</b><br/>                     1) Turn the ignition switch to OFF.<br/>                     2) Disconnect the connector from fuel injector.<br/>                     3) Turn the ignition switch to ON.<br/>                     4) Measure the voltage between fuel injector connector and the engine ground.<br/> <b>Connector &amp; terminal</b><br/> <b>DTC P0201; (E5) No. 2 (+) — Engine ground (-):</b><br/> <b>DTC P0202; (E16) No. 2 (+) — Engine ground (-):</b><br/> <b>DTC P0203; (E6) No. 2 (+) — Engine ground (-):</b><br/> <b>DTC P0204; (E17) No. 2 (+) — Engine ground (-):</b></p> | Is the voltage 10 V or more?            | Go to step 2.                             | Repair the harness and connector.<br><br>NOTE:<br>In this case, repair the following item:<br><ul style="list-style-type: none"> <li>• Open circuit in harness between main relay and fuel injector connector</li> <li>• Poor contact of main relay connector</li> <li>• Poor contact of coupling connector</li> </ul> |
| <p><b>2</b>      <b>CHECK HARNESS BETWEEN ECM AND FUEL INJECTOR CONNECTOR.</b><br/>                     1) Turn the ignition switch to OFF.<br/>                     2) Disconnect the connector from ECM.<br/>                     3) Measure the resistance between fuel injector connector and engine ground.<br/> <b>Connector &amp; terminal</b><br/> <b>DTC P0201; (E5) No. 1 — Engine ground:</b><br/> <b>DTC P0202; (E16) No. 1 — Engine ground:</b><br/> <b>DTC P0203; (E6) No. 1 — Engine ground:</b><br/> <b>DTC P0204; (E17) No. 1 — Engine ground:</b></p>  | Is the resistance 1 MΩ or more?         | Go to step 3.                             | Repair the short circuit to ground in harness between ECM connector and fuel injector connector.   |
| <p><b>3</b>      <b>CHECK HARNESS BETWEEN ECM AND FUEL INJECTOR CONNECTOR.</b><br/>                     Measure the resistance of harness between ECM connector and fuel injector connector.<br/> <b>Connector &amp; terminal</b><br/> <b>DTC P0201; (B134) No. 12 — (E5) No. 1:</b><br/> <b>DTC P0202; (B134) No. 22 — (E16) No. 1:</b><br/> <b>DTC P0203; (B134) No. 32 — (E6) No. 1:</b><br/> <b>DTC P0204; (B134) No. 13 — (E17) No. 1:</b></p>  | Is the resistance less than 1 Ω?        | Go to step 4.                             | Repair the harness and connector.<br><br>NOTE:<br>In this case, repair the following item:<br><ul style="list-style-type: none"> <li>• Open circuit in harness between ECM connector and fuel injector connector</li> <li>• Poor contact of coupling connector</li> </ul>  |
| <p><b>4</b>      <b>CHECK FUEL INJECTOR.</b><br/>                     Measure the resistance between fuel injector terminals on the corresponding cylinder.<br/> <b>Terminals</b><br/> <b>No. 1 — No. 2:</b></p>   | Is the resistance 5 — 20 Ω?             | Go to step 5.                             | Replace the fuel injector. <Ref. to FU(H4DO(HEV))-69, Fuel Injector.>  |
| <p><b>5</b>      <b>CHECK FOR POOR CONTACT.</b><br/>                     Check for poor contact of ECM connector.</p>  | Is there poor contact of ECM connector? | Repair the poor contact of ECM connector. | Go to step 6.  |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

## ENGINE (DIAGNOSTICS)

| Step  | Check  | Yes  | No  |
|---|--|--|---|
| <b>6</b><br><b>CHECK FUEL INJECTOR OPERATION.</b><br>1) Connect all connectors.<br>2) Start the engine.<br>3) Check if the corresponding fuel injector emits operating sound.<br><br>NOTE:<br>Use a sound scope to check the operating sound. | Does the fuel injector emit operating sound? | Even if DTC is detected, the circuit has returned to a normal condition at this time. Reproduce the failure, and then perform the diagnosis again.<br><br>NOTE:<br>In this case, temporary poor contact of connector, temporary open or short circuit of harness may be the cause. | Repair the poor contact of fuel injector connector. |

### BI: DTC P0202 INJECTOR #2

NOTE:

For the diagnostic procedure, refer to DTC P0201. <Ref. to EN(H4DO HEV)(diag)-192, DTC P0201 INJECTOR #1, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

### BJ: DTC P0203 INJECTOR #3

NOTE:

For the diagnostic procedure, refer to DTC P0201. <Ref. to EN(H4DO HEV)(diag)-192, DTC P0201 INJECTOR #1, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

### BK: DTC P0204 INJECTOR #4

NOTE:

For the diagnostic procedure, refer to DTC P0201. <Ref. to EN(H4DO HEV)(diag)-192, DTC P0201 INJECTOR #1, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

## **BL:DTC P0222 THROTTLE/PEDAL POSITION SENSOR/SWITCH “B” CIRCUIT LOW**

### **DTC DETECTING CONDITION:**

- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-81, DTC P0222 THROTTLE/PEDAL POSITION SENSOR/SWITCH “B” CIRCUIT LOW, Diagnostic Trouble Code (DTC) Detecting Criteria.>

### **TROUBLE SYMPTOM:**

- Improper idling
- Poor driving performance
- Engine stalls.

### **CAUTION:**



**After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.**

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

## ENGINE (DIAGNOSTICS)

### WIRING DIAGRAM:

- Engine electrical system (without push button start) <Ref. to WI(HEV)-100, WITHOUT PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>
- Engine electrical system (with push button start) <Ref. to WI(HEV)-114, WITH PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>



EN-10744

| Step  | Check                                  | Yes                  | No   |
|---|--|----------------------|--|
| <p><b>1</b></p> <p><b>CHECK HARNESS BETWEEN ECM AND ELECTRONIC THROTTLE CONTROL CONNECTOR.</b></p> <p>1) Turn the ignition switch to OFF.</p> <p>2) Disconnect the connectors from ECM and electronic throttle control.</p> <p>3) Measure the resistance between ECM connector and chassis ground.</p> <p><b>Connector &amp; terminal</b></p> <p><b>(B134) No. 19 — Chassis ground:</b></p> <p><b>(B134) No. 28 — Chassis ground:</b></p> <p><b>(B134) No. 28 — (B137) No. 4:</b></p> | <p>Is the resistance 1 MΩ or more?</p> | <p>Go to step 2.</p> | <p>Repair the ground short circuit of harness between ECM connector and electronic throttle control connector.</p> |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step   | Check                           | Yes   | No  |
|--|---------------------------------|---|---|
| <b>2</b><br><b>CHECK SHORT CIRCUIT INSIDE THE ECM.</b><br>1) Connect the connector to ECM.<br>2) Measure the resistance between electronic throttle control connector and engine ground.<br><b>Connector &amp; terminal</b><br><b>(E57) No. 4 — Engine ground:</b> | Is the resistance 1 MΩ or more? | Replace the electronic throttle control. <Ref. to FU(H4DO(HEV))-14, Throttle Body.> | Repair the ground short circuit of harness between ECM connector and electronic throttle control connector.<br>Replace the ECM if defective. <Ref. to FU(H4DO(HEV))-85, Engine Control Module (ECM).> |

## Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

---

### **BM:DTC P0223 THROTTLE/PEDAL POSITION SENSOR/SWITCH “B” CIRCUIT HIGH**

#### **DTC DETECTING CONDITION:**

- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-82, DTC P0223 THROTTLE/PEDAL POSITION SENSOR/SWITCH “B” CIRCUIT HIGH, Diagnostic Trouble Code (DTC) Detecting Criteria.>

#### **TROUBLE SYMPTOM:**

- Improper idling
- Poor driving performance
- Engine stalls.

#### **CAUTION:**


After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

## WIRING DIAGRAM:

- Engine electrical system (without push button start) <Ref. to WI(HEV)-100, WITHOUT PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>
- Engine electrical system (with push button start) <Ref. to WI(HEV)-114, WITH PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>



| Step  | Check                                   | Yes                  | No   |
|---|---|----------------------|--|
| <p><b>1</b></p> <p><b>CHECK HARNESS BETWEEN ECM AND ELECTRONIC THROTTLE CONTROL CONNECTOR.</b></p> <p>1) Turn the ignition switch to OFF.</p> <p>2) Disconnect the connectors from ECM and electronic throttle control.</p> <p>3) Measure the resistance of harness between ECM connector and electronic throttle control connector.</p> <p><b>Connector &amp; terminal</b><br/> <b>(B134) No. 28 — (E57) No. 4:</b><br/> <b>(B134) No. 29 — (E57) No. 3:</b></p> | <p>Is the resistance less than 1 Ω?</p> | <p>Go to step 2.</p> | <p>Repair the harness and connector.</p> <p><b>NOTE:</b><br/>                     In this case, repair the following item:</p> <ul style="list-style-type: none"> <li>• Open circuit in harness between ECM connector and electronic throttle control connector</li> <li>• Poor contact of coupling connector</li> </ul> |

## Diagnostic Procedure with Diagnostic Trouble Code (DTC)

### ENGINE (DIAGNOSTICS)

| Step   | Check                                    | Yes  | No   |
|--|--|--|--|
| <b>2</b><br><b>CHECK HARNESS BETWEEN ECM AND ELECTRONIC THROTTLE CONTROL CONNECTOR.</b><br>1) Connect the connector to ECM.<br>2) Measure the resistance between electronic throttle control connector and engine ground.<br><b>Connector &amp; terminal</b><br><b>(E57) No. 3 — Engine ground:</b>        | Is the resistance less than 5 $\Omega$ ? | Go to step 3.  | Repair the harness and connector.<br>NOTE:<br>In this case, repair the following item:<br>• Open circuit of harness between ECM connector and engine ground<br>• Poor contact of ECM connector<br>• Poor contact of coupling connector |
| <b>3</b><br><b>CHECK HARNESS BETWEEN ECM AND ELECTRONIC THROTTLE CONTROL CONNECTOR.</b><br>1) Turn the ignition switch to ON.<br>2) Measure the voltage between electronic throttle control connector and engine ground.<br><b>Connector &amp; terminal</b><br><b>(E57) No. 4 (+) — Engine ground (-):</b> | Is the voltage 5 V or more?              | Repair the short circuit to power in the harness between ECM connector and electronic throttle control connector.  | Go to step 4.  |
| <b>4</b><br><b>CHECK HARNESS BETWEEN ECM AND ELECTRONIC THROTTLE CONTROL CONNECTOR.</b><br>1) Turn the ignition switch to OFF.<br>2) Disconnect the connector from ECM.<br>3) Measure the resistance between ECM connectors.<br><b>Connector &amp; terminal</b><br><b>(B134) No. 19 — (B134) No. 28:</b>   | Is the resistance 1 M $\Omega$ or more?  | Repair the poor contact of electronic throttle control connector.<br>Replace the electronic throttle control if defective.<br><Ref. to FU(H4DO(HEV))-14, Throttle Body.> | Repair the short circuit to power in the harness between ECM connector and electronic throttle control connector.  |

## **BN:DTC P0300 RANDOM/MULTIPLE CYLINDER MISFIRE DETECTED**

### **DTC DETECTING CONDITION:**

- Detected when two consecutive driving cycles with fault occur.
- Immediately at fault recognition (A misfire which could damage catalyst occurs.)
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-82, DTC P0300 RANDOM/MULTIPLE CYLINDER MISFIRE DETECTED, Diagnostic Trouble Code (DTC) Detecting Criteria.>

### **TROUBLE SYMPTOM:**

- Engine stalls.
- Improper idling
- Rough driving

### **CAUTION:**


**After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.**

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

## ENGINE (DIAGNOSTICS)

### WIRING DIAGRAM:

- Engine electrical system (without push button start) <Ref. to WI(HEV)-100, WITHOUT PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>
- Engine electrical system (with push button start) <Ref. to WI(HEV)-114, WITH PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>



EN-10736

| Step   | Check                        | Yes           | No            |
|--|------------------------------|---------------|---------------|
| <b>1 CHECK OUTPUT SIGNAL OF ECM.</b><br>1) Turn the ignition switch to ON.<br>2) Measure the voltage between ECM and chassis ground on all cylinders.<br><b>Connector &amp; terminal</b><br>#1 (B134) No. 12 (+) — Chassis ground (-):<br>#2 (B134) No. 22 (+) — Chassis ground (-):<br>#3 (B134) No. 32 (+) — Chassis ground (-):<br>#4 (B134) No. 13 (+) — Chassis ground (-): | Is the voltage 10 V or more? | Go to step 6. | Go to step 2. |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step  | Check   | Yes   | No  |
|---|---|---|---|
| <p><b>2</b></p> <p><b>CHECK HARNESS BETWEEN ECM AND FUEL INJECTOR CONNECTOR.</b></p> <p>1) Turn the ignition switch to OFF.</p> <p>2) Disconnect the connector from all fuel injectors.</p> <p>3) Measure the resistance between all fuel injector connectors and engine ground.</p> <p><b>Connector &amp; terminal</b></p> <p><b>#1 (E5) No. 1 — Engine ground:</b></p> <p><b>#2 (E16) No. 1 — Engine ground:</b></p> <p><b>#3 (E6) No. 1 — Engine ground:</b></p> <p><b>#4 (E17) No. 1 — Engine ground:</b></p>   | <p>Is the resistance 1 M<math>\Omega</math> or more?</p>  | <p>Go to step 3.</p>  | <p>Repair the short circuit to ground in harness between ECM connector and fuel injector connector.</p>   |
| <p><b>3</b></p> <p><b>CHECK HARNESS BETWEEN ECM AND FUEL INJECTOR CONNECTOR.</b></p> <p>Measure the resistance of harness between ECM and fuel injector connector on all cylinders.</p> <p><b>Connector &amp; terminal</b></p> <p><b>#1 (B134) No. 12 — (E5) No. 1:</b></p> <p><b>#2 (B134) No. 22 — (E16) No. 1:</b></p> <p><b>#3 (B134) No. 32 — (E6) No. 1:</b></p> <p><b>#4 (B134) No. 13 — (E17) No. 1:</b></p>  | <p>Is the resistance less than 1 <math>\Omega</math>?</p> | <p>Go to step 4.</p>  | <p>Repair the harness and connector.</p> <p>NOTE:<br/>In this case, repair the following item:</p> <ul style="list-style-type: none"> <li>• Open circuit in harness between ECM connector and fuel injector connector</li> <li>• Poor contact of coupling connector</li> </ul>  |
| <p><b>4</b></p> <p><b>CHECK FUEL INJECTOR.</b></p> <p>Measure the resistance between all fuel injector terminals.</p> <p><b>Terminals</b></p> <p><b>No. 1 — No. 2:</b></p>  | <p>Is the resistance 5 — 20 <math>\Omega</math>?</p>      | <p>Go to step 5.</p>  | <p>Replace the faulty fuel injector. &lt;Ref. to FU(H4DO(HEV))-69, Fuel Injector.&gt;</p>   |
| <p><b>5</b></p> <p><b>CHECK POWER SUPPLY LINE.</b></p> <p>1) Turn the ignition switch to ON.</p> <p>2) Measure the voltage between all fuel injector connectors and the engine ground.</p> <p><b>Connector &amp; terminal</b></p> <p><b>#1 (E5) No. 2 (+) — Engine ground (-):</b></p> <p><b>#2 (E16) No. 2 (+) — Engine ground (-):</b></p> <p><b>#3 (E6) No. 2 (+) — Engine ground (-):</b></p> <p><b>#4 (E17) No. 2 (+) — Engine ground (-):</b></p>   | <p>Is the voltage 10 V or more?</p>                       | <p>Repair the poor contact of all connectors in fuel injector circuit.</p>                              | <p>Repair the harness and connector.</p> <p>NOTE:<br/>In this case, repair the following item:</p> <ul style="list-style-type: none"> <li>• Open circuit in harness between main relay connector and fuel injector connector</li> <li>• Poor contact of coupling connector</li> <li>• Poor contact of main relay connector</li> </ul> |
| <p><b>6</b></p> <p><b>CHECK HARNESS BETWEEN ECM AND FUEL INJECTOR CONNECTOR.</b></p> <p>1) Turn the ignition switch to OFF.</p> <p>2) Disconnect the connector from all fuel injectors.</p> <p>3) Turn the ignition switch to ON.</p> <p>4) Measure the voltage between ECM and chassis ground on all cylinders.</p> <p><b>Connector &amp; terminal</b></p> <p><b>#1 (B134) No. 12 (+) — Chassis ground (-):</b></p> <p><b>#2 (B134) No. 22 (+) — Chassis ground (-):</b></p> <p><b>#3 (B134) No. 32 (+) — Chassis ground (-):</b></p> <p><b>#4 (B134) No. 13 (+) — Chassis ground (-):</b></p> | <p>Is the voltage 10 V or more?</p>                       | <p>Repair the short circuit to power in harness between ECM connector and fuel injector connectors.</p> | <p>Go to step 7.</p>  |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

## ENGINE (DIAGNOSTICS)

| Step   | Check  | Yes   | No   |
|--|--|---|--|
| <b>7 CHECK FUEL INJECTOR.</b><br>1) Turn the ignition switch to OFF.<br>2) Measure the resistance between all fuel injector terminals.<br><i>Terminals</i><br><i>No. 1 — No. 2:</i>  | Is the resistance 5 — 20 Ω?  | Go to step 8.   | Replace the faulty fuel injector. <Ref. to FU(H4DO(HEV))-69, Fuel Injector.>   |
| <b>8 CHECK INSTALLATION CONDITION OF CAMSHAFT POSITION SENSOR/CRANKSHAFT POSITION SENSOR.</b>  | Is the camshaft position sensor or crankshaft position sensor loosely installed? | Tighten the camshaft position sensor or crankshaft position sensor. <Ref. to FU(H4DO(HEV))-53, INSTALLATION, Camshaft Position Sensor.> <Ref. to FU(H4DO(HEV))-48, INSTALLATION, Crankshaft Position Sensor.> | Go to step 9.  |
| <b>9 CHECK CRANKSHAFT POSITION SENSOR PLATE.</b>   | Is the crankshaft position sensor plate rusted or does it have broken teeth?     | Replace the crankshaft position sensor plate. <Ref. to ME(H4DO(w/o HEV))-304, Cylinder Block.>  | Go to step 10.   |
| <b>10 CHECK INSTALLATION CONDITION OF TIMING CHAIN.</b><br>Turn the crankshaft using ST, and align the alignment mark on crank sprocket with alignment mark on cylinder block.<br>ST 18252AA000 CRANKSHAFT SOCKET                    | Is the timing chain dislocated from its proper position?                         | Correct the installation condition of timing chain. <Ref. to ME(H4DO(w/o HEV))-169, Timing Chain Assembly.>   | Go to step 11.   |
| <b>11 CHECK FUEL LEVEL.</b>  | Is the fuel meter indication higher than the “Lower” level?                      | Go to step 12.  | Refill the fuel so that the fuel meter indication is higher than the “Lower” level, and proceed to the next step. Go to step 12. |
| <b>12 CHECK STATUS OF MALFUNCTION INDICATOR LIGHT.</b><br>1) Clear the memory using the Subaru Select Monitor. <Ref. to EN(H4DO HEV)(diag)-66, Clear Memory Mode.><br>2) Start the engine, and drive the vehicle 10 minutes or more. | Does the malfunction indicator light illuminate or blink?                        | Go to step 14.  | Go to step 13.   |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step                                  | Check   | Yes  | No  |
|---------------------------------------|---|--|---|
| 13<br><b>CHECK CAUSE OF MISFIRE.</b>  | Was the cause of misfire identified when the engine is running? | Finish diagnostics operation, if the engine has no abnormality.  | Repair the poor contact of connector.<br>NOTE:<br>In this case, repair the following item:<br><ul style="list-style-type: none"> <li>• Poor contact of ignition coil connector</li> <li>• Poor contact of fuel injector connector on faulty cylinders</li> <li>• Poor contact of ECM connector</li> <li>• Poor contact of coupling connector</li> </ul> |
| 14<br><b>CHECK AIR INTAKE SYSTEM.</b> | Is there any fault in air intake system?                        | Repair the air intake system.<br>NOTE:<br>Check the following items.<br><ul style="list-style-type: none"> <li>• Are there air leaks or air suction caused by loose or dislocated nuts and bolts?</li> <li>• Are there cracks or any disconnection of hoses?</li> </ul>                  | Go to step 15.  |
| 15<br><b>CHECK ALL CYLINDERS.</b>     | Is there a fault in any cylinder?                               | Repair or replace the faulty part of the faulty cylinder.<br>NOTE:<br>Check the following items.<br><ul style="list-style-type: none"> <li>• Spark plug</li> <li>• Ignition coil</li> <li>• Fuel injector</li> <li>• Compression ratio</li> <li>• Skipping timing chain teeth</li> </ul> | Go to DTC P0171.<br><Ref. to EN(H4DO HEV)(diag)-182, DTC P0171 SYSTEM TOO LEAN (BANK 1), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>  |

## BO:DTC P0301 CYLINDER 1 MISFIRE DETECTED

NOTE:

For the diagnostic procedure, refer to DTC P0304. <Ref. to EN(H4DO HEV)(diag)-206, DTC P0304 CYLINDER 4 MISFIRE DETECTED, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

## BP:DTC P0302 CYLINDER 2 MISFIRE DETECTED

NOTE:

For the diagnostic procedure, refer to DTC P0304. <Ref. to EN(H4DO HEV)(diag)-206, DTC P0304 CYLINDER 4 MISFIRE DETECTED, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

## BQ:DTC P0303 CYLINDER 3 MISFIRE DETECTED

NOTE:

For the diagnostic procedure, refer to DTC P0304. <Ref. to EN(H4DO HEV)(diag)-206, DTC P0304 CYLINDER 4 MISFIRE DETECTED, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

---

## **BR:DTC P0304 CYLINDER 4 MISFIRE DETECTED**

### **DTC DETECTING CONDITION:**

- Detected when two consecutive driving cycles with fault occur.
- Immediately at fault recognition (A misfire which could damage catalyst occurs.)
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-89, DTC P0304 CYLINDER 4 MISFIRE DETECTED, Diagnostic Trouble Code (DTC) Detecting Criteria.>

### **TROUBLE SYMPTOM:**

- Engine stalls.
- Improper idling
- Rough driving

### **CAUTION:**


**After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.**

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

## WIRING DIAGRAM:

- Engine electrical system (without push button start) <Ref. to WI(HEV)-100, WITHOUT PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>
- Engine electrical system (with push button start) <Ref. to WI(HEV)-114, WITH PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>



EN-10736

| Step  | Check                        | Yes           | No            |
|---|------------------------------|---------------|---------------|
| <b>1 CHECK OUTPUT SIGNAL OF ECM.</b><br>1) Turn the ignition switch to ON.<br>2) Measure the voltage between ECM and chassis ground on faulty cylinders.<br><b>Connector &amp; terminal</b><br>#1 (B134) No. 12 (+) — Chassis ground (-):<br>#2 (B134) No. 22 (+) — Chassis ground (-):<br>#3 (B134) No. 32 (+) — Chassis ground (-):<br>#4 (B134) No. 13 (+) — Chassis ground (-): | Is the voltage 10 V or more? | Go to step 6. | Go to step 2. |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

## ENGINE (DIAGNOSTICS)

| Step   | Check                                    | Yes  | No   |
|--|--|--|--|
| <p><b>2 CHECK HARNESS BETWEEN ECM AND FUEL INJECTOR CONNECTOR.</b></p> <p>1) Turn the ignition switch to OFF.<br/>2) Disconnect the connector from fuel injector on faulty cylinders.<br/>3) Measure the resistance between fuel injector connector and engine ground on faulty cylinders.</p> <p><b>Connector &amp; terminal</b><br/> <b>#1 (E5) No. 1 — Engine ground:</b><br/> <b>#2 (E16) No. 1 — Engine ground:</b><br/> <b>#3 (E6) No. 1 — Engine ground:</b><br/> <b>#4 (E17) No. 1 — Engine ground:</b></p>  | Is the resistance 1 M $\Omega$ or more?  | Go to step 3.  | Repair the short circuit to ground in harness between ECM connector and fuel injector connector.   |
| <p><b>3 CHECK HARNESS BETWEEN ECM AND FUEL INJECTOR CONNECTOR.</b></p> <p>Measure the resistance of harness between ECM and fuel injector connector on faulty cylinders.</p> <p><b>Connector &amp; terminal</b><br/> <b>#1 (B134) No. 12 — (E5) No. 1:</b><br/> <b>#2 (B134) No. 22 — (E16) No. 1:</b><br/> <b>#3 (B134) No. 32 — (E6) No. 1:</b><br/> <b>#4 (B134) No. 13 — (E17) No. 1:</b></p>  | Is the resistance less than 1 $\Omega$ ? | Go to step 4.  | Repair the harness and connector.<br><br>NOTE:<br>In this case, repair the following item:<br><ul style="list-style-type: none"> <li>• Open circuit in harness between ECM connector and fuel injector connector</li> <li>• Poor contact of coupling connector</li> </ul>  |
| <p><b>4 CHECK FUEL INJECTOR.</b></p> <p>Measure the resistance between fuel injector terminals on faulty cylinder.</p> <p><b>Terminals</b><br/> <b>No. 1 — No. 2:</b></p>  | Is the resistance 5 — 20 $\Omega$ ?      | Go to step 5.  | Replace the faulty fuel injector. <Ref. to FU(H4DO(HEV))-69, Fuel Injector.>   |
| <p><b>5 CHECK POWER SUPPLY LINE.</b></p> <p>1) Turn the ignition switch to ON.<br/>2) Measure the voltage between fuel injector and engine ground on faulty cylinders.</p> <p><b>Connector &amp; terminal</b><br/> <b>#1 (E5) No. 2 (+) — Engine ground (-):</b><br/> <b>#2 (E16) No. 2 (+) — Engine ground (-):</b><br/> <b>#3 (E6) No. 2 (+) — Engine ground (-):</b><br/> <b>#4 (E17) No. 2 (+) — Engine ground (-):</b></p>  | Is the voltage 10 V or more?             | Repair the poor contact of all connectors in fuel injector circuit.                              | Repair the harness and connector.<br><br>NOTE:<br>In this case, repair the following item:<br><ul style="list-style-type: none"> <li>• Open circuit in harness between the main relay connector and fuel injector connector on faulty cylinders</li> <li>• Poor contact of coupling connector</li> <li>• Poor contact of main relay connector</li> </ul> |
| <p><b>6 CHECK HARNESS BETWEEN ECM AND FUEL INJECTOR CONNECTOR.</b></p> <p>1) Turn the ignition switch to OFF.<br/>2) Disconnect the connector from fuel injector on faulty cylinders.<br/>3) Turn the ignition switch to ON.<br/>4) Measure the voltage between ECM and chassis ground on faulty cylinders.</p> <p><b>Connector &amp; terminal</b><br/> <b>#1 (B134) No. 12 (+) — Chassis ground (-):</b><br/> <b>#2 (B134) No. 22 (+) — Chassis ground (-):</b><br/> <b>#3 (B134) No. 32 (+) — Chassis ground (-):</b><br/> <b>#4 (B134) No. 13 (+) — Chassis ground (-):</b></p> | Is the voltage 10 V or more?             | Repair the short circuit to power in harness between ECM connector and fuel injector connectors. | Go to step 7.  |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step   | Check  | Yes   | No   |
|--|--|---|--|
| <b>7 CHECK FUEL INJECTOR.</b><br>1) Turn the ignition switch to OFF.<br>2) Measure the resistance between fuel injector terminals on faulty cylinder.<br><b>Terminals</b><br><b>No. 1 — No. 2:</b>                                   | Is the resistance 5 — 20 Ω?  | Go to step 8.   | Replace the faulty fuel injector. <Ref. to FU(H4DO(HEV))-69, Fuel Injector.>   |
| <b>8 CHECK INSTALLATION CONDITION OF CAMSHAFT POSITION SENSOR/CRANKSHAFT POSITION SENSOR.</b>  | Is the camshaft position sensor or crankshaft position sensor loosely installed? | Tighten the camshaft position sensor or crankshaft position sensor. <Ref. to FU(H4DO(HEV))-53, INSTALLATION, Camshaft Position Sensor.> <Ref. to FU(H4DO(HEV))-48, INSTALLATION, Crankshaft Position Sensor.> | Go to step 9.  |
| <b>9 CHECK CRANKSHAFT POSITION SENSOR PLATE.</b>   | Is the crankshaft position sensor plate rusted or does it have broken teeth?     | Replace the crankshaft position sensor plate. <Ref. to ME(H4DO(w/o HEV))-304, Cylinder Block.>  | Go to step 10.   |
| <b>10 CHECK INSTALLATION CONDITION OF TIMING CHAIN.</b><br>Turn the crankshaft using ST, and align the alignment mark on crank sprocket with alignment mark on cylinder block.<br>ST 18252AA000 CRANKSHAFT SOCKET                    | Is the timing chain dislocated from its proper position?                         | Correct the installation condition of timing chain. <Ref. to ME(H4DO(w/o HEV))-169, Timing Chain Assembly.>   | Go to step 11.   |
| <b>11 CHECK FUEL LEVEL.</b>  | Is the fuel meter indication higher than the “Lower” level?                      | Go to step 12.  | Refill the fuel so that the fuel meter indication is higher than the “Lower” level, and proceed to the next step. Go to step 12. |
| <b>12 CHECK STATUS OF MALFUNCTION INDICATOR LIGHT.</b><br>1) Clear the memory using the Subaru Select Monitor. <Ref. to EN(H4DO HEV)(diag)-66, Clear Memory Mode.><br>2) Start the engine, and drive the vehicle 10 minutes or more. | Does the malfunction indicator light illuminate or blink?                        | Go to step 14.  | Go to step 13.   |

## Diagnostic Procedure with Diagnostic Trouble Code (DTC)

### ENGINE (DIAGNOSTICS)

| Step      | Check                           | Yes   | No   |
|-----------|---------------------------------|---|--|
| <b>13</b> | <b>CHECK CAUSE OF MISFIRE.</b>  | Was the cause of misfire identified when the engine is running? | Finish diagnostics operation, if the engine has no abnormality.<br><br>Repair the poor contact of connector.<br>NOTE:<br>In this case, repair the following item:<br><ul style="list-style-type: none"> <li>• Poor contact of ignition coil connector</li> <li>• Poor contact of fuel injector connector on faulty cylinders</li> <li>• Poor contact of ECM connector</li> <li>• Poor contact of coupling connector</li> </ul> |
| <b>14</b> | <b>CHECK AIR INTAKE SYSTEM.</b> | Is there any fault in air intake system?                        | Repair the air intake system.<br>NOTE:<br>Check the following items.<br><ul style="list-style-type: none"> <li>• Are there air leaks or air suction caused by loose or dislocated nuts and bolts?</li> <li>• Are there cracks or any disconnection of hoses?</li> </ul>  |
| <b>15</b> | <b>CHECK CYLINDER.</b>          | Is there any fault in the cylinder?                             | Repair or replace faulty parts.<br>NOTE:<br>Check the following items.<br><ul style="list-style-type: none"> <li>• Spark plug</li> <li>• Ignition coil</li> <li>• Fuel injector</li> <li>• Compression ratio</li> <li>• Skipping timing chain teeth</li> </ul>   |

## BS:DTC P0327 KNOCK SENSOR 1 CIRCUIT LOW (BANK 1 OR SINGLE SENSOR)

### DTC DETECTING CONDITION:

- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-90, DTC P0327 KNOCK SENSOR 1 CIRCUIT LOW (BANK 1 OR SINGLE SENSOR), Diagnostic Trouble Code (DTC) Detecting Criteria.>

### TROUBLE SYMPTOM:



- Poor driving performance
- Knocking occurs

### CAUTION:

**After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.**

### WIRING DIAGRAM:

- Engine electrical system (without push button start) <Ref. to WI(HEV)-100, WITHOUT PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>
- Engine electrical system (with push button start) <Ref. to WI(HEV)-114, WITH PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>



# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step  | Check                                      | Yes  | No  |
|---|--|--|---|
| <p><b>1</b></p> <p><b>CHECK HARNESS BETWEEN ECM AND KNOCK SENSOR CONNECTOR.</b></p> <p>1) Turn the ignition switch to OFF.<br/>2) Disconnect the connector from ECM.<br/>3) Measure the resistance between ECM connectors.</p> <p><b>Connector &amp; terminal</b><br/><b>(B136) No. 28 — (B134) No. 29:</b></p> | <p>Is the resistance less than 500 kΩ?</p> | <p>Go to step 2.</p>   | <p>Go to step 3.</p>  |
| <p><b>2</b></p> <p><b>CHECK KNOCK SENSOR.</b></p> <p>1) Disconnect the connector from the knock sensor.<br/>2) Measure the resistance between knock sensor terminals.</p> <p><b>Terminals</b><br/><b>No. 1 — No. 2:</b></p>   | <p>Is the resistance less than 500 kΩ?</p> | <p>Replace the knock sensor. &lt;Ref. to FU(H4DO(HEV))-59, Knock Sensor.&gt;</p>   | <p>Repair the short circuit to ground in harness between ECM connector and knock sensor connector.</p> <p><b>NOTE:</b><br/>The harness between both connectors are shielded. Remove the shield and repair the short circuit of harness.</p> |
| <p><b>3</b></p> <p><b>CHECK INPUT SIGNAL OF ECM.</b></p> <p>1) Connect the connector to ECM.<br/>2) Turn the ignition switch to ON.<br/>3) Measure the voltage between ECM connector and chassis ground.</p> <p><b>Connector &amp; terminal</b><br/><b>(B136) No. 28 (+) — Chassis ground (-):</b></p>          | <p>Is the voltage 2 V or more?</p>         | <p>Even if DTC is detected, the circuit has returned to a normal condition at this time. Reproduce the failure, and then perform the diagnosis</p> <p><b>NOTE:</b><br/>In this case, temporary poor contact of connector, temporary open or short circuit of harness may be the cause.</p> | <p>Repair the short circuit to ground in harness between ECM connector and knock sensor connector.</p> <p><b>NOTE:</b><br/>The harness between both connectors are shielded. Remove the shield and repair the short circuit of harness.</p> |

## BT:DTC P0328 KNOCK SENSOR 1 CIRCUIT HIGH (BANK 1 OR SINGLE SENSOR)

### DTC DETECTING CONDITION:

- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-91, DTC P0328 KNOCK SENSOR 1 CIRCUIT HIGH (BANK 1 OR SINGLE SENSOR), Diagnostic Trouble Code (DTC) Detecting Criteria.>

### TROUBLE SYMPTOM:



- Poor driving performance
- Knocking occurs

### CAUTION:

**After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.**

### WIRING DIAGRAM:

- Engine electrical system (without push button start) <Ref. to WI(HEV)-100, WITHOUT PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>
- Engine electrical system (with push button start) <Ref. to WI(HEV)-114, WITH PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>



# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step  | Check                             | Yes   | No  |
|---|-----------------------------------|---|---|
| <b>1</b><br><b>CHECK HARNESS BETWEEN ECM AND KNOCK SENSOR CONNECTOR.</b><br>1) Turn the ignition switch to OFF.<br>2) Disconnect the connector from ECM.<br>3) Measure the resistance between ECM connectors.<br><i><b>Connector &amp; terminal</b></i><br><i><b>(B136) No. 28 — (B134) No. 29:</b></i> | Is the resistance 600 kΩ or more? | Go to step 2.   | Repair the poor contact of ECM connector.   |
| <b>2</b><br><b>CHECK KNOCK SENSOR.</b><br>1) Disconnect the connector from the knock sensor.<br>2) Measure the resistance between knock sensor terminals.<br><i><b>Terminals</b></i><br><i><b>No. 1 — No. 2:</b></i>  | Is the resistance 600 kΩ or more? | Replace the knock sensor. <Ref. to FU(H4DO(HEV))-59, Knock Sensor.> | Repair the harness and connector.<br>NOTE:<br>In this case, repair the following item: <ul style="list-style-type: none"> <li>• Open circuit in harness between ECM connector and knock sensor connector</li> <li>• Poor contact of knock sensor connector</li> <li>• Poor contact of coupling connector</li> </ul> |

## BU:DTC P0335 CRANKSHAFT POSITION SENSOR "A" CIRCUIT

### DTC DETECTING CONDITION:

- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-92, DTC P0335 CRANKSHAFT POSITION SENSOR "A" CIRCUIT, Diagnostic Trouble Code (DTC) Detecting Criteria.>

### TROUBLE SYMPTOM:


- Engine stalls.
- Failure of engine to start

### CAUTION:

**After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.**

### WIRING DIAGRAM:

- Engine electrical system (without push button start) <Ref. to WI(HEV)-100, WITHOUT PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>
- Engine electrical system (with push button start) <Ref. to WI(HEV)-114, WITH PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>



# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

## ENGINE (DIAGNOSTICS)

| Step  | Check   | Yes  | No  |
|---|---|--|---|
| <b>1 CHECK CONDITION OF CRANKSHAFT POSITION SENSOR.</b>   | Is the crankshaft position sensor installation bolt tightened securely? | Go to step 2.  | Tighten the crankshaft position sensor installation bolt securely. <Ref. to FU(H4DO(HEV))-48, INSTALLATION, Crankshaft Position Sensor.>  |
| <b>2 CHECK POWER SUPPLY OF CRANKSHAFT POSITION SENSOR.</b><br>1) Turn the ignition switch to OFF.<br>2) Disconnect the connector from the crankshaft position sensor.<br>3) Turn the ignition switch to ON.<br>4) Measure the voltage between crankshaft position sensor connector and engine ground.<br><i>Connector &amp; terminal</i><br><i>(E10) No. 3 (+) — Engine ground (-):</i> | Is the voltage 4.5 V or more?   | Go to step 3.  | Repair the harness and connector.<br>NOTE:<br>In this case, repair the following item:<br>• Open circuit in harness between ECM connector and crankshaft position sensor connector<br>• Poor contact of ECM connector<br>• Poor contact of coupling connector |
| <b>3 CHECK HARNESS BETWEEN ECM AND CRANKSHAFT POSITION SENSOR CONNECTOR.</b><br>1) Turn the ignition switch to OFF.<br>2) Disconnect the connector from ECM.<br>3) Measure the resistance between ECM connector and crankshaft position sensor connector.<br><i>Connector &amp; terminal</i><br><i>(B136) No. 16 — (E10) No. 1:</i><br><i>(B136) No. 27 — (E10) No. 2:</i>              | Is the resistance less than 1 Ω?  | Go to step 4.  | Repair the harness and connector.<br>NOTE:<br>In this case, repair the following item:<br>• Open circuit in harness between ECM connector and crankshaft position sensor connector<br>• Poor contact of coupling connector                                    |
| <b>4 CHECK HARNESS BETWEEN ECM AND CRANKSHAFT POSITION SENSOR CONNECTOR.</b><br>Measure the resistance between crankshaft position sensor connector and engine ground.<br><i>Connector &amp; terminal</i><br><i>(E10) No. 1 — Engine ground:</i><br><i>(E10) No. 2 — Engine ground:</i>   | Is the resistance 1 MΩ or more?   | Go to step 5.  | Repair short circuit to ground in harness between ECM connector and crankshaft position sensor connector.   |
| <b>5 CHECK HARNESS BETWEEN ECM AND CRANKSHAFT POSITION SENSOR CONNECTOR.</b><br>Measure the voltage between crankshaft position sensor connector and engine ground.<br><i>Connector &amp; terminal</i><br><i>(E10) No. 1 (+) — Engine ground (-):</i><br><i>(E10) No. 2 (+) — Engine ground (-):</i>  | Is the voltage 5 V or more?   | Repair the short circuit to power in the harness between ECM connector and crankshaft position sensor connector. | Go to step 6.   |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step   | Check                                 | Yes   | No   |
|--|---------------------------------------|---|--|
| <b>6</b><br><b>CHECK CRANKSHAFT POSITION SENSOR.</b><br>Check waveform of crankshaft position sensor.<br><Ref. to EN(H4DO HEV)(diag)-19, Control Module I/O Signal.> | Is there any abnormality in waveform? | Replace the crankshaft position sensor. <Ref. to FU(H4DO(HEV))-46, Crankshaft Position Sensor.> | Repair the following item. <ul style="list-style-type: none"><li>• Poor contact of ECM connector</li><li>• Poor contact of crankshaft position sensor connector</li><li>• Poor contact of coupling connector</li></ul> |

## Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

### BV:DTC P0336 CRANKSHAFT POSITION SENSOR “A” CIRCUIT RANGE/PERFORMANCE

#### DTC DETECTING CONDITION:

- Detected when two consecutive driving cycles with fault occur.
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-94, DTC P0336 CRANKSHAFT POSITION SENSOR “A” CIRCUIT RANGE/PERFORMANCE, Diagnostic Trouble Code (DTC) Detecting Criteria.>

#### TROUBLE SYMPTOM:

- Engine stalls.
- Failure of engine to start

#### CAUTION:

After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.

| Step   | Check   | Yes   | No   |
|--|---|---|--|
| <b>1</b><br><b>CHECK CONDITION OF CRANKSHAFT POSITION SENSOR.</b><br>Turn the ignition switch to OFF.  | Is the crankshaft position sensor installation bolt tightened securely? | Go to step 2.   | Tighten the crankshaft position sensor installation bolt securely. <Ref. to FU(H4DO(HEV))-48, INSTALLATION, Crankshaft Position Sensor.> |
| <b>2</b><br><b>CHECK CRANKSHAFT POSITION SENSOR PLATE.</b>   | Is there crack or damage in the crankshaft position sensor plate teeth? | Replace the crankshaft position sensor plate. <Ref. to ME(H4DO(w/o HEV))-304, Cylinder Block.>              | Go to step 3.  |
| <b>3</b><br><b>CHECK INSTALLATION CONDITION OF TIMING CHAIN.</b><br>Turn the crankshaft, and align alignment mark on crank sprocket with alignment mark on cylinder block.<br>ST 18252AA000      CRANKSHAFT SOCKET | Is the timing chain dislocated from its proper position?                | Correct the installation condition of timing chain. <Ref. to ME(H4DO(w/o HEV))-169, Timing Chain Assembly.> | Replace the crankshaft position sensor. <Ref. to FU(H4DO(HEV))-46, Crankshaft Position Sensor.>  |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

## BW:DTC P0340 CAMSHAFT POSITION SENSOR "A" CIRCUIT (BANK 1 OR SINGLE SENSOR)

### DTC DETECTING CONDITION:

- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-96, DTC P0340 CAMSHAFT POSITION SENSOR "A" CIRCUIT (BANK 1 OR SINGLE SENSOR), Diagnostic Trouble Code (DTC) Detecting Criteria.>

### TROUBLE SYMPTOM:


- Engine stalls.
- Failure of engine to start

### CAUTION:

After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.

### WIRING DIAGRAM:

- Engine electrical system (without push button start) <Ref. to WI(HEV)-100, WITHOUT PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>
- Engine electrical system (with push button start) <Ref. to WI(HEV)-114, WITH PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>



EN-10747

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

## ENGINE (DIAGNOSTICS)

| Step   | Check   | Yes  | No  |
|--|---|--|---|
| <p><b>1 CHECK POWER SUPPLY OF CAMSHAFT POSITION SENSOR.</b></p> <p>1) Turn the ignition switch to OFF.<br/>2) Disconnect the connector from camshaft position sensor.<br/>3) Turn the ignition switch to ON.<br/>4) Measure the voltage between camshaft position sensor connector and engine ground.</p> <p><b>Connector &amp; terminal</b><br/><b>(E36) No. 1 (+) — Engine ground (-):</b></p> | Is the voltage 10 V or more?  | Go to step 2.  | Repair the harness and connector.<br><br><b>NOTE:</b><br>In this case, repair the following item:<br><ul style="list-style-type: none"> <li>• Open circuit or short circuit to ground in harness between main relay connector and camshaft position sensor connector</li> <li>• Poor contact of coupling connector</li> </ul> |
| <p><b>2 CHECK HARNESS BETWEEN ECM AND CAMSHAFT POSITION SENSOR CONNECTOR.</b></p> <p>1) Turn the ignition switch to OFF.<br/>2) Disconnect the connector from ECM.<br/>3) Measure the resistance between ECM connector and camshaft position sensor connector.</p> <p><b>Connector &amp; terminal</b><br/><b>(B136) No. 26 — (E36) No. 2:</b><br/><b>(B136) No. 34 — (E36) No. 3:</b></p>        | Is the resistance less than 1 Ω?                                      | Go to step 3.  | Repair the harness and connector.<br><br><b>NOTE:</b><br>In this case, repair the following item:<br><ul style="list-style-type: none"> <li>• Open circuit in harness between ECM connector and camshaft position sensor connector</li> <li>• Poor contact of coupling connector</li> </ul>                                   |
| <p><b>3 CHECK HARNESS BETWEEN ECM AND CAMSHAFT POSITION SENSOR CONNECTOR.</b></p> <p>Measure the resistance between camshaft position sensor connector and engine ground.</p> <p><b>Connector &amp; terminal</b><br/><b>(E36) No. 2 — Engine ground:</b></p>   | Is the resistance 1 MΩ or more?                                       | Go to step 4.  | Repair short circuit to ground in harness between ECM connector and camshaft position sensor connector.   |
| <p><b>4 CHECK HARNESS BETWEEN ECM AND CAMSHAFT POSITION SENSOR CONNECTOR.</b></p> <p>Measure the voltage between camshaft position sensor connector and engine ground.</p> <p><b>Connector &amp; terminal</b><br/><b>(E36) No. 2 (+) — Engine ground (-):</b></p>  | Is the voltage 5 V or more?   | Repair the short circuit to power in the harness between ECM connector and camshaft position sensor connector. | Go to step 5.   |
| <p><b>5 CHECK CONDITION OF CAMSHAFT POSITION SENSOR.</b></p>   | Is the camshaft position sensor installation bolt tightened securely? | Go to step 6.  | Tighten the camshaft position sensor installation bolt securely. <Ref. to FU(H4DO(HEV))-53, INSTALLATION, Camshaft Position Sensor.>  |
| <p><b>6 CHECK CAMSHAFT POSITION SENSOR.</b></p> <p>Check the waveform of the camshaft position sensor. &lt;Ref. to EN(H4DO HEV)(diag)-19, ENGINE CONTROL MODULE (ECM), ELECTRICAL SPECIFICATION, Control Module I/O Signal.&gt;</p>  | Is there any abnormality in waveform?                                 | Replace the camshaft position sensor. <Ref. to FU(H4DO(HEV))-52, Camshaft Position Sensor.>                    | Repair the following item.<br><ul style="list-style-type: none"> <li>• Poor contact of ECM connector</li> <li>• Poor contact of camshaft position sensor connector</li> <li>• Poor contact of coupling connector</li> </ul>   |

## Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

---

### **BX:DTC P0341 CAMSHAFT POSITION SENSOR "A" CIRCUIT RANGE/PERFORMANCE (BANK 1 OR SINGLE SENSOR)**

**NOTE:**

For the diagnostic procedure, refer to DTC P0340. <Ref. to EN(H4DO HEV)(diag)-219, DTC P0340 CAMSHAFT POSITION SENSOR "A" CIRCUIT (BANK 1 OR SINGLE SENSOR), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

## BY:DTC P0345 CAMSHAFT POSITION SENSOR "A" CIRCUIT (BANK 2)

### DTC DETECTING CONDITION:

- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-99, DTC P0345 CAMSHAFT POSITION SENSOR "A" CIRCUIT (BANK 2), Diagnostic Trouble Code (DTC) Detecting Criteria.>

### TROUBLE SYMPTOM:


- Engine stalls.
- Failure of engine to start

### CAUTION:

After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.

### WIRING DIAGRAM:

- Engine electrical system (without push button start) <Ref. to WI(HEV)-100, WITHOUT PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>
- Engine electrical system (with push button start) <Ref. to WI(HEV)-114, WITH PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>



EN-10747

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step   | Check  | Yes   | No  |
|--|--|---|---|
| <p><b>1</b></p> <p><b>CHECK POWER SUPPLY OF CAMSHAFT POSITION SENSOR.</b></p> <p>1) Turn the ignition switch to OFF.<br/>2) Disconnect the connector from camshaft position sensor.<br/>3) Turn the ignition switch to ON.<br/>4) Measure the voltage between camshaft position sensor connector and engine ground.</p> <p><b>Connector &amp; terminal</b><br/><b>(E35) No. 1 (+) — Engine ground (-):</b></p> | <p>Is the voltage 10 V or more?</p>  | <p>Go to step 2.</p>  | <p>Repair the harness and connector.</p> <p>NOTE:<br/>In this case, repair the following item:</p> <ul style="list-style-type: none"> <li>• Open circuit or short circuit to ground in harness between main relay connector and camshaft position sensor connector</li> <li>• Poor contact of coupling connector</li> </ul> |
| <p><b>2</b></p> <p><b>CHECK HARNESS BETWEEN ECM AND CAMSHAFT POSITION SENSOR CONNECTOR.</b></p> <p>1) Turn the ignition switch to OFF.<br/>2) Disconnect the connector from ECM.<br/>3) Measure the resistance between ECM connector and camshaft position sensor connector.</p> <p><b>Connector &amp; terminal</b><br/><b>(B136) No. 15 — (E35) No. 2:</b><br/><b>(B136) No. 34 — (E35) No. 3:</b></p>        | <p>Is the resistance less than 1 Ω?</p>                                      | <p>Go to step 3.</p>  | <p>Repair the harness and connector.</p> <p>NOTE:<br/>In this case, repair the following item:</p> <ul style="list-style-type: none"> <li>• Open circuit in harness between ECM connector and camshaft position sensor connector</li> <li>• Poor contact of coupling connector</li> </ul>                                   |
| <p><b>3</b></p> <p><b>CHECK HARNESS BETWEEN ECM AND CAMSHAFT POSITION SENSOR CONNECTOR.</b></p> <p>Measure the resistance between camshaft position sensor connector and engine ground.</p> <p><b>Connector &amp; terminal</b><br/><b>(E35) No. 2 — Engine ground:</b></p>   | <p>Is the resistance 1 MΩ or more?</p>                                       | <p>Go to step 4.</p>  | <p>Repair short circuit to ground in harness between ECM connector and camshaft position sensor connector.</p>  |
| <p><b>4</b></p> <p><b>CHECK HARNESS BETWEEN ECM AND CAMSHAFT POSITION SENSOR CONNECTOR.</b></p> <p>Measure the voltage between camshaft position sensor connector and engine ground.</p> <p><b>Connector &amp; terminal</b><br/><b>(E35) No. 2 (+) — Engine ground (-):</b></p>  | <p>Is the voltage 5 V or more?</p>   | <p>Repair the short circuit to power in the harness between ECM connector and camshaft position sensor connector.</p> | <p>Go to step 5.</p>  |
| <p><b>5</b></p> <p><b>CHECK CONDITION OF CAMSHAFT POSITION SENSOR.</b></p>   | <p>Is the camshaft position sensor installation bolt tightened securely?</p> | <p>Go to step 6.</p>  | <p>Tighten the camshaft position sensor installation bolt securely. &lt;Ref. to FU(H4DO(HEV))-53, INSTALLATION, Camshaft Position Sensor.&gt;</p>   |
| <p><b>6</b></p> <p><b>CHECK CAMSHAFT POSITION SENSOR.</b></p> <p>Check the waveform of the camshaft position sensor. &lt;Ref. to EN(H4DO HEV)(diag)-19, ENGINE CONTROL MODULE (ECM), ELECTRICAL SPECIFICATION, Control Module I/O Signal.&gt;</p>  | <p>Is there any abnormality in waveform?</p>                                 | <p>Replace the camshaft position sensor. &lt;Ref. to FU(H4DO(HEV))-52, Camshaft Position Sensor.&gt;</p>              | <p>Repair the following item.</p> <ul style="list-style-type: none"> <li>• Poor contact of ECM connector</li> <li>• Poor contact of camshaft position sensor connector</li> <li>• Poor contact of coupling connector</li> </ul>   |

## **Diagnostic Procedure with Diagnostic Trouble Code (DTC)**

ENGINE (DIAGNOSTICS)

---

### **BZ:DTC P0346 CAMSHAFT POSITION SENSOR "A" CIRCUIT RANGE/PERFORMANCE (BANK 2)**

NOTE:

For the diagnostic procedure, refer to DTC P0345. <Ref. to EN(H4DO HEV)(diag)-222, DTC P0345 CAMSHAFT POSITION SENSOR "A" CIRCUIT (BANK 2), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

## CA:DTC P0351 IGNITION COIL A PRIMARY/SECONDARY CIRCUIT

### DTC DETECTING CONDITION:

- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-100, DTC P0351 IGNITION COIL A PRIMARY/SECONDARY CIRCUIT, Diagnostic Trouble Code (DTC) Detecting Criteria.>

### TROUBLE SYMPTOM:


- Improper idling
- Poor driving performance

### CAUTION:

After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.

### WIRING DIAGRAM:

- Engine electrical system (without push button start) <Ref. to WI(HEV)-100, WITHOUT PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>
- Engine electrical system (with push button start) <Ref. to WI(HEV)-114, WITH PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>



EN-11312

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

## ENGINE (DIAGNOSTICS)

| Step  | Check                                   | Yes   | No   |
|---|---|---|--|
| <p><b>1 CHECK IGNITION COIL POWER SUPPLY CIRCUIT.</b></p> <p>1) Turn the ignition switch to OFF.<br/>                     2) Disconnect the connector from ignition coil.<br/>                     3) Turn the ignition switch to ON.<br/>                     4) Measure the voltage between ignition coil connector and engine ground.</p> <p><b>Connector &amp; terminal</b><br/> <b>DTC P0351; (E31) No. 1 (+) — Engine ground (-):</b><br/> <b>DTC P0352; (E32) No. 1 (+) — Engine ground (-):</b><br/> <b>DTC P0353; (E33) No. 1 (+) — Engine ground (-):</b><br/> <b>DTC P0354; (E34) No. 1 (+) — Engine ground (-):</b></p> | Is the voltage 10 V or more?            | Go to step 2.   | Repair the harness and connector.<br><br>NOTE:<br>In this case, repair the following item:<br>• Open circuit or short circuit to ground in harness of power supply circuit<br>• Blown out of fuse<br>• Poor contact of IG relay connector<br>• Poor contact of coupling connector<br>• Faulty IG relay |
| <p><b>2 CHECK HARNESS OF IGNITION COIL GROUND CIRCUIT.</b></p> <p>1) Turn the ignition switch to OFF.<br/>                     2) Measure the resistance of harness between ignition coil connector and engine ground.</p> <p><b>Connector &amp; terminal</b><br/> <b>DTC P0351; (E31) No. 3 — Engine ground:</b><br/> <b>DTC P0352; (E32) No. 3 — Engine ground:</b><br/> <b>DTC P0353; (E33) No. 3 — Engine ground:</b><br/> <b>DTC P0354; (E34) No. 3 — Engine ground:</b></p>   | Is the resistance less than 5 Ω?        | Go to step 3.   | Repair the open circuit in harness between ignition coil connector and engine grounding terminal.  |
| <p><b>3 CHECK HARNESS BETWEEN ECM AND IGNITION COIL CONNECTOR.</b></p> <p>1) Disconnect the connector from ECM.<br/>                     2) Measure the resistance between ignition coil connector and engine ground.</p> <p><b>Connector &amp; terminal</b><br/> <b>DTC P0351; (E31) No. 2 — Engine ground:</b><br/> <b>DTC P0352; (E32) No. 2 — Engine ground:</b><br/> <b>DTC P0353; (E33) No. 2 — Engine ground:</b><br/> <b>DTC P0354; (E34) No. 2 — Engine ground:</b></p>  | Is the resistance 1 MΩ or more?         | Go to step 4.   | Repair the ground short circuit of harness between ECM connector and ignition coil connector.  |
| <p><b>4 CHECK HARNESS BETWEEN ECM AND IGNITION COIL CONNECTOR.</b></p> <p>Measure the resistance of harness between ECM connector and ignition coil connector.</p> <p><b>Connector &amp; terminal</b><br/> <b>DTC P0351; (B134) No. 21 — (E31) No. 2:</b><br/> <b>DTC P0352; (B134) No. 10 — (E32) No. 2:</b><br/> <b>DTC P0353; (B134) No. 31 — (E33) No. 2:</b><br/> <b>DTC P0354; (B134) No. 8 — (E34) No. 2:</b></p>  | Is the resistance less than 1 Ω?        | Go to step 5.   | Repair the harness and connector.<br><br>NOTE:<br>In this case, repair the following item:<br>• Open circuit of harness between ECM connector and the ignition coil connector<br>• Poor contact of coupling connector  |
| <p><b>5 CHECK FOR POOR CONTACT.</b></p> <p>Check for poor contact of ECM connector.</p>   | Is there poor contact of ECM connector? | Repair the poor contact of ECM connector.                                 | Go to step 6.  |
| <p><b>6 CHECK SPARK PLUG CONDITION.</b></p> <p>1) Remove the spark plug of the corresponding cylinder. &lt;Ref. to IG(H4DO(w/o HEV))-4, REMOVAL, Spark Plug.&gt;<br/>                     2) Check the spark plug condition. &lt;Ref. to IG(H4DO(w/o HEV))-7, INSPECTION, Spark Plug.&gt;</p>   | Is the spark plug condition normal?     | Replace the ignition coil. <Ref. to IG(H4DO(w/o HEV))-12, Ignition Coil.> | Replace the spark plug. <Ref. to IG(H4DO(w/o HEV))-4, Spark Plug.>   |

## **CB:DTC P0352 IGNITION COIL B PRIMARY/SECONDARY CIRCUIT**

**NOTE:**

For the diagnostic procedure, refer to DTC P0351. <Ref. to EN(H4DO HEV)(diag)-225, DTC P0351 IGNITION COIL A PRIMARY/SECONDARY CIRCUIT, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

## **CC:DTC P0353 IGNITION COIL C PRIMARY/SECONDARY CIRCUIT**

**NOTE:**

For the diagnostic procedure, refer to DTC P0351. <Ref. to EN(H4DO HEV)(diag)-225, DTC P0351 IGNITION COIL A PRIMARY/SECONDARY CIRCUIT, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

## **CD:DTC P0354 IGNITION COIL D PRIMARY/SECONDARY CIRCUIT**

**NOTE:**

For the diagnostic procedure, refer to DTC P0351. <Ref. to EN(H4DO HEV)(diag)-225, DTC P0351 IGNITION COIL A PRIMARY/SECONDARY CIRCUIT, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

## CE:DTC P0365 CAMSHAFT POSITION SENSOR "B" CIRCUIT (BANK 1)

### DTC DETECTING CONDITION:

- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-101, DTC P0365 CAMSHAFT POSITION SENSOR "B" CIRCUIT (BANK 1), Diagnostic Trouble Code (DTC) Detecting Criteria.>

### TROUBLE SYMPTOM:



- Engine stalls.
- Failure of engine to start

### CAUTION:

After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.

### WIRING DIAGRAM:

- Engine electrical system (without push button start) <Ref. to WI(HEV)-100, WITHOUT PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>
- Engine electrical system (with push button start) <Ref. to WI(HEV)-114, WITH PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>



EN-10748

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step  | Check   | Yes  | No   |
|---|---|--|--|
| <b>1 CHECK POWER SUPPLY OF CAMSHAFT POSITION SENSOR.</b><br>1) Turn the ignition switch to OFF.<br>2) Disconnect the connector from camshaft position sensor.<br>3) Turn the ignition switch to ON.<br>4) Measure the voltage between camshaft position sensor connector and engine ground.<br><b>Connector &amp; terminal</b><br><b>(E62) No. 1 (+) — Engine ground (-):</b> | Is the voltage 10 V or more?  | Go to step 2.  | Repair the harness and connector.<br>NOTE:<br>In this case, repair the following item:<br>• Open circuit or short circuit to ground in harness between main relay connector and camshaft position sensor connector<br>• Poor contact of coupling connector |
| <b>2 CHECK HARNESS BETWEEN ECM AND CAMSHAFT POSITION SENSOR CONNECTOR.</b><br>1) Turn the ignition switch to OFF.<br>2) Disconnect the connector from ECM.<br>3) Measure the resistance between ECM connector and camshaft position sensor connector.<br><b>Connector &amp; terminal</b><br><b>(B136) No. 14 — (E62) No. 2:</b><br><b>(B136) No. 34 — (E62) No. 3:</b>        | Is the resistance less than 1 Ω?                                      | Go to step 3.  | Repair the harness and connector.<br>NOTE:<br>In this case, repair the following item:<br>• Open circuit in harness between ECM connector and camshaft position sensor connector<br>• Poor contact of coupling connector                                   |
| <b>3 CHECK HARNESS BETWEEN ECM AND CAMSHAFT POSITION SENSOR CONNECTOR.</b><br>Measure the resistance between camshaft position sensor connector and engine ground.<br><b>Connector &amp; terminal</b><br><b>(E62) No. 2 — Engine ground:</b>  | Is the resistance 1 MΩ or more?                                       | Go to step 4.  | Repair short circuit to ground in harness between ECM connector and camshaft position sensor connector.  |
| <b>4 CHECK HARNESS BETWEEN ECM AND CAMSHAFT POSITION SENSOR CONNECTOR.</b><br>Measure the voltage between camshaft position sensor connector and engine ground.<br><b>Connector &amp; terminal</b><br><b>(E62) No. 2 (+) — Engine ground (-):</b>   | Is the voltage 5 V or more?   | Repair the short circuit to power in the harness between ECM connector and camshaft position sensor connector. | Go to step 5.  |
| <b>5 CHECK CONDITION OF CAMSHAFT POSITION SENSOR.</b>   | Is the camshaft position sensor installation bolt tightened securely? | Go to step 6.  | Tighten the camshaft position sensor installation bolt securely. <Ref. to FU(H4DO(HEV))-53, INSTALLATION, Camshaft Position Sensor.>   |
| <b>6 CHECK CAMSHAFT POSITION SENSOR.</b><br>Check the waveform of the camshaft position sensor. <Ref. to EN(H4DO HEV)(diag)-19, ENGINE CONTROL MODULE (ECM), ELECTRICAL SPECIFICATION, Control Module I/O Signal.>  | Is there any abnormality in waveform?                                 | Replace the camshaft position sensor. <Ref. to FU(H4DO(HEV))-52, Camshaft Position Sensor.>                    | Repair the following item.<br>• Poor contact of ECM connector<br>• Poor contact of camshaft position sensor connector<br>• Poor contact of coupling connector  |

## **Diagnostic Procedure with Diagnostic Trouble Code (DTC)**

ENGINE (DIAGNOSTICS)

---

### **CF:DTC P0366 CAMSHAFT POSITION SENSOR B CIRCUIT RANGE/PERFORMANCE (BANK 1)**

**NOTE:**

For the diagnostic procedure, refer to DTC P0365. <Ref. to EN(H4DO HEV)(diag)-228, DTC P0365 CAMSHAFT POSITION SENSOR "B" CIRCUIT (BANK 1), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

## CG:DTC P0390 CAMSHAFT POSITION SENSOR "B" CIRCUIT (BANK 2)

### DTC DETECTING CONDITION:

- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-103, DTC P0390 CAMSHAFT POSITION SENSOR "B" CIRCUIT (BANK 2), Diagnostic Trouble Code (DTC) Detecting Criteria.>

### TROUBLE SYMPTOM:


- Engine stalls.
- Failure of engine to start

### CAUTION:

After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.

### WIRING DIAGRAM:

- Engine electrical system (without push button start) <Ref. to WI(HEV)-100, WITHOUT PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>
- Engine electrical system (with push button start) <Ref. to WI(HEV)-114, WITH PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>



EN-10748

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

## ENGINE (DIAGNOSTICS)

| Step   | Check   | Yes  | No   |
|--|---|--|--|
| <p><b>1 CHECK POWER SUPPLY OF CAMSHAFT POSITION SENSOR.</b></p> <p>1) Turn the ignition switch to OFF.<br/>                     2) Disconnect the connector from camshaft position sensor.<br/>                     3) Turn the ignition switch to ON.<br/>                     4) Measure the voltage between camshaft position sensor connector and engine ground.</p> <p><b>Connector &amp; terminal</b><br/> <b>(E65) No. 1 (+) — Engine ground (-):</b></p> | Is the voltage 10 V or more?  | Go to step 2.  | Repair the harness and connector.<br><br>NOTE:<br>In this case, repair the following item:<br>• Open circuit or short circuit to ground in harness between main relay connector and camshaft position sensor connector<br>• Poor contact of coupling connector |
| <p><b>2 CHECK HARNESS BETWEEN ECM AND CAMSHAFT POSITION SENSOR CONNECTOR.</b></p> <p>1) Turn the ignition switch to OFF.<br/>                     2) Disconnect the connector from ECM.<br/>                     3) Measure the resistance between ECM connector and camshaft position sensor connector.</p> <p><b>Connector &amp; terminal</b><br/> <b>(B136) No. 25 — (E65) No. 2:</b><br/> <b>(B136) No. 34 — (E65) No. 3:</b></p>                            | Is the resistance less than 1 Ω?                                      | Go to step 3.  | Repair the harness and connector.<br><br>NOTE:<br>In this case, repair the following item:<br>• Open circuit in harness between ECM connector and camshaft position sensor connector<br>• Poor contact of coupling connector                                   |
| <p><b>3 CHECK HARNESS BETWEEN ECM AND CAMSHAFT POSITION SENSOR CONNECTOR.</b></p> <p>Measure the resistance between camshaft position sensor connector and engine ground.</p> <p><b>Connector &amp; terminal</b><br/> <b>(E65) No. 2 — Engine ground:</b></p>  | Is the resistance 1 MΩ or more?                                       | Go to step 4.  | Repair short circuit to ground in harness between ECM connector and camshaft position sensor connector.  |
| <p><b>4 CHECK HARNESS BETWEEN ECM AND CAMSHAFT POSITION SENSOR CONNECTOR.</b></p> <p>Measure the voltage between camshaft position sensor connector and engine ground.</p> <p><b>Connector &amp; terminal</b><br/> <b>(E65) No. 2 (+) — Engine ground (-):</b></p>   | Is the voltage 5 V or more?   | Repair the short circuit to power in the harness between ECM connector and camshaft position sensor connector. | Go to step 5.  |
| <p><b>5 CHECK CONDITION OF CAMSHAFT POSITION SENSOR.</b></p>   | Is the camshaft position sensor installation bolt tightened securely? | Go to step 6.  | Tighten the camshaft position sensor installation bolt securely. <Ref. to FU(H4DO(HEV))-53, INSTALLATION, Camshaft Position Sensor.>   |
| <p><b>6 CHECK CAMSHAFT POSITION SENSOR.</b></p> <p>Check the waveform of the camshaft position sensor. &lt;Ref. to EN(H4DO HEV)(diag)-19, ENGINE CONTROL MODULE (ECM), ELECTRICAL SPECIFICATION, Control Module I/O Signal.&gt;</p>  | Is there any abnormality in waveform?                                 | Replace the camshaft position sensor. <Ref. to FU(H4DO(HEV))-52, Camshaft Position Sensor.>                    | Repair the following item.<br>• Poor contact of ECM connector<br>• Poor contact of camshaft position sensor connector<br>• Poor contact of coupling connector  |

## Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

---

### **CH:DTC P0391 CAMSHAFT POSITION SENSOR B CIRCUIT RANGE/PERFORMANCE (BANK 2)**

**NOTE:**

For the diagnostic procedure, refer to DTC P0390. <Ref. to EN(H4DO HEV)(diag)-231, DTC P0390 CAMSHAFT POSITION SENSOR "B" CIRCUIT (BANK 2), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

## CI: DTC P0400 EXHAUST GAS RECIRCULATION FLOW

### DTC DETECTING CONDITION:

- Detected when two consecutive driving cycles with fault occur.
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-104, DTC P0400 EXHAUST GAS RECIRCULATION FLOW, Diagnostic Trouble Code (DTC) Detecting Criteria.>

### TROUBLE SYMPTOM:

- Movement performance problem when engine is low speed
- Improper idling
- Movement performance problem

### CAUTION:

After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.

|   | Step  | Check  | Yes   | No  |
|---|---|--|---|---|
| 1 | <b>CHECK CURRENT DATA.</b><br>1) Start the engine.<br>2) Read the value of «Mani. Absolute Pressure» using the Subaru Select Monitor or a general scan tool.<br><b>NOTE:</b> <ul style="list-style-type: none"><li>• Subaru Select Monitor</li></ul> For detailed operation procedures, refer to “Current Data Display For Engine”. <Ref. to EN(H4DO HEV)(diag)-36, Subaru Select Monitor.> <ul style="list-style-type: none"><li>• General scan tool</li></ul> For detailed operation procedures, refer to the general scan tool operation manual. | Is the value of «Mani. Absolute Pressure» 53.3 kPa (400 mmHg, 15.75 inHg) or more? | Make sure that the EGR control valve, manifold absolute pressure sensor and throttle body are installed securely. | Go to step 2.   |
| 2 | <b>CHECK EGR CONTROL VALVE.</b><br>Remove the EGR control valve.  | Are there any holes, clogged lines or foreign matters in the EGR system?           | Repair the EGR system.  | Replace EGR control valve. <Ref. to EC(H4DO(HEV))-26, EGR Control Valve.> |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

## CJ:DTC P0420 CATALYST SYSTEM EFFICIENCY BELOW THRESHOLD (BANK 1)

### DTC DETECTING CONDITION:

- Detected when two consecutive driving cycles with fault occur.
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-106, DTC P0420 CATALYST SYSTEM EFFICIENCY BELOW THRESHOLD (BANK 1), Diagnostic Trouble Code (DTC) Detecting Criteria.>

### TROUBLE SYMPTOM:


- Engine stalls.
- Idle mixture is out of specifications.

### CAUTION:

After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.

### WIRING DIAGRAM:



- Engine electrical system (without push button start) <Ref. to WI(HEV)-100, WITHOUT PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>
- Engine electrical system (with push button start) <Ref. to WI(HEV)-114, WITH PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>



EN-10740




# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

## ENGINE (DIAGNOSTICS)

| Step  | Check  | Yes  | No                   |
|---|--|--|----------------------|
| <p><b>1</b></p> <p><b>CHECK EXHAUST SYSTEM.</b><br/>Check for gas leaks or air suction caused by loose or dislocated nuts and bolts, and open hole at exhaust pipes.</p> <p>NOTE:<br/>Check the following positions.</p> <ul style="list-style-type: none"> <li>• Between cylinder head and front exhaust pipe</li> <li>• Between front exhaust pipe and front catalytic converter</li> <li>• Between front catalytic converter and rear catalytic converter</li> <li>• Loose or improperly attached front oxygen (A/F) sensor or rear oxygen sensor</li> </ul>   | <p>Is there any fault in exhaust system?</p> | <p>Repair or replace the exhaust system. &lt;Ref. to EX(H4DO(w/o HEV))-2, General Description.&gt;</p>   | <p>Go to step 2.</p> |
| <p><b>2</b></p> <p><b>CHECK WAVEFORM DATA ON THE SUBARU SELECT MONITOR (WHILE DRIVING).</b></p> <p>1) Drive at a constant speed between 80 — 112 km/h (50 — 70 MPH).</p> <p>2) After 5 minutes have elapsed in the condition of step 1), use the Subaru Select Monitor while still driving to read the waveform data.</p> <ul style="list-style-type: none"> <li>• At normal condition</li> </ul>  <p>10 sec/div EN-06666</p> <ul style="list-style-type: none"> <li>• At abnormal condition (numerous inversion)</li> </ul>  <p>10 sec/div EN-06667</p> | <p>Is a normal waveform displayed?</p>       | <p>Even if DTC is detected, the circuit has returned to a normal condition at this time. Reproduce the failure, and then perform the diagnosis again.</p> <p>NOTE:<br/>In this case, temporary poor contact of connector, temporary open or short circuit of harness may be the cause.</p> | <p>Go to step 3.</p> |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step  | Check                                      | Yes   | No   |
|---|--|---|--|
| <p><b>3</b>      <b>CHECK WAVEFORM DATA ON THE SUBARU SELECT MONITOR (WHILE IDLING).</b></p> <p>1) Run the engine at idle.<br/>2) In the condition of step 1), use the Subaru Select Monitor to read the waveform data.</p> <ul style="list-style-type: none"> <li>• At normal condition</li> </ul>  <p>10 sec/div      EN-06668</p> <ul style="list-style-type: none"> <li>• At abnormal condition 1 (numerous inversion)</li> </ul>  <p>10 sec/div      EN-06669</p> <ul style="list-style-type: none"> <li>• At abnormal condition 2 (noise input)</li> </ul>  <p>10 sec/div      EN-06670</p> | <p>Is a normal waveform displayed?</p>     | <p>Go to step 4.</p>  | <ul style="list-style-type: none"> <li>• The waveform is displayed at abnormal condition 1: Go to step 4.</li> <li>• The waveform is displayed at abnormal condition 2: Go to step 5.</li> </ul> |
| <p><b>4</b>      <b>CHECK CATALYTIC CONVERTER.</b></p>  | <p>Is the catalytic converter damaged?</p> | <p>Replace the catalytic converter.<br/>&lt;Ref. to EC(H4DO(HEV))-6, Front Catalytic Converter.&gt;</p> | <p>Go to step 5.</p>   |
| <p><b>5</b>      <b>CHECK REAR OXYGEN SENSOR CONNECTOR AND COUPLING CONNECTOR.</b></p>  | <p>Has water entered the connector?</p>    | <p>Completely remove any water inside.</p>  | <p>Go to step 6.</p>   |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

## ENGINE (DIAGNOSTICS)

| Step  | Check   | Yes   | No  |
|---|---|---|---|
| <p><b>6 CHECK HARNESS BETWEEN ECM AND REAR OXYGEN SENSOR CONNECTOR.</b></p> <p>1) Turn the ignition switch to OFF.<br/>                     2) Disconnect the connector from ECM and rear oxygen sensor.<br/>                     3) Measure the resistance of harness between ECM connector and rear oxygen sensor connector.</p> <p><b>Connector &amp; terminal</b><br/> <b>(B136) No. 21 — (E25) No. 3:</b><br/> <b>(B135) No. 30 — (E25) No. 4:</b></p> | Is the resistance less than 1 Ω?                                      | Go to step 7.   | Repair the harness and connector.<br>NOTE:<br>Repair the following locations.<br>• Open circuit in harness between ECM connector and rear oxygen sensor connector<br>• Poor contact of coupling connector |
| <p><b>7 CHECK REAR OXYGEN SENSOR SHIELD.</b></p> <p>1) Turn the ignition switch to OFF.<br/>                     2) Expose the rear oxygen sensor connector body side harness sensor shield.<br/>                     3) Measure the resistance between sensor shield and chassis ground.</p>   | Is the resistance less than 1 Ω?                                      | Go to step 8.   | Repair the open circuit of rear oxygen sensor harness.  |
| <p><b>8 CHECK ENGINE OIL AMOUNT AND EXHAUST GAS.</b></p> <p>1) Check the engine oil amount. &lt;Ref. to LU(H4DO(w/o HEV))-12, INSPECTION, Engine Oil.&gt;<br/>                     2) Check exhaust gas during idling.</p>  | Does the engine oil amount drop or white smoke emit from the muffler? | Check the engine, and repair the defective part.<br><Ref. to ME(H4DO(w/o HEV))-421, INSPECTION, Engine Trouble in General.><br>After repairing the engine, replace the front catalytic converter. <Ref. to EX(H4DO(w/o HEV))-6, Front Exhaust Pipe.><br>After the catalytic converter is replaced, perform step 2 to check the normal waveform is displayed, and then exit the procedure. | Go to step 9.   |
| <p><b>9 CHECK IGNITION SYSTEM.</b></p> <p>1) Check the spark plug. &lt;Ref. to IG(H4DO(w/o HEV))-7, INSPECTION, Spark Plug.&gt;<br/>                     2) Check the status of the ignition coil connector and the spark plug terminal.</p>  | Is there any fault in the ignition system?                            | After repairing the ignition system, replace the front catalytic converter. <Ref. to EX(H4DO(w/o HEV))-6, Front Exhaust Pipe.><br>After the catalytic converter is replaced, perform step 2 to check the normal waveform is displayed, and then exit the procedure.   | Go to step 10.  |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step  | Check   | Yes   | No   |
|---|---|---|--|
| <p><b>10</b>      <b>CHECK FUEL SYSTEM.</b><br/>                     1) Refer to and check the items in "Insufficient fuel supply to fuel injector (except for "a. Fuel pump does not operate.")" and "Leakage or blow out of fuel". &lt;Ref. to FU(H4DO(HEV))-158, INSPECTION, Fuel System Trouble in General.&gt;<br/>                     2) Check throttle body. &lt;Ref. to FU(H4DO(HEV))-17, INSPECTION, Throttle Body.&gt;<br/>                     3) Check intake manifold. &lt;Ref. to FU(H4DO(HEV))-33, INSPECTION, Intake Manifold.&gt;</p> | <p>Is there any fault in the fuel system?</p> | <p>After repairing the fuel system, replace the front catalytic converter. &lt;Ref. to EX(H4DO(w/o HEV))-6, Front Exhaust Pipe.&gt;<br/>                     After the catalytic converter is replaced, perform step 2 to check the normal waveform is displayed, and then exit the procedure.</p>  | <p>Go to step 11.</p>  |
| <p><b>11</b>      <b>CHECK DTC.</b></p>   | <p>Is any other DTC displayed?</p>            | <p>Check the appropriate DTC using the "List of Diagnostic Trouble Code (DTC)". &lt;Ref. to EN(H4DO HEV)(diag)-92, List of Diagnostic Trouble Code (DTC).&gt;<br/>                     After checking the DTC, replace the front catalytic converter. &lt;Ref. to EX(H4DO(w/o HEV))-6, Front Exhaust Pipe.&gt;<br/>                     After the catalytic converter is replaced, perform step 2 to check the normal waveform is displayed, and then exit the procedure.</p> | <p>Replace the rear oxygen sensor. &lt;Ref. to FU(H4DO(HEV))-82, Rear Oxygen Sensor.&gt;</p> |

## Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

### CK:DTC P0441 EVAPORATIVE EMISSION CONT. SYS. INCORRECT PURGE FLOW

#### DTC DETECTING CONDITION:

- Detected when two consecutive driving cycles with fault occur.
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-108, DTC P0441 EVAPORATIVE EMISSION CONT. SYS. INCORRECT PURGE FLOW, Diagnostic Trouble Code (DTC) Detecting Criteria.>

#### TROUBLE SYMPTOM:

Improper idling

#### CAUTION:

**After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.**

| Step   | Check  | Yes  | No  |
|--|--|--|---|
| <b>1</b><br><b>CHECK FOR ANY OTHER DTC ON DISPLAY.</b>   | Is any other DTC displayed?  | Check the appropriate DTC using the "List of Diagnostic Trouble Code (DTC)". <Ref. to EN(H4DO HEV)(diag)-92, List of Diagnostic Trouble Code (DTC).> | Go to step 2.   |
| <b>2</b><br><b>CHECK PURGE CONTROL SOLENOID VALVE.</b><br>Operate the purge control solenoid valve using the Subaru Select Monitor.<br>NOTE:<br>For detailed procedures, refer to "System Operation Check Mode". <Ref. to EN(H4DO HEV)(diag)-67, System Operation Check Mode.> | Does the purge control solenoid valve operate?   | Go to step 3.  | Replace the purge control solenoid valve. <Ref. to EC(H4DO(HEV))-21, Purge Control Solenoid Valve.> |
| <b>3</b><br><b>CHECK EVAPORATIVE EMISSION CONTROL SYSTEM LINE.</b><br>Turn the ignition switch to OFF.   | Are there holes, cracks, clogging, or disconnection, misconnection of hoses or pipes in evaporative emission control system? | Repair or replace the hoses or pipes.  | Repair the poor contact of ECM connector.   |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

## CL:DTC P0451 EVAPORATIVE EMISSION SYSTEM PRESSURE SENSOR/ SWITCH RANGE/PERFORMANCE

### DTC DETECTING CONDITION:

- Detected when two consecutive driving cycles with fault occur.
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-111, DTC P0451 EVAPORATIVE EMISSION SYSTEM PRESSURE SENSOR/SWITCH RANGE/PERFORMANCE, Diagnostic Trouble Code (DTC) Detecting Criteria.>

### CAUTION:

After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.

| Step  | Check   | Yes  | No  |
|---|---|--|---|
| 1<br><b>CHECK FOR ANY OTHER DTC ON DISPLAY.</b>   | Is any other DTC displayed?   | Check the appropriate DTC using the "List of Diagnostic Trouble Code (DTC)". <Ref. to EN(H4DO HEV)(diag)-92, List of Diagnostic Trouble Code (DTC).>   | Go to step 2.   |
| 2<br><b>CHECK CURRENT DATA.</b><br>1) Turn the ignition switch to ON (engine OFF).<br>2) Using the Subaru Select Monitor or general scan tool, read the value in «Absolute Evap Sys. Pressure» and «Mani. Absolute Pressure», and compare them with the actual atmospheric pressure.<br><b>NOTE:</b><br>• Subaru Select Monitor<br>For detailed operation procedures, refer to "Current Data Display For Engine". <Ref. to EN(H4DO HEV)(diag)-36, Subaru Select Monitor.><br>• General scan tool<br>For detailed operation procedures, refer to the general scan tool operation manual.<br>• To read the actual atmospheric pressure, connect the Subaru Select Monitor or general scan tool to the other known good vehicle. | Is the difference with the actual atmospheric pressure 2.4 kPa (17.8 mmHg, 0.7 inHg) or more? | Replace the part that showed larger deviation from the actual atmospheric pressure than the other.<br>• If deviations in value for «Absolute Evap Sys. Pressure» is larger:<br>Replace the leak check valve assembly. <Ref. to EC(H4DO(HEV))-39, Leak Check Valve Assembly.><br>• If deviations in value for «Mani. Absolute Pressure» is larger:<br>Replace the manifold absolute pressure sensor. <Ref. to FU(H4DO(HEV))-66, Manifold Absolute Pressure Sensor.> | Even if DTC is detected, the circuit has returned to a normal condition at this time. Reproduce the failure, and then perform the diagnosis again.<br><b>NOTE:</b><br>In this case, temporary poor contact of connector, temporary open or short circuit of harness may be the cause. |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

## CM:DTC P0452 EVAPORATIVE EMISSION SYSTEM PRESSURE SENSOR/ SWITCH LOW

### DTC DETECTING CONDITION:


- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-113, DTC P0452 EVAPORATIVE EMISSION SYSTEM PRESSURE SENSOR/SWITCH LOW, Diagnostic Trouble Code (DTC) Detecting Criteria.>

### CAUTION:

After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.

### WIRING DIAGRAM:

- Engine electrical system (without push button start) <Ref. to WI(HEV)-100, WITHOUT PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>
- Engine electrical system (with push button start) <Ref. to WI(HEV)-114, WITH PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>



EN-10749

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

|   | Step  | Check  | Yes  | No   |
|---|---|--|--|--|
| 1 | <p><b>CHECK CURRENT DATA.</b></p> <p>1) Turn the ignition switch to ON.</p> <p>2) Read the value of «Atmosphere Pressure» using the Subaru Select Monitor or a general scan tool.</p> <p>NOTE:</p> <ul style="list-style-type: none"> <li>Subaru Select Monitor</li> </ul> <p>For detailed operation procedures, refer to “Current Data Display For Engine”. &lt;Ref. to EN(H4DO HEV)(diag)-36, Subaru Select Monitor.&gt;</p> <ul style="list-style-type: none"> <li>General scan tool</li> </ul> <p>For detailed operation procedures, refer to the general scan tool operation manual.</p> | <p>Is the value in «Atmosphere Pressure» 34 kPa (255 mmHg, 10 inHg) or less?</p> | <p>Go to step 2.</p>   | <p>Even if DTC is detected, the circuit has returned to a normal condition at this time. Reproduce the failure, and then perform the diagnosis again.</p> <p>NOTE:</p> <p>In this case, temporary poor contact of connector, temporary open or short circuit of harness may be the cause.</p>  |
| 2 | <p><b>CHECK POWER SUPPLY OF LEAK CHECK VALVE ASSEMBLY.</b></p> <p>1) Turn the ignition switch to OFF.</p> <p>2) Disconnect the connector from the leak check valve assembly.</p> <p>3) Turn the ignition switch to ON.</p> <p>4) Measure the voltage between the leak check valve assembly connector and chassis ground.</p> <p><b>Connector &amp; terminal</b><br/><b>(R400) No. 6 (+) — Chassis ground (-):</b></p>   | <p>Is the voltage 4.5 V or more?</p>   | <p>Go to step 3.</p>   | <p>Repair the harness and connector.</p> <p>NOTE:</p> <p>In this case, repair the following item:</p> <ul style="list-style-type: none"> <li>Open circuit in harness between ECM connector and the leak check valve assembly connector</li> <li>Poor contact of ECM connector</li> <li>Poor contact of coupling connector</li> </ul> |
| 3 | <p><b>CHECK HARNESS BETWEEN ECM AND LEAK CHECK VALVE ASSEMBLY CONNECTOR.</b></p> <p>1) Turn the ignition switch to OFF.</p> <p>2) Disconnect the connector from ECM.</p> <p>3) Measure the resistance between ECM connector and chassis ground.</p> <p><b>Connector &amp; terminal</b><br/><b>(B135) No. 20 — Chassis ground:</b></p>   | <p>Is the resistance 1 MΩ or more?</p>   | <p>Go to step 4.</p>   | <p>Repair the short circuit to ground in harness between ECM connector and leak check valve assembly connector.</p>  |
| 4 | <p><b>CHECK FOR POOR CONTACT.</b></p> <p>Check for poor contact of leak check valve assembly connector.</p>   | <p>Is there poor contact in the leak check valve assembly connector?</p>         | <p>Repair the poor contact in the leak check valve assembly connector.</p> | <p>Replace the leak check valve assembly. &lt;Ref. to EC(H4DO(HEV))-39, Leak Check Valve Assembly.&gt;</p>   |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

## CN:DTC P0453 EVAPORATIVE EMISSION SYSTEM PRESSURE SENSOR/ SWITCH HIGH

### DTC DETECTING CONDITION:


- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-114, DTC P0453 EVAPORATIVE EMISSION SYSTEM PRESSURE SENSOR/SWITCH HIGH, Diagnostic Trouble Code (DTC) Detecting Criteria.>

### CAUTION:

After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.

### WIRING DIAGRAM:

- Engine electrical system (without push button start) <Ref. to WI(HEV)-100, WITHOUT PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>
- Engine electrical system (with push button start) <Ref. to WI(HEV)-114, WITH PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>



EN-10749

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step  | Check   | Yes  | No  |
|---|---|--|---|
| <p><b>1</b>      <b>CHECK CURRENT DATA.</b><br/>                     1) Turn the ignition switch to ON.<br/>                     2) Read the value of «Atmosphere Pressure» using the Subaru Select Monitor or a general scan tool.<br/>                     NOTE:<br/>                     • Subaru Select Monitor<br/>                     For detailed operation procedures, refer to “Current Data Display For Engine”. &lt;Ref. to EN(H4DO HEV)(diag)-36, Subaru Select Monitor.&gt;<br/>                     • General scan tool<br/>                     For detailed operation procedures, refer to the general scan tool operation manual.</p> | <p>Is the value in «Atmosphere Pressure» 125 kPa (938 mmHg, 36.9 inHg) or more?</p> | <p>Go to step 2.</p>   | <p>Even if DTC is detected, the circuit has returned to a normal condition at this time. Reproduce the failure, and then perform the diagnosis again.<br/>                     NOTE:<br/>                     In this case, temporary poor contact of connector, temporary open or short circuit of harness may be the cause.</p>   |
| <p><b>2</b>      <b>CHECK HARNESS BETWEEN ECM AND LEAK CHECK VALVE ASSEMBLY CONNECTOR.</b><br/>                     1) Turn the ignition switch to OFF.<br/>                     2) Disconnect the connector from ECM and the leak check valve assembly.<br/>                     3) Measure the resistance of harness between ECM connector and the leak check valve assembly connector.<br/> <i><b>Connector &amp; terminal</b></i><br/> <i><b>(B135) No. 20 — (R400) No. 7:</b></i><br/> <i><b>(B135) No. 30 — (R400) No. 8:</b></i></p>   | <p>Is the resistance less than 1 Ω?</p>   | <p>Go to step 3.</p>   | <p>Repair the harness and connector.<br/>                     NOTE:<br/>                     In this case, repair the following item:<br/>                     • Open circuit in harness between ECM connector and the leak check valve assembly connector<br/>                     • Poor contact of coupling connector<br/>                     • Poor contact of joint connector</p> |
| <p><b>3</b>      <b>CHECK FOR POOR CONTACT.</b><br/>                     Check for poor contact of ECM and the leak check valve assembly connector.</p>   | <p>Is there poor contact in ECM and the leak check valve assembly connector?</p>    | <p>Repair the poor contact of ECM and the leak check valve assembly connector.</p>                                 | <p>Go to step 4.</p>  |
| <p><b>4</b>      <b>CHECK LEAK CHECK VALVE ASSEMBLY.</b><br/>                     Check the pressure sensor of the leak check valve assembly. &lt;Ref. to EC(H4DO(HEV))-49, CHECK PRESSURE SENSOR, INSPECTION, Leak Check Valve Assembly.&gt;</p>   | <p>Is the pressure sensor of the leak check valve assembly OK?</p>                  | <p>Repair the short circuit to power in harness between ECM connector and leak check valve assembly connector.</p> | <p>Replace the leak check valve assembly. &lt;Ref. to EC(H4DO(HEV))-39, Leak Check Valve Assembly.&gt;</p>  |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

## CO:DTC P0455 EVAPORATIVE EMISSION SYSTEM LEAK DETECTED (LARGE LEAK)

### DTC DETECTING CONDITION:

- Detected when two consecutive driving cycles with fault occur.
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-115, DTC P0455 EVAPORATIVE EMISSION SYSTEM LEAK DETECTED (LARGE LEAK), Diagnostic Trouble Code (DTC) Detecting Criteria.>

### TROUBLE SYMPTOM:

- Fuel odor
- There is a hole of more than 1.0 mm (0.04 in) dia. in evaporation system or fuel tank.
- Fuel filler cap loose or lost

### CAUTION:

After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.

|   | Step  | Check   | Yes  | No  |
|---|---|---|--|---|
| 1 | <b>CHECK FUEL FILLER CAP.</b><br>1) Turn the ignition switch to OFF.<br>2) Check the fuel filler cap.<br><br>NOTE:<br>The DTC is stored in memory if fuel filler cap is or was loose or if the cap chain has caught while tightening. | Is the fuel filler cap tightened securely?                                    | Go to step 2.  | Tighten fuel filler cap securely.   |
| 2 | <b>CHECK FUEL FILLER CAP.</b>   | Is the fuel filler cap genuine?   | Go to step 3.  | Replace with a genuine fuel filler cap.   |
| 3 | <b>CHECK FUEL FILLER PIPE GASKET.</b>   | Is there any damage to the seal between fuel filler cap and fuel filler pipe? | Repair or replace the fuel filler cap and fuel filler pipe. <Ref. to FU(H4DO(HEV))-118, Fuel Filler Pipe.> | Go to step 4.   |
| 4 | <b>CHECK PURGE CONTROL SOLENOID VALVE.</b><br>Check air-tightness of the purge control solenoid valve. <Ref. to EC(H4DO(HEV))-24, INSPECTION, Purge Control Solenoid Valve.>  | Is the purge control solenoid valve OK?                                       | Go to step 5.  | Replace the purge control solenoid valve. <Ref. to EC(H4DO(HEV))-21, Purge Control Solenoid Valve.> |
| 5 | <b>CHECK EVAPORATIVE EMISSION CONTROL SYSTEM LINE.</b>  | Are there holes on the evaporation line?                                      | Repair or replace the evaporation line. <Ref. to FU(H4DO(HEV))-149, Fuel Delivery and Evaporation Lines.>  | Go to step 6.   |
| 6 | <b>CHECK CANISTER.</b>  | Are there holes on the canister?  | Replace the canister. <Ref. to EC(H4DO(HEV))-8, Canister.>   | Go to step 7.   |
| 7 | <b>CHECK LEAK CHECK VALVE ASSEMBLY.</b>   | Are there damage or holes on the leak check valve assembly?                   | Replace the leak check valve assembly. <Ref. to EC(H4DO(HEV))-39, Leak Check Valve Assembly.>              | Go to step 8.   |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step   | Check  | Yes  | No  |
|--|--|--|---|
| <b>8</b><br><b>CHECK FUEL TANK.</b><br>Remove the fuel tank. <Ref. to FU(H4DO(HEV))-105, Fuel Tank.> | Are there damage or holes on the fuel tank?  | Repair or replace the fuel tank. <Ref. to FU(H4DO(HEV))-105, Fuel Tank.> | Go to step 9.                             |
| <b>9</b><br><b>CHECK ANY OTHER MECHANICAL TROUBLE IN EVAPORATIVE EMISSION CONTROL SYSTEM.</b>        | Are there holes, cracks, clogging, or disconnection, misconnection of hoses or pipes in evaporative emission control system? | Repair or replace the hoses or pipes.                                    | Repair the poor contact of ECM connector. |

## CP:DTC P0456 EVAPORATIVE EMISSION CONTROL SYSTEM LEAK DETECTED (VERY SMALL LEAK)

### NOTE:

For the diagnostic procedure, refer to DTC P0455. <Ref. to EN(H4DO HEV)(diag)-246, DTC P0455 EVAPORATIVE EMISSION SYSTEM LEAK DETECTED (LARGE LEAK), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

## CQ:DTC P0458 EVAPORATIVE EMISSION SYSTEM PURGE CONTROL VALVE CIRCUIT LOW

### DTC DETECTING CONDITION:

- Detected when two consecutive driving cycles with fault occur.
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-121, DTC P0458 EVAPORATIVE EMISSION SYSTEM PURGE CONTROL VALVE CIRCUIT LOW, Diagnostic Trouble Code (DTC) Detecting Criteria.>

### TROUBLE SYMPTOM:


Improper idling

### CAUTION:

After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.

### WIRING DIAGRAM:

- Engine electrical system (without push button start) <Ref. to WI(HEV)-100, WITHOUT PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>
- Engine electrical system (with push button start) <Ref. to WI(HEV)-114, WITH PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>



EN-10750

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

|   | Step  | Check                                    | Yes                                       | No  |
|---|---|--|---|---|
| 1 | <p><b>CHECK OUTPUT SIGNAL OF ECM.</b><br/>                     1) Turn the ignition switch to ON.<br/>                     2) Measure the voltage between ECM connector and chassis ground.<br/> <b>Connector &amp; terminal</b><br/> <b>(B134) No. 11 (+) — Chassis ground (-):</b></p>  | Is the voltage 10 V or more?             | Go to step 2.                             | Go to step 3.   |
| 2 | <p><b>CHECK FOR POOR CONTACT.</b><br/>                     Check for poor contact of ECM connector.</p>   | Is there poor contact of ECM connector?  | Repair the poor contact of ECM connector. | Even if DTC is detected, the circuit has returned to a normal condition at this time. Reproduce the failure, and then perform the diagnosis again.<br>NOTE:<br>In this case, temporary poor contact of connector, temporary open or short circuit of harness may be the cause.    |
| 3 | <p><b>CHECK POWER SUPPLY TO PURGE CONTROL SOLENOID VALVE.</b><br/>                     Measure the voltage between purge control solenoid valve connector and engine ground.<br/> <b>Connector &amp; terminal</b><br/> <b>(E4) No. 1 (+) — Engine ground (-):</b></p>   | Is the voltage 10 V or more?             | Go to step 4.                             | Repair the power supply circuit.  |
| 4 | <p><b>CHECK HARNESS BETWEEN ECM AND PURGE CONTROL SOLENOID VALVE CONNECTOR.</b><br/>                     1) Turn the ignition switch to OFF.<br/>                     2) Disconnect the connectors from ECM and purge control solenoid valve.<br/>                     3) Measure the resistance between the purge control solenoid valve connector and engine ground.<br/> <b>Connector &amp; terminal</b><br/> <b>(E4) No. 2 — Engine ground:</b></p> | Is the resistance 1 M $\Omega$ or more?  | Go to step 5.                             | Repair the short circuit to ground in harness between ECM connector and purge control solenoid valve connector.   |
| 5 | <p><b>CHECK HARNESS BETWEEN ECM AND PURGE CONTROL SOLENOID VALVE CONNECTOR.</b><br/>                     Measure the resistance of harness between ECM connector and purge control solenoid valve.<br/> <b>Connector &amp; terminal</b><br/> <b>(B134) No. 11 — (E4) No. 2:</b></p>   | Is the resistance less than 1 $\Omega$ ? | Go to step 6.                             | Repair the harness and connector.<br>NOTE:<br>In this case, repair the following item: <ul style="list-style-type: none"> <li>• Open circuit in harness between ECM connector and purge control solenoid valve connector</li> <li>• Poor contact of coupling connector</li> </ul> |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step  | Check                                 | Yes  | No  |
|---|---------------------------------------|--|---|
| <b>6</b><br><b>CHECK PURGE CONTROL SOLENOID VALVE.</b><br>1) Remove the purge control solenoid valve.<br>2) Measure the resistance between purge control solenoid valve terminals.<br><b>Terminals</b><br><b>No. 1 — No. 2:</b> | Is the resistance 10 — 100 $\Omega$ ? | Repair the poor contact of purge control solenoid valve connector. | Replace the purge control solenoid valve. <Ref. to EC(H4DO(HEV))-21, Purge Control Solenoid Valve.> |

## CR:DTC P0459 EVAPORATIVE EMISSION SYSTEM PURGE CONTROL VALVE CIRCUIT HIGH

### DTC DETECTING CONDITION:

- Detected when two consecutive driving cycles with fault occur.
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-122, DTC P0459 EVAPORATIVE EMISSION SYSTEM PURGE CONTROL VALVE CIRCUIT HIGH, Diagnostic Trouble Code (DTC) Detecting Criteria.>

### TROUBLE SYMPTOM:


Improper idling

### CAUTION:

**After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.**

### WIRING DIAGRAM:

- Engine electrical system (without push button start) <Ref. to WI(HEV)-100, WITHOUT PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>
- Engine electrical system (with push button start) <Ref. to WI(HEV)-114, WITH PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>



EN-10750

## Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step   | Check   | Yes   | No   |
|--|---|---|--|
| <p><b>1</b></p> <p><b>CHECK HARNESS BETWEEN ECM AND PURGE CONTROL SOLENOID VALVE CONNECTOR.</b></p> <p>1) Turn the ignition switch to OFF.<br/>                     2) Disconnect the connectors from ECM and purge control solenoid valve.<br/>                     3) Turn the ignition switch to ON.<br/>                     4) Measure the voltage between ECM connector and chassis ground.</p> <p><b>Connector &amp; terminal</b><br/> <b>(B134) No. 11 (+) — Chassis ground (-):</b></p> | <p>Is the voltage 10 V or more?</p>                       | <p>Repair the short circuit to power in the harness between ECM connector and purge control solenoid valve connector.</p> | <p>Go to step 2.</p>                             |
| <p><b>2</b></p> <p><b>CHECK PURGE CONTROL SOLENOID VALVE.</b></p> <p>1) Turn the ignition switch to OFF.<br/>                     2) Measure the resistance between purge control solenoid valve terminals.</p> <p><b>Terminals</b><br/> <b>No. 1 — No. 2:</b></p>   | <p>Is the resistance less than 1 <math>\Omega</math>?</p> | <p>Replace the purge control solenoid valve. &lt;Ref. to EC(H4DO(HEV))-21, Purge Control Solenoid Valve.&gt;</p>          | <p>Repair the poor contact of ECM connector.</p> |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

## CS:DTC P0461 FUEL LEVEL SENSOR “A” CIRCUIT RANGE/PERFORMANCE

### DTC DETECTING CONDITION:

- Detected when two consecutive driving cycles with fault occur.
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-123, DTC P0461 FUEL LEVEL SENSOR “A” CIRCUIT RANGE/PERFORMANCE, Diagnostic Trouble Code (DTC) Detecting Criteria.>

### CAUTION:

After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.

| Step                                     | Check                       | Yes  | No   |
|--|-----------------------------|--|--|
| 1<br>CHECK FOR ANY OTHER DTC ON DISPLAY. | Is any other DTC displayed? | Check the appropriate DTC using the “List of Diagnostic Trouble Code (DTC)”. <Ref. to EN(H4DO HEV)(diag)-92, List of Diagnostic Trouble Code (DTC).> | Replace the fuel level sensor and fuel sub level sensor. <Ref. to FU(H4DO(HEV))-128, Fuel Level Sensor.> <Ref. to FU(H4DO(HEV))-131, Fuel Sub Level Sensor.> |

## CT:DTC P0462 FUEL LEVEL SENSOR “A” CIRCUIT LOW

### NOTE:

For the diagnostic procedure, refer to DTC P0463. <Ref. to EN(H4DO HEV)(diag)-254, DTC P0463 FUEL LEVEL SENSOR “A” CIRCUIT HIGH, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

## Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

### CU:DTC P0463 FUEL LEVEL SENSOR “A” CIRCUIT HIGH

#### DTC DETECTING CONDITION:

- Detected when two consecutive driving cycles with fault occur.
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-125, DTC P0463 FUEL LEVEL SENSOR “A” CIRCUIT HIGH, Diagnostic Trouble Code (DTC) Detecting Criteria.>

#### CAUTION:

After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.

| Step | Check   | Yes   | No   |
|------|---|---|--|
| 1    | <b>CHECK FOR ANY OTHER DTC ON DISPLAY.</b><br>Is DTC P0462 or P0463 displayed on the Subaru Select Monitor? | Check the combination meter. <Ref. to IDI(diag)-2, Basic Diagnostic Procedure.> | Even if DTC is detected, the circuit has returned to a normal condition at this time. Reproduce the failure, and then perform the diagnosis again.<br><br>NOTE:<br>In this case, temporary poor contact of connector, temporary open or short circuit of harness may be the cause. |

### CV:DTC P0500 VEHICLE SPEED SENSOR “A”

#### DTC DETECTING CONDITION:

- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-126, DTC P0500 VEHICLE SPEED SENSOR “A”, Diagnostic Trouble Code (DTC) Detecting Criteria.>

#### CAUTION:

After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.

| Step | Check   | Yes  | No  |
|------|---|--|---|
| 1    | <b>CHECK DTC OF VDC.</b><br>Check DTC of VDC. | Perform the diagnosis according to DTC. <Ref. to VDC(diag)-40, List of Diagnostic Trouble Code (DTC).> | Repair the poor contact of ECM connector. |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

## CW:DTC P0506 IDLE AIR CONTROL SYSTEM RPM LOWER THAN EXPECTED

### DTC DETECTING CONDITION:

- Detected when two consecutive driving cycles with fault occur.
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-127, DTC P0506 IDLE AIR CONTROL SYSTEM RPM LOWER THAN EXPECTED, Diagnostic Trouble Code (DTC) Detecting Criteria.>

### TROUBLE SYMPTOM:

- Hard to start the engine.
- Engine does not start.
- Improper idling
- Engine stalls.

### CAUTION:

After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.

| Step  | Check  | Yes  | No  |
|---|--|--|---|
| 1<br><b>CHECK FOR ANY OTHER DTC ON DISPLAY.</b>   | Is any other DTC displayed?                                  | Check the appropriate DTC using the "List of Diagnostic Trouble Code (DTC)". <Ref. to EN(H4DO HEV)(diag)-92, List of Diagnostic Trouble Code (DTC).> | Go to step 2.   |
| 2<br><b>CHECK AIR CLEANER ELEMENT.</b><br>1) Turn the ignition switch to OFF.<br>2) Check the air cleaner element.  | Is there excessive clogging on air cleaner element?          | Replace the air cleaner element. <Ref. to IN(H4DO(HEV))-4, Air Cleaner Element.>   | Go to step 3.   |
| 3<br><b>CHECK ELECTRONIC THROTTLE CONTROL.</b><br>1) Remove the electronic throttle control. <Ref. to FU(H4DO(HEV))-14, REMOVAL, Throttle Body.><br>2) Check the electronic throttle control. | Are foreign matter found inside electronic throttle control? | Remove foreign matter from electronic throttle control.  | Perform the diagnosis of DTC P2101. <Ref. to EN(H4DO HEV)(diag)-335, DTC P2101 THROTTLE ACTUATOR CONTROL MOTOR CIRCUIT RANGE/PERFORMANCE, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

## CX:DTC P0507 IDLE AIR CONTROL SYSTEM RPM HIGHER THAN EXPECTED

### DTC DETECTING CONDITION:

- Detected when two consecutive driving cycles with fault occur.
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-128, DTC P0507 IDLE AIR CONTROL SYSTEM RPM HIGHER THAN EXPECTED, Diagnostic Trouble Code (DTC) Detecting Criteria.>

### TROUBLE SYMPTOM:

Engine keeps running at higher speed than specified idle speed.

### CAUTION:

After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.

| Step   | Check  | Yes  | No  |
|--|--|--|---|
| 1<br><b>CHECK FOR ANY OTHER DTC ON DISPLAY.</b>  | Is any other DTC displayed?                                  | Check the appropriate DTC using the "List of Diagnostic Trouble Code (DTC)". <Ref. to EN(H4DO HEV)(diag)-92, List of Diagnostic Trouble Code (DTC).> | Go to step 2.   |
| 2<br><b>CHECK AIR INTAKE SYSTEM.</b><br>1) Start and idle the engine.<br>2) Check the following items. <ul style="list-style-type: none"> <li>• Loose installation of intake manifold and throttle body</li> <li>• Cracks of intake manifold gasket and throttle body gasket</li> <li>• Disconnection of vacuum hoses</li> </ul> | Is there any fault in air intake system?                     | Repair air suction and leaks.  | Go to step 3.   |
| 3<br><b>CHECK ELECTRONIC THROTTLE CONTROL.</b><br>1) Turn the ignition switch to OFF.<br>2) Remove the electronic throttle control. <Ref. to FU(H4DO(HEV))-14, REMOVAL, Throttle Body.><br>3) Check the electronic throttle control.   | Are foreign matter found inside electronic throttle control? | Remove foreign matter from electronic throttle control.  | Perform the diagnosis of DTC P2101. <Ref. to EN(H4DO HEV)(diag)-335, DTC P2101 THROTTLE ACTUATOR CONTROL MOTOR CIRCUIT RANGE/PERFORMANCE, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

## CY:DTC P050A COLD START IDLE AIR CONTROL SYSTEM PERFORMANCE

### DTC DETECTING CONDITION:

- Detected when two consecutive driving cycles with fault occur.
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-129, DTC P050A COLD START IDLE AIR CONTROL SYSTEM PERFORMANCE, Diagnostic Trouble Code (DTC) Detecting Criteria.>

### TROUBLE SYMPTOM:


- Engine keeps running at higher speed than specified idle speed.
- Engine keeps running at a lower speed than the specified idle speed.
- Engine stalls.

### CAUTION:

After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.

### WIRING DIAGRAM:


- Engine electrical system (without push button start) <Ref. to WI(HEV)-100, WITHOUT PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>
- Engine electrical system (with push button start) <Ref. to WI(HEV)-114, WITH PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>



EN-10736

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

## ENGINE (DIAGNOSTICS)



| Step | Check   | Yes   | No  |
|------|---|---|---|
| 1    | <b>CHECK FOR ANY OTHER DTC ON DISPLAY.</b><br>Is any other DTC displayed?         | Check the appropriate DTC using the "List of Diagnostic Trouble Code (DTC)".<br><Ref. to EN(H4DO HEV)(diag)-92, List of Diagnostic Trouble Code (DTC).> | Go to step 2.   |
| 2    | <b>CHECK ENGINE OIL.</b><br>Is there a proper amount of engine oil?               | Go to step 3.   | Replace engine oil.<br><Ref. to LU(H4DO(w/o HEV))-13, REPLACEMENT, Engine Oil.> |
| 3    | <b>CHECK EXHAUST SYSTEM.</b><br>Are there holes or loose bolts on exhaust system? | Repair the exhaust system.  | Go to step 4.   |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check   | Yes   | No                            |   |
|------|---|---|-------------------------------|---|
| 4    | <b>CHECK AIR INTAKE SYSTEM.</b>   | Are there holes, loose bolts or disconnection of hose on air intake system?       | Repair the air intake system. | Go to step 5.   |
| 5    | <b>CHECK FUEL PRESSURE.</b><br><b>WARNING:</b><br>Place “NO OPEN FLAMES” signs near the working area.<br><b>CAUTION:</b><br>Be careful not to spill fuel.<br>Measure the fuel pressure. <Ref. to ME(H4DO(w/o HEV))-35, INSPECTION, Fuel Pressure.><br><b>CAUTION:</b><br>Release fuel pressure before removing the fuel pressure gauge.   | Is the measured value 340 — 400 kPa (3.5 — 4.1 kg/cm <sup>2</sup> , 49 — 58 psi)? | Go to step 6.                 | Check the fuel pump and fuel delivery line. <Ref. to FU(H4DO(HEV))-127, INSPECTION, Fuel Pump.> <Ref. to FU(H4DO(HEV))-157, INSPECTION, Fuel Delivery and Evaporation Lines.> |
| 6    | <b>CHECK ENGINE COOLANT TEMPERATURE SENSOR.</b><br>1) Start the engine and warm up completely.<br>2) Read the value of «Coolant Temp.» using the Subaru Select Monitor or a general scan tool.<br><b>NOTE:</b><br>• Subaru Select Monitor<br>For detailed operation procedures, refer to “Current Data Display For Engine”. <Ref. to EN(H4DO HEV)(diag)-36, Subaru Select Monitor.><br>• General scan tool<br>For detailed operation procedures, refer to the general scan tool operation manual.   | Is the value of «Coolant Temp.» 75°C (167°F) or more?                             | Go to step 7.                 | Replace the engine coolant temperature sensor. <Ref. to FU(H4DO(HEV))-41, Engine Coolant Temperature Sensor.>   |
| 7    | <b>CHECK MASS AIR FLOW AND INTAKE AIR TEMPERATURE SENSOR.</b><br>1) Start the engine and warm up engine until coolant temperature is higher than 75°C (167°F).<br>2) Place the select lever in “P” range or “N” range.<br>3) Turn the A/C switch to OFF.<br>4) Turn all the accessory switches to OFF.<br>5) Read the value of «Mass Air Flow» using the Subaru Select Monitor or a general scan tool.<br><b>NOTE:</b><br>• Subaru Select Monitor<br>For detailed operation procedures, refer to “Current Data Display For Engine”. <Ref. to EN(H4DO HEV)(diag)-36, Subaru Select Monitor.><br>• General scan tool<br>For detailed operation procedures, refer to the general scan tool operation manual. | Is the value of «Mass Air Flow» 2.0 — 5.0 g/s (0.26 — 0.66 lb/m)?                 | Go to step 8.                 | Replace the mass air flow and intake air temperature sensor. <Ref. to FU(H4DO(HEV))-63, Mass Air Flow and Intake Air Temperature Sensor.>                                     |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

## ENGINE (DIAGNOSTICS)

| Step   | Check   | Yes            | No  |
|--|---|----------------|---|
| <p><b>8</b></p> <p><b>CHECK MASS AIR FLOW AND INTAKE AIR TEMPERATURE SENSOR.</b></p> <p>1) Start the engine and warm up engine until coolant temperature is higher than 75°C (167°F).</p> <p>2) Place the select lever in “P” range or “N” range.</p> <p>3) Turn the A/C switch to OFF.</p> <p>4) Turn all the accessory switches to OFF.</p> <p>5) Open the front hood.</p> <p>6) Measure the ambient temperature.</p> <p>7) Read the value of «Intake Air Temp.» using the Subaru Select Monitor or a general scan tool.</p> <p>NOTE:</p> <ul style="list-style-type: none"> <li>• Subaru Select Monitor</li> </ul> <p>For detailed operation procedures, refer to “Current Data Display For Engine”. &lt;Ref. to EN(H4DO HEV)(diag)-36, Subaru Select Monitor.&gt;</p> <ul style="list-style-type: none"> <li>• General scan tool</li> </ul> <p>For detailed operation procedures, refer to the general scan tool operation manual.</p> | <p>Subtract ambient temperature from «Intake Air Temp.». Is the obtained value -10 — 50°C (-18 — 90°F)?</p> | Go to step 9.  | Check the mass air flow and intake air temperature sensor. <Ref. to FU(H4DO(HEV))-63, Mass Air Flow and Intake Air Temperature Sensor.>   |
| <p><b>9</b></p> <p><b>CHECK OUTPUT SIGNAL OF ECM.</b></p> <p>1) Turn the ignition switch to ON.</p> <p>2) Measure the voltage between ECM and chassis ground on faulty cylinders.</p> <p><b>Connector &amp; terminal</b></p> <p><b>#1 (B134) No. 12 (+) — Chassis ground (-):</b></p> <p><b>#2 (B134) No. 22 (+) — Chassis ground (-):</b></p> <p><b>#3 (B134) No. 32 (+) — Chassis ground (-):</b></p> <p><b>#4 (B134) No. 13 (+) — Chassis ground (-):</b></p>   | Is the voltage 10 V or more?  | Go to step 14. | Go to step 10.  |
| <p><b>10</b></p> <p><b>CHECK HARNESS BETWEEN ECM AND FUEL INJECTOR CONNECTOR.</b></p> <p>1) Turn the ignition switch to OFF.</p> <p>2) Disconnect the connector from fuel injector on faulty cylinders.</p> <p>3) Measure the resistance between fuel injector connector and engine ground on faulty cylinders.</p> <p><b>Connector &amp; terminal</b></p> <p><b>#1 (E5) No. 1 — Engine ground:</b></p> <p><b>#2 (E16) No. 1 — Engine ground:</b></p> <p><b>#3 (E6) No. 1 — Engine ground:</b></p> <p><b>#4 (E17) No. 1 — Engine ground:</b></p>   | Is the resistance 1 MΩ or more?   | Go to step 11. | Repair the short circuit to ground in harness between ECM connector and fuel injector connector.  |
| <p><b>11</b></p> <p><b>CHECK HARNESS BETWEEN ECM AND FUEL INJECTOR CONNECTOR.</b></p> <p>Measure the resistance of harness between ECM and fuel injector connector on faulty cylinders.</p> <p><b>Connector &amp; terminal</b></p> <p><b>#1 (B134) No. 12 — (E5) No. 1:</b></p> <p><b>#2 (B134) No. 22 — (E16) No. 1:</b></p> <p><b>#3 (B134) No. 32 — (E6) No. 1:</b></p> <p><b>#4 (B134) No. 13 — (E17) No. 1:</b></p>   | Is the resistance less than 1 Ω?  | Go to step 12. | Repair the harness and connector.<br>NOTE:<br>In this case, repair the following item:<br>• Open circuit in harness between ECM connector and fuel injector connector<br>• Poor contact of coupling connector |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step  | Check  | Yes   | No  |
|---|--|---|---|
| <b>12 CHECK FUEL INJECTOR.</b><br>Measure the resistance between fuel injector terminals on faulty cylinder.<br><i>Terminals</i><br><i>No. 1 — No. 2:</i>   | Is the resistance 5 — 20 Ω?  | Go to step 13.  | Replace the faulty fuel injector. <Ref. to FU(H4DO(HEV))-69, Fuel Injector.>  |
| <b>13 CHECK POWER SUPPLY LINE.</b><br>1) Turn the ignition switch to ON.<br>2) Measure the voltage between fuel injector and engine ground on faulty cylinders.<br><i>Connector &amp; terminal</i><br><i>#1 (E5) No. 2 (+) — Engine ground (-):</i><br><i>#2 (E16) No. 2 (+) — Engine ground (-):</i><br><i>#3 (E6) No. 2 (+) — Engine ground (-):</i><br><i>#4 (E17) No. 2 (+) — Engine ground (-):</i>  | Is the voltage 10 V or more?   | Repair the poor contact of all connectors in fuel injector circuit.   | Repair the harness and connector.<br>NOTE:<br>In this case, repair the following item: <ul style="list-style-type: none"> <li>• Open circuit in harness between the main relay connector and fuel injector connector on faulty cylinders</li> <li>• Poor contact of coupling connector</li> <li>• Poor contact of main relay connector</li> </ul> |
| <b>14 CHECK HARNESS BETWEEN ECM AND FUEL INJECTOR CONNECTOR.</b><br>1) Turn the ignition switch to OFF.<br>2) Disconnect the connector from fuel injector on faulty cylinders.<br>3) Turn the ignition switch to ON.<br>4) Measure the voltage between ECM and chassis ground on faulty cylinders.<br><i>Connector &amp; terminal</i><br><i>#1 (B134) No. 12 (+) — Chassis ground (-):</i><br><i>#2 (B134) No. 22 (+) — Chassis ground (-):</i><br><i>#3 (B134) No. 32 (+) — Chassis ground (-):</i><br><i>#4 (B134) No. 13 (+) — Chassis ground (-):</i> | Is the voltage 10 V or more?   | Repair the short circuit to power in harness between ECM connector and fuel injector.   | Go to step 15.  |
| <b>15 CHECK FUEL INJECTOR.</b><br>1) Turn the ignition switch to OFF.<br>2) Measure the resistance between fuel injector terminals on faulty cylinder.<br><i>Terminals</i><br><i>No. 1 — No. 2:</i>   | Is the resistance 5 — 20 Ω?  | Go to step 16.  | Replace the faulty fuel injector. <Ref. to FU(H4DO(HEV))-69, Fuel Injector.>  |
| <b>16 CHECK INSTALLATION CONDITION OF CAMSHAFT POSITION SENSOR/CRANKSHAFT POSITION SENSOR.</b>  | Is the camshaft position sensor or crankshaft position sensor loosely installed? | Tighten the camshaft position sensor or crankshaft position sensor.<br><Ref. to FU(H4DO(HEV))-53, INSTALLATION, Camshaft Position Sensor.><br><Ref. to FU(H4DO(HEV))-48, INSTALLATION, Crankshaft Position Sensor.> | Go to step 17.  |
| <b>17 CHECK CRANKSHAFT POSITION SENSOR PLATE.</b>   | Is the crankshaft position sensor plate rusted or does it have broken teeth?     | Replace the crankshaft position sensor plate. <Ref. to ME(H4DO(w/o HEV))-304, Cylinder Block.>  | Go to step 18.  |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

## ENGINE (DIAGNOSTICS)

| Step  | Check  | Yes   | No   |
|---|--|---|--|
| <b>18 CHECK INSTALLATION CONDITION OF TIMING CHAIN.</b><br>Turn the crankshaft using ST, and align the alignment mark on crank sprocket with alignment mark on cylinder block.<br>ST 18252AA000 CRANKSHAFT SOCKET   | Is the timing chain dislocated from its proper position? | Correct the installation condition of timing chain. <Ref. to ME(H4DO(w/o HEV))-169, Timing Chain Assembly.>             | Go to step 19.   |
| <b>19 CHECK ELECTRONIC THROTTLE CONTROL RELAY.</b><br>1) Turn the ignition switch to OFF.<br>2) Remove the electronic throttle control relay.<br>3) Connect the battery to terminals No. 16 and No. 17 of electronic throttle control relay.<br>4) Measure the resistance between electronic throttle control relay terminals.<br><i>Terminals</i><br><i>No. 14 — No. 15:</i> | Is the resistance less than 1 $\Omega$ ?                 | Go to step 20.  | Replace the electronic throttle control relay. <Ref. to FU(H4DO(HEV))-94, Electronic Throttle Control Relay.>        |
| <b>20 CHECK POWER SUPPLY OF ELECTRONIC THROTTLE CONTROL RELAY.</b><br>Measure the voltage between electronic throttle control relay connector and chassis ground.<br><i>Connector &amp; terminal</i><br><i>(B225) No. 15 (+) — Chassis ground (-):</i>  | Is the voltage 10 V or more?                             | Go to step 21.  | Repair the open or ground short circuit of power supply circuit.   |
| <b>21 CHECK HARNESS BETWEEN ECM AND ELECTRONIC THROTTLE CONTROL RELAY CONNECTOR.</b><br>1) Disconnect the connector from ECM.<br>2) Turn the ignition switch to ON.<br>3) Measure the voltage between electronic throttle control relay connector and chassis ground.<br><i>Connector &amp; terminal</i><br><i>(B225) No. 17 (+) — Chassis ground (-):</i>                    | Is the voltage 10 V or more?                             | Repair the short circuit to power in the harness between ECM connector and electronic throttle control relay connector. | Go to step 22.   |
| <b>22 CHECK HARNESS BETWEEN ECM AND ELECTRONIC THROTTLE CONTROL RELAY CONNECTOR.</b><br>1) Turn the ignition switch to OFF.<br>2) Measure the resistance between electronic throttle control relay connector and chassis ground.<br><i>Connector &amp; terminal</i><br><i>(B225) No. 14 — Chassis ground:</i><br><i>(B225) No. 17 — Chassis ground:</i>                       | Is the resistance 1 M $\Omega$ or more?                  | Go to step 23.  | Repair the short circuit to ground in harness between ECM connector and electronic throttle control relay connector. |
| <b>23 CHECK HARNESS BETWEEN ECM AND ELECTRONIC THROTTLE CONTROL RELAY CONNECTOR.</b><br>Measure the resistance of harness between ECM connector and electronic throttle control relay connector.<br><i>Connector &amp; terminal</i><br><i>(B135) No. 17 — (B225) No. 17:</i><br><i>(B135) No. 7 — (B225) No. 14:</i>  | Is the resistance less than 1 $\Omega$ ?                 | Go to step 24.  | Repair the open circuit in harness between ECM connector and electronic throttle control relay connector.            |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step  | Check                            | Yes            | No   |
|---|----------------------------------|----------------|--|
| <p><b>24 CHECK HARNESS BETWEEN ECM AND ELECTRONIC THROTTLE CONTROL CONNECTOR.</b></p> <p>1) Turn the ignition switch to OFF.<br/>                     2) Disconnect the connectors from ECM and electronic throttle control.<br/>                     3) Measure the resistance between ECM connector and chassis ground.</p> <p><b>Connector &amp; terminal</b><br/>                     (B134) No. 19 — Chassis ground:<br/>                     (B134) No. 18 — Chassis ground:<br/>                     (B134) No. 18 — (B137) No. 4:<br/>                     (B134) No. 28 — Chassis ground:<br/>                     (B134) No. 28 — (B137) No. 4:</p> | Is the resistance 1 MΩ or more?  | Go to step 25. | Repair the ground short circuit of harness between ECM connector and electronic throttle control connector.  |
| <p><b>25 CHECK SHORT CIRCUIT INSIDE THE ECM.</b></p> <p>1) Connect the connector to ECM.<br/>                     2) Measure the resistance between electronic throttle control connector and engine ground.</p> <p><b>Connector &amp; terminal</b><br/>                     (E57) No. 6 — Engine ground:<br/>                     (E57) No. 4 — Engine ground:</p>   | Is the resistance 1 MΩ or more?  | Go to step 26. | Repair the ground short circuit of harness between ECM connector and electronic throttle control connector.<br><br>Replace the ECM if defective. <Ref. to FU(H4DO(HEV))-85, Engine Control Module (ECM).>                                  |
| <p><b>26 CHECK HARNESS BETWEEN ECM AND ELECTRONIC THROTTLE CONTROL CONNECTOR.</b></p> <p>1) Disconnect the connector from ECM.<br/>                     2) Measure the resistance of harness between ECM connector and electronic throttle control connector.</p> <p><b>Connector &amp; terminal</b><br/>                     (B134) No. 18 — (E57) No. 6:<br/>                     (B134) No. 28 — (E57) No. 4:<br/>                     (B134) No. 29 — (E57) No. 3:</p>  | Is the resistance less than 1 Ω? | Go to step 27. | Repair the harness and connector.<br><br>NOTE:<br>In this case, repair the following item:<br>• Open circuit in harness between ECM connector and electronic throttle control connector<br>• Poor contact of coupling connector            |
| <p><b>27 CHECK HARNESS BETWEEN ECM AND ELECTRONIC THROTTLE CONTROL CONNECTOR.</b></p> <p>1) Connect the connector to ECM.<br/>                     2) Measure the resistance between electronic throttle control connector and engine ground.</p> <p><b>Connector &amp; terminal</b><br/>                     (E57) No. 3 — Engine ground:</p>  | Is the resistance less than 5 Ω? | Go to step 28. | Repair the harness and connector.<br><br>NOTE:<br>In this case, repair the following item:<br>• Open circuit of harness between ECM connector and engine ground<br>• Poor contact of ECM connector<br>• Poor contact of coupling connector |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

## ENGINE (DIAGNOSTICS)

| Step   | Check   | Yes   | No  |
|--|---|---|---|
| <b>28</b><br><b>CHECK HARNESS BETWEEN ECM AND ELECTRONIC THROTTLE CONTROL CONNECTOR.</b><br>1) Turn the ignition switch to ON.<br>2) Measure the voltage between electronic throttle control connector and engine ground.<br><b>Connector &amp; terminal</b><br><i>(E57) No. 6 (+) — Engine ground (-):</i><br><i>(E57) No. 4 (+) — Engine ground (-):</i>   | Is the voltage 5 V or more?                           | Repair the short circuit to power in the harness between ECM connector and electronic throttle control connector. | Go to step 29.  |
| <b>29</b><br><b>CHECK HARNESS BETWEEN ECM AND ELECTRONIC THROTTLE CONTROL CONNECTOR.</b><br>1) Turn the ignition switch to OFF.<br>2) Disconnect the connector from ECM.<br>3) Measure the resistance between ECM connectors.<br><b>Connector &amp; terminal</b><br><i>(B134) No. 19 — (B134) No. 18:</i><br><i>(B134) No. 19 — (B134) No. 28:</i>   | Is the resistance 1 M $\Omega$ or more?               | Go to step 30.  | Repair the short circuit to power in the harness between ECM connector and electronic throttle control connector.   |
| <b>30</b><br><b>CHECK SENSOR OUTPUT.</b><br>1) Connect all connectors.<br>2) Turn the ignition switch to ON.<br>3) Read the value of «Main-Throttle Sensor» using Subaru Select Monitor.<br>NOTE:<br>For detailed operation procedures, refer to “Current Data Display For Engine”. <Ref. to EN(H4DO HEV)(diag)-36, Subaru Select Monitor.>  | Is the value of «Main-Throttle Sensor» 0.81 — 0.87 V? | Go to step 31.  | Repair the poor contact of electronic throttle control connector.<br>Replace the electronic throttle control if defective.<br><Ref. to FU(H4DO(HEV))-14, Throttle Body.>  |
| <b>31</b><br><b>CHECK SENSOR OUTPUT.</b><br>Read the value of «Sub-Throttle Sensor» using Subaru Select Monitor.<br>NOTE:<br>For detailed operation procedures, refer to “Current Data Display For Engine”. <Ref. to EN(H4DO HEV)(diag)-36, Subaru Select Monitor.>  | Is the value of «Sub-Throttle Sensor» 1.64 — 1.70 V?  | Go to step 32.  | Repair the poor contact of electronic throttle control connector.<br>Replace the electronic throttle control if defective.<br><Ref. to FU(H4DO(HEV))-14, Throttle Body.>  |
| <b>32</b><br><b>CHECK HARNESS BETWEEN ECM AND ELECTRONIC THROTTLE CONTROL CONNECTOR.</b><br>1) Turn the ignition switch to OFF.<br>2) Disconnect the connectors from ECM and electronic throttle control.<br>3) Measure the resistance between ECM connector and electronic throttle control connector.<br><b>Connector &amp; terminal</b><br><i>(B134) No. 2 — (E57) No. 2:</i><br><i>(B134) No. 1 — (E57) No. 1:</i> | Is the resistance less than 1 $\Omega$ ?              | Go to step 33.  | Repair the harness and connector.<br>NOTE:<br>In this case, repair the following item:<br>• Open circuit in harness between ECM connector and electronic throttle control connector<br>• Poor contact of coupling connector |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step   | Check  | Yes   | No  |
|--|--|---|---|
| <b>33 CHECK HARNESS BETWEEN ECM AND ELECTRONIC THROTTLE CONTROL CONNECTOR.</b><br>1) Connect the connector to ECM.<br>2) Turn the ignition switch to ON.<br>3) Measure the voltage between electronic throttle control connector and engine ground.<br><i>Connector &amp; terminal</i><br>(E57) No. 2 (+) — Engine ground (-):<br>(E57) No. 1 (+) — Engine ground (-): | Is the voltage 5 V or more?  | Repair the short circuit to power in the harness between ECM connector and electronic throttle control connector. | Go to step 34.  |
| <b>34 CHECK HARNESS BETWEEN ECM AND ELECTRONIC THROTTLE CONTROL CONNECTOR.</b><br>1) Turn the ignition switch to OFF.<br>2) Disconnect the connector from ECM.<br>3) Measure the resistance between electronic throttle control connector and engine ground.<br><i>Connector &amp; terminal</i><br>(E57) No. 2 — Engine ground:<br>(E57) No. 1 — Engine ground:        | Is the resistance 1 M $\Omega$ or more?  | Go to step 35.  | Repair the ground short circuit of harness between ECM connector and electronic throttle control connector.   |
| <b>35 CHECK HARNESS BETWEEN ELECTRONIC THROTTLE CONTROL CONNECTOR.</b><br>Measure the resistance between electronic throttle control connectors.<br><i>Connector &amp; terminal</i><br>(E57) No. 2 — (E57) No. 1:  | Is the resistance 1 M $\Omega$ or more?  | Go to step 36.  | Repair the short circuit in harness between ECM connector and electronic throttle control connector.  |
| <b>36 CHECK ELECTRONIC THROTTLE CONTROL GROUND CIRCUIT.</b><br>Measure the resistance between ECM connector and chassis ground.<br><i>Connector &amp; terminal</i><br>(B134) No. 3 — Chassis ground:<br>(B134) No. 4 — Chassis ground:<br>(B136) No. 1 — Chassis ground:<br>(B136) No. 2 — Chassis ground:<br>(B136) No. 3 — Chassis ground:                           | Is the resistance less than 5 $\Omega$ ?   | Go to step 37.  | Repair the harness and connector.<br>NOTE:<br>In this case, repair the following item:<br>• Open circuit of harness between ECM connector and engine ground<br>• Poor contact of coupling connector |
| <b>37 CHECK ELECTRONIC THROTTLE CONTROL.</b><br>Measure the resistance between electronic throttle control terminals.<br><i>Terminals</i><br>No. 2 — No. 1:  | Is the resistance 50 $\Omega$ or less?   | Go to step 38.  | Replace the electronic throttle control. <Ref. to FU(H4DO(HEV))-14, Throttle Body.>   |
| <b>38 CHECK ELECTRONIC THROTTLE CONTROL.</b><br>Move the throttle valve to the fully open and fully closed positions with fingers.<br>Check that the valve returns to the specified position when releasing fingers.   | Does the valve return to the specified position? Standard value: 3 mm (0.12 in) from fully closed position | Repair the poor contact of ECM connector.   | Replace the electronic throttle control. <Ref. to FU(H4DO(HEV))-14, Throttle Body.>   |

## CZ:DTC P050B COLD START IGNITION TIMING PERFORMANCE

### NOTE:

For the diagnostic procedure, refer to DTC P050A. <Ref. to EN(H4DO HEV)(diag)-257, DTC P050A COLD START IDLE AIR CONTROL SYSTEM PERFORMANCE, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

---

## DA:DTC P0512 STARTER REQUEST CIRCUIT

### DTC DETECTING CONDITION:

- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-132, DTC P0512 STARTER REQUEST CIRCUIT, Diagnostic Trouble Code (DTC) Detecting Criteria.>

### TROUBLE SYMPTOM:

Failure of engine to start

### CAUTION:



After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

## WIRING DIAGRAM:

Engine electrical system (with push button start) <Ref. to WI(HEV)-114, WITH PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>



EN-10732

## Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step   | Check  | Yes  | No   |
|--|--|--|--|
| <b>1</b><br><b>CHECK PUSH BUTTON IGNITION SWITCH.</b><br>Operate the push button ignition switch.  | Does it operate smoothly without catch?      | Go to step 2.  | Replace the push button ignition switch. <Ref. to SL-114, Push Button Ignition Switch.>  |
| <b>2</b><br><b>CHECK DTC.</b><br>1) Clear the memory using the Subaru Select Monitor. <Ref. to EN(H4DO HEV)(diag)-66, Clear Memory Mode.><br>2) Start and idle the engine for three minutes or more.   | Is the same DTC as current diagnosis output? | Go to step 3.  | Even if DTC is detected, the circuit has returned to a normal condition at this time. Reproduce the failure, and then perform the diagnosis again.<br><br>NOTE:<br>In this case, temporary poor contact of connector, temporary open or short circuit of harness may be the cause. |
| <b>3</b><br><b>CHECK HARNESS BETWEEN ECM AND KEYLESS ACCESS CM.</b><br>1) Turn the ignition to OFF.<br>2) Disconnect the connector from ECM.<br>3) Turn the ignition to ON.<br>4) Measure the voltage between ECM connector and chassis ground.<br><b>Connector &amp; terminal</b><br><b>(B137) No. 17 (+) — Chassis ground (-):</b> | Is the voltage 10 V or more?                 | Repair the short circuit to power supply in harness between ECM connector and keyless access CM connector. | Repair the poor contact of ECM connector.  |

## **DB:DTC P0560 SYSTEM VOLTAGE**

### **DTC DETECTING CONDITION:**

- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-133, DTC P0560 SYSTEM VOLTAGE, Diagnostic Trouble Code (DTC) Detecting Criteria.>

### **CAUTION:**



**After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.**

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

## ENGINE (DIAGNOSTICS)

### WIRING DIAGRAM:

- Engine electrical system (without push button start) <Ref. to WI(HEV)-100, WITHOUT PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>
- Engine electrical system (with push button start) <Ref. to WI(HEV)-114, WITH PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>



EN-10733

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

|   | Step  | Check                           | Yes                                       | No  |
|---|---|---------------------------------|---|---|
| 1 | <b>CHECK INPUT SIGNAL OF ECM.</b><br>1) Turn the ignition switch to OFF.<br>2) Measure the voltage between ECM connector and chassis ground.<br><b>Connector &amp; terminal</b><br><b>(B137) No. 2 (+) — Chassis ground (-):</b>                          | Is the voltage 10 V or more?    | Repair the poor contact of ECM connector. | Go to step 2.   |
| 2 | <b>CHECK HARNESS BETWEEN ECM AND MAIN FUSE BOX CONNECTOR.</b><br>1) Disconnect the connector from ECM.<br>2) Measure the resistance between ECM connector and chassis ground.<br><b>Connector &amp; terminal</b><br><b>(B137) No. 2 — Chassis ground:</b> | Is the resistance 1 MΩ or more? | Go to step 3.                             | Repair the short circuit to ground in harness between ECM connector and 12 volt auxiliary battery terminal.   |
| 3 | <b>CHECK FUSE NO. 13 (MAIN FUSE BOX).</b>   | Is the fuse blown out?          | Replace the fuse.                         | Repair the harness and connector.<br>NOTE:<br>In this case, repair the following item: <ul style="list-style-type: none"> <li>• Open circuit in harness between ECM connector and 12 volt auxiliary battery</li> <li>• Poor contact of ECM connector</li> <li>• Poor contact of 12 volt auxiliary battery terminal</li> </ul> |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

## DC:DTC P059A ACTIVE GRILLE SHUTTER "A" POSITION SENSOR CIRCUIT

### DTC DETECTING CONDITION:

- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-134, DTC P059A ACTIVE GRILLE SHUTTER "A" POSITION SENSOR CIRCUIT, Diagnostic Trouble Code (DTC) Detecting Criteria.>

### CAUTION:

**After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.**

| Step   | Check   | Yes   | No  |
|--|---|---|---|
| 1<br><b>CHECK ACTIVE GRILLE SHUTTER.</b><br>1) Turn the ignition switch to OFF and then wait for around 30 seconds.<br>2) Turn the ignition switch to ON.<br>3) Perform operation check for the active grille shutter using the Subaru Select Monitor.<br><b>NOTE:</b><br>For detailed procedures, refer to "System Operation Check Mode". <Ref. to EN(H4DO HEV)(diag)-67, System Operation Check Mode.> | Are the closing and opening operations finished normally? | Even if DTC is detected, it has returned to a normal condition at this time.<br><b>NOTE:</b><br>In this case, the possible causes are the tentative adhering and biting of foreign matter to the active grille shutter or freezing. | Replace the active grille shutter. <Ref. to HEV-77, Active Grille Shutter.> |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

## DD:DTC P059F ACTIVE GRILLE SHUTTER "A" PERFORMANCE

### DTC DETECTING CONDITION:

- Detected when two consecutive driving cycles with fault occur.
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-135, DTC P059F ACTIVE GRILLE SHUTTER "A" PERFORMANCE, Diagnostic Trouble Code (DTC) Detecting Criteria.>

### CAUTION:

After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.

| Step | Check  | Yes   | No  |   |
|------|--|---|---|---|
| 1    | <b>CHECK DTC.</b><br>Check for DTC. <Ref. to EN(H4DO HEV)(diag)-51, Read Diagnostic Trouble Code (DTC).>   | Is DTC P059F displayed in «Present fault»?                                | Go to step 2.   | Even if DTC is detected, it has returned to a normal condition at this time. Reproduce the failure, and then perform the diagnosis again.<br><br>NOTE:<br>In this case, the possible causes are the tentative adhering and biting of foreign matter to the active grille shutter or freezing. |
| 2    | <b>CHECK ACTIVE GRILLE SHUTTER.</b><br>Check the louver area of active grille shutter, louver link area and actuator part.   | Is there any trouble such as foreign matter adhesion, biting or freezing? | Remove the foreign matter from active grille shutter and go to the next step. Go to step 3.   | Go to step 3.   |
| 3    | <b>CHECK ACTIVE GRILLE SHUTTER.</b><br>1) Turn the ignition switch to ON (engine OFF).<br>2) Perform the active grille shutter operation check using Subaru Select Monitor to measure the time required for closing and opening operations.<br><br>NOTE:<br>For detailed procedures, refer to "System Operation Check Mode". <Ref. to EN(H4DO HEV)(diag)-67, System Operation Check Mode.> | Is the time less than 15 seconds?   | Even if DTC is detected, it has returned to a normal condition at this time. Reproduce the failure, and then perform the diagnosis again. | Go to step 4.   |
| 4    | <b>CHECK CURRENT DATA.</b><br>Using the Subaru Select Monitor, read the value of «Active Grille Shutter Voltage Error Status».<br><br>NOTE:<br>For detailed operation procedures, refer to "Current Data Display For Engine". <Ref. to EN(H4DO HEV)(diag)-36, Subaru Select Monitor.>  | Is «Normal» displayed?  | Go to step 5.   | Check the power supply circuit.<br>Replace the active grille shutter if the power supply circuit is normal.<br><Ref. to HEV-77, Active Grille Shutter.>   |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

## ENGINE (DIAGNOSTICS)

| Step   | Check                  | Yes   | No  |
|--|------------------------|---|---|
| <p><b>5</b>      <b>CHECK CURRENT DATA.</b><br/>1) Cool down the engine sufficiently after turning the ignition switch OFF.<br/>NOTE:<br/>Cool until you do not feel heat when touching the engine body.<br/>2) Turn the ignition switch to ON.<br/>3) Using the Subaru Select Monitor, read the value of «Active Grille Shutter Temperature Error Status».<br/>NOTE:<br/>For detailed operation procedures, refer to “Current Data Display For Engine”. &lt;Ref. to EN(H4DO HEV)(diag)-36, Subaru Select Monitor.&gt;</p> | Is «Normal» displayed? | Even if DTC is detected, it has returned to a normal condition at this time. Reproduce the failure, and then perform the diagnosis again. | Replace the active grille shutter. <Ref. to HEV-77, Active Grille Shutter.> |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

## DE:DTC P05A0 ACTIVE GRILLE SHUTTER "A" STUCK

### DTC DETECTING CONDITION:

- Detected when two consecutive driving cycles with fault occur.
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-136, DTC P05A0 ACTIVE GRILLE SHUTTER "A" STUCK, Diagnostic Trouble Code (DTC) Detecting Criteria.>

### CAUTION:

After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.

| Step | Check  | Yes   | No   |   |
|------|--|---|--|---|
| 1    | <b>CHECK ACTIVE GRILLE SHUTTER.</b><br>Check the louver area of active grille shutter, louver link area and actuator part.   | Is there any trouble such as foreign matter adhesion, biting or freezing? | Remove the foreign matter from active grille shutter.  | Go to step 2.   |
| 2    | <b>CHECK ACTIVE GRILLE SHUTTER.</b><br>Check the louver area of active grille shutter, louver link area and actuator part.   | Is each part of active grille shutter damaged?                            | Replace the active grille shutter. <Ref. to HEV-77, Active Grille Shutter.>  | Go to step 3.   |
| 3    | <b>CHECK ACTIVE GRILLE SHUTTER.</b><br>1) Turn the ignition switch to OFF and then wait for around 30 seconds.<br>2) Turn the ignition switch to ON.<br>3) Perform operation check for the active grille shutter using the Subaru Select Monitor.<br>NOTE:<br>For detailed procedures, refer to "System Operation Check Mode". <Ref. to EN(H4DO HEV)(diag)-67, System Operation Check Mode.> | Are the closing and opening operations finished normally?                 | Even if DTC is detected, it has returned to a normal condition at this time.<br>NOTE:<br>In this case, the possible causes are the tentative adhering and biting of foreign matter to the active grille shutter or freezing. | Replace the active grille shutter. <Ref. to HEV-77, Active Grille Shutter.> |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

## DF:DTC P05A1 ACTIVE GRILLE SHUTTER "A" RANGE OVER

### DTC DETECTING CONDITION:

- Detected when two consecutive driving cycles with fault occur.
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-137, DTC P05A1 ACTIVE GRILLE SHUTTER "A" RANGE OVER, Diagnostic Trouble Code (DTC) Detecting Criteria.>

### CAUTION:

After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.

| Step   | Check   | Yes  | No  |
|--|---|--|---|
| <b>1</b><br><b>CHECK ACTIVE GRILLE SHUTTER.</b><br>Check the louver area of active grille shutter, louver link area and actuator part.   | Is there any trouble such as foreign matter adhesion, biting or freezing? | Remove the foreign matter from active grille shutter.  | Go to step 2.   |
| <b>2</b><br><b>CHECK ACTIVE GRILLE SHUTTER.</b><br>Check the louver area of active grille shutter, louver link area and actuator part.   | Is each part of active grille shutter damaged?                            | Replace the active grille shutter. <Ref. to HEV-77, Active Grille Shutter.>  | Go to step 3.   |
| <b>3</b><br><b>CHECK ACTIVE GRILLE SHUTTER.</b><br>1) Turn the ignition switch to OFF and then wait for around 30 seconds.<br>2) Turn the ignition switch to ON.<br>3) Perform operation check for the active grille shutter using the Subaru Select Monitor.<br>NOTE:<br>For detailed procedures, refer to "System Operation Check Mode". <Ref. to EN(H4DO HEV)(diag)-67, System Operation Check Mode.> | Are the closing and opening operations finished normally?                 | Even if DTC is detected, it has returned to a normal condition at this time.<br>NOTE:<br>In this case, the possible causes are the tentative adhering and biting of foreign matter to the active grille shutter or freezing. | Replace the active grille shutter. <Ref. to HEV-77, Active Grille Shutter.> |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

## DG:DTC P05A2 ACTIVE GRILLE SHUTTER "A" CONTROL CIRCUIT

### DTC DETECTING CONDITION:

- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-138, DTC P05A2 ACTIVE GRILLE SHUTTER "A" CONTROL CIRCUIT, Diagnostic Trouble Code (DTC) Detecting Criteria.>

### CAUTION:

After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.

| Step  | Check   | Yes   | No  |
|---|---|---|---|
| 1<br><b>CHECK DTC.</b><br>1) Turn the ignition switch to OFF and then wait for around 30 seconds.<br>2) Turn the ignition switch to ON.<br>3) Check for DTC. <Ref. to EN(H4DO HEV)(diag)-51, Read Diagnostic Trouble Code (DTC).> | Is DTC P05A2 displayed in «Present fault» or «Past faults»? | Replace the active grille shutter. <Ref. to HEV-77, Active Grille Shutter.> | Perform the active grille shutter operation check using Subaru Select Monitor to confirm that closing and opening operations finish normally.<br><b>NOTE:</b><br>For detailed procedures, refer to "System Operation Check Mode". <Ref. to EN(H4DO HEV)(diag)-67, System Operation Check Mode.> |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

## DH:DTC P05A6 ACTIVE GRILLE SHUTTER "A" SUPPLY VOLTAGE CIRCUIT/ OPEN

### DTC DETECTING CONDITION:


- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-140, DTC P05A6 ACTIVE GRILLE SHUTTER "A" SUPPLY VOLTAGE CIRCUIT/OPEN, Diagnostic Trouble Code (DTC) Detecting Criteria.>

### CAUTION:

After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.

### WIRING DIAGRAM:

Active grille shutter <Ref. to WI(HEV)-50, Active Grille Shutter.>



EN-10751

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

|   | Step  | Check                                      | Yes   | No   |
|---|---|--|---|--|
| 1 | <b>CHECK DTC.</b><br>1) Turn the ignition switch to OFF and then wait for around 30 seconds.<br>2) Turn the ignition switch to ON.<br>3) Check for DTC. <Ref. to EN(H4DO HEV)(diag)-51, Read Diagnostic Trouble Code (DTC).>  | Is DTC P05A6 displayed in «Present fault»? | Go to step 2.   | Even if DTC is detected, the circuit has returned to a normal condition at this time. Reproduce the failure, and then perform the diagnosis again.<br><br><b>NOTE:</b><br>In this case, temporary battery voltage drop, temporary poor contact of connector or temporary open or short circuit of harness or may be the cause. |
| 2 | <b>CHECK 12 VOLT AUXILIARY BATTERY.</b><br>Check the battery. <Ref. to SC(H4DO(HEV))-39, Battery.>  | Is the battery OK?                         | Go to step 3.   | Charge or replace the battery. <Ref. to SC(H4DO(HEV))-39, Battery.>  |
| 3 | <b>CHECK ACTIVE GRILLE SHUTTER POWER SUPPLY.</b><br>1) Turn the ignition switch to OFF.<br>2) Disconnect the 12 volt auxiliary battery. <Ref. to NT-5, BATTERY, NOTE, Note.><br>3) Disconnect the connector from the active grille shutter.<br>4) Measure the voltage between active grille shutter connector and chassis ground.<br><br><b>Connector &amp; terminal</b><br><b>(F157) No. 2 (+) — Chassis ground (-):</b> | Is the voltage 9 V or more?                | Replace the active grille shutter. <Ref. to HEV-77, Active Grille Shutter.> | Repair the power supply circuit.   |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

## DI: DTC P05C0 ACTIVE GRILLE SHUTTER "A" OVER TEMPERATURE

### DTC DETECTING CONDITION:

- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-141, DTC P05C0 ACTIVE GRILLE SHUTTER "A" OVER TEMPERATURE, Diagnostic Trouble Code (DTC) Detecting Criteria.>

### CAUTION:

After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.

|   | Step  | Check                                      | Yes   | No  |
|---|---|--|---|---|
| 1 | <b>CHECK DTC.</b><br>1) Cool down the engine sufficiently after turning the ignition switch OFF.<br>NOTE:<br>Cool until you do not feel heat when touching the engine body.<br>2) Turn the ignition switch to ON.<br>3) Check for DTC. <Ref. to EN(H4DO HEV)(diag)-51, Read Diagnostic Trouble Code (DTC).> | Is DTC P05C0 displayed in «Present fault»? | Replace the active grille shutter. <Ref. to HEV-77, Active Grille Shutter.> | Even if DTC is detected, it has returned to a normal condition at this time.<br>NOTE:<br>In this case, temporary temperature rise in engine compartment may be the cause. |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

## DJ:DTC P0604 INTERNAL CONTROL MODULE RANDOM ACCESS MEMORY (RAM) ERROR

### DTC DETECTING CONDITION:

- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-142, DTC P0604 INTERNAL CONTROL MODULE RANDOM ACCESS MEMORY (RAM) ERROR, Diagnostic Trouble Code (DTC) Detecting Criteria.>

### TROUBLE SYMPTOM:

- Engine does not start.
- Engine stalls.

### CAUTION:

After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.

| Step                                     | Check                       | Yes  | No   |
|--|-----------------------------|--|--|
| 1<br>CHECK FOR ANY OTHER DTC ON DISPLAY. | Is any other DTC displayed? | Check the appropriate DTC using the "List of Diagnostic Trouble Code (DTC)". <Ref. to EN(H4DO HEV)(diag)-92, List of Diagnostic Trouble Code (DTC).> | Even if DTC is detected, the circuit has returned to a normal condition at this time. Reproduce the failure, and then perform the diagnosis again.<br><br>NOTE:<br>In this case, temporary poor contact of connector, temporary open or short circuit of harness may be the cause. |

## DK:DTC P0605 INTERNAL CONTROL MODULE READ ONLY MEMORY (ROM) ERROR

### NOTE:

For the diagnostic procedure, refer to DTC P0606. <Ref. to EN(H4DO HEV)(diag)-282, DTC P0606 CONTROL MODULE PROCESSOR, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

## DL:DTC P0606 CONTROL MODULE PROCESSOR

### DTC DETECTING CONDITION:

- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-144, DTC P0606 CONTROL MODULE PROCESOR, Diagnostic Trouble Code (DTC) Detecting Criteria.>

### TROUBLE SYMPTOM:



- Improper idling
- Poor driving performance

### CAUTION:

After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.

### WIRING DIAGRAM:

- Engine electrical system (without push button start) <Ref. to WI(HEV)-100, WITHOUT PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>
- Engine electrical system (with push button start) <Ref. to WI(HEV)-114, WITH PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>



EN-10752

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step  | Check                            | Yes  | No  |
|---|----------------------------------|--|---|
| <b>1 CHECK INPUT VOLTAGE OF ECM.</b><br>1) Turn the ignition switch to ON.<br>2) Measure the voltage between ECM connector and chassis ground.<br><b>Connector &amp; terminal</b><br><b>(B136) No. 6 (+) — Chassis ground (-):</b><br><b>(B137) No. 1 (+) — Chassis ground (-):</b>   | Is the voltage 10 — 13 V?        | Go to step 2.  | Repair the open or ground short circuit of power supply circuit.  |
| <b>2 CHECK INPUT VOLTAGE OF ECM.</b><br>1) Start the engine.<br>2) Measure the voltage between ECM connector and chassis ground.<br><b>Connector &amp; terminal</b><br><b>(B136) No. 6 (+) — Chassis ground (-):</b><br><b>(B137) No. 1 (+) — Chassis ground (-):</b>   | Is the voltage 13 — 15 V?        | Go to step 3.  | Repair the open or ground short circuit of power supply circuit.  |
| <b>3 CHECK HARNESS BETWEEN ECM AND ELECTRONIC THROTTLE CONTROL CONNECTOR.</b><br>1) Turn the ignition switch to OFF.<br>2) Disconnect the connectors from ECM and electronic throttle control.<br>3) Measure the resistance of harness between ECM connector and electronic throttle control connector.<br><b>Connector &amp; terminal</b><br><b>(B134) No. 19 — (E57) No. 5:</b><br><b>(B134) No. 29 — (E57) No. 3:</b>                                    | Is the resistance less than 1 Ω? | Go to step 4.  | Repair the harness and connector.<br>NOTE:<br>In this case, repair the following item:<br>• Open circuit in harness between ECM connector and electronic throttle control connector<br>• Poor contact of coupling connector |
| <b>4 CHECK ECM GROUND HARNESS.</b><br>1) Connect all connectors.<br>2) Turn the ignition to ON.<br>3) Measure the voltage between ECM connector and chassis ground.<br><b>Connector &amp; terminal</b><br><b>(B134) No. 3 (+) — Chassis ground (-):</b><br><b>(B134) No. 4 (+) — Chassis ground (-):</b><br><b>(B136) No. 1 (+) — Chassis ground (-):</b><br><b>(B136) No. 2 (+) — Chassis ground (-):</b><br><b>(B136) No. 3 (+) — Chassis ground (-):</b> | Is the voltage less than 1 V?    | Check the connector for poor contact and check the harness.<br>Replace the ECM if no fault is found.<br><Ref. to FU(H4DO(HEV))-85, Engine Control Module (ECM).> | Repair the harness and connector.<br>NOTE:<br>In this case, repair the following item:<br>• Open circuit in ground circuit<br>• Loose engine ground terminal<br>• Poor contact of coupling connector                        |

## DM:DTC P060A INTERNAL CONTROL MODULE MONITORING PROCESSOR PERFORMANCE

NOTE:

For the diagnostic procedure, refer to DTC P0606. <Ref. to EN(H4DO HEV)(diag)-282, DTC P0606 CONTROL MODULE PROCESSOR, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

## DN:DTC P060B INTERNAL CONTROL MODULE A/D PROCESSING PERFORMANCE

NOTE:

For the diagnostic procedure, refer to DTC P0606. <Ref. to EN(H4DO HEV)(diag)-282, DTC P0606 CONTROL MODULE PROCESSOR, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

## DO:DTC P0616 STARTER RELAY CIRCUIT LOW

### 1. MODEL WITHOUT PUSH BUTTON START

#### DTC DETECTING CONDITION:


- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-150, DTC P0616 STARTER RELAY CIRCUIT LOW, Diagnostic Trouble Code (DTC) Detecting Criteria.>

#### CAUTION:

After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.

#### WIRING DIAGRAM:

Engine electrical system (without push button start) <Ref. to WI(HEV)-100, WITHOUT PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>



EN-11625

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

|   | Step   | Check                            | Yes  | No   |
|---|--|----------------------------------|--|--|
| 1 | <b>CHECK FOR ANY OTHER DTC ON DISPLAY.</b>   | Is any other DTC displayed?      | Check DTC using "List of Diagnostic Trouble Code (DTC)". <Ref. to EN(H4DO HEV)(diag)-92, List of Diagnostic Trouble Code (DTC).> | Go to step 2.  |
| 2 | <b>CHECK HARNESS BETWEEN ECM AND STARTER RELAY 1 CONNECTOR.</b><br>1) Turn the ignition switch to OFF.<br>2) Remove the starter relay 1.<br>3) Disconnect the connectors from ECM and starter motor.<br>4) Measure the resistance of harness between ECM connector and starter relay 1 connector.<br><b>Connector &amp; terminal</b><br><b>(B137) No. 17 — (B225) No. 1:</b><br>NOTE:<br>Place the select lever in "P" range or "N" range. | Is the resistance less than 1 Ω? | Go to step 3.  | NOTE:<br>Check the following item and repair or replace if necessary.<br>• Open circuit of harness between ECM connector and starter relay 1 connector<br>• Poor contact of coupling connector |
| 3 | <b>CHECK HARNESS BETWEEN ECM AND STARTER RELAY 1 CONNECTOR.</b><br>Measure the resistance between ECM connector and chassis ground.<br><b>Connector &amp; terminal</b><br><b>(B137) No. 17 — Chassis ground:</b>   | Is the resistance 1 MΩ or more?  | Repair the poor contact of ECM connector.  | Repair the short circuit to ground in harness between ECM connector and starter relay 1 connector.   |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

---

## 2. MODEL WITH PUSH BUTTON START

### DTC DETECTING CONDITION:

- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-150, DTC P0616 STARTER RELAY CIRCUIT LOW, Diagnostic Trouble Code (DTC) Detecting Criteria.>

### TROUBLE SYMPTOM:

Failure of engine to start

### CAUTION:



After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

## WIRING DIAGRAM:

Engine electrical system (with push button start) <Ref. to WI(HEV)-114, WITH PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>



EN-10732

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

## ENGINE (DIAGNOSTICS)

| Step  | Check                                   | Yes  | No  |
|---|---|--|---|
| <p><b>1</b>    <b>CHECK HARNESS BETWEEN ECM AND STARTER RELAY 1 CONNECTOR.</b></p> <p>1) Turn the ignition to OFF.<br/>           2) Disconnect the connector from ECM.<br/>           3) Remove the starter relay 1.<br/>           4) Measure the resistance of harness between ECM connector and starter relay 1 connector.</p> <p>NOTE:<br/>           Place the select lever in "P" range or "N" range.</p> <p><b>Connector &amp; terminal</b><br/> <b>(B137) No. 14 — (B225) No. 1:</b></p> | <p>Is the resistance less than 1 Ω?</p> | <p>Go to step 2.</p>                             | <p>Repair the harness and connector.</p> <p>NOTE:<br/>           In this case, repair the following item:</p> <ul style="list-style-type: none"> <li>• Open circuit of harness between ECM connector and starter relay 1 connector</li> <li>• Poor contact of coupling connector</li> </ul> |
| <p><b>2</b>    <b>CHECK HARNESS BETWEEN ECM AND STARTER RELAY 1 CONNECTOR.</b></p> <p>1) Disconnect the connector from starter motor.<br/>           2) Measure the resistance between ECM connector and chassis ground.</p> <p><b>Connector &amp; terminal</b><br/> <b>(B137) No. 14 — Chassis ground:</b></p>   | <p>Is the resistance 1 MΩ or more?</p>  | <p>Repair the poor contact of ECM connector.</p> | <p>Repair the short circuit to ground in harness between ECM connector and starter relay 1 connector.</p>   |

## DP:DTC P0617 STARTER RELAY CIRCUIT HIGH

### 1. MODEL WITHOUT PUSH BUTTON START

#### DTC DETECTING CONDITION:

- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-151, DTC P0617 STARTER RELAY CIRCUIT HIGH, Diagnostic Trouble Code (DTC) Detecting Criteria.>

#### TROUBLE SYMPTOM:



Failure of engine to start

#### CAUTION:

After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.

#### WIRING DIAGRAM:

Engine electrical system (without push button start) <Ref. to WI(HEV)-100, WITHOUT PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>



# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step   | Check                        | Yes   | No  |
|--|------------------------------|---|---|
| <b>1</b><br><b>CHECK FOR ANY OTHER DTC ON DISPLAY.</b>   | Is any other DTC displayed?  | Check the appropriate DTC using the "List of Diagnostic Trouble Code (DTC)".<br><Ref. to EN(H4DO HEV)(diag)-92, List of Diagnostic Trouble Code (DTC).> | Go to step 2.                             |
| <b>2</b><br><b>CHECK HARNESS BETWEEN ECM AND STARTER RELAY 1 CONNECTOR.</b><br>1) Turn the ignition switch to OFF.<br>2) Disconnect the connector from ECM.<br>3) Turn the ignition switch to ON.<br>4) Measure the voltage between ECM connector and chassis ground.<br><b>Connector &amp; terminal</b><br><b>(B137) No. 17 (+) — Chassis ground (-):</b><br>NOTE:<br>Place the select lever in "P" range or "N" range. | Is the voltage 10 V or more? | Repair the short circuit to power in harness between ECM connector and starter relay 1 connector.   | Repair the poor contact of ECM connector. |

## 2. MODEL WITH PUSH BUTTON START

### DTC DETECTING CONDITION:

- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-151, DTC P0617 STARTER RELAY CIRCUIT HIGH, Diagnostic Trouble Code (DTC) Detecting Criteria.>

### TROUBLE SYMPTOM:

Failure of engine to start

### CAUTION:









After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

## WIRING DIAGRAM:

Engine electrical system (with push button start) <Ref. to WI(HEV)-114, WITH PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>



EN-10732

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

|   | Step  | Check                           | Yes   | No  |
|---|---|---------------------------------|---|---|
| 1 | <b>CHECK STARTER MOTOR.</b><br>1) Turn the ignition to ON.<br>2) Check the starter motor condition.   | Is the starter motor rotating?  | Go to step 2.   | Repair the short circuit to power supply.<br>NOTE:<br>In this case, repair the following harnesses:<br>• Short circuit to power supply in harness between ECM connector and starter relay 1 connector<br>• Short circuit to power supply in harness between ECM connector and starter motor<br>• Short circuit to power supply in harness between starter relay 1 connector and starter motor |
| 2 | <b>CHECK HARNESS BETWEEN STARTER CUT RELAY CONNECTOR AND STARTER RELAY 1 CONNECTOR.</b><br>1) Turn the ignition to OFF.<br>2) Disconnect the connector from starter motor.<br>3) Remove the starter cut relay and starter relay 1.<br>4) Turn the ignition to ON.<br>5) Measure the voltage between starter relay 1 connector and chassis ground.<br><b>Connector &amp; terminal</b><br><b>(B225) No. 2 (+) — Chassis ground (-):</b> | Is the voltage 10 V or more?    | Repair the short circuit to power in harness between starter cut relay connector and starter relay 1 connector. | Go to step 3.   |
| 3 | <b>CHECK STARTER CUT RELAY.</b><br>1) Connect the battery to starter cut relay terminals No. 40 and No. 42.<br>2) Measure the resistance between starter cut relay terminals.<br><b>Terminals</b><br><b>No. 41 — No. 44:</b>  | Is the resistance 1 MΩ or more? | Go to step 6.   | Replace the starter cut relay. <Ref. to SL-124, Starter Cut Relay.><br>Go to step 4.  |
| 4 | <b>CHECK HARNESS BETWEEN ECM AND STARTER RELAY 1 CONNECTOR.</b><br>1) Disconnect the connector from ECM.<br>2) Measure the resistance between ECM connector and chassis ground.<br><b>Connector &amp; terminal</b><br><b>(B135) No. 26 — Chassis ground:</b>  | Is the resistance 1 MΩ or more? | Go to step 5.   | Repair the short circuit to ground in harness between ECM connector and starter relay 1 connector.  |
| 5 | <b>CHECK STARTER RELAY 1.</b><br>Measure the resistance between starter relay 1 terminals.<br><b>Terminals</b><br><b>No. 1 — No. 2:</b>   | Is the resistance 1 MΩ or more? | Go to step 6.   | Replace the starter relay 1. <Ref. to EN(H4DO HEV)(diag)-9, LOCATION, Electrical Component Location.>   |

## Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step   | Check                               | Yes  | No   |
|--|-------------------------------------|--|--|
| <p><b>6</b></p> <p><b>CHECK HARNESS BETWEEN ECM, STARTER RELAY 1 CONNECTOR AND STARTER MOTOR.</b></p> <p>1) Disconnect the connector from ECM.<br/>                     2) Turn the ignition to ON.<br/>                     3) Measure the voltage between ECM connector and chassis ground.</p> <p><b>Connector &amp; terminal</b><br/> <b>(B137) No. 14 (+) — Chassis ground (-):</b></p> | <p>Is the voltage 10 V or more?</p> | <p>Repair the short circuit to power supply.</p> <p><b>NOTE:</b><br/>                     In this case, repair the following harnesses:</p> <ul style="list-style-type: none"> <li>• Short circuit to power supply in harness between ECM connector and starter relay 1 connector</li> <li>• Short circuit to power supply in harness between ECM connector and starter motor</li> <li>• Short circuit to power supply in harness between starter relay 1 connector and starter motor</li> </ul> | <p>Repair the poor contact of ECM connector.</p> |

### DQ:DTC P062F INTERNAL CONTROL MODULE EEPROM ERROR

NOTE:

For the diagnostic procedure, refer to DTC P0606. <Ref. to EN(H4DO HEV)(diag)-282, DTC P0606 CONTROL MODULE PROCESSOR, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

## **DR:DTC P0685 ECM/PCM POWER RELAY CONTROL CIRCUIT/OPEN**

### **DTC DETECTING CONDITION:**

- Detected when two consecutive driving cycles with fault occur.
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-153, DTC P0685 ECM/PCM POWER RELAY CONTROL CIRCUIT/OPEN, Diagnostic Trouble Code (DTC) Detecting Criteria.>

### **CAUTION:**

**After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.**



# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step  | Check                           | Yes  | No  |
|---|---------------------------------|--|---|
| <b>2</b><br><b>CHECK HARNESS BETWEEN ECM AND MAIN RELAY CONNECTOR.</b><br>1) Turn the ignition switch to OFF.<br>2) Measure the voltage between ECM connector and engine ground.<br><b>Connector &amp; terminal</b><br><i>(B136) No. 6 (+) — Engine ground (-):</i><br><i>(B137) No. 1 (+) — Engine ground (-):</i>                       | Is the voltage 10 V or more?    | Repair the harness and connector.<br><b>NOTE:</b><br>In this case, repair the following item:<br>• Short circuit to power supply in harness between ECM connector and main relay connector<br>• Defective main relay | Go to step 3.   |
| <b>3</b><br><b>CHECK HARNESS BETWEEN ECM AND MAIN RELAY CONNECTOR.</b><br>1) Turn the ignition switch to OFF.<br>2) Remove the main relay.<br>3) Disconnect the connector from ECM.<br>4) Measure the resistance between the ECM connector and engine ground.<br><b>Connector &amp; terminal</b><br><i>(B135) No. 13 — Engine ground:</i> | Is the resistance 1 MΩ or more? | Repair the poor contact of ECM connector.  | Repair the short circuit to ground in harness between ECM connector and main relay connector. |

## DS:DTC P0700 TRANSMISSION CONTROL SYSTEM (MIL REQUEST)

NOTE:

For the diagnostic procedure, refer to CVT section. <Ref. to CVT(w/o HEV)(diag)-2, Basic Diagnostic Procedure.>

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

---

## **DT:DTC P081A STARTER DISABLE CIRCUIT LOW**

### **DTC DETECTING CONDITION:**

- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-155, DTC P081A STARTER DISABLE CIRCUIT LOW, Diagnostic Trouble Code (DTC) Detecting Criteria.>

### **TROUBLE SYMPTOM:**

Failure of engine to start

### **CAUTION:**










**After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.**

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

## WIRING DIAGRAM:

Engine electrical system (with push button start) <Ref. to WI(HEV)-114, WITH PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>



EN-10732

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

## ENGINE (DIAGNOSTICS)

| Step   | Check                            | Yes                                       | No  |
|--|----------------------------------|---|---|
| <p><b>1 CHECK HARNESS BETWEEN STARTER RELAY (PUSH BUTTON START) CONNECTOR AND STARTER CUT RELAY CONNECTOR.</b></p> <p>1) Turn the ignition to OFF.<br/>2) Remove the starter relay (push button start) and starter cut relay.<br/>3) Measure the resistance of harness between starter relay (push button start) connector and starter cut relay connector.</p> <p><b>Connector &amp; terminal</b><br/><b>(B225) No. 28 — (B225) No. 42:</b></p> | Is the resistance less than 1 Ω? | Go to step 2.                             | Repair the open circuit in harness between starter relay (push button start) connector and starter cut relay connector. |
| <p><b>2 CHECK HARNESS BETWEEN ECM AND STARTER CUT RELAY CONNECTOR.</b></p> <p>1) Disconnect the connector from ECM.<br/>2) Measure the resistance of harness between ECM connector and starter cut relay connector.</p> <p><b>Connector &amp; terminal</b><br/><b>(B135) No. 34 — (B225) No. 40:</b></p>   | Is the resistance less than 1 Ω? | Go to step 3.                             | Repair the open circuit of harness between ECM connector and starter cut relay connector.                               |
| <p><b>3 CHECK STARTER CUT RELAY.</b></p> <p>1) Connect the battery to starter cut relay terminals No. 40 and No. 42.<br/>2) Measure the resistance between starter cut relay terminals.</p> <p><b>Terminals</b><br/><b>No. 41 — No. 44:</b></p>  | Is the resistance 1 MΩ or more?  | Repair the poor contact of ECM connector. | Replace the starter cut relay. <Ref. to SL-124, Starter Cut Relay.>   |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

## DU:DTC P0851 PARK/NEUTRAL SWITCH INPUT CIRCUIT LOW (AT MODEL)

### DTC DETECTING CONDITION:

- Detected when two consecutive driving cycles with fault occur.
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-156, DTC P0851 PARK/NEUTRAL SWITCH INPUT CIRCUIT LOW (AT MODEL), Diagnostic Trouble Code (DTC) Detecting Criteria.>

### TROUBLE SYMPTOM:


Improper idling

### CAUTION:

After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.

### WIRING DIAGRAM:

- Engine electrical system (without push button start) <Ref. to WI(HEV)-100, WITHOUT PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>
- Engine electrical system (with push button start) <Ref. to WI(HEV)-114, WITH PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>



EN-10753

| Step | Check  | Yes   | No            |
|------|--|---|---------------|
| 1    | <b>CHECK SELECT CABLE.</b>   | Repair or adjust the select cable. <Ref. to CS-51, Select Cable.> | Go to step 2. |
| 2    | <b>CHECK INPUT SIGNAL OF ECM.</b><br>1) Turn the ignition switch to ON.<br>2) Place the select lever in other than "P" range and "N" range.<br>3) Measure the voltage between ECM connector and chassis ground.<br><b>Connector &amp; terminal</b><br><b>(B137) No. 16 (+) — Chassis ground (-):</b> | Repair the poor contact of ECM connector.                         | Go to step 3. |

## Diagnostic Procedure with Diagnostic Trouble Code (DTC)

### ENGINE (DIAGNOSTICS)

| Step  | Check                           | Yes  | No   |
|---|---------------------------------|--|--|
| <b>3</b><br><b>CHECK HARNESS BETWEEN ECM AND TRANSMISSION HARNESS CONNECTOR.</b><br>1) Turn the ignition switch to OFF.<br>2) Disconnect the connectors from ECM and transmission harness connector (T3).<br>3) Measure the resistance between ECM connector and chassis ground.<br><i><b>Connector &amp; terminal</b></i><br><i><b>(B137) No. 16 — Chassis ground:</b></i> | Is the resistance 1 MΩ or more? | Go to step 4.  | Repair the short circuit to ground in harness between ECM connector and transmission harness connector.          |
| <b>4</b><br><b>CHECK TRANSMISSION HARNESS CONNECTOR.</b><br>1) Disconnect the connector from inhibitor switch.<br>2) Measure the resistance between transmission harness connector and engine ground.<br><i><b>Connector &amp; terminal</b></i><br><i><b>(T3) No. 16 — Engine ground:</b></i>   | Is the resistance 1 MΩ or more? | Replace the inhibitor switch. <Ref. to CVT(TH58A)-97, Inhibitor Switch.> | Repair short circuit to ground in harness between transmission harness connector and inhibitor switch connector. |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

## DV:DTC P0852 PARK/NEUTRAL SWITCH INPUT CIRCUIT HIGH (AT MODEL)

### DTC DETECTING CONDITION:

- Detected when two consecutive driving cycles with fault occur.
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-157, DTC P0852 PARK/NEUTRAL SWITCH INPUT CIRCUIT HIGH (AT MODEL), Diagnostic Trouble Code (DTC) Detecting Criteria.>

### TROUBLE SYMPTOM:


Improper idling

### CAUTION:

After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.

### WIRING DIAGRAM:

- Engine electrical system (without push button start) <Ref. to WI(HEV)-100, WITHOUT PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>
- Engine electrical system (with push button start) <Ref. to WI(HEV)-114, WITH PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>



EN-10753

| Step | Check   | Yes   | No            |
|------|---|---|---------------|
| 1    | <b>CHECK SELECT CABLE.</b>  | Repair or adjust the select cable. <Ref. to CS-51, Select Cable.> | Go to step 2. |
| 2    | <b>CHECK INPUT SIGNAL OF ECM.</b><br>1) Turn the ignition switch to ON.<br>2) Measure the voltage between ECM and chassis ground with select lever at "P" range and "N" range.<br><b>Connector &amp; terminal</b><br><b>(B137) No. 16 (+) — Chassis ground (-):</b> | Repair the poor contact of ECM connector.                         | Go to step 3. |

## Diagnostic Procedure with Diagnostic Trouble Code (DTC)

### ENGINE (DIAGNOSTICS)

| Step  | Check                                    | Yes  | No  |
|---|--|--|---|
| <b>3</b><br><b>CHECK HARNESS BETWEEN ECM AND INHIBITOR SWITCH CONNECTOR.</b><br>1) Turn the ignition switch to OFF.<br>2) Disconnect the connectors from ECM and inhibitor switch.<br>3) Measure the resistance of harness between ECM connector and inhibitor switch connector.<br><b>Connector &amp; terminal</b><br><b>(B137) No. 16 — (T7) No. 6:</b> | Is the resistance less than 1 $\Omega$ ? | Go to step 4.  | Repair the harness and connector.<br><b>NOTE:</b><br>In this case, repair the following item:<br>• Open circuit in harness between ECM connector and inhibitor switch connector<br>• Poor contact of coupling connector   |
| <b>4</b><br><b>CHECK INHIBITOR SWITCH GROUND LINE.</b><br>Measure the resistance of harness between inhibitor switch connector and engine ground.<br><b>Connector &amp; terminal</b><br><b>(T7) No. 9 — Engine ground:</b>  | Is the resistance less than 5 $\Omega$ ? | Replace the inhibitor switch. <Ref. to CVT(TH58A)-97, Inhibitor Switch.> | Repair the harness and connector.<br><b>NOTE:</b><br>In this case, repair the following item:<br>• Open circuit of harness between inhibitor switch connector and starter motor ground line<br>• Poor contact of coupling connector<br>• Poor contact of starter motor connector<br>• Poor contact of starter motor ground<br>• Starter motor |

## **DW:DTC P0A7B BATTERY ENERGY CONTROL MODULE REQUEST MIL ILLUMINATION**

**NOTE:**

Refer to HEV section for diagnostic procedure. <Ref. to HEV(diag)-2, Basic Diagnostic Procedure.>

## **DX:DTC P0AC4 HYBRID POWERTRAIN CONTROL MODULE REQUEST MIL ILLUMINATION**

**NOTE:**

Refer to HEV section for diagnostic procedure. <Ref. to HEV(diag)-2, Basic Diagnostic Procedure.>

## **DY:DTC P0CA1 DRIVE MOTOR CONTROL MODULE REQUEST MIL ILLUMINATION**

**NOTE:**

Refer to HEV section for diagnostic procedure. <Ref. to HEV(diag)-2, Basic Diagnostic Procedure.>

## **DZ:DTC P1160 RETURN SPRING FAILURE**

**NOTE:**

For the diagnostic procedure, refer to DTC P2101. <Ref. to EN(H4DO HEV)(diag)-335, DTC P2101 THROTTLE ACTUATOR CONTROL MOTOR CIRCUIT RANGE/PERFORMANCE, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

## EA:DTC P1449 EVAPORATIVE EMISSION CONT. SYS. AIR FILTER CLOG

### DTC DETECTING CONDITION:

- Detected when two consecutive driving cycles with fault occur.
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-162, DTC P1449 EVAPORATIVE EMISSION CONT. SYS. AIR FILTER CLOG, Diagnostic Trouble Code (DTC) Detecting Criteria.>

### CAUTION:

After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.

| Step  | Check                                      | Yes  | No  |
|---|--|--|---|
| 1<br><b>CHECK FOR ANY OTHER DTC ON DISPLAY.</b> | Is any other DTC displayed?                | Check the appropriate DTC using the "List of Diagnostic Trouble Code (DTC)". <Ref. to EN(H4DO HEV)(diag)-92, List of Diagnostic Trouble Code (DTC).> | Go to step 2.   |
| 2<br><b>CHECK DRAIN FILTER AND DRAIN TUBE.</b>  | Is the drain filter or drain tube clogged? | Replace the drain filter. <Ref. to EC(H4DO(HEV))-38, Drain Filter.>  | Replace the leak check valve assembly. <Ref. to EC(H4DO(HEV))-39, Leak Check Valve Assembly.> |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

## EB:DTC P1451 EVAPORATIVE EMISSION CONT. SYS.

### DTC DETECTING CONDITION:

- Detected when two consecutive driving cycles with fault occur.
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-163, DTC P1451 EVAPORATIVE EMISSION CONT. SYS., Diagnostic Trouble Code (DTC) Detecting Criteria.>

### CAUTION:

After servicing or replacing faulty parts, perform **Clear Memory Mode** <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and **Inspection Mode** <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.

| Step  | Check   | Yes  | No   |
|---|---|--|--|
| <b>1</b><br><b>CHECK DRAIN TUBE BETWEEN CANISTER AND LEAK CHECK VALVE ASSEMBLY.</b>   | Is the drain tube between canister and leak check valve assembly clogged? | Replace the drain tube between the canister and leak check valve assembly. <Ref. to EC(H4DO(HEV))-8, Canister.> <Ref. to EC(H4DO(HEV))-39, Leak Check Valve Assembly.> | Go to step 2.  |
| <b>2</b><br><b>CHECK HOSES BETWEEN CANISTER AND FUEL TANK.</b>  | Are the hoses between the canister and fuel tank clogged?                 | Replace the hoses between the canister and fuel tank. <Ref. to EC(H4DO(HEV))-8, Canister.> <Ref. to FU(H4DO(HEV))-105, Fuel Tank.>                                     | Replace the canister. <Ref. to EC(H4DO(HEV))-8, Canister.> After the operation is complete, go to the next step. Go to step 3. |
| <b>3</b><br><b>CHECK EVAPORATIVE EMISSION CONTROL SYSTEM.</b><br>Perform drive cycle I. <Ref. to EN(H4DO HEV)(diag)-62, DRIVE CYCLE I, PROCEDURE, Drive Cycle.> | Is DTC P1451 displayed on the display?                                    | Replace the leak check valve assembly. <Ref. to EC(H4DO(HEV))-39, Leak Check Valve Assembly.>  | End.   |

## Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

---

### **EC:DTC P1492 EGR SOLENOID VALVE SIGNAL #1 CIRCUIT MALFUNCTION (LOW INPUT)**

NOTE:

For the diagnostic procedure, refer to DTC P1498. <Ref. to EN(H4DO HEV)(diag)-309, DTC P1498 EGR SOLENOID VALVE SIGNAL #4 CIRCUIT MALFUNCTION (LOW INPUT), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

### **ED:DTC P1493 EGR SOLENOID VALVE SIGNAL #1 CIRCUIT MALFUNCTION (HIGH INPUT)**

NOTE:

For the diagnostic procedure, refer to DTC P1499. <Ref. to EN(H4DO HEV)(diag)-312, DTC P1499 EGR SOLENOID VALVE SIGNAL #4 CIRCUIT MALFUNCTION (HIGH INPUT), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

### **EE:DTC P1494 EGR SOLENOID VALVE SIGNAL #2 CIRCUIT MALFUNCTION (LOW INPUT)**

NOTE:

For the diagnostic procedure, refer to DTC P1498. <Ref. to EN(H4DO HEV)(diag)-309, DTC P1498 EGR SOLENOID VALVE SIGNAL #4 CIRCUIT MALFUNCTION (LOW INPUT), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

### **EF:DTC P1495 EGR SOLENOID VALVE SIGNAL #2 CIRCUIT MALFUNCTION (HIGH INPUT)**

NOTE:

For the diagnostic procedure, refer to DTC P1499. <Ref. to EN(H4DO HEV)(diag)-312, DTC P1499 EGR SOLENOID VALVE SIGNAL #4 CIRCUIT MALFUNCTION (HIGH INPUT), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

### **EG:DTC P1496 EGR SOLENOID VALVE SIGNAL #3 CIRCUIT MALFUNCTION (LOW INPUT)**

NOTE:

For the diagnostic procedure, refer to DTC P1498. <Ref. to EN(H4DO HEV)(diag)-309, DTC P1498 EGR SOLENOID VALVE SIGNAL #4 CIRCUIT MALFUNCTION (LOW INPUT), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

### **EH:DTC P1497 EGR SOLENOID VALVE SIGNAL #3 CIRCUIT MALFUNCTION (HIGH INPUT)**

NOTE:

For the diagnostic procedure, refer to DTC P1499. <Ref. to EN(H4DO HEV)(diag)-312, DTC P1499 EGR SOLENOID VALVE SIGNAL #4 CIRCUIT MALFUNCTION (HIGH INPUT), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

## **EI: DTC P1498 EGR SOLENOID VALVE SIGNAL #4 CIRCUIT MALFUNCTION (LOW INPUT)**

### **DTC DETECTING CONDITION:**

- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-166, DTC P1498 EGR SOLENOID VALVE SIGNAL #4 CIRCUIT MALFUNCTION (LOW INPUT), Diagnostic Trouble Code (DTC) Detecting Criteria.>

### **TROUBLE SYMPTOM:**

- Improper idling
- Poor driving performance
- Engine breathing

### **CAUTION:**



**After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.**

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

## ENGINE (DIAGNOSTICS)

### WIRING DIAGRAM:

- Engine electrical system (without push button start) <Ref. to WI(HEV)-100, WITHOUT PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>
- Engine electrical system (with push button start) <Ref. to WI(HEV)-114, WITH PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>



EN-10754

| Step  | Check                        | Yes           | No  |
|---|------------------------------|---------------|---|
| <b>1</b><br><b>CHECK POWER SUPPLY TO EGR CONTROL VALVE.</b><br>1) Turn the ignition switch to OFF.<br>2) Disconnect the connector from the EGR control valve.<br>3) Turn the ignition switch to ON.<br>4) Measure the voltage between EGR control valve connector and engine ground.<br><b>Connector &amp; terminal</b><br><b>(E18) No. 2 (+) — Engine ground (-):</b><br><b>(E18) No. 5 (+) — Engine ground (-):</b> | Is the voltage 10 V or more? | Go to step 2. | Repair the harness and connector.<br><b>NOTE:</b><br>In this case, repair the following item:<br>• Open circuit in harness between EGR control valve and main relay connector<br>• Poor contact of coupling connector |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step   | Check  | Yes  | No  |
|--|--|--|---|
| <b>2 CHECK HARNESS BETWEEN ECM AND EGR CONTROL VALVE CONNECTOR.</b><br>1) Turn the ignition switch to OFF.<br>2) Disconnect the connector from ECM.<br>3) Measure the resistance between ECM connector and EGR control valve connector.<br><b>Connector &amp; terminal</b><br><i>DTC P1492; (B136) No. 11 — (E18) No. 3:</i><br><i>DTC P1494; (B136) No. 13 — (E18) No. 1:</i><br><i>DTC P1496; (B136) No. 31 — (E18) No. 4:</i><br><i>DTC P1498; (B136) No. 32 — (E18) No. 6:</i> | Is the resistance less than 1 Ω?                             | Go to step 3.  | Repair the harness and connector.<br>NOTE:<br>In this case, repair the following item:<br><ul style="list-style-type: none"> <li>• Open circuit of harness between ECM connector and EGR control valve connector</li> <li>• Poor contact of coupling connector</li> </ul> |
| <b>3 CHECK HARNESS BETWEEN ECM AND EGR CONTROL VALVE CONNECTOR.</b><br>1) Disconnect the connector from ECM.<br>2) Measure the resistance between ECM connector and chassis ground.<br><b>Connector &amp; terminal</b><br><i>DTC P1492; (B136) No. 11 — Chassis ground:</i><br><i>DTC P1494; (B136) No. 13 — Chassis ground:</i><br><i>DTC P1496; (B136) No. 31 — Chassis ground:</i><br><i>DTC P1498; (B136) No. 32 — Chassis ground:</i>   | Is the resistance 1 MΩ or more?                              | Go to step 4.  | Repair ground short circuit of harness between ECM connector and EGR control valve connector.   |
| <b>4 CHECK FOR POOR CONTACT.</b><br>Check for poor contact between ECM connector and EGR control valve connector.  | Is there poor contact in ECM or EGR control valve connector? | Repair the poor contact of ECM or EGR control valve connector. | Replace EGR control valve. <Ref. to EC(H4DO(HEV))-26, EGR Control Valve.>   |

## Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

---

### **EJ: DTC P1499 EGR SOLENOID VALVE SIGNAL #4 CIRCUIT MALFUNCTION (HIGH INPUT)**

#### **DTC DETECTING CONDITION:**

- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-166, DTC P1499 EGR SOLENOID VALVE SIGNAL #4 CIRCUIT MALFUNCTION (HIGH INPUT), Diagnostic Trouble Code (DTC) Detecting Criteria.>

#### **TROUBLE SYMPTOM:**

- Improper idling
- Poor driving performance
- Engine breathing

#### **CAUTION:**



After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

## WIRING DIAGRAM:

- Engine electrical system (without push button start) <Ref. to WI(HEV)-100, WITHOUT PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>
- Engine electrical system (with push button start) <Ref. to WI(HEV)-114, WITH PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>



EN-10754

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step   | Check                                  | Yes   | No   |
|--|--|---|--|
| <p><b>1</b>     <b>CHECK HARNESS BETWEEN ECM AND EGR CONTROL VALVE CONNECTOR.</b><br/>           1) Turn the ignition switch to OFF.<br/>           2) Disconnect the connector from ECM and EGR control valve.<br/>           3) Turn the ignition switch to ON.<br/>           4) Measure the voltage between ECM connector and chassis ground.</p> <p><b>Connector &amp; terminal</b><br/> <b>DTC P1493; (B136) No. 11 (+) — Chassis ground (-):</b><br/> <b>DTC P1495; (B136) No. 13 (+) — Chassis ground (-):</b><br/> <b>DTC P1497; (B136) No. 31 (+) — Chassis ground (-):</b><br/> <b>DTC P1499; (B136) No. 32 (+) — Chassis ground (-):</b></p> | <p>Is the voltage 10 V or more?</p>    | <p>Repair the short circuit to power supply in the harness between the ECM connector and EGR control valve connector.</p> | <p>Go to step 2.</p>   |
| <p><b>2</b>     <b>CHECK EGR CONTROL VALVE.</b><br/>           Measure the resistance between EGR control valve terminals.</p> <p><b>Terminals</b><br/> <b>DTC P1493; No. 2 — No. 3:</b><br/> <b>DTC P1495; No. 2 — No. 1:</b><br/> <b>DTC P1497; No. 5 — No. 4:</b><br/> <b>DTC P1499; No. 5 — No. 6:</b></p>   | <p>Is the resistance 20 Ω or more?</p> | <p>Repair the poor contact of ECM connector.</p>  | <p>Replace EGR control valve. &lt;Ref. to EC(H4DO(HEV))-26, EGR Control Valve.&gt;</p> |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

## EK:DTC P2004 INTAKE MANIFOLD RUNNER CONTROL STUCK OPEN (BANK 1)

### DTC DETECTING CONDITION:

- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-167, DTC P2004 INTAKE MANIFOLD RUNNER CONTROL STUCK OPEN (BANK 1), Diagnostic Trouble Code (DTC) Detecting Criteria.>

### CAUTION:

After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.

| Step  | Check   | Yes  | No  |
|---|---|--|---|
| 1<br><b>CHECK FOR ANY OTHER DTC ON DISPLAY.</b>   | Is any other DTC displayed?   | Check the appropriate DTC using the "List of Diagnostic Trouble Code (DTC)". <Ref. to EN(H4DO HEV)(diag)-92, List of Diagnostic Trouble Code (DTC).> | Go to step 2.   |
| 2<br><b>CHECK TUMBLE GENERATOR VALVE RH.</b><br>1) Remove the tumble generator valve assembly RH.<br>2) Check the tumble generator valve. | Is there any dirt or clogging with foreign objects in the tumble generator valve? | Clean the tumble generator valve.  | Replace the tumble generator valve RH. <Ref. to FU(H4DO(HEV))-73, Tumble Generator Valve Assembly.> |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

## EL:DTC P2005 INTAKE MANIFOLD RUNNER CONTROL STUCK OPEN (BANK 2)

### DTC DETECTING CONDITION:

- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-168, DTC P2005 INTAKE MANIFOLD RUNNER CONTROL STUCK OPEN (BANK 2), Diagnostic Trouble Code (DTC) Detecting Criteria.>

### CAUTION:

After servicing or replacing faulty parts, perform **Clear Memory Mode** <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and **Inspection Mode** <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.

| Step  | Check   | Yes  | No  |
|---|---|--|---|
| 1<br><b>CHECK FOR ANY OTHER DTC ON DISPLAY.</b>   | Is any other DTC displayed?   | Check the appropriate DTC using the "List of Diagnostic Trouble Code (DTC)". <Ref. to EN(H4DO HEV)(diag)-92, List of Diagnostic Trouble Code (DTC).> | Go to step 2.   |
| 2<br><b>CHECK TUMBLE GENERATOR VALVE LH.</b><br>1) Remove the tumble generator valve assembly LH.<br>2) Check the tumble generator valve. | Is there any dirt or clogging with foreign objects in the tumble generator valve? | Clean the tumble generator valve.  | Replace the tumble generator valve LH. <Ref. to FU(H4DO(HEV))-73, Tumble Generator Valve Assembly.> |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

## EM:DTC P2006 INTAKE MANIFOLD RUNNER CONTROL STUCK CLOSED (BANK 1)

### DTC DETECTING CONDITION:

- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-169, DTC P2006 INTAKE MANIFOLD RUNNER CONTROL STUCK CLOSED (BANK 1), Diagnostic Trouble Code (DTC) Detecting Criteria.>

### CAUTION:

After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.

| Step  | Check   | Yes  | No  |
|---|---|--|---|
| 1<br><b>CHECK FOR ANY OTHER DTC ON DISPLAY.</b>   | Is any other DTC displayed?   | Check the appropriate DTC using the "List of Diagnostic Trouble Code (DTC)". <Ref. to EN(H4DO HEV)(diag)-92, List of Diagnostic Trouble Code (DTC).> | Go to step 2.   |
| 2<br><b>CHECK TUMBLE GENERATOR VALVE RH.</b><br>1) Remove the tumble generator valve assembly RH.<br>2) Check the tumble generator valve. | Is there any dirt or clogging with foreign objects in the tumble generator valve? | Clean the tumble generator valve.  | Replace the tumble generator valve RH. <Ref. to FU(H4DO(HEV))-73, Tumble Generator Valve Assembly.> |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

## EN:DTC P2007 INTAKE MANIFOLD RUNNER CONTROL STUCK CLOSED (BANK 2)

### DTC DETECTING CONDITION:

- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-170, DTC P2007 INTAKE MANIFOLD RUNNER CONTROL STUCK CLOSED (BANK 2), Diagnostic Trouble Code (DTC) Detecting Criteria.>

### CAUTION:

After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.

| Step   | Check   | Yes  | No  |
|--|---|--|---|
| <b>1</b><br><b>CHECK FOR ANY OTHER DTC ON DISPLAY.</b>   | Is any other DTC displayed?   | Check the appropriate DTC using the "List of Diagnostic Trouble Code (DTC)". <Ref. to EN(H4DO HEV)(diag)-92, List of Diagnostic Trouble Code (DTC).> | Go to step 2.   |
| <b>2</b><br><b>CHECK TUMBLE GENERATOR VALVE LH.</b><br>1) Remove the tumble generator valve assembly LH.<br>2) Check the tumble generator valve. | Is there any dirt or clogging with foreign objects in the tumble generator valve? | Clean the tumble generator valve.  | Replace the tumble generator valve LH. <Ref. to FU(H4DO(HEV))-73, Tumble Generator Valve Assembly.> |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

## EO:DTC P2009 INTAKE MANIFOLD RUNNER CONTROL CIRCUIT LOW (BANK 1)

### DTC DETECTING CONDITION:


- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-171, DTC P2009 INTAKE MANIFOLD RUNNER CONTROL CIRCUIT LOW (BANK 1), Diagnostic Trouble Code (DTC) Detecting Criteria.>

### CAUTION:

After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.

### WIRING DIAGRAM:

- Engine electrical system (without push button start) <Ref. to WI(HEV)-100, WITHOUT PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>
- Engine electrical system (with push button start) <Ref. to WI(HEV)-114, WITH PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>



EN-09699

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step   | Check                              | Yes   | No  |
|--|------------------------------------|---|---|
| <p><b>1</b>    <b>CHECK HARNESS BETWEEN ECM AND TUMBLE GENERATOR VALVE ACTUATOR RH CONNECTOR.</b></p> <p>1) Turn the ignition switch to OFF.<br/>2) Disconnect the connector from ECM.<br/>3) Measure the voltage between ECM connector and chassis ground.</p> <p><b>Connector &amp; terminal</b><br/><b>(B134) No. 25 (+) — Chassis ground (-):</b><br/><b>(B134) No. 14 (+) — Chassis ground (-):</b></p> | <p>Is the voltage 5 V or more?</p> | <p>Repair the short circuit to power in harness between ECM connector and tumble generator valve actuator RH connector.</p> | <p>Replace the tumble generator valve actuator RH. &lt;Ref. to FU(H4DO(HEV))-76, Tumble Generator Valve Actuator.&gt;</p> |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

## EP:DTC P2012 INTAKE MANIFOLD RUNNER CONTROL CIRCUIT LOW (BANK 2)

### DTC DETECTING CONDITION:


- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-171, DTC P2012 INTAKE MANIFOLD RUNNER CONTROL CIRCUIT LOW (BANK 2), Diagnostic Trouble Code (DTC) Detecting Criteria.>

### CAUTION:

After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.

### WIRING DIAGRAM:

- Engine electrical system (without push button start) <Ref. to WI(HEV)-100, WITHOUT PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>
- Engine electrical system (with push button start) <Ref. to WI(HEV)-114, WITH PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>



EN-09699

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step   | Check                              | Yes   | No  |
|--|------------------------------------|---|---|
| <p><b>1</b>    <b>CHECK HARNESS BETWEEN ECM AND TUMBLE GENERATOR VALVE ACTUATOR LH CONNECTOR.</b></p> <p>1) Turn the ignition switch to OFF.<br/>2) Disconnect the connector from ECM.<br/>3) Measure the voltage between ECM connector and chassis ground.</p> <p><b>Connector &amp; terminal</b><br/><b>(B134) No. 23 (+) — Chassis ground (-):</b><br/><b>(B134) No. 24 (+) — Chassis ground (-):</b></p> | <p>Is the voltage 5 V or more?</p> | <p>Repair the short circuit to power in harness between ECM connector and tumble generator valve actuator LH connector.</p> | <p>Replace the tumble generator valve actuator LH. &lt;Ref. to FU(H4DO(HEV))-76, Tumble Generator Valve Actuator.&gt;</p> |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

## EQ:DTC P2096 POST CATALYST FUEL TRIM SYSTEM TOO LEAN (BANK 1)

### DTC DETECTING CONDITION:


- Detected when two consecutive driving cycles with fault occur.
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-172, DTC P2096 POST CATALYST FUEL TRIM SYSTEM TOO LEAN (BANK 1), Diagnostic Trouble Code (DTC) Detecting Criteria.>

### CAUTION:

After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.

### WIRING DIAGRAM:


- Engine electrical system (without push button start) <Ref. to WI(HEV)-100, WITHOUT PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>
- Engine electrical system (with push button start) <Ref. to WI(HEV)-114, WITH PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>



EN-10739

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

## ENGINE (DIAGNOSTICS)



| Step | Check   | Yes  | No            |
|------|---|--|---------------|
| 1    | <b>CHECK FOR ANY OTHER DTC ON DISPLAY.</b> Is any other DTC displayed?                                    | Check DTC using "List of Diagnostic Trouble Code (DTC)". <Ref. to EN(H4DO HEV)(diag)-92, List of Diagnostic Trouble Code (DTC).> | Go to step 2. |
| 2    | <b>CHECK FRONT OXYGEN (A/F) SENSOR CONNECTOR AND COUPLING CONNECTOR.</b> Has water entered the connector? | Completely remove any water inside.  | Go to step 3. |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step   | Check   | Yes   | No  |
|--|---|---|---|
| <b>3 CHECK HARNESS BETWEEN ECM AND FRONT OXYGEN (A/F) SENSOR CONNECTOR.</b><br>1) Turn the ignition switch to OFF.<br>2) Disconnect the connectors from ECM and front oxygen (A/F) sensor.<br>3) Measure the resistance of harness between ECM connector and front oxygen (A/F) sensor connector.<br><i>Connector &amp; terminal</i><br><i>(B136) No. 19 — (E24) No. 3:</i><br><i>(B136) No. 18 — (E24) No. 4:</i> | Is the resistance less than 1 $\Omega$ ?                                    | Go to step 4.   | Repair the harness and connector.<br>NOTE:<br>In this case, repair the following item:<br><ul style="list-style-type: none"> <li>• Open circuit in harness between ECM connector and front oxygen (A/F) sensor connector</li> <li>• Poor contact of coupling connector</li> </ul> |
| <b>4 CHECK HARNESS BETWEEN ECM AND FRONT OXYGEN (A/F) SENSOR CONNECTOR.</b><br>Measure the resistance between ECM connector and chassis ground.<br><i>Connector &amp; terminal</i><br><i>(B136) No. 19 — Chassis ground:</i><br><i>(B136) No. 18 — Chassis ground:</i>   | Is the resistance 1 M $\Omega$ or more?                                     | Go to step 5.   | Repair the short circuit to ground in harness between ECM connector and front oxygen (A/F) sensor connector.  |
| <b>5 CHECK OUTPUT SIGNAL FOR ECM.</b><br>1) Connect the connector to ECM.<br>2) Turn the ignition switch to ON.<br>3) Measure the voltage between front oxygen (A/F) sensor connector and chassis ground.<br><i>Connector &amp; terminal</i><br><i>(E24) No. 3 (+) — Chassis ground (-):</i>   | Is the voltage 4.5 V or more?   | Go to step 7.   | Go to step 6.   |
| <b>6 CHECK OUTPUT SIGNAL FOR ECM.</b><br>Measure the voltage between front oxygen (A/F) sensor connector and chassis ground.<br><i>Connector &amp; terminal</i><br><i>(E24) No. 4 (+) — Chassis ground (-):</i>  | Is the voltage 4.95 V or more?  | Go to step 7.   | Go to step 8.   |
| <b>7 CHECK OUTPUT SIGNAL FOR ECM.</b><br>Measure the voltage between front oxygen (A/F) sensor connector and chassis ground.<br><i>Connector &amp; terminal</i><br><i>(E24) No. 3 (+) — Chassis ground (-):</i><br><i>(E24) No. 4 (+) — Chassis ground (-):</i>  | Is the voltage 8 V or more?   | Repair the short circuit to power in the harness between ECM connector and front oxygen (A/F) sensor connector.<br>After repair, replace the ECM.<br><Ref. to FU(H4DO(HEV))-85, Engine Control Module (ECM).> | Repair the poor contact of ECM connector.   |
| <b>8 CHECK EXHAUST SYSTEM.</b>   | Are there holes or loose bolts on exhaust system?                           | Repair the exhaust system.  | Go to step 9.   |
| <b>9 CHECK AIR INTAKE SYSTEM.</b>  | Are there holes, loose bolts or disconnection of hose on air intake system? | Repair the air intake system.   | Go to step 10.  |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

## ENGINE (DIAGNOSTICS)

| Step   | Check   | Yes            | No  |
|--|---|----------------|---|
| <b>10 CHECK FUEL PRESSURE.</b><br><b>WARNING:</b><br><b>Place “NO OPEN FLAMES” signs near the working area.</b><br><b>CAUTION:</b><br><b>Be careful not to spill fuel.</b><br>1) Connect the front oxygen (A/F) sensor connector.<br>2) Measure the fuel pressure. <Ref. to ME(H4DO(w/o HEV))-35, INSPECTION, Fuel Pressure.><br><b>CAUTION:</b><br><b>Release fuel pressure before removing the fuel pressure gauge.</b>  | Is the measured value 340 — 400 kPa (3.5 — 4.1 kg/cm <sup>2</sup> , 49 — 58 psi)? | Go to step 11. | Check the fuel pump and fuel delivery line. <Ref. to FU(H4DO(HEV))-127, INSPECTION, Fuel Pump.> <Ref. to FU(H4DO(HEV))-157, INSPECTION, Fuel Delivery and Evaporation Lines.> |
| <b>11 CHECK ENGINE COOLANT TEMPERATURE SENSOR.</b><br>1) Start the engine and warm up completely.<br>2) Read the value of «Coolant Temp.» using the Subaru Select Monitor or a general scan tool.<br><b>NOTE:</b><br><ul style="list-style-type: none"> <li>Subaru Select Monitor</li> </ul> For detailed operation procedures, refer to “Current Data Display For Engine”. <Ref. to EN(H4DO HEV)(diag)-36, Subaru Select Monitor.><br><ul style="list-style-type: none"> <li>General scan tool</li> </ul> For detailed operation procedures, refer to the general scan tool operation manual.   | Is the value of «Coolant Temp.» 75°C (167°F) or more?                             | Go to step 12. | Replace the engine coolant temperature sensor. <Ref. to FU(H4DO(HEV))-41, Engine Coolant Temperature Sensor.>   |
| <b>12 CHECK MASS AIR FLOW AND INTAKE AIR TEMPERATURE SENSOR.</b><br>1) Start the engine and warm up engine until coolant temperature is higher than 75°C (167°F).<br>2) Place the select lever in “P” range or “N” range.<br>3) Turn the A/C switch to OFF.<br>4) Turn all the accessory switches to OFF.<br>5) Read the value of «Mass Air Flow» using the Subaru Select Monitor or a general scan tool.<br><b>NOTE:</b><br><ul style="list-style-type: none"> <li>Subaru Select Monitor</li> </ul> For detailed operation procedures, refer to “Current Data Display For Engine”. <Ref. to EN(H4DO HEV)(diag)-36, Subaru Select Monitor.><br><ul style="list-style-type: none"> <li>General scan tool</li> </ul> For detailed operation procedures, refer to the general scan tool operation manual. | Is the value of «Mass Air Flow» 2.0 — 5.0 g/s (0.26 — 0.66 lb/m)?                 | Go to step 13. | Replace the mass air flow and intake air temperature sensor. <Ref. to FU(H4DO(HEV))-63, Mass Air Flow and Intake Air Temperature Sensor.>                                     |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step  | Check   | Yes                                 | No  |
|---|---|-------------------------------------|---|
| <p><b>13 CHECK MASS AIR FLOW AND INTAKE AIR TEMPERATURE SENSOR.</b></p> <p>1) Start the engine and warm up engine until coolant temperature is higher than 75°C (167°F).</p> <p>2) Place the select lever in “P” range or “N” range.</p> <p>3) Turn the A/C switch to OFF.</p> <p>4) Turn all the accessory switches to OFF.</p> <p>5) Open the front hood.</p> <p>6) Measure the ambient temperature.</p> <p>7) Read the value of «Intake Air Temp.» using the Subaru Select Monitor or a general scan tool.</p> <p>NOTE:</p> <ul style="list-style-type: none"> <li>• Subaru Select Monitor</li> </ul> <p>For detailed operation procedures, refer to “Current Data Display For Engine”. &lt;Ref. to EN(H4DO HEV)(diag)-36, Subaru Select Monitor.&gt;</p> <ul style="list-style-type: none"> <li>• General scan tool</li> </ul> <p>For detailed operation procedures, refer to the general scan tool operation manual.</p> | <p>Subtract ambient temperature from «Intake Air Temp.». Is the obtained value -10 — 50°C (-18 — 90°F)?</p> | Go to step 14.                      | Check the mass air flow and intake air temperature sensor. <Ref. to FU(H4DO(HEV))-63, Mass Air Flow and Intake Air Temperature Sensor.> |
| <p><b>14 CHECK REAR OXYGEN SENSOR DATA.</b></p> <p>1) Warm up the engine until engine coolant temperature is higher than 75°C (167°F), and keep the engine speed at 3,000 rpm. (2 minutes maximum)</p> <p>2) Read the value of «Oxygen sensor #12» using the Subaru Select Monitor or a general scan tool.</p> <p>NOTE:</p> <ul style="list-style-type: none"> <li>• Subaru Select Monitor</li> </ul> <p>For detailed operation procedures, refer to “Current Data Display For Engine”. &lt;Ref. to EN(H4DO HEV)(diag)-36, Subaru Select Monitor.&gt;</p> <ul style="list-style-type: none"> <li>• General scan tool</li> </ul> <p>For detailed operation procedures, refer to the general scan tool operation manual.</p>  | <p>Is the value of «Oxygen sensor #12» 0.490 V or more?</p>   | Go to step 15.                      | Go to step 16.  |
| <p><b>15 CHECK REAR OXYGEN SENSOR DATA.</b></p> <p>1) Warm up the engine until engine coolant temperature is higher than 75°C (167°F), and rapidly reduce the engine speed from 3,000 rpm.</p> <p>2) Read the value of «Oxygen sensor #12» using the Subaru Select Monitor or a general scan tool.</p> <p>NOTE:</p> <ul style="list-style-type: none"> <li>• Subaru Select Monitor</li> </ul> <p>For detailed operation procedures, refer to “Current Data Display For Engine”. &lt;Ref. to EN(H4DO HEV)(diag)-36, Subaru Select Monitor.&gt;</p> <ul style="list-style-type: none"> <li>• General scan tool</li> </ul> <p>For detailed operation procedures, refer to the general scan tool operation manual.</p>  | <p>Is the value of «Oxygen sensor #12» 0.250 V or less?</p>   | Go to step 17.                      | Go to step 16.  |
| <p><b>16 CHECK REAR OXYGEN SENSOR CONNECTOR AND COUPLING CONNECTOR.</b></p>   | <p>Has water entered the connector?</p>   | Completely remove any water inside. | Go to step 18.  |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

## ENGINE (DIAGNOSTICS)

| Step  | Check   | Yes  | No  |
|---|---|--|---|
| <p><b>17 CHECK FRONT OXYGEN (A/F) SENSOR USING REAR OXYGEN SENSOR SIGNAL.</b></p> <p>1) Warm up the engine until engine coolant temperature is higher than 75°C (167°F), then keep the engine idling for 5 minutes or more.</p> <p>2) Read the value of «Oxygen sensor #12» using the Subaru Select Monitor or a general scan tool.</p> <p>NOTE:</p> <ul style="list-style-type: none"> <li>• Subaru Select Monitor</li> </ul> <p>For detailed operation procedures, refer to “Current Data Display For Engine”. &lt;Ref. to EN(H4DO HEV)(diag)-36, Subaru Select Monitor.&gt;</p> <ul style="list-style-type: none"> <li>• General scan tool</li> </ul> <p>For detailed operation procedures, refer to the general scan tool operation manual.</p> | <p>Is the value of «Oxygen sensor #12» 0.250 V or less for 5 minutes or more?</p> | <p>Replace the front oxygen (A/F) sensor. &lt;Ref. to FU(H4DO(HEV))-78, Front Oxygen (A/F) Sensor.&gt;</p> | <p>Go to step 18.</p>   |
| <p><b>18 CHECK HARNESS BETWEEN ECM AND REAR OXYGEN SENSOR CONNECTOR.</b></p> <p>1) Turn the ignition switch to OFF.</p> <p>2) Disconnect the connector from ECM and rear oxygen sensor.</p> <p>3) Measure the resistance of harness between ECM connector and rear oxygen sensor connector.</p> <p><b>Connector &amp; terminal</b><br/> <b>(B136) No. 21 — (E25) No. 3:</b><br/> <b>(B135) No. 30 — (E25) No. 4:</b></p>  | <p>Is the resistance less than 1 Ω?</p>   | <p>Go to step 19.</p>  | <p>Repair the harness and connector.</p> <p>NOTE:</p> <p>In this case, repair the following item:</p> <ul style="list-style-type: none"> <li>• Open circuit in harness between ECM connector and rear oxygen sensor connector</li> <li>• Poor contact of coupling connector</li> </ul>  |
| <p><b>19 CHECK HARNESS BETWEEN ECM AND REAR OXYGEN SENSOR CONNECTOR.</b></p> <p>1) Connect the connector to ECM.</p> <p>2) Turn the ignition switch to ON.</p> <p>3) Measure the voltage between rear oxygen sensor connector and chassis ground.</p> <p><b>Connector &amp; terminal</b><br/> <b>(E25) No. 3 (+) — Chassis ground (-):</b></p>  | <p>Is the voltage 0.2 — 0.5 V?</p>  | <p>Replace the rear oxygen sensor. &lt;Ref. to FU(H4DO(HEV))-82, Rear Oxygen Sensor.&gt;</p>               | <p>Repair the harness and connector.</p> <p>NOTE:</p> <p>In this case, repair the following item:</p> <ul style="list-style-type: none"> <li>• Open circuit in harness between ECM connector and rear oxygen sensor connector</li> <li>• Poor contact of ECM connector</li> <li>• Poor contact of coupling connector</li> </ul> |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

## ER:DTC P2097 POST CATALYST FUEL TRIM SYSTEM TOO RICH (BANK 1)

### DTC DETECTING CONDITION:


- Detected when two consecutive driving cycles with fault occur.
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-173, DTC P2097 POST CATALYST FUEL TRIM SYSTEM TOO RICH (BANK 1), Diagnostic Trouble Code (DTC) Detecting Criteria.>

### CAUTION:

After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.

### WIRING DIAGRAM:


- Engine electrical system (without push button start) <Ref. to WI(HEV)-100, WITHOUT PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>
- Engine electrical system (with push button start) <Ref. to WI(HEV)-114, WITH PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>



EN-10739

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

## ENGINE (DIAGNOSTICS)



| Step | Check   | Yes  | No            |
|------|---|--|---------------|
| 1    | <b>CHECK FOR ANY OTHER DTC ON DISPLAY.</b> Is any other DTC displayed?                                    | Check DTC using "List of Diagnostic Trouble Code (DTC)". <Ref. to EN(H4DO HEV)(diag)-92, List of Diagnostic Trouble Code (DTC).> | Go to step 2. |
| 2    | <b>CHECK FRONT OXYGEN (A/F) SENSOR CONNECTOR AND COUPLING CONNECTOR.</b> Has water entered the connector? | Completely remove any water inside.  | Go to step 3. |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step   | Check   | Yes   | No  |
|--|---|---|---|
| <b>3 CHECK HARNESS BETWEEN ECM AND FRONT OXYGEN (A/F) SENSOR CONNECTOR.</b><br>1) Turn the ignition switch to OFF.<br>2) Disconnect the connectors from ECM and front oxygen (A/F) sensor.<br>3) Measure the resistance of harness between ECM connector and front oxygen (A/F) sensor connector.<br><b>Connector &amp; terminal</b><br><b>(B136) No. 19 — (E24) No. 3:</b><br><b>(B136) No. 18 — (E24) No. 4:</b> | Is the resistance less than 1 Ω?  | Go to step 4.   | Repair the harness and connector.<br>NOTE:<br>In this case, repair the following item:<br>• Open circuit in harness between ECM connector and front oxygen (A/F) sensor connector<br>• Poor contact of coupling connector |
| <b>4 CHECK HARNESS BETWEEN ECM AND FRONT OXYGEN (A/F) SENSOR CONNECTOR.</b><br>Measure the resistance between ECM connector and chassis ground.<br><b>Connector &amp; terminal</b><br><b>(B136) No. 19 — Chassis ground:</b><br><b>(B136) No. 18 — Chassis ground:</b>   | Is the resistance 1 MΩ or more?   | Go to step 5.   | Repair the short circuit to ground in harness between ECM connector and front oxygen (A/F) sensor connector.  |
| <b>5 CHECK OUTPUT SIGNAL FOR ECM.</b><br>1) Connect the connector to ECM.<br>2) Turn the ignition switch to ON.<br>3) Measure the voltage between front oxygen (A/F) sensor connector and chassis ground.<br><b>Connector &amp; terminal</b><br><b>(E24) No. 3 (+) — Chassis ground (-):</b>   | Is the voltage 4.5 V or more?   | Go to step 7.   | Go to step 6.   |
| <b>6 CHECK OUTPUT SIGNAL FOR ECM.</b><br>Measure the voltage between front oxygen (A/F) sensor connector and chassis ground.<br><b>Connector &amp; terminal</b><br><b>(E24) No. 4 (+) — Chassis ground (-):</b>  | Is the voltage 4.95 V or more?  | Go to step 7.   | Go to step 8.   |
| <b>7 CHECK OUTPUT SIGNAL FOR ECM.</b><br>Measure the voltage between front oxygen (A/F) sensor connector and chassis ground.<br><b>Connector &amp; terminal</b><br><b>(E24) No. 3 (+) — Chassis ground (-):</b><br><b>(E24) No. 4 (+) — Chassis ground (-):</b>  | Is the voltage 8 V or more?   | Repair the short circuit to power in the harness between ECM connector and front oxygen (A/F) sensor connector.<br>After repair, replace the ECM.<br><Ref. to FU(H4DO(HEV))-85, Engine Control Module (ECM).> | Repair the poor contact of ECM connector.   |
| <b>8 CHECK EXHAUST SYSTEM.</b>   | Are there holes or loose bolts on exhaust system?                           | Repair the exhaust system.  | Go to step 9.   |
| <b>9 CHECK AIR INTAKE SYSTEM.</b>  | Are there holes, loose bolts or disconnection of hose on air intake system? | Repair the air intake system.   | Go to step 10.  |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

## ENGINE (DIAGNOSTICS)

| Step   | Check  | Yes                   | No   |
|--|--|-----------------------|--|
| <p><b>10 CHECK FUEL PRESSURE.</b></p> <p><b>WARNING:</b><br/>Place “NO OPEN FLAMES” signs near the working area.</p> <p><b>CAUTION:</b><br/>Be careful not to spill fuel.</p> <p>1) Connect the front oxygen (A/F) sensor connector.</p> <p>2) Measure the fuel pressure. &lt;Ref. to ME(H4DO(w/o HEV))-35, INSPECTION, Fuel Pressure.&gt;</p> <p><b>CAUTION:</b><br/>Release fuel pressure before removing the fuel pressure gauge.</p>   | <p>Is the measured value 340 — 400 kPa (3.5 — 4.1 kg/cm<sup>2</sup>, 49 — 58 psi)?</p> | <p>Go to step 11.</p> | <p>Check the fuel pump and fuel delivery line. &lt;Ref. to FU(H4DO(HEV))-127, INSPECTION, Fuel Pump.&gt; &lt;Ref. to FU(H4DO(HEV))-157, INSPECTION, Fuel Delivery and Evaporation Lines.&gt;</p> |
| <p><b>11 CHECK ENGINE COOLANT TEMPERATURE SENSOR.</b></p> <p>1) Start the engine and warm up completely.</p> <p>2) Read the value of «Coolant Temp.» using the Subaru Select Monitor or a general scan tool.</p> <p>NOTE:</p> <ul style="list-style-type: none"> <li>• Subaru Select Monitor</li> </ul> <p>For detailed operation procedures, refer to “Current Data Display For Engine”. &lt;Ref. to EN(H4DO HEV)(diag)-36, Subaru Select Monitor.&gt;</p> <ul style="list-style-type: none"> <li>• General scan tool</li> </ul> <p>For detailed operation procedures, refer to the general scan tool operation manual.</p>   | <p>Is the value of «Coolant Temp.» 75°C (167°F) or more?</p>                           | <p>Go to step 12.</p> | <p>Replace the engine coolant temperature sensor. &lt;Ref. to FU(H4DO(HEV))-41, Engine Coolant Temperature Sensor.&gt;</p>   |
| <p><b>12 CHECK MASS AIR FLOW AND INTAKE AIR TEMPERATURE SENSOR.</b></p> <p>1) Start the engine and warm up engine until coolant temperature is higher than 75°C (167°F).</p> <p>2) Place the select lever in “P” range or “N” range.</p> <p>3) Turn the A/C switch to OFF.</p> <p>4) Turn all the accessory switches to OFF.</p> <p>5) Read the value of «Mass Air Flow» using the Subaru Select Monitor or a general scan tool.</p> <p>NOTE:</p> <ul style="list-style-type: none"> <li>• Subaru Select Monitor</li> </ul> <p>For detailed operation procedures, refer to “Current Data Display For Engine”. &lt;Ref. to EN(H4DO HEV)(diag)-36, Subaru Select Monitor.&gt;</p> <ul style="list-style-type: none"> <li>• General scan tool</li> </ul> <p>For detailed operation procedures, refer to the general scan tool operation manual.</p> | <p>Is the value of «Mass Air Flow» 2.0 — 5.0 g/s (0.26 — 0.66 lb/m)?</p>               | <p>Go to step 13.</p> | <p>Replace the mass air flow and intake air temperature sensor. &lt;Ref. to FU(H4DO(HEV))-63, Mass Air Flow and Intake Air Temperature Sensor.&gt;</p>   |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step  | Check   | Yes  | No   |
|---|---|--|--|
| <p><b>13 CHECK MASS AIR FLOW AND INTAKE AIR TEMPERATURE SENSOR.</b></p> <p>1) Start the engine and warm up engine until coolant temperature is higher than 75°C (167°F).</p> <p>2) Place the select lever in “P” range or “N” range.</p> <p>3) Turn the A/C switch to OFF.</p> <p>4) Turn all the accessory switches to OFF.</p> <p>5) Open the front hood.</p> <p>6) Measure the ambient temperature.</p> <p>7) Read the value of «Intake Air Temp.» using the Subaru Select Monitor or a general scan tool.</p> <p>NOTE:</p> <ul style="list-style-type: none"> <li>• Subaru Select Monitor</li> </ul> <p>For detailed operation procedures, refer to “Current Data Display For Engine”. &lt;Ref. to EN(H4DO HEV)(diag)-36, Subaru Select Monitor.&gt;</p> <ul style="list-style-type: none"> <li>• General scan tool</li> </ul> <p>For detailed operation procedures, refer to the general scan tool operation manual.</p> | <p>Subtract ambient temperature from «Intake Air Temp.». Is the obtained value -10 — 50°C (-18 — 90°F)?</p> | <p>Go to step 14.</p>                      | <p>Check the mass air flow and intake air temperature sensor. &lt;Ref. to FU(H4DO(HEV))-63, Mass Air Flow and Intake Air Temperature Sensor.&gt;</p> |
| <p><b>14 CHECK REAR OXYGEN SENSOR DATA.</b></p> <p>1) Warm up the engine until engine coolant temperature is higher than 75°C (167°F), and keep the engine speed at 3,000 rpm. (2 minutes maximum)</p> <p>2) Read the value of «Oxygen sensor #12» using the Subaru Select Monitor or a general scan tool.</p> <p>NOTE:</p> <ul style="list-style-type: none"> <li>• Subaru Select Monitor</li> </ul> <p>For detailed operation procedures, refer to “Current Data Display For Engine”. &lt;Ref. to EN(H4DO HEV)(diag)-36, Subaru Select Monitor.&gt;</p> <ul style="list-style-type: none"> <li>• General scan tool</li> </ul> <p>For detailed operation procedures, refer to the general scan tool operation manual.</p>  | <p>Is the value of «Oxygen sensor #12» 0.490 V or more?</p>   | <p>Go to step 15.</p>                      | <p>Go to step 16.</p>  |
| <p><b>15 CHECK REAR OXYGEN SENSOR DATA.</b></p> <p>1) Warm up the engine until engine coolant temperature is higher than 75°C (167°F), and rapidly reduce the engine speed from 3,000 rpm.</p> <p>2) Read the value of «Oxygen sensor #12» using the Subaru Select Monitor or a general scan tool.</p> <p>NOTE:</p> <ul style="list-style-type: none"> <li>• Subaru Select Monitor</li> </ul> <p>For detailed operation procedures, refer to “Current Data Display For Engine”. &lt;Ref. to EN(H4DO HEV)(diag)-36, Subaru Select Monitor.&gt;</p> <ul style="list-style-type: none"> <li>• General scan tool</li> </ul> <p>For detailed operation procedures, refer to the general scan tool operation manual.</p>  | <p>Is the value of «Oxygen sensor #12» 0.250 V or less?</p>   | <p>Go to step 17.</p>                      | <p>Go to step 16.</p>  |
| <p><b>16 CHECK REAR OXYGEN SENSOR CONNECTOR AND COUPLING CONNECTOR.</b></p>   | <p>Has water entered the connector?</p>   | <p>Completely remove any water inside.</p> | <p>Go to step 18.</p>  |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

## ENGINE (DIAGNOSTICS)

| Step  | Check   | Yes  | No  |
|---|---|--|---|
| <p><b>17 CHECK FRONT OXYGEN (A/F) SENSOR USING REAR OXYGEN SENSOR SIGNAL.</b></p> <p>1) Warm up the engine until engine coolant temperature is higher than 75°C (167°F), then keep the engine idling for 5 minutes or more.</p> <p>2) Read the value of «Oxygen sensor #12» using the Subaru Select Monitor or a general scan tool.</p> <p>NOTE:</p> <ul style="list-style-type: none"> <li>• Subaru Select Monitor</li> </ul> <p>For detailed operation procedures, refer to “Current Data Display For Engine”. &lt;Ref. to EN(H4DO HEV)(diag)-36, Subaru Select Monitor.&gt;</p> <ul style="list-style-type: none"> <li>• General scan tool</li> </ul> <p>For detailed operation procedures, refer to the general scan tool operation manual.</p> | <p>Is the value of «Oxygen sensor #12» 0.8 V or more for 5 minutes or more?</p> | <p>Replace the front oxygen (A/F) sensor. &lt;Ref. to FU(H4DO(HEV))-78, Front Oxygen (A/F) Sensor.&gt;</p> | <p>Go to step 18.</p>   |
| <p><b>18 CHECK HARNESS BETWEEN ECM AND REAR OXYGEN SENSOR CONNECTOR.</b></p> <p>1) Turn the ignition switch to OFF.</p> <p>2) Disconnect the connector from ECM and rear oxygen sensor.</p> <p>3) Measure the resistance of harness between ECM connector and rear oxygen sensor connector.</p> <p><b>Connector &amp; terminal</b><br/> <b>(B136) No. 21 — (E25) No. 3:</b><br/> <b>(B135) No. 30 — (E25) No. 4:</b></p>  | <p>Is the resistance less than 1 Ω?</p>   | <p>Go to step 19.</p>  | <p>Repair the harness and connector.</p> <p>NOTE:</p> <p>In this case, repair the following item:</p> <ul style="list-style-type: none"> <li>• Open circuit in harness between ECM connector and rear oxygen sensor connector</li> <li>• Poor contact of coupling connector</li> </ul>  |
| <p><b>19 CHECK HARNESS BETWEEN ECM AND REAR OXYGEN SENSOR CONNECTOR.</b></p> <p>1) Connect the connector to ECM.</p> <p>2) Turn the ignition switch to ON.</p> <p>3) Measure the voltage between rear oxygen sensor connector and chassis ground.</p> <p><b>Connector &amp; terminal</b><br/> <b>(E25) No. 3 (+) — Chassis ground (-):</b></p>  | <p>Is the voltage 0.2 — 0.5 V?</p>  | <p>Replace the rear oxygen sensor. &lt;Ref. to FU(H4DO(HEV))-82, Rear Oxygen Sensor.&gt;</p>               | <p>Repair the harness and connector.</p> <p>NOTE:</p> <p>In this case, repair the following item:</p> <ul style="list-style-type: none"> <li>• Open circuit in harness between ECM connector and rear oxygen sensor connector</li> <li>• Poor contact of ECM connector</li> <li>• Poor contact of coupling connector</li> </ul> |

## **ES:DTC P2101 THROTTLE ACTUATOR CONTROL MOTOR CIRCUIT RANGE/ PERFORMANCE**

### **DTC DETECTING CONDITION:**

- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-174, DTC P2101 THROTTLE ACTUATOR CONTROL MOTOR CIRCUIT RANGE/PERFORMANCE, Diagnostic Trouble Code (DTC) Detecting Criteria.>

### **TROUBLE SYMPTOM:**

- Improper idling
- Poor driving performance
- Engine stalls.

### **CAUTION:**



**After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.**

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

## ENGINE (DIAGNOSTICS)

### WIRING DIAGRAM:

- Engine electrical system (without push button start) <Ref. to WI(HEV)-100, WITHOUT PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>
- Engine electrical system (with push button start) <Ref. to WI(HEV)-114, WITH PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>



EN-10744

| Step   | Check                            | Yes           | No  |
|--|----------------------------------|---------------|---|
| <b>1</b><br><b>CHECK ELECTRONIC THROTTLE CONTROL RELAY.</b><br>1) Turn the ignition switch to OFF.<br>2) Remove the electronic throttle control relay.<br>3) Connect the battery to terminals No. 16 and No. 17 of electronic throttle control relay.<br>4) Measure the resistance between electronic throttle control relay terminals.<br><b>Terminals</b><br><b>No. 14 — No. 15:</b> | Is the resistance less than 1 Ω? | Go to step 2. | Replace the electronic throttle control relay. <Ref. to FU(H4DO(HEV))-94, Electronic Throttle Control Relay.> |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step   | Check                                    | Yes   | No   |
|--|--|---|--|
| <p><b>2</b></p> <p><b>CHECK POWER SUPPLY OF ELECTRONIC THROTTLE CONTROL RELAY.</b><br/>Measure the voltage between electronic throttle control relay connector and chassis ground.<br/><b>Connector &amp; terminal</b><br/><b>(B225) No. 15 (+) — Chassis ground (-):</b></p>  | Is the voltage 10 V or more?             | Go to step 3.   | Repair the open or ground short circuit of power supply circuit.   |
| <p><b>3</b></p> <p><b>CHECK HARNESS BETWEEN ECM AND ELECTRONIC THROTTLE CONTROL RELAY CONNECTOR.</b><br/>1) Disconnect the connector from ECM.<br/>2) Turn the ignition switch to ON.<br/>3) Measure the voltage between electronic throttle control relay connector and chassis ground.<br/><b>Connector &amp; terminal</b><br/><b>(B225) No. 17 (+) — Chassis ground (-):</b></p>  | Is the voltage 10 V or more?             | Repair the short circuit to power in the harness between ECM connector and electronic throttle control relay connector. | Go to step 4.  |
| <p><b>4</b></p> <p><b>CHECK HARNESS BETWEEN ECM AND ELECTRONIC THROTTLE CONTROL RELAY CONNECTOR.</b><br/>1) Turn the ignition switch to OFF.<br/>2) Measure the resistance between electronic throttle control relay connector and chassis ground.<br/><b>Connector &amp; terminal</b><br/><b>(B225) No. 14 — Chassis ground:</b><br/><b>(B225) No. 17 — Chassis ground:</b></p>   | Is the resistance 1 M $\Omega$ or more?  | Go to step 5.   | Repair the short circuit to ground in harness between ECM connector and electronic throttle control relay connector. |
| <p><b>5</b></p> <p><b>CHECK HARNESS BETWEEN ECM AND ELECTRONIC THROTTLE CONTROL RELAY CONNECTOR.</b><br/>Measure the resistance between ECM connector and electronic throttle control relay connector.<br/><b>Connector &amp; terminal</b><br/><b>(B135) No. 7 — (B225) No. 14:</b><br/><b>(B135) No. 17 — (B225) No. 17:</b></p>  | Is the resistance less than 1 $\Omega$ ? | Go to step 6.   | Repair the open circuit in harness between ECM connector and electronic throttle control relay connector.            |
| <p><b>6</b></p> <p><b>CHECK HARNESS BETWEEN ECM AND ELECTRONIC THROTTLE CONTROL CONNECTOR.</b><br/>1) Turn the ignition switch to OFF.<br/>2) Disconnect the connectors from electronic throttle control.<br/>3) Measure the resistance between ECM connector and chassis ground.<br/><b>Connector &amp; terminal</b><br/><b>(B134) No. 19 — Chassis ground:</b><br/><b>(B134) No. 18 — Chassis ground:</b><br/><b>(B134) No. 18 — (B137) No. 4:</b><br/><b>(B134) No. 28 — Chassis ground:</b><br/><b>(B134) No. 28 — (B137) No. 4:</b></p> | Is the resistance 1 M $\Omega$ or more?  | Go to step 7.   | Repair the ground short circuit of harness between ECM connector and electronic throttle control connector.          |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

## ENGINE (DIAGNOSTICS)

| Step  | Check                                    | Yes   | No   |
|---|--|---|--|
| <b>7</b><br><b>CHECK SHORT CIRCUIT INSIDE THE ECM.</b><br>1) Connect the connector to ECM.<br>2) Measure the resistance between electronic throttle control connector and engine ground.<br><b>Connector &amp; terminal</b><br><i>(E57) No. 6 — Engine ground:</i><br><i>(E57) No. 4 — Engine ground:</i>   | Is the resistance 1 M $\Omega$ or more?  | Go to step 8.   | Repair the ground short circuit of harness between ECM connector and electronic throttle control connector.<br>Replace the ECM if defective. <Ref. to FU(H4DO(HEV))-85, Engine Control Module (ECM).>  |
| <b>8</b><br><b>CHECK HARNESS BETWEEN ECM AND ELECTRONIC THROTTLE CONTROL CONNECTOR.</b><br>1) Disconnect the connector from ECM.<br>2) Measure the resistance of harness between ECM connector and electronic throttle control connector.<br><b>Connector &amp; terminal</b><br><i>(B134) No. 18 — (E57) No. 6:</i><br><i>(B134) No. 28 — (E57) No. 4:</i><br><i>(B134) No. 29 — (E57) No. 3:</i> | Is the resistance less than 1 $\Omega$ ? | Go to step 9.   | Repair the harness and connector.<br>NOTE:<br>In this case, repair the following item:<br><ul style="list-style-type: none"> <li>• Open circuit in harness between ECM connector and electronic throttle control connector</li> <li>• Poor contact of coupling connector</li> </ul>                  |
| <b>9</b><br><b>CHECK HARNESS BETWEEN ECM AND ELECTRONIC THROTTLE CONTROL CONNECTOR.</b><br>1) Connect the connector to ECM.<br>2) Measure the resistance between electronic throttle control connector and engine ground.<br><b>Connector &amp; terminal</b><br><i>(E57) No. 3 — Engine ground:</i>   | Is the resistance less than 5 $\Omega$ ? | Go to step 10.  | Repair the harness and connector.<br>NOTE:<br>In this case, repair the following item:<br><ul style="list-style-type: none"> <li>• Open circuit of harness between ECM connector and engine ground</li> <li>• Poor contact of ECM connector</li> <li>• Poor contact of coupling connector</li> </ul> |
| <b>10</b><br><b>CHECK HARNESS BETWEEN ECM AND ELECTRONIC THROTTLE CONTROL CONNECTOR.</b><br>1) Turn the ignition switch to ON.<br>2) Measure the voltage between electronic throttle control connector and engine ground.<br><b>Connector &amp; terminal</b><br><i>(E57) No. 6 (+) — Engine ground (-):</i><br><i>(E57) No. 4 (+) — Engine ground (-):</i>  | Is the voltage 5 V or more?              | Repair the short circuit to power in the harness between ECM connector and electronic throttle control connector. | Go to step 11.   |
| <b>11</b><br><b>CHECK HARNESS BETWEEN ECM AND ELECTRONIC THROTTLE CONTROL CONNECTOR.</b><br>1) Turn the ignition switch to OFF.<br>2) Disconnect the connector from ECM.<br>3) Measure the resistance between ECM connectors.<br><b>Connector &amp; terminal</b><br><i>(B134) No. 19 — (B134) No. 18:</i><br><i>(B134) No. 19 — (B134) No. 28:</i>  | Is the resistance 1 M $\Omega$ or more?  | Go to step 12.  | Repair the short circuit to power in the harness between ECM connector and electronic throttle control connector.  |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step  | Check   | Yes   | No  |
|---|---|---|---|
| <b>12 CHECK SENSOR OUTPUT.</b><br>1) Connect all connectors.<br>2) Start the engine and warm up completely.<br>3) Stop the engine, and then turn the ignition switch to ON (engine OFF).<br>4) Read the value of «Main-Throttle Sensor» using Subaru Select Monitor.<br><br>NOTE:<br>For detailed operation procedures, refer to “Current Data Display For Engine”. <Ref. to EN(H4DO HEV)(diag)-36, Subaru Select Monitor.> | Is the value of «Main-Throttle Sensor» 0.81 — 0.87 V? | Go to step 13.  | Repair the poor contact of electronic throttle control connector.<br>Replace the electronic throttle control if defective.<br><Ref. to FU(H4DO(HEV))-14, Throttle Body.>  |
| <b>13 CHECK SENSOR OUTPUT.</b><br>Read the value of «Sub-Throttle Sensor» using Subaru Select Monitor.<br><br>NOTE:<br>For detailed operation procedures, refer to “Current Data Display For Engine”. <Ref. to EN(H4DO HEV)(diag)-36, Subaru Select Monitor.>   | Is the value of «Sub-Throttle Sensor» 1.64 — 1.70 V?  | Go to step 14.  | Repair the poor contact of electronic throttle control connector.<br>Replace the electronic throttle control if defective.<br><Ref. to FU(H4DO(HEV))-14, Throttle Body.>  |
| <b>14 CHECK HARNESS BETWEEN ECM AND ELECTRONIC THROTTLE CONTROL CONNECTOR.</b><br>1) Turn the ignition switch to OFF.<br>2) Disconnect the connectors from ECM and electronic throttle control.<br>3) Measure the resistance between ECM connector and electronic throttle control connector.<br><br><b>Connector &amp; terminal</b><br><b>(B134) No. 2 — (E57) No. 2:</b><br><b>(B134) No. 1 — (E57) No. 1:</b>            | Is the resistance less than 1 Ω?                      | Go to step 15.  | Repair the harness and connector.<br><br>NOTE:<br>In this case, repair the following item:<br>• Open circuit in harness between ECM connector and electronic throttle control connector<br>• Poor contact of coupling connector |
| <b>15 CHECK HARNESS BETWEEN ECM AND ELECTRONIC THROTTLE CONTROL CONNECTOR.</b><br>1) Connect the connector to ECM.<br>2) Turn the ignition switch to ON.<br>3) Measure the voltage between electronic throttle control connector and engine ground.<br><br><b>Connector &amp; terminal</b><br><b>(E57) No. 2 (+) — Engine ground (-):</b><br><b>(E57) No. 1 (+) — Engine ground (-):</b>                                    | Is the voltage 5 V or more?                           | Repair the short circuit to power in the harness between ECM connector and electronic throttle control connector. | Go to step 16.  |
| <b>16 CHECK HARNESS BETWEEN ECM AND ELECTRONIC THROTTLE CONTROL CONNECTOR.</b><br>1) Turn the ignition switch to OFF.<br>2) Disconnect the connector from ECM.<br>3) Measure the resistance between electronic throttle control connector and engine ground.<br><br><b>Connector &amp; terminal</b><br><b>(E57) No. 2 — Engine ground:</b><br><b>(E57) No. 1 — Engine ground:</b>   | Is the resistance 1 MΩ or more?                       | Go to step 17.  | Repair the ground short circuit of harness between ECM connector and electronic throttle control connector.   |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

## ENGINE (DIAGNOSTICS)

| Step  | Check  | Yes                                       | No  |
|---|--|---|---|
| <b>17 CHECK ELECTRONIC THROTTLE CONTROL CONNECTOR HARNESS.</b><br>Measure the resistance between electronic throttle control connectors.<br><i>Connector &amp; terminal</i><br><i>(E57) No. 2 — (E57) No. 1:</i>  | Is the resistance 1 M $\Omega$ or more?  | Go to step 18.                            | Repair the short circuit in harness between ECM connector and electronic throttle control connector.  |
| <b>18 CHECK ELECTRONIC THROTTLE CONTROL GROUND CIRCUIT.</b><br>Measure the resistance between ECM connector and chassis ground.<br><i>Connector &amp; terminal</i><br><i>(B134) No. 3 — Chassis ground:</i><br><i>(B134) No. 4 — Chassis ground:</i><br><i>(B136) No. 1 — Chassis ground:</i><br><i>(B136) No. 2 — Chassis ground:</i><br><i>(B136) No. 3 — Chassis ground:</i> | Is the resistance less than 5 $\Omega$ ?   | Go to step 19.                            | Repair the harness and connector.<br>NOTE:<br>In this case, repair the following item:<br>• Open circuit of harness between ECM connector and engine ground<br>• Poor contact of coupling connector |
| <b>19 CHECK ELECTRONIC THROTTLE CONTROL.</b><br>Measure the resistance between electronic throttle control terminals.<br><i>Terminals</i><br><i>No. 2 — No. 1:</i>  | Is the resistance 50 $\Omega$ or less?   | Go to step 20.                            | Replace the electronic throttle control. <Ref. to FU(H4DO(HEV))-14, Throttle Body.>   |
| <b>20 CHECK ELECTRONIC THROTTLE CONTROL.</b><br>Move the throttle valve to the fully open and fully closed positions with fingers.<br>Check that the valve returns to the specified position when releasing fingers.  | Does the valve return to the specified position? Standard value: 3 mm (0.12 in) from fully closed position | Repair the poor contact of ECM connector. | Replace the electronic throttle control. <Ref. to FU(H4DO(HEV))-14, Throttle Body.>   |

## ET:DTC P2102 THROTTLE ACTUATOR CONTROL MOTOR CIRCUIT LOW

### DTC DETECTING CONDITION:

- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-175, DTC P2102 THROTTLE ACTUATOR CONTROL MOTOR CIRCUIT LOW, Diagnostic Trouble Code (DTC) Detecting Criteria.>

### TROUBLE SYMPTOM:


- Improper idling
- Poor driving performance
- Engine stalls.

### CAUTION:

**After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.**

### WIRING DIAGRAM:

- Engine electrical system (without push button start) <Ref. to WI(HEV)-100, WITHOUT PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>
- Engine electrical system (with push button start) <Ref. to WI(HEV)-114, WITH PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>



# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

## ENGINE (DIAGNOSTICS)

| Step   | Check                                    | Yes   | No   |
|--|--|---|--|
| <b>1 CHECK ELECTRONIC THROTTLE CONTROL RELAY.</b><br>1) Turn the ignition switch to OFF.<br>2) Remove the electronic throttle control relay.<br>3) Connect the battery to terminals No. 16 and No. 17 of electronic throttle control relay.<br>4) Measure the resistance between electronic throttle control relay terminals.<br><b>Terminals</b><br><b>No. 14 — No. 15:</b> | Is the resistance less than 1 $\Omega$ ? | Go to step 2.   | Replace the electronic throttle control relay. <Ref. to FU(H4DO(HEV))-94, Electronic Throttle Control Relay.>        |
| <b>2 CHECK POWER SUPPLY OF ELECTRONIC THROTTLE CONTROL RELAY.</b><br>Measure the voltage between electronic throttle control relay connector and chassis ground.<br><b>Connector &amp; terminal</b><br><b>(B225) No. 15 (+) — Chassis ground (-):</b>  | Is the voltage 10 V or more?             | Go to step 3.   | Repair the open or ground short circuit of power supply circuit.   |
| <b>3 CHECK HARNESS BETWEEN ECM AND ELECTRONIC THROTTLE CONTROL RELAY CONNECTOR.</b><br>1) Disconnect the connector from ECM.<br>2) Turn the ignition switch to ON.<br>3) Measure the voltage between electronic throttle control relay connector and chassis ground.<br><b>Connector &amp; terminal</b><br><b>(B225) No. 17 (+) — Chassis ground (-):</b>                    | Is the voltage 10 V or more?             | Repair the short circuit to power in the harness between ECM connector and electronic throttle control relay connector. | Go to step 4.  |
| <b>4 CHECK HARNESS BETWEEN ECM AND ELECTRONIC THROTTLE CONTROL RELAY CONNECTOR.</b><br>1) Turn the ignition switch to OFF.<br>2) Measure the resistance between electronic throttle control relay connector and chassis ground.<br><b>Connector &amp; terminal</b><br><b>(B225) No. 14 — Chassis ground:</b><br><b>(B225) No. 17 — Chassis ground:</b>                       | Is the resistance 1 M $\Omega$ or more?  | Go to step 5.   | Repair the short circuit to ground in harness between ECM connector and electronic throttle control relay connector. |
| <b>5 CHECK HARNESS BETWEEN ECM AND ELECTRONIC THROTTLE CONTROL RELAY CONNECTOR.</b><br>Measure the resistance between ECM connector and electronic throttle control relay connector.<br><b>Connector &amp; terminal</b><br><b>(B135) No. 7 — (B225) No. 14:</b><br><b>(B135) No. 17 — (B225) No. 17:</b>   | Is the resistance less than 1 $\Omega$ ? | Repair the poor contact of ECM connector.   | Repair the open circuit in harness between ECM connector and electronic throttle control relay connector.            |

## EU:DTC P2103 THROTTLE ACTUATOR CONTROL MOTOR CIRCUIT HIGH

### DTC DETECTING CONDITION:



- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-176, DTC P2103 THROTTLE ACTUATOR CONTROL MOTOR CIRCUIT HIGH, Diagnostic Trouble Code (DTC) Detecting Criteria.>

### CAUTION:

**After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.**

### WIRING DIAGRAM:

- Engine electrical system (without push button start) <Ref. to WI(HEV)-100, WITHOUT PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>
- Engine electrical system (with push button start) <Ref. to WI(HEV)-114, WITH PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>



EN-10744

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step  | Check                           | Yes   | No   |
|---|---------------------------------|---|--|
| <b>1 CHECK ELECTRONIC THROTTLE CONTROL RELAY.</b><br>1) Turn the ignition switch to OFF.<br>2) Remove the electronic throttle control relay.<br>3) Measure the resistance between electronic throttle control relay terminals.<br><b>Terminals</b><br><b>No. 14 — No. 15:</b>   | Is the resistance 1 MΩ or more? | Go to step 2.   | Replace the electronic throttle control relay. <Ref. to FU(H4DO(HEV))-94, Electronic Throttle Control Relay.>        |
| <b>2 CHECK SHORT CIRCUIT OF ELECTRONIC THROTTLE CONTROL RELAY POWER SUPPLY.</b><br>1) Turn the ignition switch to ON.<br>2) Measure the voltage between electronic throttle control relay connector and chassis ground.<br><b>Connector &amp; terminal</b><br><b>(B225) No. 14 (+) — Chassis ground (-):</b>            | Is the voltage 10 V or more?    | Repair the short circuit to power in the harness between ECM connector and electronic throttle control relay connector. | Go to step 3.  |
| <b>3 CHECK HARNESS BETWEEN ECM AND ELECTRONIC THROTTLE CONTROL RELAY CONNECTOR.</b><br>1) Turn the ignition switch to OFF.<br>2) Disconnect the connector from ECM.<br>3) Measure the resistance between ECM connector and chassis ground.<br><b>Connector &amp; terminal</b><br><b>(B135) No. 17 — Chassis ground:</b> | Is the resistance 1 MΩ or more? | Repair the poor contact of ECM connector.   | Repair the short circuit to ground in harness between ECM connector and electronic throttle control relay connector. |

## EV:DTC P2109 THROTTLE/PEDAL POSITION SENSOR “A” MINIMUM STOP PERFORMANCE

NOTE:

For the diagnostic procedure, refer to DTC P2101. <Ref. to EN(H4DO HEV)(diag)-335, DTC P2101 THROTTLE ACTUATOR CONTROL MOTOR CIRCUIT RANGE/PERFORMANCE, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

## EW:DTC P2119 THROTTLE ACTUATOR CONTROL THROTTLE BODY RANGE/PERFORMANCE

NOTE:

For the diagnostic procedure, refer to DTC P2101. <Ref. to EN(H4DO HEV)(diag)-335, DTC P2101 THROTTLE ACTUATOR CONTROL MOTOR CIRCUIT RANGE/PERFORMANCE, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

## EX:DTC P2122 THROTTLE/PEDAL POSITION SENSOR/SWITCH “D” CIRCUIT LOW INPUT

### DTC DETECTING CONDITION:

- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-180, DTC P2122 THROTTLE/PEDAL POSITION SENSOR/SWITCH “D” CIRCUIT LOW INPUT, Diagnostic Trouble Code (DTC) Detecting Criteria.>

### TROUBLE SYMPTOM:



- Improper idling
- Poor driving performance

### CAUTION:

**After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.**

### WIRING DIAGRAM:

- Engine electrical system (without push button start) <Ref. to WI(HEV)-100, WITHOUT PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>
- Engine electrical system (with push button start) <Ref. to WI(HEV)-114, WITH PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>



# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

## ENGINE (DIAGNOSTICS)

| Step  | Check                                  | Yes   | No  |
|---|--|---|---|
| <p><b>1</b>    <b>CHECK HARNESS BETWEEN ECM AND ACCELERATOR PEDAL POSITION SENSOR CONNECTOR.</b></p> <p>1) Turn the ignition switch to OFF.<br/>                 2) Disconnect the connectors from ECM and accelerator pedal position sensor.<br/>                 3) Measure the resistance between ECM connector and chassis ground.</p> <p><b>Connector &amp; terminal</b><br/> <b>(B135) No. 21 — Chassis ground:</b><br/> <b>(B135) No. 23 — Chassis ground:</b><br/> <b>(B135) No. 23 — (B137) No. 4:</b></p> | <p>Is the resistance 1 MΩ or more?</p> | <p>Go to step 2.</p>  | <p>Repair the short circuit to ground in harness between ECM connector and accelerator pedal position sensor connector.</p>   |
| <p><b>2</b>    <b>CHECK SHORT CIRCUIT INSIDE THE ECM.</b></p> <p>1) Connect the connector to ECM.<br/>                 2) Measure the resistance between accelerator pedal position sensor connector and chassis ground.</p> <p><b>Connector &amp; terminal</b><br/> <b>(B315) No. 6 — Chassis ground:</b></p>  | <p>Is the resistance 1 MΩ or more?</p> | <p>Replace the accelerator pedal. &lt;Ref. to SP(H4DO(w/o HEV))-4, Accelerator Pedal.&gt;</p> | <p>Repair the short circuit to ground in harness between ECM connector and accelerator pedal position sensor connector.<br/>                 Replace the ECM if defective. &lt;Ref. to FU(H4DO(HEV))-85, Engine Control Module (ECM).&gt;</p> |

## EY:DTC P2123 THROTTLE/PEDAL POSITION SENSOR/SWITCH “D” CIRCUIT HIGH INPUT

### DTC DETECTING CONDITION:

- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-181, DTC P2123 THROTTLE/PEDAL POSITION SENSOR/SWITCH “D” CIRCUIT HIGH INPUT, Diagnostic Trouble Code (DTC) Detecting Criteria.>

### TROUBLE SYMPTOM:



- Improper idling
- Poor driving performance

### CAUTION:

**After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.**

### WIRING DIAGRAM:

- Engine electrical system (without push button start) <Ref. to WI(HEV)-100, WITHOUT PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>
- Engine electrical system (with push button start) <Ref. to WI(HEV)-114, WITH PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>



# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step  | Check                            | Yes   | No  |
|---|----------------------------------|---|---|
| <p><b>1</b></p> <p><b>CHECK HARNESS BETWEEN ECM AND ACCELERATOR PEDAL POSITION SENSOR CONNECTOR.</b></p> <p>1) Turn the ignition switch to OFF.<br/>2) Disconnect the connectors from ECM and accelerator pedal position sensor.<br/>3) Measure the resistance of harness between ECM connector and accelerator pedal position sensor connector.</p> <p><b>Connector &amp; terminal</b><br/><b>(B135) No. 23 — (B315) No. 6:</b><br/><b>(B135) No. 29 — (B315) No. 5:</b></p> | Is the resistance less than 1 Ω? | Go to step 2.   | Repair the open circuit of harness between ECM connector and accelerator pedal position sensor connector.   |
| <p><b>2</b></p> <p><b>CHECK HARNESS BETWEEN ECM AND ACCELERATOR PEDAL POSITION SENSOR CONNECTOR.</b></p> <p>1) Connect the connector to ECM.<br/>2) Measure the resistance between accelerator pedal position sensor connector and chassis ground.</p> <p><b>Connector &amp; terminal</b><br/><b>(B315) No. 5 — Chassis ground:</b></p>   | Is the resistance less than 5 Ω? | Go to step 3.   | Repair the harness and connector.<br><b>NOTE:</b><br>In this case, repair the following item:<br>• Open circuit of harness between ECM connector and engine ground<br>• Poor contact of ECM connector<br>• Poor contact of coupling connector |
| <p><b>3</b></p> <p><b>CHECK HARNESS BETWEEN ECM AND ACCELERATOR PEDAL POSITION SENSOR CONNECTOR.</b></p> <p>1) Turn the ignition switch to ON.<br/>2) Measure the voltage between accelerator pedal position sensor connector and chassis ground.</p> <p><b>Connector &amp; terminal</b><br/><b>(B315) No. 6 (+) — Chassis ground (-):</b></p>  | Is the voltage 5 V or more?      | Repair the short circuit to power supply in harness between ECM connector and accelerator pedal position sensor connector.  | Go to step 4.   |
| <p><b>4</b></p> <p><b>CHECK HARNESS BETWEEN ECM AND ACCELERATOR PEDAL POSITION SENSOR CONNECTOR.</b></p> <p>1) Turn the ignition switch to OFF.<br/>2) Disconnect the connector from ECM.<br/>3) Measure the resistance between ECM connectors.</p> <p><b>Connector &amp; terminal</b><br/><b>(B135) No. 21 — (B135) No. 23:</b></p>  | Is the resistance 1 MΩ or more?  | Repair the poor contact of accelerator pedal position sensor connector. Replace the accelerator pedal if defective. <Ref. to SP(H4DO(w/o HEV))-4, Accelerator Pedal.> | Repair the short circuit to power supply in harness between ECM connector and accelerator pedal position sensor connector.  |

## EZ:DTC P2127 THROTTLE/PEDAL POSITION SENSOR/SWITCH “E” CIRCUIT LOW INPUT

### DTC DETECTING CONDITION:

- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-182, DTC P2127 THROTTLE/PEDAL POSITION SENSOR/SWITCH “E” CIRCUIT LOW INPUT, Diagnostic Trouble Code (DTC) Detecting Criteria.>

### TROUBLE SYMPTOM:



- Improper idling
- Poor driving performance

### CAUTION:

**After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.**

### WIRING DIAGRAM:

- Engine electrical system (without push button start) <Ref. to WI(HEV)-100, WITHOUT PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>
- Engine electrical system (with push button start) <Ref. to WI(HEV)-114, WITH PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>



# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step  | Check                                  | Yes   | No  |
|---|--|---|---|
| <p><b>1</b></p> <p><b>CHECK HARNESS BETWEEN ECM AND ACCELERATOR PEDAL POSITION SENSOR CONNECTOR.</b></p> <p>1) Turn the ignition switch to OFF.<br/>                     2) Disconnect the connectors from ECM and accelerator pedal position sensor.<br/>                     3) Measure the resistance between ECM connector and chassis ground.</p> <p><b>Connector &amp; terminal</b><br/> <b>(B135) No. 22 — Chassis ground:</b><br/> <b>(B135) No. 31 — Chassis ground:</b></p> | <p>Is the resistance 1 MΩ or more?</p> | <p>Go to step 2.</p>  | <p>Repair the short circuit to ground in harness between ECM connector and accelerator pedal position sensor connector.</p>   |
| <p><b>2</b></p> <p><b>CHECK SHORT CIRCUIT INSIDE THE ECM.</b></p> <p>1) Connect the connector to ECM.<br/>                     2) Measure the resistance between accelerator pedal position sensor connector and chassis ground.</p> <p><b>Connector &amp; terminal</b><br/> <b>(B315) No. 3 — Chassis ground:</b></p>  | <p>Is the resistance 1 MΩ or more?</p> | <p>Replace the accelerator pedal. &lt;Ref. to SP(H4DO(w/o HEV))-4, Accelerator Pedal.&gt;</p> | <p>Repair the short circuit to ground in harness between ECM connector and accelerator pedal position sensor connector.<br/>                     Replace the ECM if defective. &lt;Ref. to FU(H4DO(HEV))-85, Engine Control Module (ECM).&gt;</p> |

## FA:DTC P2128 THROTTLE/PEDAL POSITION SENSOR/SWITCH “E” CIRCUIT HIGH INPUT

### DTC DETECTING CONDITION:

- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-183, DTC P2128 THROTTLE/PEDAL POSITION SENSOR/SWITCH “E” CIRCUIT HIGH INPUT, Diagnostic Trouble Code (DTC) Detecting Criteria.>

### TROUBLE SYMPTOM:



- Improper idling
- Poor driving performance

### CAUTION:

**After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.**

### WIRING DIAGRAM:

- Engine electrical system (without push button start) <Ref. to WI(HEV)-100, WITHOUT PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>
- Engine electrical system (with push button start) <Ref. to WI(HEV)-114, WITH PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>



# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

## ENGINE (DIAGNOSTICS)

| Step  | Check                            | Yes   | No   |
|---|----------------------------------|---|--|
| <p><b>1</b>    <b>CHECK HARNESS BETWEEN ECM AND ACCELERATOR PEDAL POSITION SENSOR CONNECTOR.</b></p> <p>1) Turn the ignition switch to OFF.<br/>                 2) Disconnect the connectors from ECM and accelerator pedal position sensor.<br/>                 3) Measure the resistance of harness between ECM connector and accelerator pedal position sensor connector.</p> <p><b>Connector &amp; terminal</b><br/> <b>(B135) No. 31 — (B315) No. 3:</b><br/> <b>(B135) No. 30 — (B315) No. 2:</b></p> | Is the resistance less than 1 Ω? | Go to step 2.   | Repair the harness and connector.<br><br>NOTE:<br>In this case, repair the following item:<br><ul style="list-style-type: none"> <li>• Open circuit of harness between ECM connector and accelerator pedal position sensor connector</li> <li>• Poor contact of joint connector</li> </ul>               |
| <p><b>2</b>    <b>CHECK HARNESS BETWEEN ECM AND ACCELERATOR PEDAL POSITION SENSOR CONNECTOR.</b></p> <p>1) Connect the connector to ECM.<br/>                 2) Measure the resistance between accelerator pedal position sensor connector and chassis ground.</p> <p><b>Connector &amp; terminal</b><br/> <b>(B315) No. 2 — Chassis ground:</b></p>   | Is the resistance less than 1 Ω? | Go to step 3.   | Repair the harness and connector.<br><br>NOTE:<br>In this case, repair the following item:<br><ul style="list-style-type: none"> <li>• Open circuit of harness between ECM connector and engine ground</li> <li>• Poor contact of ECM connector</li> <li>• Poor contact of coupling connector</li> </ul> |
| <p><b>3</b>    <b>CHECK HARNESS BETWEEN ECM AND ACCELERATOR PEDAL POSITION SENSOR CONNECTOR.</b></p> <p>1) Turn the ignition switch to ON.<br/>                 2) Measure the voltage between accelerator pedal position sensor connector and chassis ground.</p> <p><b>Connector &amp; terminal</b><br/> <b>(B315) No. 3 (+) — Chassis ground (-):</b></p>  | Is the voltage 5 V or more?      | Repair the short circuit to power supply in harness between ECM connector and accelerator pedal position sensor connector.  | Go to step 4.  |
| <p><b>4</b>    <b>CHECK HARNESS BETWEEN ECM AND ACCELERATOR PEDAL POSITION SENSOR CONNECTOR.</b></p> <p>1) Turn the ignition switch to OFF.<br/>                 2) Disconnect the connector from ECM.<br/>                 3) Measure the resistance between ECM connectors.</p> <p><b>Connector &amp; terminal</b><br/> <b>(B135) No. 22 — (B135) No. 31:</b></p>   | Is the resistance 1 MΩ or more?  | Repair the poor contact of accelerator pedal position sensor connector. Replace the accelerator pedal if defective. <Ref. to SP(H4DO(w/o HEV))-4, Accelerator Pedal.> | Repair the short circuit to power supply in harness between ECM connector and accelerator pedal position sensor connector.   |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

## FB:DTC P2135 THROTTLE/PEDAL POSITION SENSOR/SWITCH "A"/"B" VOLTAGE CORRELATION

### DTC DETECTING CONDITION:

- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-184, DTC P2135 THROTTLE/PEDAL POSITION SENSOR/SWITCH "A"/"B" VOLTAGE CORRELATION, Diagnostic Trouble Code (DTC) Detecting Criteria.>

### TROUBLE SYMPTOM:


- Improper idling
- Poor driving performance

### CAUTION:

After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.

### WIRING DIAGRAM:

- Engine electrical system (without push button start) <Ref. to WI(HEV)-100, WITHOUT PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>
- Engine electrical system (with push button start) <Ref. to WI(HEV)-114, WITH PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>



EN-10744

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step   | Check   | Yes                  | No   |
|--|---|----------------------|--|
| <p><b>1</b></p> <p><b>CHECK HARNESS BETWEEN ECM AND ELECTRONIC THROTTLE CONTROL CONNECTOR.</b></p> <p>1) Turn the ignition switch to OFF.<br/>2) Disconnect the connectors from ECM and electronic throttle control.<br/>3) Measure the resistance between ECM connector and chassis ground.</p> <p><b>Connector &amp; terminal</b><br/><b>(B134) No. 19 — Chassis ground:</b><br/><b>(B134) No. 18 — Chassis ground:</b><br/><b>(B134) No. 18 — (B137) No. 4:</b><br/><b>(B134) No. 28 — Chassis ground:</b><br/><b>(B134) No. 28 — (B137) No. 4:</b></p> | <p>Is the resistance 1 M<math>\Omega</math> or more?</p>  | <p>Go to step 2.</p> | <p>Repair the ground short circuit of harness between ECM connector and electronic throttle control connector.</p>   |
| <p><b>2</b></p> <p><b>CHECK SHORT CIRCUIT INSIDE THE ECM.</b></p> <p>1) Connect the connector to ECM.<br/>2) Measure the resistance between electronic throttle control connector and engine ground.</p> <p><b>Connector &amp; terminal</b><br/><b>(E57) No. 6 — Engine ground:</b><br/><b>(E57) No. 4 — Engine ground:</b></p>  | <p>Is the resistance 1 M<math>\Omega</math> or more?</p>  | <p>Go to step 3.</p> | <p>Repair the ground short circuit of harness between ECM connector and electronic throttle control connector.<br/>Replace the ECM if defective. &lt;Ref. to FU(H4DO(HEV))-85, Engine Control Module (ECM).&gt;</p>                                |
| <p><b>3</b></p> <p><b>CHECK HARNESS BETWEEN ECM AND ELECTRONIC THROTTLE CONTROL CONNECTOR.</b></p> <p>1) Disconnect the connector from ECM.<br/>2) Measure the resistance of harness between ECM connector and electronic throttle control connector.</p> <p><b>Connector &amp; terminal</b><br/><b>(B134) No. 18 — (E57) No. 6:</b><br/><b>(B134) No. 28 — (E57) No. 4:</b><br/><b>(B134) No. 29 — (E57) No. 3:</b></p>   | <p>Is the resistance less than 1 <math>\Omega</math>?</p> | <p>Go to step 4.</p> | <p>Repair the harness and connector.<br/>NOTE:<br/>In this case, repair the following item:<br/>• Open circuit in harness between ECM connector and electronic throttle control connector<br/>• Poor contact of coupling connector</p>             |
| <p><b>4</b></p> <p><b>CHECK HARNESS BETWEEN ECM AND ELECTRONIC THROTTLE CONTROL CONNECTOR.</b></p> <p>1) Connect the connector to ECM.<br/>2) Measure the resistance between electronic throttle control connector and engine ground.</p> <p><b>Connector &amp; terminal</b><br/><b>(E57) No. 3 — Engine ground:</b></p>   | <p>Is the resistance less than 5 <math>\Omega</math>?</p> | <p>Go to step 5.</p> | <p>Repair the harness and connector.<br/>NOTE:<br/>In this case, repair the following item:<br/>• Open circuit of harness between ECM connector and engine ground<br/>• Poor contact of ECM connector<br/>• Poor contact of coupling connector</p> |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step  | Check                                  | Yes   | No   |
|---|--|---|--|
| <p><b>5</b></p> <p><b>CHECK HARNESS BETWEEN ECM AND ELECTRONIC THROTTLE CONTROL CONNECTOR.</b></p> <p>1) Turn the ignition switch to ON.<br/>2) Measure the voltage between electronic throttle control connector and engine ground.</p> <p><b>Connector &amp; terminal</b><br/><b>(E57) No. 6 (+) — Engine ground (-):</b><br/><b>(E57) No. 4 (+) — Engine ground (-):</b></p> | <p>Is the voltage 5 V or more?</p>     | <p>Repair the short circuit to power in the harness between ECM connector and electronic throttle control connector.</p>  | <p>Go to step 6.</p>   |
| <p><b>6</b></p> <p><b>CHECK HARNESS BETWEEN ECM AND ELECTRONIC THROTTLE CONTROL CONNECTOR.</b></p> <p>1) Turn the ignition switch to OFF.<br/>2) Disconnect the connector from ECM.<br/>3) Measure the resistance between ECM connectors.</p> <p><b>Connector &amp; terminal</b><br/><b>(B134) No. 19 — (B134) No. 18:</b><br/><b>(B134) No. 19 — (B134) No. 28:</b></p>        | <p>Is the resistance 1 MΩ or more?</p> | <p>Repair the poor contact of electronic throttle control connector.<br/>Replace the electronic throttle control if defective.<br/>&lt;Ref. to FU(H4DO(HEV))-14, Throttle Body.&gt;</p> | <p>Repair the short circuit to power in the harness between ECM connector and electronic throttle control connector.</p> |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

## FC:DTC P2138 THROTTLE/PEDAL POSITION SENSOR/SWITCH “D”/“E” VOLTAGE CORRELATION

### DTC DETECTING CONDITION:

- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-186, DTC P2138 THROTTLE/PEDAL POSITION SENSOR/SWITCH “D”/“E” VOLTAGE CORRELATION, Diagnostic Trouble Code (DTC) Detecting Criteria.>

### TROUBLE SYMPTOM:



- Improper idling
- Poor driving performance

### CAUTION:

After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.

### WIRING DIAGRAM:

- Engine electrical system (without push button start) <Ref. to WI(HEV)-100, WITHOUT PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>
- Engine electrical system (with push button start) <Ref. to WI(HEV)-114, WITH PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>



EN-10755

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

|   | Step   | Check   | Yes   | No   |
|---|--|---|---|--|
| 1 | <p><b>CHECK ACCELERATOR PEDAL POSITION SENSOR OUTPUT.</b></p> <p>1) Turn the ignition switch to ON.<br/>2) Measure the voltage between ECM connector and chassis ground.</p> <p><b>Connector &amp; terminal</b><br/><b>Main accelerator pedal position sensor signal</b><br/><b>(B135) No. 23 (+) — Chassis ground (-):</b><br/><b>Sub accelerator pedal position sensor signal</b><br/><b>(B135) No. 31 (+) — Chassis ground (-):</b></p> | <p>Is the difference in measured values for the main accelerator pedal position sensor signal and the sub accelerator pedal position sensor signal 0 V?</p> | <p>Go to step 3.</p>  | <p>Go to step 2.</p>   |
| 2 | <p><b>CHECK ACCELERATOR PEDAL POSITION SENSOR OUTPUT.</b></p> <p>1) Measure the voltage between accelerator pedal position sensor connector and chassis ground.</p> <p><b>Connector &amp; terminal</b><br/><b>(B315) No. 6 (+) — Chassis ground (-):</b><br/><b>(B315) No. 3 (+) — Chassis ground (-):</b></p>   | <p>Is the difference in measured values for the main accelerator pedal position sensor signal and the sub accelerator pedal position sensor signal 0 V?</p> | <p>Replace the accelerator pedal. &lt;Ref. to SP(H4DO(w/o HEV))-4, Accelerator Pedal.&gt;</p> | <p>Repair the harness and connector.</p> <p><b>NOTE:</b><br/>In this case, repair the following item:</p> <ul style="list-style-type: none"> <li>• Open circuit of harness between ECM connector and accelerator pedal position sensor connector</li> <li>• Short circuit to ground in harness between ECM connector and accelerator pedal position sensor connector</li> </ul>  |
| 3 | <p><b>CHECK HARNESS BETWEEN ECM AND ACCELERATOR PEDAL POSITION SENSOR CONNECTOR.</b></p> <p>Measure the resistance of harness between accelerator pedal position sensor connector and chassis ground.</p> <p><b>Connector &amp; terminal</b><br/><b>(B315) No. 5 — Chassis ground:</b><br/><b>(B315) No. 2 — Chassis ground:</b></p>   | <p>Is the resistance less than 5 Ω?</p>   | <p>Repair the poor contact of ECM connector.</p>  | <p>Repair the harness and connector.</p> <p><b>NOTE:</b><br/>In this case, repair the following item:</p> <ul style="list-style-type: none"> <li>• Open circuit of harness between ECM connector and accelerator pedal position sensor connector</li> <li>• Open circuit of harness between ECM connector and engine ground</li> <li>• Poor contact of ECM connector</li> <li>• Poor contact of joint connector</li> </ul> |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

## FD:DTC P2195 O2 SENSOR SIGNAL BIASED/STUCK LEAN (BANK 1 SENSOR 1)

### DTC DETECTING CONDITION:


- Detected when two consecutive driving cycles with fault occur.
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-188, DTC P2195 O2 SENSOR SIGNAL BIASED/STUCK LEAN (BANK 1 SENSOR 1), Diagnostic Trouble Code (DTC) Detecting Criteria.>

### CAUTION:

After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.

### WIRING DIAGRAM:

- Engine electrical system (without push button start) <Ref. to WI(HEV)-100, WITHOUT PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>
- Engine electrical system (with push button start) <Ref. to WI(HEV)-114, WITH PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>



EN-10739

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step  | Check   | Yes   | No  |
|---|---|---|---|
| <b>1</b><br><b>CHECK FRONT OXYGEN (A/F) SENSOR CONNECTOR AND COUPLING CONNECTOR.</b>  | Has water entered the connector?                              | Completely remove any water inside.                             | Go to step 2.   |
| <b>2</b><br><b>CHECK HARNESS BETWEEN ECM AND FRONT OXYGEN (A/F) SENSOR CONNECTOR.</b><br>1) Turn the ignition switch to OFF.<br>2) Disconnect the connectors from ECM and front oxygen (A/F) sensor.<br>3) Measure the resistance of harness between ECM connector and front oxygen (A/F) sensor connector.<br><i><b>Connector &amp; terminal</b></i><br><i><b>(B136) No. 19 — (E24) No. 3:</b></i><br><i><b>(B136) No. 18 — (E24) No. 4:</b></i> | Is the resistance less than 1 Ω?                              | Go to step 3.   | Repair the harness and connector.<br>NOTE:<br>In this case, repair the following item:<br>• Open circuit in harness between ECM connector and front oxygen (A/F) sensor connector<br>• Poor contact of coupling connector |
| <b>3</b><br><b>CHECK FOR POOR CONTACT.</b><br>Check for poor contact of the front oxygen (A/F) sensor connector.  | Is there poor contact of front oxygen (A/F) sensor connector? | Repair the poor contact of front oxygen (A/F) sensor connector. | Replace the front oxygen (A/F) sensor. <Ref. to FU(H4DO(HEV))-78, Front Oxygen (A/F) Sensor.>   |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

## FE:DTC P2196 O2 SENSOR SIGNAL BIASED/STUCK RICH (BANK 1 SENSOR 1)

### DTC DETECTING CONDITION:


- Detected when two consecutive driving cycles with fault occur.
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-190, DTC P2196 O2 SENSOR SIGNAL BIASED/STUCK RICH (BANK 1 SENSOR 1), Diagnostic Trouble Code (DTC) Detecting Criteria.>

### CAUTION:

After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.

### WIRING DIAGRAM:

- Engine electrical system (without push button start) <Ref. to WI(HEV)-100, WITHOUT PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>
- Engine electrical system (with push button start) <Ref. to WI(HEV)-114, WITH PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>



EN-10739

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check   | Yes                              | No  |
|------|---|----------------------------------|---|
| 1    | <b>CHECK FRONT OXYGEN (A/F) SENSOR CONNECTOR AND COUPLING CONNECTOR.</b>  | Has water entered the connector? | Completely remove any water inside.   |
| 2    | <b>CHECK HARNESS BETWEEN ECM AND FRONT OXYGEN (A/F) SENSOR CONNECTOR.</b><br>1) Turn the ignition switch to OFF.<br>2) Disconnect the connector from ECM.<br>3) Measure the resistance between ECM connector and chassis ground.<br><b>Connector &amp; terminal</b><br><b>(B136) No. 19 — Chassis ground:</b><br><b>(B136) No. 18 — Chassis ground:</b> | Is the resistance 1 MΩ or more?  | Go to step 3. Repair the short circuit to ground in harness between ECM connector and front oxygen (A/F) sensor connector.  |
| 3    | <b>CHECK OUTPUT SIGNAL FOR ECM.</b><br>1) Connect the connector to ECM.<br>2) Turn the ignition switch to ON.<br>3) Measure the voltage between ECM connector and chassis ground.<br><b>Connector &amp; terminal</b><br><b>(B136) No. 19 (+) — Chassis ground (-):</b>  | Is the voltage 4.5 V or more?    | Go to step 5. Go to step 4.   |
| 4    | <b>CHECK OUTPUT SIGNAL FOR ECM.</b><br>Measure the voltage between ECM connector and chassis ground.<br><b>Connector &amp; terminal</b><br><b>(B136) No. 18 (+) — Chassis ground (-):</b>   | Is the voltage 4.95 V or more?   | Go to step 5. Replace the front oxygen (A/F) sensor. <Ref. to FU(H4DO(HEV))-78, Front Oxygen (A/F) Sensor.>   |
| 5    | <b>CHECK OUTPUT SIGNAL FOR ECM.</b><br>Measure the voltage between ECM connector and chassis ground.<br><b>Connector &amp; terminal</b><br><b>(B136) No. 19 (+) — Chassis ground (-):</b><br><b>(B136) No. 18 (+) — Chassis ground (-):</b>   | Is the voltage 8 V or more?      | Repair the short circuit to power in the harness between ECM connector and front oxygen (A/F) sensor connector. After repair, replace the ECM. <Ref. to FU(H4DO(HEV))-85, Engine Control Module (ECM).> Repair the poor contact of ECM connector. |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

## FF:DTC P219A BANK 1 AIR-FUEL RATIO IMBALANCE

### DTC DETECTING CONDITION:

- Detected when two consecutive driving cycles with fault occur.
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-192, DTC P219A BANK 1 AIR-FUEL RATIO IMBALANCE, Diagnostic Trouble Code (DTC) Detecting Criteria.>

### TROUBLE SYMPTOM:


- Engine stalls.
- Improper idling

### CAUTION:

After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.

### WIRING DIAGRAM:


- Engine electrical system (without push button start) <Ref. to WI(HEV)-100, WITHOUT PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>
- Engine electrical system (with push button start) <Ref. to WI(HEV)-114, WITH PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>



EN-10739

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)


ENGINE (DIAGNOSTICS)



EN-10740

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

## ENGINE (DIAGNOSTICS)



EN-10736

| Step | Check  | Yes   | No   |
|------|--|---|--|
| 1    | <b>CHECK FRONT OXYGEN (A/F) SENSOR CONNECTOR AND COUPLING CONNECTOR.</b><br>Has water entered the connector?   | Completely remove any water inside.               | Go to step 2.  |
| 2    | <b>CHECK HARNESS BETWEEN ECM AND FRONT OXYGEN (A/F) SENSOR CONNECTOR.</b><br>1) Turn the ignition switch to OFF.<br>2) Disconnect the connectors from ECM and front oxygen (A/F) sensor.<br>3) Measure the resistance of harness between ECM connector and front oxygen (A/F) sensor connector.<br><b>Connector &amp; terminal</b><br><b>(B136) No. 19 — (E24) No. 3:</b><br><b>(B136) No. 18 — (E24) No. 4:</b> | Is the resistance less than 1 Ω?<br>Go to step 3. | Repair the harness and connector.<br><b>NOTE:</b><br>In this case, repair the following item:<br>• Open circuit in harness between ECM connector and front oxygen (A/F) sensor connector<br>• Poor contact of coupling connector |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step  | Check   | Yes   | No  |
|---|---|---|---|
| <b>3</b><br><b>CHECK HARNESS BETWEEN ECM AND FRONT OXYGEN (A/F) SENSOR CONNECTOR.</b><br>Measure the resistance between ECM connector and chassis ground.<br><b>Connector &amp; terminal</b><br><i>(B136) No. 19 — Chassis ground:</i><br><i>(B136) No. 18 — Chassis ground:</i>  | Is the resistance 1 MΩ or more?   | Go to step 4.   | Repair the short circuit to ground in harness between ECM connector and front oxygen (A/F) sensor connector.  |
| <b>4</b><br><b>CHECK OUTPUT SIGNAL FOR ECM.</b><br>1) Connect the connector to ECM.<br>2) Turn the ignition switch to ON.<br>3) Measure the voltage between front oxygen (A/F) sensor connector and chassis ground.<br><b>Connector &amp; terminal</b><br><i>(E24) No. 3 (+) — Chassis ground (-):</i>  | Is the voltage 4.5 V or more?   | Go to step 6.   | Go to step 5.   |
| <b>5</b><br><b>CHECK OUTPUT SIGNAL FOR ECM.</b><br>Measure the voltage between front oxygen (A/F) sensor connector and chassis ground.<br><b>Connector &amp; terminal</b><br><i>(E24) No. 4 (+) — Chassis ground (-):</i>   | Is the voltage 4.95 V or more?  | Go to step 6.   | Go to step 7.   |
| <b>6</b><br><b>CHECK OUTPUT SIGNAL FOR ECM.</b><br>Measure the voltage between front oxygen (A/F) sensor connector and chassis ground.<br><b>Connector &amp; terminal</b><br><i>(E24) No. 3 (+) — Chassis ground (-):</i><br><i>(E24) No. 4 (+) — Chassis ground (-):</i>   | Is the voltage 8 V or more?   | Repair the short circuit to power in the harness between ECM connector and front oxygen (A/F) sensor connector. After repair, replace the ECM. <Ref. to FU(H4DO(HEV))-85, Engine Control Module (ECM).> | Repair the poor contact of ECM connector.   |
| <b>7</b><br><b>CHECK EXHAUST SYSTEM.</b>  | Are there holes or loose bolts on exhaust system?                                 | Repair the exhaust system.  | Go to step 8.   |
| <b>8</b><br><b>CHECK AIR INTAKE SYSTEM.</b>   | Are there holes, loose bolts or disconnection of hose on air intake system?       | Repair the air intake system.   | Go to step 9.   |
| <b>9</b><br><b>CHECK FUEL PRESSURE.</b><br><b>WARNING:</b><br>Place “NO OPEN FLAMES” signs near the working area.<br><b>CAUTION:</b><br>Be careful not to spill fuel.<br>1) Connect the front oxygen (A/F) sensor connector.<br>2) Measure the fuel pressure. <Ref. to ME(H4DO(w/o HEV))-35, INSPECTION, Fuel Pressure.><br><b>CAUTION:</b><br>Release fuel pressure before removing the fuel pressure gauge. | Is the measured value 340 — 400 kPa (3.5 — 4.1 kg/cm <sup>2</sup> , 49 — 58 psi)? | Go to step 10.  | Check the fuel pump and fuel delivery line. <Ref. to FU(H4DO(HEV))-127, INSPECTION, Fuel Pump.> <Ref. to FU(H4DO(HEV))-157, INSPECTION, Fuel Delivery and Evaporation Lines.> |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

## ENGINE (DIAGNOSTICS)

| Step  | Check   | Yes                   | No   |
|---|---|-----------------------|--|
| <p><b>10 CHECK ENGINE COOLANT TEMPERATURE SENSOR.</b></p> <p>1) Start the engine and warm up completely.<br/>2) Read the value of «Coolant Temp.» using the Subaru Select Monitor or a general scan tool.</p> <p>NOTE:<br/>• Subaru Select Monitor<br/>For detailed operation procedures, refer to “Current Data Display For Engine”. &lt;Ref. to EN(H4DO HEV)(diag)-36, Subaru Select Monitor.&gt;<br/>• General scan tool<br/>For detailed operation procedures, refer to the general scan tool operation manual.</p>   | <p>Is the value of «Coolant Temp.» 75°C (167°F) or more?</p>  | <p>Go to step 11.</p> | <p>Replace the engine coolant temperature sensor. &lt;Ref. to FU(H4DO(HEV))-41, Engine Coolant Temperature Sensor.&gt;</p>                             |
| <p><b>11 CHECK MASS AIR FLOW AND INTAKE AIR TEMPERATURE SENSOR.</b></p> <p>1) Start the engine and warm up engine until coolant temperature is higher than 75°C (167°F).<br/>2) Place the select lever in “P” range or “N” range.<br/>3) Turn the A/C switch to OFF.<br/>4) Turn all the accessory switches to OFF.<br/>5) Read the value of «Mass Air Flow» using the Subaru Select Monitor or a general scan tool.</p> <p>NOTE:<br/>• Subaru Select Monitor<br/>For detailed operation procedures, refer to “Current Data Display For Engine”. &lt;Ref. to EN(H4DO HEV)(diag)-36, Subaru Select Monitor.&gt;<br/>• General scan tool<br/>For detailed operation procedures, refer to the general scan tool operation manual.</p>  | <p>Is the value of «Mass Air Flow» 2.0 — 5.0 g/s (0.26 — 0.66 lb/m)?</p>                                    | <p>Go to step 12.</p> | <p>Replace the mass air flow and intake air temperature sensor. &lt;Ref. to FU(H4DO(HEV))-63, Mass Air Flow and Intake Air Temperature Sensor.&gt;</p> |
| <p><b>12 CHECK MASS AIR FLOW AND INTAKE AIR TEMPERATURE SENSOR.</b></p> <p>1) Start the engine and warm up engine until coolant temperature is higher than 75°C (167°F).<br/>2) Place the select lever in “P” range or “N” range.<br/>3) Turn the A/C switch to OFF.<br/>4) Turn all the accessory switches to OFF.<br/>5) Open the front hood.<br/>6) Measure the ambient temperature.<br/>7) Read the value of «Intake Air Temp.» using the Subaru Select Monitor or a general scan tool.</p> <p>NOTE:<br/>• Subaru Select Monitor<br/>For detailed operation procedures, refer to “Current Data Display For Engine”. &lt;Ref. to EN(H4DO HEV)(diag)-36, Subaru Select Monitor.&gt;<br/>• General scan tool<br/>For detailed operation procedures, refer to the general scan tool operation manual.</p> | <p>Subtract ambient temperature from «Intake Air Temp.». Is the obtained value -10 — 50°C (-18 — 90°F)?</p> | <p>Go to step 13.</p> | <p>Check the mass air flow and intake air temperature sensor. &lt;Ref. to FU(H4DO(HEV))-63, Mass Air Flow and Intake Air Temperature Sensor.&gt;</p>   |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step  | Check   | Yes  | No                    |
|---|---|--|-----------------------|
| <p><b>13 CHECK REAR OXYGEN SENSOR DATA.</b><br/>                     1) Warm up the engine until engine coolant temperature is higher than 75°C (167°F), and keep the engine speed at 3,000 rpm. (2 minutes maximum)<br/>                     2) Read the value of «Oxygen sensor #12» using the Subaru Select Monitor or a general scan tool.<br/>                     NOTE:<br/>                     • Subaru Select Monitor<br/>                     For detailed operation procedures, refer to “Current Data Display For Engine”. &lt;Ref. to EN(H4DO HEV)(diag)-36, Subaru Select Monitor.&gt;<br/>                     • General scan tool<br/>                     For detailed operation procedures, refer to the general scan tool operation manual.</p>                          | <p>Is the value of «Oxygen sensor #12» 0.490 V or more?</p>                       | <p>Go to step 14.</p>  | <p>Go to step 15.</p> |
| <p><b>14 CHECK REAR OXYGEN SENSOR DATA.</b><br/>                     1) Warm up the engine until engine coolant temperature is higher than 75°C (167°F), and rapidly reduce the engine speed from 3,000 rpm.<br/>                     2) Read the value of «Oxygen sensor #12» using the Subaru Select Monitor or a general scan tool.<br/>                     NOTE:<br/>                     • Subaru Select Monitor<br/>                     For detailed operation procedures, refer to “Current Data Display For Engine”. &lt;Ref. to EN(H4DO HEV)(diag)-36, Subaru Select Monitor.&gt;<br/>                     • General scan tool<br/>                     For detailed operation procedures, refer to the general scan tool operation manual.</p>                                  | <p>Is the value of «Oxygen sensor #12» 0.250 V or less?</p>                       | <p>Go to step 16.</p>  | <p>Go to step 15.</p> |
| <p><b>15 CHECK REAR OXYGEN SENSOR CONNECTOR AND COUPLING CONNECTOR.</b></p>   | <p>Has water entered the connector?</p>   | <p>Completely remove any water inside.</p>   | <p>Go to step 17.</p> |
| <p><b>16 CHECK FRONT OXYGEN (A/F) SENSOR USING REAR OXYGEN SENSOR SIGNAL.</b><br/>                     1) Warm up the engine until engine coolant temperature is higher than 75°C (167°F), then keep the engine idling for 5 minutes or more.<br/>                     2) Read the value of «Oxygen sensor #12» using the Subaru Select Monitor or a general scan tool.<br/>                     NOTE:<br/>                     • Subaru Select Monitor<br/>                     For detailed operation procedures, refer to “Current Data Display For Engine”. &lt;Ref. to EN(H4DO HEV)(diag)-36, Subaru Select Monitor.&gt;<br/>                     • General scan tool<br/>                     For detailed operation procedures, refer to the general scan tool operation manual.</p> | <p>Is the value of «Oxygen sensor #12» 0.250 V or less for 5 minutes or more?</p> | <p>Replace the front oxygen (A/F) sensor. &lt;Ref. to FU(H4DO(HEV))-78, Front Oxygen (A/F) Sensor.&gt;</p> | <p>Go to step 17.</p> |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

## ENGINE (DIAGNOSTICS)

| Step  | Check                                    | Yes   | No   |
|---|--|---|--|
| <b>17 CHECK HARNESS BETWEEN ECM AND REAR OXYGEN SENSOR CONNECTOR.</b><br>1) Turn the ignition switch to OFF.<br>2) Disconnect the connector from ECM and rear oxygen sensor.<br>3) Measure the resistance of harness between ECM connector and rear oxygen sensor connector.<br><i>Connector &amp; terminal</i><br><i>(B136) No. 21 — (E25) No. 3:</i><br><i>(B135) No. 30 — (E25) No. 4:</i>   | Is the resistance less than 1 $\Omega$ ? | Go to step 18.  | Repair the harness and connector.<br>NOTE:<br>In this case, repair the following item:<br><ul style="list-style-type: none"> <li>• Open circuit in harness between ECM connector and rear oxygen sensor connector</li> <li>• Poor contact of coupling connector</li> </ul> |
| <b>18 CHECK HARNESS BETWEEN ECM AND REAR OXYGEN SENSOR CONNECTOR.</b><br>1) Connect the connector to ECM.<br>2) Turn the ignition switch to ON.<br>3) Measure the voltage between rear oxygen sensor connector and chassis ground.<br><i>Connector &amp; terminal</i><br><i>(E25) No. 3 (+) — Chassis ground (-):</i>   | Is the voltage 0.2 — 0.5 V?              | Replace the rear oxygen sensor.<br><Ref. to FU(H4DO(HEV))-78, Front Oxygen (A/F) Sensor.> | Go to step 19.   |
| <b>19 CHECK OUTPUT SIGNAL OF ECM.</b><br>1) Turn the ignition switch to ON.<br>2) Measure the voltage between ECM and chassis ground on faulty cylinders.<br><i>Connector &amp; terminal</i><br><i>#1 (B134) No. 12 (+) — Chassis ground (-):</i><br><i>#2 (B134) No. 22 (+) — Chassis ground (-):</i><br><i>#3 (B134) No. 32 (+) — Chassis ground (-):</i><br><i>#4 (B134) No. 13 (+) — Chassis ground (-):</i>  | Is the voltage 10 V or more?             | Go to step 24.  | Go to step 20.   |
| <b>20 CHECK HARNESS BETWEEN ECM AND FUEL INJECTOR CONNECTOR.</b><br>1) Turn the ignition switch to OFF.<br>2) Disconnect the connector from fuel injector on faulty cylinders.<br>3) Measure the resistance between fuel injector connector and engine ground on faulty cylinders.<br><i>Connector &amp; terminal</i><br><i>#1 (E5) No. 1 — Engine ground:</i><br><i>#2 (E16) No. 1 — Engine ground:</i><br><i>#3 (E6) No. 1 — Engine ground:</i><br><i>#4 (E17) No. 1 — Engine ground:</i> | Is the resistance 1 M $\Omega$ or more?  | Go to step 21.  | Repair the short circuit to ground in harness between ECM connector and fuel injector connector.   |
| <b>21 CHECK HARNESS BETWEEN ECM AND FUEL INJECTOR CONNECTOR.</b><br>Measure the resistance of harness between ECM and fuel injector connector on faulty cylinders.<br><i>Connector &amp; terminal</i><br><i>#1 (B134) No. 12 — (E5) No. 1:</i><br><i>#2 (B134) No. 22 — (E16) No. 1:</i><br><i>#3 (B134) No. 32 — (E6) No. 1:</i><br><i>#4 (B134) No. 13 — (E17) No. 1:</i>   | Is the resistance less than 1 $\Omega$ ? | Go to step 22.  | Repair the harness and connector.<br>NOTE:<br>In this case, repair the following item:<br><ul style="list-style-type: none"> <li>• Open circuit in harness between ECM connector and fuel injector connector</li> <li>• Poor contact of coupling connector</li> </ul>      |
| <b>22 CHECK FUEL INJECTOR.</b><br>Measure the resistance between fuel injector terminals on faulty cylinder.<br><i>Terminals</i><br><i>No. 1 — No. 2:</i>   | Is the resistance 5 — 20 $\Omega$ ?      | Go to step 23.  | Replace the faulty fuel injector. <Ref. to FU(H4DO(HEV))-69, Fuel Injector.>   |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step  | Check  | Yes   | No   |
|---|--|---|--|
| <b>23 CHECK POWER SUPPLY LINE.</b><br>1) Turn the ignition switch to ON.<br>2) Measure the voltage between fuel injector connector of faulty cylinders and engine ground.<br><b>Connector &amp; terminal</b><br><b>#1 (E5) No. 2 (+) — Engine ground (-):</b><br><b>#2 (E16) No. 2 (+) — Engine ground (-):</b><br><b>#3 (E6) No. 2 (+) — Engine ground (-):</b><br><b>#4 (E17) No. 2 (+) — Engine ground (-):</b>  | Is the voltage 10 V or more?   | Repair the poor contact of all connectors in fuel injector circuit.   | Repair the harness and connector.<br>NOTE:<br>In this case, repair the following item:<br><ul style="list-style-type: none"> <li>• Open circuit in harness between the main relay and fuel injector connector on faulty cylinders</li> <li>• Poor contact of coupling connector</li> <li>• Poor contact of main relay connector</li> </ul> |
| <b>24 CHECK HARNESS BETWEEN ECM AND FUEL INJECTOR CONNECTOR.</b><br>1) Turn the ignition switch to OFF.<br>2) Disconnect the connector from fuel injector on faulty cylinders.<br>3) Turn the ignition switch to ON.<br>4) Measure the voltage between ECM and chassis ground on faulty cylinders.<br><b>Connector &amp; terminal</b><br><b>#1 (B134) No. 12 (+) — Chassis ground (-):</b><br><b>#2 (B134) No. 22 (+) — Chassis ground (-):</b><br><b>#3 (B134) No. 32 (+) — Chassis ground (-):</b><br><b>#4 (B134) No. 13 (+) — Chassis ground (-):</b> | Is the voltage 10 V or more?   | Repair the short circuit to power in harness between ECM connector and fuel injector connectors.  | Go to step 25.   |
| <b>25 CHECK FUEL INJECTOR.</b><br>1) Turn the ignition switch to OFF.<br>2) Measure the resistance between fuel injector terminals on faulty cylinder.<br><b>Terminals</b><br><b>No. 1 — No. 2:</b>   | Is the resistance 5 — 20 Ω?  | Go to step 26.  | Replace the faulty fuel injector. <Ref. to FU(H4DO(HEV))-69, Fuel Injector.>   |
| <b>26 CHECK INSTALLATION CONDITION OF CAMSHAFT POSITION SENSOR/CRANKSHAFT POSITION SENSOR.</b>  | Is the camshaft position sensor or crankshaft position sensor loosely installed? | Tighten the camshaft position sensor or crankshaft position sensor.<br><Ref. to FU(H4DO(HEV))-53, INSTALLATION, Camshaft Position Sensor.><br><Ref. to FU(H4DO(HEV))-48, INSTALLATION, Crankshaft Position Sensor.> | Go to step 27.   |
| <b>27 CHECK CRANKSHAFT POSITION SENSOR PLATE.</b>   | Is the crankshaft position sensor plate rusted or does it have broken teeth?     | Replace the crankshaft position sensor plate. <Ref. to ME(H4DO(w/o HEV))-304, Cylinder Block.>  | Go to step 28.   |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

## ENGINE (DIAGNOSTICS)

| Step  | Check   | Yes  | No   |
|---|---|--|--|
| <b>28 CHECK INSTALLATION CONDITION OF TIMING CHAIN.</b><br>Turn the crankshaft using ST, and align the alignment mark on crank sprocket with alignment mark on cylinder block.<br>ST 18252AA000 CRANKSHAFT SOCKET   | Is the timing chain dislocated from its proper position?                            | Correct the installation condition of timing chain. <Ref. to ME(H4DO(w/o HEV))-169, Timing Chain Assembly.>  | Go to step 29.   |
| <b>29 CHECK FUEL LEVEL.</b>   | Is the fuel meter indication higher than the "Lower" level?                         | Go to step 30.   | Refill the fuel so that the fuel meter indication is higher than the "Lower" level, and proceed to the next step. Go to step 30.   |
| <b>30 CHECK STATUS OF MALFUNCTION INDICATOR LIGHT.</b><br>1) Clear the memory using the Subaru Select Monitor or general scan tool. <Ref. to EN(H4DO HEV)(diag)-66, Clear Memory Mode.><br>2) Start the engine, and drive the vehicle 10 minutes or more. | Does the malfunction indicator light illuminate or blink?                           | Go to step 32.   | Go to step 31.   |
| <b>31 CHECK CAUSE OF MISFIRE.</b>   | Was the cause of misfire identified when the engine is running?                     | Finish diagnostics operation, if the engine has no abnormality.  | Repair the poor contact of connector.<br>NOTE:<br>In this case, repair the following item: <ul style="list-style-type: none"> <li>• Poor contact of ignition coil connector</li> <li>• Poor contact of fuel injector connector on faulty cylinders</li> <li>• Poor contact of ECM connector</li> <li>• Poor contact of coupling connector</li> </ul> |
| <b>32 CHECK AIR INTAKE SYSTEM.</b>  | Is there any fault in air intake system?  | Repair the air intake system.<br>NOTE:<br>Check the following items. <ul style="list-style-type: none"> <li>• Are there air leaks or air suction caused by loose or dislocated nuts and bolts?</li> <li>• Are there cracks or any disconnection of hoses?</li> </ul> | Go to step 33.   |
| <b>33 CHECK MISFIRE SYMPTOM.</b><br>1) Turn the ignition switch to ON.<br>2) Check for DTC. <Ref. to EN(H4DO HEV)(diag)-51, Read Diagnostic Trouble Code (DTC).>  | Does the Subaru Select Monitor or general scan tool indicate only one DTC?          | Go to step 36.   | Go to step 34.   |
| <b>34 CHECK DTC.</b>  | Is DTC P0301 and P0303 displayed on the Subaru Select Monitor or general scan tool? | Go to step 37.   | Go to step 35.   |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step   | Check   | Yes  | No  |
|--|---|--|---|
| <b>35</b> <b>CHECK DTC.</b>                    | Is DTC P0302 and P0304 displayed on the Subaru Select Monitor or general scan tool? | Go to step <b>38</b> .   | Go to step <b>39</b> .  |
| <b>36</b> <b>ONLY ONE CYLINDER.</b>            | Is there any fault in the cylinder?   | Repair or replace faulty parts.<br>NOTE:<br>Check the following items.<br>• Spark plug<br>• Ignition coil<br>• Fuel injector<br>• Compression ratio                                  | Go to DTC P0171. <Ref. to EN(H4DO HEV)(diag)-182, DTC P0171 SYSTEM TOO LEAN (BANK 1), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>     |
| <b>37</b> <b>GROUP OF #1 AND #3 CYLINDERS.</b> | Are there any faults in #1 and #3 cylinders?  | Repair or replace faulty parts.<br>NOTE:<br>Check the following items.<br>• Spark plug<br>• Ignition coil<br>• Fuel injector<br>• Compression ratio<br>• Skipping timing chain teeth | Go to DTC P0171. <Ref. to EN(H4DO HEV)(diag)-182, DTC P0171 SYSTEM TOO LEAN (BANK 1), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>     |
| <b>38</b> <b>GROUP OF #2 AND #4 CYLINDERS.</b> | Are there any faults in #2 and #4 cylinders?  | Repair or replace faulty parts.<br>NOTE:<br>Check the following items.<br>• Spark plug<br>• Ignition coil<br>• Fuel injector<br>• Compression ratio<br>• Skipping timing chain teeth | Go to DTC P0171. <Ref. to EN(H4DO HEV)(diag)-182, DTC P0171 SYSTEM TOO LEAN (BANK 1), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>     |
| <b>39</b> <b>CYLINDER AT RANDOM.</b>           | Is the engine idle rough?   | Go to DTC P0171. <Ref. to EN(H4DO HEV)(diag)-182, DTC P0171 SYSTEM TOO LEAN (BANK 1), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>                                      | Repair or replace faulty parts.<br>NOTE:<br>Check the following items.<br>• Spark plug<br>• Ignition coil<br>• Fuel injector<br>• Compression ratio |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

## FG:DTC P2270 O2 SENSOR SIGNAL BIASED/STUCK LEAN (BANK 1 SENSOR 2)

### DTC DETECTING CONDITION:


- Detected when two consecutive driving cycles with fault occur.
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-197, DTC P2270 O2 SENSOR SIGNAL BIASED/STUCK LEAN (BANK 1 SENSOR 2), Diagnostic Trouble Code (DTC) Detecting Criteria.>

### CAUTION:

After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.

### WIRING DIAGRAM:

- Engine electrical system (without push button start) <Ref. to WI(HEV)-100, WITHOUT PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>
- Engine electrical system (with push button start) <Ref. to WI(HEV)-114, WITH PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>



EN-10740

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step   | Check                                 | Yes  | No   |
|--|---------------------------------------|--|--|
| <b>1</b><br><b>CHECK REAR OXYGEN SENSOR CONNECTOR.</b>   | Has water entered the connector?      | Completely remove any water inside.  | Go to step 2.  |
| <b>2</b><br><b>CHECK HARNESS BETWEEN ECM AND REAR OXYGEN SENSOR CONNECTOR.</b><br>1) Turn the ignition switch to OFF.<br>2) Disconnect the connector from ECM and rear oxygen sensor.<br>3) Measure the resistance of harness between ECM connector and rear oxygen sensor connector.<br><br><b>Connector &amp; terminal</b><br><b>(B136) No. 30 — (E25) No. 4:</b><br><b>(B135) No. 21 — (E25) No. 3:</b> | Is the resistance less than 1 Ω?      | Go to step 3.  | Repair the open circuit of harness between ECM connector and rear oxygen sensor connector. |
| <b>3</b><br><b>CHECK HARNESS BETWEEN ECM AND REAR OXYGEN SENSOR CONNECTOR.</b><br>1) Connect the connector to ECM.<br>2) Turn the ignition switch to ON.<br>3) Measure the voltage between rear oxygen sensor connector and engine ground.<br><br><b>Connector &amp; terminal</b><br><b>(E25) No. 3 (+) — Engine ground (-):</b>   | Is the voltage 0.15 V or more?        | Repair the short circuit to power in the harness between ECM connector and rear oxygen sensor connector. | Go to step 4.  |
| <b>4</b><br><b>CHECK EXHAUST SYSTEM.</b><br>Check exhaust system parts.<br>NOTE:<br>Check the following items. <ul style="list-style-type: none"> <li>• Looseness and improper fitting of exhaust system parts</li> <li>• Damage (crack, hole etc.) of parts</li> <li>• Damage (crack, hole etc.) between front oxygen (A/F) sensor and rear oxygen sensor</li> </ul>                                      | Is there any fault in exhaust system? | Repair or replace faulty parts.  | Replace the rear oxygen sensor.<br><Ref. to FU(H4DO(HEV))-82, Rear Oxygen Sensor.>         |



# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step   | Check                                 | Yes                                 | No  |
|--|---------------------------------------|-------------------------------------|---|
| <b>1</b><br><b>CHECK REAR OXYGEN SENSOR CONNECTOR.</b>   | Has water entered the connector?      | Completely remove any water inside. | Go to step 2.   |
| <b>2</b><br><b>CHECK HARNESS BETWEEN ECM AND REAR OXYGEN SENSOR CONNECTOR.</b><br>1) Turn the ignition switch to OFF.<br>2) Disconnect the connector from ECM and rear oxygen sensor.<br>3) Measure the resistance of harness between ECM connector and rear oxygen sensor connector.<br><br><b>Connector &amp; terminal</b><br><b>(B135) No. 30 — (E25) No. 4:</b><br><b>(B135) No. 21 — (E25) No. 3:</b> | Is the resistance less than 1 Ω?      | Go to step 3.                       | Repair the open circuit of harness between ECM connector and rear oxygen sensor connector.            |
| <b>3</b><br><b>CHECK HARNESS BETWEEN ECM AND REAR OXYGEN SENSOR CONNECTOR.</b><br>Measure the resistance between the ECM connector and engine ground.<br><br><b>Connector &amp; terminal</b><br><b>(B135) No. 30 — Engine ground:</b>  | Is the resistance 1 MΩ or more?       | Go to step 4.                       | Repair the short circuit to ground in harness between ECM connector and rear oxygen sensor connector. |
| <b>4</b><br><b>CHECK EXHAUST SYSTEM.</b><br>Check exhaust system parts.<br><br>NOTE:<br>Check the following items. <ul style="list-style-type: none"> <li>• Looseness and improper fitting of exhaust system parts</li> <li>• Damage (crack, hole etc.) of parts</li> <li>• Damage (crack, hole etc.) between front oxygen (A/F) sensor and rear oxygen sensor</li> </ul>                                  | Is there any fault in exhaust system? | Repair or replace faulty parts.     | Replace the rear oxygen sensor.<br><Ref. to FU(H4DO(HEV))-82, Rear Oxygen Sensor.>                    |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

## FI: DTC P2401 EVAPORATIVE EMISSION SYSTEM LEAK DETECTION PUMP CONTROL CIRCUIT LOW

### DTC DETECTING CONDITION:


- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-200, DTC P2401 EVAPORATIVE EMISSION SYSTEM LEAK DETECTION PUMP CONTROL CIRCUIT LOW, Diagnostic Trouble Code (DTC) Detecting Criteria.>

### CAUTION:

After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.

### WIRING DIAGRAM:

- Engine electrical system (without push button start) <Ref. to WI(HEV)-100, WITHOUT PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>
- Engine electrical system (with push button start) <Ref. to WI(HEV)-114, WITH PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>



EN-10749

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step   | Check  | Yes  | No  |
|--|--|--|---|
| <p><b>1</b>     <b>CHECK HARNESS BETWEEN ECM AND LEAK CHECK VALVE ASSEMBLY CONNECTOR.</b><br/>           1) Turn the ignition switch to ON.<br/>           2) Measure the voltage between ECM connector and chassis ground.<br/> <b>Connector &amp; terminal</b><br/> <b>(B135) No. 8 (+) — Chassis ground (-):</b></p>  | <p>Is the voltage 10 V or more?</p>            | <p>Go to step 2.</p>                             | <p>Go to step 3.</p>  |
| <p><b>2</b>     <b>CHECK FOR POOR CONTACT.</b><br/>           Check for poor contact of ECM connector.</p>   | <p>Is there poor contact of ECM connector?</p> | <p>Repair the poor contact of ECM connector.</p> | <p>Even if DTC is detected, the circuit has returned to a normal condition at this time. Reproduce the failure, and then perform the diagnosis again.<br/><br/> <b>NOTE:</b><br/>           In this case, temporary open or short circuit of harness or temporary poor contact of connector may be the cause.</p> |
| <p><b>3</b>     <b>CHECK POWER SUPPLY TO LEAK CHECK VALVE ASSEMBLY.</b><br/>           Measure the voltage between the leak check valve assembly connector and engine ground.<br/> <b>Connector &amp; terminal</b><br/> <b>(R400) No. 3 (+) — Engine ground (-):</b></p>   | <p>Is the voltage 10 V or more?</p>            | <p>Go to step 4.</p>                             | <p>Repair the power supply circuit.</p>   |
| <p><b>4</b>     <b>CHECK HARNESS BETWEEN ECM AND LEAK CHECK VALVE ASSEMBLY CONNECTOR.</b><br/>           1) Turn the ignition switch to OFF.<br/>           2) Disconnect the connector from ECM and the leak check valve assembly.<br/>           3) Measure the resistance between leak check valve assembly and chassis ground.<br/> <b>Connector &amp; terminal</b><br/> <b>(R400) No. 4 — Chassis ground:</b></p> | <p>Is the resistance 1 MΩ or more?</p>         | <p>Go to step 5.</p>                             | <p>Repair the short circuit to ground in harness between ECM connector and leak check valve assembly connector.</p>   |
| <p><b>5</b>     <b>CHECK HARNESS BETWEEN ECM AND LEAK CHECK VALVE ASSEMBLY CONNECTOR.</b><br/>           Measure the resistance of harness between ECM connector and the leak check valve assembly connector.<br/> <b>Connector &amp; terminal</b><br/> <b>(B135) No. 8 — (R400) No. 4:</b></p>  | <p>Is the resistance less than 1 Ω?</p>        | <p>Go to step 6.</p>                             | <p>Repair the harness and connector.<br/><br/> <b>NOTE:</b><br/>           In this case, repair the following item:<br/>           • Open circuit in harness between ECM connector and the leak check valve assembly connector<br/>           • Poor contact of coupling connector</p>                            |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step   | Check   | Yes   | No  |
|--|---|---|---|
| <b>6</b><br><b>CHECK LEAK CHECK VALVE ASSEMBLY.</b><br>Check the vacuum pump of the leak check valve assembly. <Ref. to EC(H4DO(HEV))-48, CHECK VACUUM PUMP, INSPECTION, Leak Check Valve Assembly.> | Is the vacuum pump of the leak check valve assembly OK? | Repair the poor contact in the leak check valve assembly connector. | Replace the leak check valve assembly. <Ref. to EC(H4DO(HEV))-39, Leak Check Valve Assembly.> |

## FJ: DTC P2402 EVAPORATIVE EMISSION SYSTEM LEAK DETECTION PUMP CONTROL CIRCUIT HIGH

### DTC DETECTING CONDITION:


- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-201, DTC P2402 EVAPORATIVE EMISSION SYSTEM LEAK DETECTION PUMP CONTROL CIRCUIT HIGH, Diagnostic Trouble Code (DTC) Detecting Criteria.>

### CAUTION:

**After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.**

### WIRING DIAGRAM:

- Engine electrical system (without push button start) <Ref. to WI(HEV)-100, WITHOUT PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>
- Engine electrical system (with push button start) <Ref. to WI(HEV)-114, WITH PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>



# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step  | Check  | Yes  | No   |
|---|--|--|--|
| <p><b>1</b>     <b>CHECK HARNESS BETWEEN ECM AND LEAK CHECK VALVE ASSEMBLY CONNECTOR.</b></p> <p>1) Turn the ignition switch to OFF.<br/>           2) Disconnect the connector from the leak check valve assembly.<br/>           3) Turn the ignition switch to ON.<br/>           4) Measure the voltage between leak check valve assembly and chassis ground.</p> <p><b>Connector &amp; terminal</b><br/> <b>(R400) No. 4 (+) — Chassis ground (-):</b></p> | <p>Is the voltage 10 V or more?</p>                            | <p>Repair the short circuit to power in harness between ECM connector and leak check valve assembly connector.</p> | <p>Go to step 2.</p>   |
| <p><b>2</b>     <b>CHECK LEAK CHECK VALVE ASSEMBLY.</b></p> <p>1) Turn the ignition switch to OFF.<br/>           2) Check the vacuum pump of the leak check valve assembly. &lt;Ref. to EC(H4DO(HEV))-48, CHECK VACUUM PUMP, INSPECTION, Leak Check Valve Assembly.&gt;</p>  | <p>Is the vacuum pump of the leak check valve assembly OK?</p> | <p>Repair the poor contact in the leak check valve assembly connector.</p>   | <p>Replace the leak check valve assembly. &lt;Ref. to EC(H4DO(HEV))-39, Leak Check Valve Assembly.&gt;</p> |

## FK:DTC P2404 EVAPORATIVE EMISSION SYSTEM LEAK DETECTION PUMP SENSE CIRCUIT RANGE/PERFORMANCE

### DTC DETECTING CONDITION:


- Detected when two consecutive driving cycles with fault occur.
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-202, DTC P2404 EVAPORATIVE EMISSION SYSTEM LEAK DETECTION PUMP SENSE CIRCUIT RANGE/PERFORMANCE, Diagnostic Trouble Code (DTC) Detecting Criteria.>

### CAUTION:


**After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.**

### WIRING DIAGRAM:

- Engine electrical system (without push button start) <Ref. to WI(HEV)-100, WITHOUT PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>
- Engine electrical system (with push button start) <Ref. to WI(HEV)-114, WITH PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>



\* : TERMINAL No. OPTIONAL ARRANGEMENT



# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step  | Check                            | Yes   | No  |
|---|----------------------------------|---|---|
| <b>1</b><br><b>CHECK FOR ANY OTHER DTC ON DISPLAY.</b>  | Is any other DTC displayed?      | Check the appropriate DTC using the "List of Diagnostic Trouble Code (DTC)".<br><Ref. to EN(H4DO HEV)(diag)-92, List of Diagnostic Trouble Code (DTC).> | Go to step 2.   |
| <b>2</b><br><b>CHECK ELCM PUMP.</b><br>Operate the ELCM pump using the Subaru Select Monitor.<br><br>NOTE:<br>For detailed procedures, refer to "System Operation Check Mode". <Ref. to EN(H4DO HEV)(diag)-67, System Operation Check Mode.>  | Does the ELCM pump operate?      | Go to step 6.   | Go to step 3.   |
| <b>3</b><br><b>CHECK POWER SUPPLY OF LEAK CHECK VALVE ASSEMBLY.</b><br>1) Turn the ignition switch to OFF.<br>2) Disconnect the connector from the leak check valve assembly.<br>3) Turn the ignition switch to ON.<br>4) Measure the voltage between the leak check valve assembly connector and chassis ground.<br><br><b>Connector &amp; terminal</b><br><b>(R400) No. 3 (+) — Chassis ground (-):</b> | Is the voltage 10 V or more?     | Go to step 4.   | Repair the harness and connector.<br><br>NOTE:<br>In this case, repair the following item: <ul style="list-style-type: none"> <li>• Open circuit in harness between the main relay and the leak check valve assembly connector</li> <li>• Poor contact of main relay connector</li> <li>• Poor contact of coupling connector</li> </ul> |
| <b>4</b><br><b>CHECK HARNESS BETWEEN ECM AND LEAK CHECK VALVE ASSEMBLY CONNECTOR.</b><br>1) Turn the ignition switch to OFF.<br>2) Disconnect the connector from ECM.<br>3) Measure the resistance of harness between ECM connector and the leak check valve assembly connector.<br><br><b>Connector &amp; terminal</b><br><b>(B135) No. 8 — (R400) No. 4:</b>  | Is the resistance less than 1 Ω? | Go to step 5.   | Repair the harness and connector.<br><br>NOTE:<br>In this case, repair the following item: <ul style="list-style-type: none"> <li>• Open circuit in harness between ECM connector and the leak check valve assembly connector</li> <li>• Poor contact of coupling connector</li> </ul>  |
| <b>5</b><br><b>CHECK HARNESS BETWEEN ECM AND LEAK CHECK VALVE ASSEMBLY CONNECTOR.</b><br>1) Measure the resistance of harness between ECM connector and chassis ground.<br><br><b>Connector &amp; terminal</b><br><b>(B135) No. 8 — Chassis ground:</b>   | Is the resistance 1 MΩ or more?  | Replace the leak check valve assembly. <Ref. to EC(H4DO(HEV))-39, Leak Check Valve Assembly.>   | Repair the short circuit to ground in harness between ECM connector and leak check valve assembly connector.  |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step  | Check                                  | Yes   | No   |
|---|--|---|--|
| <p><b>6</b></p> <p><b>CHECK ELCM SWITCHING VALVE.</b><br/>Operate the ELCM switching valve using the Subaru Select Monitor.</p> <p>NOTE:<br/>For detailed procedures, refer to “System Operation Check Mode”. &lt;Ref. to EN(H4DO HEV)(diag)-67, System Operation Check Mode.&gt;</p>   | Does the ELCM switching valve operate? | Go to step 10.  | Go to step 7.  |
| <p><b>7</b></p> <p><b>CHECK POWER SUPPLY OF LEAK CHECK VALVE ASSEMBLY.</b><br/>1) Turn the ignition switch to OFF.<br/>2) Disconnect the connector from the leak check valve assembly.<br/>3) Turn the ignition switch to ON.<br/>4) Measure the voltage between the leak check valve assembly connector and chassis ground.</p> <p><b>Connector &amp; terminal</b><br/><b>(R400) No. 5 (+) — Chassis ground (-):</b></p> | Is the voltage 10 V or more?           | Go to step 8.   | Repair the harness and connector.<br><br>NOTE:<br>In this case, repair the following item:<br>• Open circuit in harness between the main relay and the leak check valve assembly connector<br>• Poor contact of main relay connector<br>• Poor contact of coupling connector |
| <p><b>8</b></p> <p><b>CHECK HARNESS BETWEEN ECM AND LEAK CHECK VALVE ASSEMBLY CONNECTOR.</b><br/>1) Turn the ignition switch to OFF.<br/>2) Disconnect the connector from ECM.<br/>3) Measure the resistance of harness between ECM connector and the leak check valve assembly connector.</p> <p><b>Connector &amp; terminal</b><br/><b>(B135) No. 1 — (R400) No. 1:</b></p>   | Is the resistance less than 1 Ω?       | Go to step 9.   | Repair the harness and connector.<br><br>NOTE:<br>In this case, repair the following item:<br>• Open circuit in harness between ECM connector and the leak check valve assembly connector<br>• Poor contact of coupling connector  |
| <p><b>9</b></p> <p><b>CHECK HARNESS BETWEEN ECM AND LEAK CHECK VALVE ASSEMBLY CONNECTOR.</b><br/>1) Measure the resistance of harness between ECM connector and chassis ground.</p> <p><b>Connector &amp; terminal</b><br/><b>(B135) No. 1 — Chassis ground:</b></p>  | Is the resistance 1 MΩ or more?        | Replace the leak check valve assembly. <Ref. to EC(H4DO(HEV))-39, Leak Check Valve Assembly.> | Repair the short circuit to ground in harness between ECM connector and leak check valve assembly connector.   |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step  | Check   | Yes  | No   |
|---|---|--|--|
| <p><b>10</b></p> <p><b>CHECK EVAPORATIVE EMISSION CONTROL SYSTEM.</b></p> <p>Perform drive cycle I. &lt;Ref. to EN(H4DO HEV)(diag)-62, DRIVE CYCLE I, PROCEDURE, Drive Cycle.&gt;</p> | <p>Is DTC P2404 displayed on the display?</p> | <p>Replace the leak check valve assembly. &lt;Ref. to EC(H4DO(HEV))-39, Leak Check Valve Assembly.&gt;</p> | <p>Even if DTC is detected, the circuit has returned to a normal condition at this time. Reproduce the failure, and then perform the diagnosis again.</p> <p><b>NOTE:</b></p> <p>In this case, temporary poor contact of connector, temporary open or short circuit of harness may be the cause.</p> |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

## FL:DTC P2419 EVAPORATIVE EMISSION SYSTEM SWITCHING VALVE CONTROL CIRCUIT LOW

### DTC DETECTING CONDITION:


- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-203, DTC P2419 EVAPORATIVE EMISSION SYSTEM SWITCHING VALVE CONTROL CIRCUIT LOW, Diagnostic Trouble Code (DTC) Detecting Criteria.>

### CAUTION:

After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.

### WIRING DIAGRAM:

- Engine electrical system (without push button start) <Ref. to WI(HEV)-100, WITHOUT PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>
- Engine electrical system (with push button start) <Ref. to WI(HEV)-114, WITH PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>



# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step   | Check                                    | Yes                                       | No  |
|--|--|---|---|
| <p><b>1</b></p> <p><b>CHECK HARNESS BETWEEN ECM AND LEAK CHECK VALVE ASSEMBLY CONNECTOR.</b></p> <p>1) Turn the ignition switch to ON.<br/>2) Measure the voltage between ECM connector and chassis ground.</p> <p><b>Connector &amp; terminal</b><br/><b>(B135) No. 1 (+) — Chassis ground (-):</b></p>   | Is the voltage 10 V or more?             | Go to step 2.                             | Go to step 3.   |
| <p><b>2</b></p> <p><b>CHECK FOR POOR CONTACT.</b></p> <p>Check for poor contact of ECM connector.</p>  | Is there poor contact of ECM connector?  | Repair the poor contact of ECM connector. | <p>Even if DTC is detected, the circuit has returned to a normal condition at this time. Reproduce the failure, and then perform the diagnosis again.</p> <p><b>NOTE:</b><br/>In this case, temporary open or short circuit of harness or temporary poor contact of connector may be the cause.</p>   |
| <p><b>3</b></p> <p><b>CHECK POWER SUPPLY TO LEAK CHECK VALVE ASSEMBLY.</b></p> <p>Measure the voltage between the leak check valve assembly connector and engine ground.</p> <p><b>Connector &amp; terminal</b><br/><b>(R400) No. 5 (+) — Engine ground (-):</b></p>   | Is the voltage 10 V or more?             | Go to step 4.                             | Repair the power supply circuit.  |
| <p><b>4</b></p> <p><b>CHECK HARNESS BETWEEN ECM AND LEAK CHECK VALVE ASSEMBLY CONNECTOR.</b></p> <p>1) Turn the ignition switch to OFF.<br/>2) Disconnect the connector from ECM and the leak check valve assembly.<br/>3) Measure the resistance between leak check valve assembly and chassis ground.</p> <p><b>Connector &amp; terminal</b><br/><b>(R400) No. 1 — Chassis ground:</b></p> | Is the resistance 1 M $\Omega$ or more?  | Go to step 5.                             | Repair the short circuit to ground in harness between ECM connector and leak check valve assembly connector.  |
| <p><b>5</b></p> <p><b>CHECK HARNESS BETWEEN ECM AND LEAK CHECK VALVE ASSEMBLY CONNECTOR.</b></p> <p>Measure the resistance of harness between ECM connector and the leak check valve assembly connector.</p> <p><b>Connector &amp; terminal</b><br/><b>(B135) No. 1 — (R400) No. 1:</b></p>  | Is the resistance less than 1 $\Omega$ ? | Go to step 6.                             | <p>Repair the harness and connector.</p> <p><b>NOTE:</b><br/>In this case, repair the following item:</p> <ul style="list-style-type: none"> <li>• Open circuit in harness between ECM connector and the leak check valve assembly connector</li> <li>• Poor contact of coupling connector</li> </ul> |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step   | Check   | Yes   | No  |
|--|---|---|---|
| <b>6</b><br><b>CHECK LEAK CHECK VALVE ASSEMBLY.</b><br>Check the switching valve of the leak check valve assembly. <Ref. to EC(H4DO(HEV))-47, CHECK SWITCHING VALVE, INSPECTION, Leak Check Valve Assembly.> | Is the switching valve of the leak check valve assembly OK? | Repair the poor contact in the leak check valve assembly connector. | Replace the leak check valve assembly. <Ref. to EC(H4DO(HEV))-39, Leak Check Valve Assembly.> |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

## FM:DTC P2420 EVAPORATIVE EMISSION SYSTEM SWITCHING VALVE CONTROL CIRCUIT HIGH

### DTC DETECTING CONDITION:


- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-204, DTC P2420 EVAPORATIVE EMISSION SYSTEM SWITCHING VALVE CONTROL CIRCUIT HIGH, Diagnostic Trouble Code (DTC) Detecting Criteria.>

### CAUTION:

After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.

### WIRING DIAGRAM:

- Engine electrical system (without push button start) <Ref. to WI(HEV)-100, WITHOUT PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>
- Engine electrical system (with push button start) <Ref. to WI(HEV)-114, WITH PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>



EN-10749

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step  | Check   | Yes   | No  |
|---|---|---|---|
| <b>1</b><br><b>CHECK HARNESS BETWEEN ECM AND LEAK CHECK VALVE ASSEMBLY CONNECTOR.</b><br>1) Turn the ignition switch to OFF.<br>2) Disconnect the connector from the leak check valve assembly.<br>3) Turn the ignition switch to ON.<br>4) Measure the voltage between leak check valve assembly and chassis ground.<br><b>Connector &amp; terminal</b><br><b>(R400) No. 1 (+) — Chassis ground (-):</b> | Is the voltage 10 V or more?                                | Repair the short circuit to power in harness between ECM connector and leak check valve assembly connector. | Go to step 2.   |
| <b>2</b><br><b>CHECK LEAK CHECK VALVE ASSEMBLY.</b><br>1) Turn the ignition switch to OFF.<br>2) Check the switching valve of the leak check valve assembly. <Ref. to EC(H4DO(HEV))-47, CHECK SWITCHING VALVE, INSPECTION, Leak Check Valve Assembly.>  | Is the switching valve of the leak check valve assembly OK? | Repair the poor contact in the leak check valve assembly connector.   | Replace the leak check valve assembly. <Ref. to EC(H4DO(HEV))-39, Leak Check Valve Assembly.> |

## Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

---

### **FN:DTC P2530 IGNITION SWITCH RUN POSITION CIRCUIT**

#### **DTC DETECTING CONDITION:**

- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-205, DTC P2530 IGNITION SWITCH RUN POSITION CIRCUIT, Diagnostic Trouble Code (DTC) Detecting Criteria.>

#### **TROUBLE SYMPTOM:**

Improper idling

#### **CAUTION:**



**After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.**

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

## WIRING DIAGRAM:

- Engine electrical system (without push button start) <Ref. to WI(HEV)-100, WITHOUT PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>
- Engine electrical system (with push button start) <Ref. to WI(HEV)-114, WITH PUSH BUTTON START, WIRING DIAGRAM, Engine Electrical System.>



EN-10733

| Step | Check   | Yes           | No                                   |
|------|---|---------------|--------------------------------------|
| 1    | <b>CHECK ECM CONNECTOR.</b><br>Check the connecting condition of ECM connector. | Go to step 2. | Connect the ECM connector correctly. |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

## ENGINE (DIAGNOSTICS)

| Step   | Check   | Yes   | No   |
|--|---|---|--|
| <p><b>2</b></p> <p><b>CHECK INPUT VOLTAGE OF ECM.</b></p> <p>1) Turn the ignition switch to ON.</p> <p>2) Connect the check board.<br/>ST 18460AA050 CHECK BOARD</p> <p>3) Measure the voltage between ECM connector and engine ground while wiggling the harness between ECM connector and F/B connector.</p> <p><b>Connector &amp; terminal</b><br/><b>(B137) No. 2 (+) — Engine ground (-):</b></p> | <p>Is the voltage 8 V or more all the time?</p> | <p>Even if DTC is detected, the circuit has returned to a normal condition at this time. Reproduce the failure, and then perform the diagnosis again.</p> <p><b>NOTE:</b><br/>In this case, the following items may be the cause of fault.</p> <ul style="list-style-type: none"> <li>• Open circuit or short circuit to ground in harness between ECM connector and F/B connector</li> <li>• Poor contact of fuse (F/B No. 5)</li> <li>• Poor contact of IG2 relay connector</li> <li>• Poor contact of IG2 relay</li> </ul> | <p>Repair the harness and connector.</p> <p><b>NOTE:</b><br/>In this case, repair the following item:</p> <ul style="list-style-type: none"> <li>• Open circuit or short circuit to ground in harness between ECM connector and F/B connector</li> <li>• Poor contact of fuse (F/B No. 5)</li> <li>• Poor contact of IG2 relay connector</li> <li>• Poor contact of IG2 relay</li> </ul> |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

## FO:DTC P2610 ECM/PCM INTERNAL ENGINE OFF TIMER PERFORMANCE

### DTC DETECTING CONDITION:

- Detected when two consecutive driving cycles with fault occur.
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-206, DTC P2610 ECM/PCM INTERNAL ENGINE OFF TIMER PERFORMANCE, Diagnostic Trouble Code (DTC) Detecting Criteria.>

### CAUTION:

After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.

| Step | Check                               | Yes                         | No   |  |
|------|-------------------------------------|-----------------------------|--|--|
| 1    | CHECK FOR ANY OTHER DTC ON DISPLAY. | Is any other DTC displayed? | Check DTC using "List of Diagnostic Trouble Code (DTC)". <Ref. to EN(H4DO HEV)(diag)-92, List of Diagnostic Trouble Code (DTC).> | Replace the ECM. <Ref. to FU(H4DO(HEV))-85, Engine Control Module (ECM).><br>NOTE:<br>The soak timer IC is built into the ECM. |

## FP:DTC U0073 CONTROL MODULE COMMUNICATION BUS OFF

### NOTE:

For the diagnostic procedure, refer to LAN section. <Ref. to LAN(HEV)(diag)-2, Basic Diagnostic Procedure.>

## FQ:DTC U0075 CONTROL MODULE COMMUNICATION BUS "PU-CAN" OFF

### NOTE:

For the diagnostic procedure, refer to LAN section. <Ref. to LAN(HEV)(diag)-2, Basic Diagnostic Procedure.>

## FR:DTC U0101 LOST COMMUNICATION WITH TCM

### NOTE:

For the diagnostic procedure, refer to LAN section. <Ref. to LAN(HEV)(diag)-2, Basic Diagnostic Procedure.>

## FS:DTC U0122 LOST COMMUNICATION WITH VEHICLE DYNAMICS CONTROL MODULE

### NOTE:

For the diagnostic procedure, refer to LAN section. <Ref. to LAN(HEV)(diag)-2, Basic Diagnostic Procedure.>

## FT:DTC U0155 LOST COMMUNICATION WITH INSTRUMENT PANEL CLUSTER (IPC) CONTROL MODULE

### NOTE:

For the diagnostic procedure, refer to LAN section. <Ref. to LAN(HEV)(diag)-2, Basic Diagnostic Procedure.>

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

## FU:DTC U0284 LOST COMMUNICATION WITH ACTIVE GRILLE SHUTTER MODULE "A"

### DTC DETECTING CONDITION:


- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DO HEV)-218, DTC U0284 LOST COMMUNICATION WITH ACTIVE GRILLE SHUTTER MODULE "A", Diagnostic Trouble Code (DTC) Detecting Criteria.>

### CAUTION:

After servicing or replacing faulty parts, perform Clear Memory Mode <Ref. to EN(H4DO HEV)(diag)-66, OPERATION, Clear Memory Mode.>, and Inspection Mode <Ref. to EN(H4DO HEV)(diag)-52, PROCEDURE, Inspection Mode.>.

### WIRING DIAGRAM:

Active grille shutter <Ref. to WI(HEV)-50, Active Grille Shutter.>



EN-10751

| Step | Check  | Yes           | No  |
|------|--|---------------|---|
| 1    | <p><b>CHECK DTC.</b><br/>Check for DTC. &lt;Ref. to EN(H4DO HEV)(diag)-51, Read Diagnostic Trouble Code (DTC).&gt;</p> | Go to step 2. | <p>Even if DTC is detected, the circuit has returned to a normal condition at this time. Reproduce the failure, and then perform the diagnosis again.</p> <p><b>NOTE:</b><br/>In this case, temporary poor contact of connector, temporary open or short circuit of harness may be the cause.</p> |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check  | Yes   | No   |
|------|--|---|--|
| 2    | <b>CHECK FOR ANY OTHER DTC ON DISPLAY.</b><br>Is any other DTC of engine control system displayed?   | Check the appropriate DTC using the "List of Diagnostic Trouble Code (DTC)".<br><Ref. to EN(H4DO HEV)(diag)-92, List of Diagnostic Trouble Code (DTC).> | Go to step 3.  |
| 3    | <b>CHECK DTC OF HYBRID POWERTRAIN CONTROL SYSTEM, DRIVE MOTOR CONTROL SYSTEM AND BATTERY ENERGY CONTROL SYSTEM.</b><br>Check DTC of hybrid powertrain control system, drive motor control system and battery energy control system.  | Check the appropriate DTC using the "List of Diagnostic Trouble Code (DTC)".<br><Ref. to HEV(diag)-74, List of Diagnostic Trouble Code (DTC).>          | Go to step 4.  |
| 4    | <b>CHECK HARNESS BETWEEN HPCM AND ACTIVE GRILLE SHUTTER CONNECTOR.</b><br>1) Turn the ignition switch to OFF.<br>2) Disconnect the 12 volt auxiliary battery.<br><Ref. to NT-5, BATTERY, NOTE, Note.><br>3) Disconnect the connector from HPCM and active grille shutter.<br>4) Measure the resistance between active grille shutter connector and chassis ground.<br><b>Connector &amp; terminal</b><br><b>(F157) No. 3 — Chassis ground:</b> | Is the resistance 1 MΩ or more?   | Go to step 5.  |
| 5    | <b>CHECK HARNESS BETWEEN HPCM AND ACTIVE GRILLE SHUTTER CONNECTOR.</b><br>Measure the resistance between HPCM and active grille shutter connector.<br><b>Connector &amp; terminal</b><br><b>(B605) No. 4 — (F157) No. 3:</b>   | Is the resistance less than 10 Ω?   | Repair the short circuit to ground in harness between HPCM and active grille shutter connector.<br><br>NOTE:<br>In this case, repair the following item:<br>• Open circuit in harness between HPCM and active grille shutter connector<br>• Poor contact of coupling connector |
| 6    | <b>CHECK ACTIVE GRILLE SHUTTER POWER SUPPLY.</b><br>1) Connect the 12 volt auxiliary battery. <Ref. to NT-5, BATTERY, NOTE, Note.><br>2) Measure the voltage between active grille shutter connector and chassis ground.<br><b>Connector &amp; terminal</b><br><b>(F157) No. 2 (+) — Chassis ground (-):</b>   | Is the voltage 9 V or more?   | Go to step 7.  |
|      |  |   | Repair the power supply circuit.   |

# Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step  | Check  | Yes  | No   |
|---|--|--|--|
| <p><b>7</b></p> <p><b>CHECK HARNESS BETWEEN ACTIVE GRILLE SHUTTER CONNECTOR AND CHASSIS GROUND.</b></p> <p>Measure the resistance of harness between active grille shutter connector and chassis ground.</p> <p><b>Connector &amp; terminal</b><br/><b>(F157) No. 4 — Chassis ground:</b></p> | <p>Is the resistance less than 10 <math>\Omega</math>?</p> | <p>Replace the active grille shutter. &lt;Ref. to HEV-77, Active Grille Shutter.&gt;</p> | <p>Repair the harness and connector.</p> <p>NOTE:<br/>In this case, repair the following item:</p> <ul style="list-style-type: none"><li>• Open circuit in harness between active grille shutter connector and chassis ground</li><li>• Poor contact of coupling connector</li></ul> |

## **FV:DTC U0293 LOST COMMUNICATION WITH HYBRID POWERTRAIN CONTROL MODULE**

**NOTE:**

For the diagnostic procedure, refer to LAN section. <Ref. to LAN(HEV)(diag)-2, Basic Diagnostic Procedure.>

## **FW:DTC U0402 INVALID DATA RECEIVED FROM TCM**

**NOTE:**

For the diagnostic procedure, refer to LAN section. <Ref. to LAN(HEV)(diag)-2, Basic Diagnostic Procedure.>

## **FX:DTC U0416 INVALID DATA RECEIVED FROM VEHICLE DYNAMICS CONTROL MODULE**

**NOTE:**

For the diagnostic procedure, refer to LAN section. <Ref. to LAN(HEV)(diag)-2, Basic Diagnostic Procedure.>

## **FY:DTC U0423 INVALID DATA RECEIVED FROM INSTRUMENT PANEL CLUSTER CONTROL MODULE**

**NOTE:**

For the diagnostic procedure, refer to LAN section. <Ref. to LAN(HEV)(diag)-2, Basic Diagnostic Procedure.>

## **FZ:DTC U0594 INVALID DATA RECEIVED FROM HYBRID POWERTRAIN CONTROL MODULE**

**NOTE:**

For the diagnostic procedure, refer to LAN section. <Ref. to LAN(HEV)(diag)-2, Basic Diagnostic Procedure.>

## **GA:DTC U1101 LOST COMMUNICATION WITH TCM PU-CAN**

**NOTE:**

For the diagnostic procedure, refer to LAN section. <Ref. to LAN(HEV)(diag)-2, Basic Diagnostic Procedure.>

## **GB:DTC U1293 LOST COMMUNICATION WITH HYBRID POWERTRAIN CONTROL MODULE PU-CAN**

**NOTE:**

For the diagnostic procedure, refer to LAN section. <Ref. to LAN(HEV)(diag)-2, Basic Diagnostic Procedure.>

## **GC:DTC U1402 INVALID DATA RECEIVED FROM TCM PU-CAN**

**NOTE:**

For the diagnostic procedure, refer to LAN section. <Ref. to LAN(HEV)(diag)-2, Basic Diagnostic Procedure.>

## **GD:DTC U1594 INVALID DATA RECEIVED FROM HYBRID POWERTRAIN CONTROL MODULE PU-CAN**

**NOTE:**

For the diagnostic procedure, refer to LAN section. <Ref. to LAN(HEV)(diag)-2, Basic Diagnostic Procedure.>