

General Description

FUEL INJECTION (FUEL SYSTEMS)


1. General Description

A: SPECIFICATION

Fuel tank	Capacity	52 L (13.7 US gal, 11.4 Imp gal)
	Location	Under rear seat
Fuel pump	Type	Impeller
	Shutoff discharge pressure	750 kPa (7.7 kg/cm ² , 108.8 psi) or less
	Discharge rate	82 L (21.7 US gal, 18 Imp gal)/h or more [12.5 V at 343 kPa (3.5 kg/cm ² , 49.7 psi)]
Fuel filter		In-tank type

B: COMPONENT

1. INTAKE MANIFOLD 1



FU-08230

- (1) Intake manifold
- (2) Manifold absolute pressure sensor
- (3) O-ring
- (4) Purge control solenoid valve
- (5) Purge control solenoid valve bracket
- (6) Gasket
- (7) Tumble generator valve actuator

- (8) Tumble generator valve LH
- (9) Tumble generator valve RH
- (10) Gasket
- (11) Intake manifold protector LH
- (12) Intake manifold protector RH
- (13) Cushion

Tightening torque: N·m (kgf·m, ft·lb)

T1: 3.4 (0.3, 2.5)

T2: 4 (0.4, 3.0)

T3: 6 (0.6, 4.4)

T4: 6.4 (0.7, 4.7)


T5: 8.3 (0.8, 6.1)

T6: 25 (2.5, 18.4)

General Description

FUEL INJECTION (FUEL SYSTEMS)

2. INTAKE MANIFOLD 2




(1)	Fuel delivery pipe	(6)	Seal ring
(2)	Vacuum hose	(7)	Rubber
(3)	Fuel pipe ASSY	(8)	O-ring
(4)	Fuel pipe	(9)	Cylinder head plate
(5)	Fuel injector	(10)	Fuel injector holder

Tightening torque: N·m (kgf·m, ft·lb)

T: 6.4 (0.7, 4.7)

3. THROTTLE BODY



(1) Throttle body
(2) Gasket A


(3) Throttle chamber duct
(4) Gasket B

Tightening torque: N·m (kgf·m, ft·lb)
**T: <Ref. to FU(H4DO(HEV))-16,
INSTALLATION, Throttle
Body.>**

General Description

FUEL INJECTION (FUEL SYSTEMS)

4. CRANKSHAFT POSITION, CAMSHAFT POSITION AND KNOCK SENSORS



(1) Oil control solenoid

(2) Camshaft position sensor

(3) Crankshaft position sensor

(4) Knock sensor

(5) O-ring

(6) Back-up ring

(7) O-ring

(8) Spacer

Tightening torque: N·m (kgf·m, ft-lb)

T1: 6.4 (0.7, 4.7)


T2: 24 (2.4, 17.7)

* Zero or one spacer for gap adjustment.

General Description

FUEL INJECTION (FUEL SYSTEMS)

5. FUEL TANK



FU-08049

General Description


FUEL INJECTION (FUEL SYSTEMS)

(1) Fuel tank	(14) Fuel sub level sensor filter	(27) Cushion
(2) Fuel tank band RH	(15) Fuel sub level sensor protector	(28) Cushion
(3) Fuel tank band LH	(16) Fuel sub level sensor upper plate cushion	(29) Cushion
(4) Delivery tube	(17) Rubber cap	(30) Tube clamp
(5) Jet pump tube	(18) Heat shield cover	
(6) Fuel pump ASSY	(19) Fuel tank protector RH	Tightening torque: N·m (kgf·m, ft-lb)
(7) Fuel pump upper plate	(20) Fuel tank protector LH	T1: 2 (0.2, 1.5)
(8) Fuel pump gasket	(21) Self-locking nut	T2: 2.5 (0.3, 1.8)
(9) Fuel level sensor	(22) Fuel filler hose	T3: 9 (0.9, 6.6)
(10) Fuel pump upper plate cushion	(23) Clamp	T4: 18 (1.8, 13.3)
(11) Fuel sub level sensor	(24) Clamp	T5: 33 (3.4, 24.3)
(12) Fuel sub level sensor upper plate	(25) Evaporation hose	T6: <Ref. to FU(H4DO(HEV))-126, INSTALLATION, Fuel Pump.>
(13) Fuel sub level sensor gasket	(26) Clip	T7: <Ref. to FU(H4DO(HEV))-135, INSTALLATION, Fuel Sub Level Sensor.>

General Description

FUEL INJECTION (FUEL SYSTEMS)

6. FUEL LINE



FU-08924

General Description


FUEL INJECTION (FUEL SYSTEMS)

(1) Fuel delivery tube	(14) Tube clamp	(27) Drain tube B
(2) Evaporation hose	(15) Purge tube	(28) Tube clamp
(3) Tube clamp	(16) Clip	(29) Drain filter
(4) Clip	(17) Vent hose	(30) Leak check valve ASSY
(5) Hose clamp	(18) Clip	(31) Clamp A
(6) Hose clamp bracket	(19) Vent tube	(32) Clamp B
(7) Fuel pipe ASSY	(20) Canister bracket A	(33) Drain bracket
(8) Fuel pipe front grommet	(21) Cushion	(34) Pipe clamp (without gasket)
(9) Pipe clamp	(22) Collar	
(10) Pipe clamp	(23) Canister bracket B	<i>Tightening torque: N·m (kgf·m, ft-lb)</i>
(11) Pipe clamp (with gasket)	(24) Canister bracket C	<i>T1: 5.4 (0.6, 4.0)</i>
(12) Pipe clamp	(25) Canister	<i>T2: 7.5 (0.8, 5.5)</i>
(13) Fuel pipe rear grommet	(26) Drain tube A	

*1 When removing the canister bracket from the canister, use the new canister and canister bracket to install.

*2 When removing the drain bracket from the drain filter, use the new drain filter and drain bracket to install.

7. FUEL FILLER PIPE



FU-06398

(1) Fuel filler pipe ASSY	(5) Fuel filler cap
(2) Neck holder A	(6) Clip
(3) Neck holder B	(7) Upper bracket
(4) Fuel filler pipe protector	(8) Lower bracket


Tightening torque: N·m (kgf·m, ft·lb)

T: 7.5 (0.8, 5.5)

General Description

FUEL INJECTION (FUEL SYSTEMS)

8. FUEL PUMP



FU-07727



(1) Fuel filter ASSY	(6) Connector cable	(11) Spring
(2) O-ring	(7) Fuel pump holder	(12) Fuel chamber ASSY
(3) O-ring	(8) O-ring	(13) Clip
(4) Back-up ring	(9) Spacer	(14) Fuel level sensor
(5) Pressure regulator	(10) Fuel pump	(15) Cushion

C: CAUTION

- Prior to starting work, pay special attention to the following:
 1. Always wear work clothes, a work cap, and protective shoes. Additionally, wear a helmet, protective goggles, etc. if necessary.
 2. Protect the vehicle using a seat cover, fender cover, etc.
 3. Prepare the service tools, clean cloth, containers to catch grease and oil, etc.
- Place "NO OPEN FLAMES" signs near the working area.
- Prepare a container and cloth to prevent scattering of fuels when performing work where fuels can be spilled. If the oil spills, wipe it off immediately to prevent from penetrating into floor or flowing out for environmental protection.
- Vehicle components are extremely hot immediately after driving. Be wary of receiving burns from heated parts.
- When performing a repair, identify the cause of trouble and avoid unnecessary removal, disassembly and replacement.
- Before disconnecting connectors of sensors or units, be sure to disconnect the ground cable from battery.
- Always use the jack-up point when the shop jacks or rigid racks are used to support the vehicle.
- Remove contamination including dirt and corrosion before removal, installation, disassembly or assembly.
- Keep the removed parts in order and protect them from dust and dirt.
- All removed parts, if to be reused, should be reinstalled in the original positions with attention to the correct directions, etc.
- Bolts, nuts and washers should be replaced with new parts as required.
- Follow all government and local regulations concerning disposal of refuse when disposing fuel.

D: PREPARATION TOOL

1. SPECIAL TOOL

ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
 ST18471AA000	18471AA000	FUEL PIPE ADAPTER	Used for draining fuel.
 ST1B022XU0	1B022XU0	SUBARU SELECT MONITOR III KIT	Used for setting of each function and troubleshooting for electrical system. NOTE: For detailed operation procedures of Subaru Select Monitor III, refer to "PC application help for Subaru Select Monitor".

2. GENERAL TOOL

TOOL NAME	REMARKS
Circuit tester	Used for measuring resistance and voltage.
Oscilloscope	Used for inspecting the waveform of each sensor.
Mighty Vac	Used for inspecting the manifold absolute pressure sensor.