


### 3. Generator


#### A: REMOVAL

- 1) Disconnect the ground cable from battery.




- 2) Remove the V-belts. <Ref. to ME(H4SO)-42, V-BELT, REMOVAL, V-belt.> <Ref. to ME(H4DOTC)-42, V-BELT, REMOVAL, V-belt.> <Ref. to ME(H6DO)-48, REMOVAL, V-belt.>


- 3) Disconnect the connector and terminal from generator.



- 4) Remove the collector cover bracket or v-belt cover bracket.



- 5) Remove the generator from the bracket.




#### B: INSTALLATION

Install in the reverse order of removal.

##### Tightening torque:


T1: 25 N·m (2.5 kgf-m, 18.4 ft-lb)  
T2: 6.4 N·m (0.7 kgf-m, 4.7 ft-lb)




#### C: DISASSEMBLY

##### 1. 2.5 L MODEL


- 1) Remove the four through bolts.



- 2) Use a drier to heat the rear cover (A) portion to 50°C (122°F).




3) Insert the end of a flat tip screwdriver into the gap between stator core and front cover. Pry them apart to disassemble.



(A) Screwdriver


4) Using a vise, support the rotor and remove the pulley bolt.



SC-00035

**CAUTION:**


**When holding the rotor with a vise, place aluminum plates or wooden pieces on the vise jaws to prevent rotor from damage.**



(A) Front cover  
(B) Pulley  
(C) Nut  
(D) Rotor


5) Use the following procedures to remove the ball bearings.

(1) Remove the bolt, and then detach the bearing retainer.



SC-00081


(2) Firmly attach an appropriate tool (such as a correct size socket wrench) to the bearing inner race.



SC-00082

(3) Use the press to push the ball bearings out from the front cover.

6) Using the bearing puller, remove the bearings from the rotor.



SC-00046


7) Disconnect the connection between the rectifier and stator coil, then remove the stator coil.

# Generator

## STARTING/CHARGING SYSTEMS


### CAUTION:

The rectifier is easily damaged by heat. Do not allow a 180 — 270 W soldering iron to contact the terminals for 5 seconds or more at a time.




8) Use the following procedures to remove the IC regulator.

(1) Remove the screws which secure the IC regulator to the rear cover.




(2) Disconnect the connection between the IC regulator and rectifier, then remove the IC regulator.




9) Use the following procedures to remove the brush.

(1) Remove the cover A.




(A) Cover A

(2) Remove the cover B.




(A) Cover B

(3) Disconnect the connection and remove the brush.




10) Remove the rectifier as follows.

(1) Remove the bolts which secure the rectifier.




(2) Remove the cover on terminal B.



SC-00090


(3) Remove the nuts of terminal B, then remove the rectifier.



SC-00091


## 2. 3.6 L MODEL

1) Remove the four through bolts.




SC-00078

2) Use a drier to heat the rear cover (A) portion to 50 — 60°C (122 — 140°F).



SC-02299


3) Insert the end of a flat tip screwdriver into the gap between stator core and front cover. Pry them apart to disassemble.



SC-00080

(A) Screwdriver


4) Using a vise, support the rotor and remove the pulley bolt.



SC-00035

### CAUTION:

When holding the rotor with a vise, place aluminum plates or wooden pieces on the vise jaws to prevent rotor from damage.



SC-02300

(A) Front cover

(B) Pulley

(C) Nut


(D) Rotor

5) Use the following procedures to remove the ball bearings.


# Generator

## STARTING/CHARGING SYSTEMS

(1) Remove the bolt, and then detach the bearing retainer.




(2) Firmly attach an appropriate tool (such as a correct size socket wrench) to the bearing inner race.




(3) Use the press to push the ball bearings out from the front cover.


6) Using the bearing puller, remove the bearings from the rotor.



7) Remove six bolts between the rectifier and stator coil, then remove the stator coil.




8) Remove four screws which secure the IC regulator to the rear cover, then remove the IC regulator.




9) Use the following procedures to remove the brush.

(1) Remove the cover A.




(A) Cover A

(2) Remove the cover B.




(A) Cover B

(3) Disconnect the connection and remove the brush.




10) Remove the rectifier as follows.


(1) Remove the cover on terminal B.



(2) Remove the nut on terminal B.



(3) Remove the bolts which secure the rectifier, and remove the rectifier.



## D: ASSEMBLY

Assemble in the reverse order of disassembly.

### NOTE:


Refer to component for tightening torque of each part. <Ref. to SC(H4SO)-5, GENERATOR, COMPONENT, General Description.>

1) Push of the brush

Before assembling the front and rear parts, press the brush down into the brush holder, then fix the brush in that position by inserting a [1 mm (0.08 in) dia., 40 — 50 mm (1.6 — 2.0 in) long] wire through the hole as shown in the figure.

### CAUTION:

After re-assembling, remove the wire.



(A) Wire

2) Install the ball bearings.

(1) Set the ball bearings in the front cover, then securely install an appropriate tool (such as a socket wrench of proper size) to the bearing outer race.

(2) Using a press to press the ball bearings into the specified location.

(3) Install the bearing retainer.

3) Use a press to install the bearings (rear side) to the rotor shaft.

4) Heat the bearing box in rear cover to 50 — 60°C (122 — 140°F), and then press the rear bearing into rear cover.

### CAUTION:

**Do not apply grease to the rear bearings. If there is any oil on the bearing box, remove it completely.**

5) After re-assembling, manually turn the pulley to check that the rotor rotates smoothly.

### E: INSPECTION

#### 1. DIODE

##### CAUTION:

There is the possibility of damaging the diodes if a mega-tester (used to measure high voltages) or a similar measuring instrument is used. Never use a mega tester or equivalent for this test.


1) Check for continuity between the diode lead and terminal E or B. If continuity is not as shown in the table, replace the rectifier.

- At analog type tester

Tester lead		Continuity
-lead	+lead	
E	P1, P2, P3, P4, P5, P6	Yes
B		No
P1, P2, P3, P4, P5, P6	E	No
	B	Yes

- At digital type tester

Tester lead		Continuity
-lead	+lead	
E	P1, P2, P3, P4, P5, P6	No
B		Yes
P1, P2, P3, P4, P5, P6	E	Yes
	B	No



#### 2. ROTOR

##### 1) Slip ring surface

Inspect the slip rings for contamination or any roughness on the sliding surface. Repair the slip ring surface using a lathe or sand paper.

##### 2) Slip ring outer diameter

Measure the slip ring outer diameter. Replace the rotor assembly if the slip ring is worn.

##### *Slip ring outer diameter:*

###### *Standard*

*22.7 mm (0.894 in)*

###### *Service limit*


*22.1 mm (0.870 in)*

##### 3) Continuity test

Using a circuit tester, check the resistance between slip rings. If the resistance is not within the standard, replace the rotor assembly.


##### *Specified resistance:*

*Approximately 2.0 — 2.3  $\Omega$*



##### 4) Insulation test

Check the continuity between slip ring and rotor core or shaft. If there is continuity, replace the rotor assembly because the rotor coil is grounded.



##### 5) Bearing (rear side)

Check the bearing (rear side). If there is any noise, or the rotor does not rotate smoothly, replace the bearings.

### 3. STATOR COIL


#### 1) Continuity test

Inspect the continuity between the stator coil terminals. If continuity is not as shown in the table, replace the stator coil.

(A)					
1	2	3	4	5	6
○	○				
○	○	—	○		
	○	—	○		
		—	○	○	○
			○	○	○
			○	—	○

SC-02349


(A) Terminals



SC-02311

#### 2) Insulation test

Inspect the continuity between the stator coil stator core and lead wire terminals. If there is continuity, replace the stator coil because the stator coil is grounded.



SC-02314

### 4. BRUSH

1) Measure the length of each brush. Replace the brush if wear exceeds service limits. There is a service limit mark (A) on each brush.


#### Brush length:

**Standard (1)**

**22.5 mm (0.886 in)**


**Service limit (2)**

**5.0 mm (0.197 in)**



SC-02313

2) Check that there is appropriate pressure on the brush spring. Using a spring pressure indicator, push the brush into the brush holder until its tip protrudes 2 mm (0.08 in). Then measure the pressure of brush spring. If the pressure is 1.7 N (173 gf, 6.11 ozf) or less, replace the brush spring. 4.1 — 5.3 N (418 — 540 gf, 14.75 — 19.06 ozf) pressure is required on the new spring.



SC-02312

### 5. BALL BEARING (FRONT SIDE)

Check the ball bearings. Replace the ball bearings if there is resistance in the rotation, or if there is any abnormal noise.