


5. Air Intake Duct

A: REMOVAL

- 1) Detach the clip connecting the air intake duct to the front vehicle body, and remove the air intake duct.



B: INSTALLATION

Install in the reverse order of removal.

C: INSPECTION

- 1) Check that the air intake duct has no deformation, cracks or other damages.
- 2) Inspect that no foreign objects are mixed in the air intake duct.