


15. Wastegate Control Solenoid Valve


A: REMOVAL

- 1) Disconnect the ground cable from battery.




- 2) Remove the radiator sub fan motor assembly.
<Ref. to CO(H4DOTC)-27, REMOVAL, Radiator Sub Fan and Fan Motor.>

- 3) Remove the screws which hold the wastegate control solenoid valve to the intake duct.



- 4) Lift up the vehicle.
- 5) Remove the under cover. <Ref. to EI-35, REMOVAL, Front Under Cover.>
- 6) Disconnect the connector and air control hose from the wastegate control solenoid valve, and remove the wastegate control solenoid valve from the intake duct.



B: INSTALLATION

Install in the reverse order of removal.

NOTE:


Use new O-rings.

Tightening torque:

1 N·m (0.1 kgf-m, 0.7 ft-lb)


C: INSPECTION

- 1) Check that the wastegate control solenoid valve has no deformation, cracks or other damages.
- 2) Check the resistance between the wastegate control solenoid valve terminals.



Terminal No.	Standard
1 and 2	$24\pm3\Omega$ (when 20°C (68°F))

- 3) Check that air does not come out from (B) when air is blown into (A).



Wastegate Control Solenoid Valve

FUEL INJECTION (FUEL SYSTEMS)

4) With terminal No. 1 connected to the battery positive terminal and terminal No. 2 to the battery ground terminal, check that air comes out from (B) when air is blown into (A).

