

5. Intake Manifold Vacuum


A: INSPECTION

- 1) Warm up the engine.
- 2) Remove the collector cover.


NOTE:

Follow these procedures for removal of the collector cover.

- (1) Lift up the rear side holding two positions (A).
- (2) Lift up the front side holding two positions (B) while moving it in the forward direction of the vehicle.



- 3) Remove the air intake boot. <Ref. to IN(H6DO)-7, REMOVAL, Air Intake Boot.>
- 4) Disconnect the brake booster vacuum hose from the intake manifold, and attach the vacuum gauge.



- 5) Install the air intake boot. <Ref. to IN(H6DO)-7, INSTALLATION, Air Intake Boot.>
- 6) Keep the engine at idle speed and read the vacuum gauge indication.

NOTE:

Condition of engine inside can be diagnosed by observing the behavior of the vacuum gauge needle as described in table below.

Intake manifold vacuum (at idling, A/C OFF): Standard

Less than -60.0 kPa (-450 mmHg, -17.72 inHg)

| Diagnosis of engine condition by measurement of intake manifold vacuum | |
|---------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------|
| Vacuum gauge indication | Possible engine condition |
| 1. Needle is steady but lower than standard value. This tendency becomes more evident as engine temperature rises. | Leakage around intake manifold gasket, disconnection or damage of vacuum hose |
| 2. Needle intermittently drops to position lower than standard value. | Leakage around cylinder |
| 3. Needle drops suddenly and intermittently from standard value. | Sticky valve |
| 4. When engine speed is gradually increased, needle begins to vibrate rapidly at certain speed, and then vibration increases as engine speed increases. | Weak or broken valve springs |
| 5. Needle vibrates above and below standard value in narrow range. | Defective ignition system |