

# General Description

## AUTOMATIC TRANSMISSION

### 1. General Description

#### A: SPECIFICATION

##### 1. TORQUE CONVERTER CLUTCH

Model	3.6 L non-turbo	
Type	Symmetric, 3-element, single stage, 2-phase torque converter	
Stall torque ratio	1.8	
Nominal diameter	246 mm (9.69 in)	
Stall speed (at sea level)	2,100 — 2,600 rpm	
One-way clutch	Sprague type one-way clutch	

##### 2. OIL PUMP

Type	Internal gear fixed displacement pump	
Driving method	Driven by engine	
Number of teeth	Inner rotor	9
	Outer rotor	10

##### 3. TRANSMISSION CONTROL ELEMENT

Type	5-forward, 1-reverse, double-row planetary gears
Multi-plate clutch	3 sets
Multi-plate brake	3 sets
One-way clutch (sprague type)	2 sets

##### 4. TRANSMISSION GEAR RATIO

1st	3.540
2nd	2.264
3rd	1.471
4th	1.000
5th	0.834
Rev.	2.370

##### 5. PLANETARY GEAR AND PLATE

Model	3.6 L non-turbo
Number of front internal gear teeth	106
Number of front carrier teeth	28
Number of front sun gear teeth	50
Number of mid internal gear teeth	78
Number of mid carrier teeth	18
Number of mid sun gear teeth	42
Number of rear internal gear teeth	110
Number of rear carrier teeth	24
Number of rear sun gear teeth	62
Number of front brake drive plates	2
Number of input clutch drive plates	6
Number of high & low reverse clutch drive plates	4
Number of direct clutch drive plates	5
Number of reverse brake drive plates	5
Number of forward brake drive plates	5

# General Description

AUTOMATIC TRANSMISSION

## 6. SELECTOR POSITION

P (Park)	Transmission is in neutral, output member is immovable, engine start is possible
R (Reverse)	Transmission is in reverse.
N (Neutral)	Transmission is in neutral and engine start is possible
D (Drive)	Automatic gear change 1st $\leftrightarrow$ 2nd $\leftrightarrow$ 3rd $\leftrightarrow$ 4th $\leftrightarrow$ 5th
M (Manual mode), Paddle shift (+)	Manual gear change 1st $\rightarrow$ 2nd $\rightarrow$ 3rd $\rightarrow$ 4th $\rightarrow$ 5th
M (Manual mode), Paddle shift (-)	Manual gear change 1st $\leftarrow$ 2nd $\leftarrow$ 3rd $\leftarrow$ 4th $\leftarrow$ 5th
Control method	Wire cable type

## 7. HYDRAULIC CONTROL AND LUBRICATION

Type	Electronic/hydraulic control [5 forward gear changes made by electronic signals of vehicle speed and accelerator (throttle) opening]	
Fluid	Recommended materials	SUBARU ATF HP
	Alternative	Idemitsu "ATF HP" <b>CAUTION:</b> Be sure to use the recommended or equivalent ATF. Using material except recommended one or substitute would cause trouble.
Fluid capacity	0 (US qt, Imp qt)	
Lubrication system	Forced feed lubrication with oil pump	

## 8. COOLING AND HARNESS

Cooling system	Liquid-cooler incorporated in radiator
Transmission harness	20 + 8 poles

## 9. TRANSFER

Transfer type	Variable torque distribution (VTD)
Number of transfer clutch drives & driven plates	3
Reduction gear ratio	1.000 (41/41)


## 10. FINAL REDUCTION GEAR

Model	3.6 L non-turbo
Front final reduction gear ratio	3.083

# General Description


## AUTOMATIC TRANSMISSION

### 11. RECOMMENDED GEAR OIL

Lubrication oil	 <p>(1) Item (2) Front differential gear oil (3) GL-5 (4) SAE viscosity No. and applicable temperature</p>									
					MT-00001					
Front differential oil capacity	ℓ (US qt, Imp qt)	1.3 — 1.5 (1.4 — 1.6, 1.1 — 1.3)								

### B: COMPONENT

#### 1. TORQUE CONVERTER CLUTCH & TRANSMISSION ASSEMBLY



# General Description


## AUTOMATIC TRANSMISSION

---

(1) Torque converter ASSY	(17) Gasket	(33) Dust cover
(2) Circlip	(18) Union screw	(34) Floating bracket
(3) Oil pump shaft	(19) Ball	(35) Turbine speed sensor 1
(4) Differential oil level gauge	(20) Spring	(36) O-ring
(5) Transmission hanger COMPL	(21) Union screw	(37) Magnet
(6) Differential oil drain plug	(22) ATF outlet pipe	
(7) Gasket	(23) ATF inlet pipe	<b>Tightening torque:N·m (kgf·m, ft·lb)</b>
(8) Oil seal	(24) Drive plate	<b>T1: 5 (0.5, 3.7)</b>
(9) Lock plate	(25) Reinforcement drive plate	<b>T2: 13 (1.3, 9.6)</b>
(10) Side retainer	(26) Oil pan	<b>T3: 20 (2.0, 14.8)</b>
(11) O-ring	(27) Gasket	<b>T4: 25 (2.5, 18.4)</b>
(12) Oil seal	(28) ATF drain plug	<b>T5: 40 (4.1, 29.5)</b>
(13) ATF level gauge	(29) Breather hose	<b>T6: 41 (4.2, 30.2)</b>
(14) O-ring	(30) Nipple	<b>T7: 45 (4.6, 33.2)</b>
(15) Oil charge pipe	(31) O-ring	<b>T8: 70 (7.1, 51.6)</b>
(16) O-ring	(32) Oil seal	<b>T9: 90 (9.2, 66.4)</b>

---

### 2. OIL PUMP & FRONT BRAKE



AT-05572

(1) O-ring	(10) Needle bearing	(19) Retaining plate
(2) Washer	(11) D-ring (Inner)	(20) Snap ring
(3) Oil pump housing	(12) D-ring (Outer)	(21) Stator shaft
(4) Oil pump rotor	(13) Front brake piston	
(5) O-ring	(14) Return spring	
(6) Air breather hose	(15) Retainer	
(7) Oil pump cover	(16) Snap ring	
(8) O-ring	(17) Driven plate	
(9) Nipple	(18) Drive plate	

#### Tightening torque:N·m (kgf·m, ft·lb)


T1: 10 (1.0, 7.4)

T2: 13 (1.3, 9.6)

# General Description

## AUTOMATIC TRANSMISSION


### 3. FRONT PLANETARY CARRIER AND MIDDLE & REAR PLANETARY CARRIER



AT-05573

(1) Thrust bearing	(8) Thrust bearing	(15) Rear carrier ASSY
(2) Front sun gear ASSY	(9) Input clutch ASSY	(16) Thrust bearing
(3) Snap ring	(10) Rear internal gear ASSY	(17) Middle & rear sun gear ASSY
(4) Front carrier ASSY	(11) Thrust bearing	(18) Washer
(5) Race bearing	(12) Middle carrier ASSY	(19) Thrust bearing
(6) O-ring	(13) Thrust bearing	(20) Seal ring
(7) Seal ring	(14) Race bearing	

## 4. DIRECT CLUTCH AND HIGH & LOW REVERSE CLUTCH



AT-02018

(1) Thrust bearing


(2) High & low reverse clutch ASSY

(3) Direct clutch ASSY

# General Description

## AUTOMATIC TRANSMISSION


### 5. REVERSE BRAKE



AT-05589

(1) Snap ring	(6) Dish plate	(11) D-ring (Outer)
(2) Retaining plate	(7) Snap ring	(12) D-ring (Inner)
(3) Leaf spring	(8) Retainer	(13) AT main case
(4) Drive plate	(9) Return spring	
(5) Driven plate	(10) Reverse brake piston	

### 6. SHORT AT ASSEMBLY



AT-04385

(1) Short AT assembly (non-disassembled)

(3) Seal ring


(4) Thrust bearing

(2) Thrust bearing

# General Description

## AUTOMATIC TRANSMISSION

### 7. CONTROL VALVE & TRANSMISSION HARNESS



AT-05574


- (1) Rear vehicle speed sensor
- (2) Transmission harness ASSY
- (3) Front vehicle speed sensor
- (4) Turbine speed sensor 1

- (5) Harness bracket
- (6) Clip
- (7) Control valve ASSY
- (8) O-ring

- (9) O-ring

**Tightening torque: N·m (kgf·m, ft·lb)**  
**T: 7 (0.7, 5.2)**

### 8. DIFFERENTIAL GEAR



AT-03807

(1) Retainer lock plate	(9) Straight pin
(2) Differential side retainer RH	(10) Differential case RH
(3) O-ring	(11) Differential case LH
(4) Oil seal	(12) Differential bevel gear
(5) Taper roller bearing	(13) Washer
(6) Hypoid driven gear	(14) Differential bevel pinion
(7) Drive pinion shaft	(15) Differential side retainer LH
(8) Pinion shaft	

**Tightening torque:N·m (kgf·m, ft·lb)**


**T1: 25 (2.5, 18.4)**

**T2: 70 (7.1, 51.6)**

# General Description

## AUTOMATIC TRANSMISSION

### 9. TRANSFER CASE, EXTENSION CASE & REDUCTION GEAR



AT-05595

# General Description

## AUTOMATIC TRANSMISSION

---


(1) Seal ring	(20) Ball bearing	(39) Extension case
(2) Reduction gear shim	(21) Rear drive shaft shim	(40) Transmission hanger
(3) Ball bearing	(22) Revolution gear	(41) Oil seal
(4) Snap ring	(23) Snap ring	(42) Dust cover
(5) Planetary pinion washer	(24) Clutch spring retainer	(43) Taper roller bearing
(6) Needle bearing	(25) Return spring	(44) Drive pinion shim
(7) Spacer	(26) Spring retainer	(45) Oil seal
(8) Pinion gear	(27) Pressure plate	(46) Drive pinion collar
(9) Planetary carrier ASSY	(28) Ball bearing	(47) O-ring
(10) Planetary pinion shaft ASSY	(29) O-ring	(48) Lock nut
(11) Snap ring	(30) Transfer clutch piston	(49) O-ring
(12) Thrust bearing	(31) D-ring	
(13) Intermediate shaft	(32) Drive pinion shaft	<b>Tightening torque:N·m (kgf·m, ft·lb)</b>
(14) Thrust washer	(33) Ball bearing	<b>T1: 13 (1.3, 9.6)</b>
(15) Rear drive shaft	(34) Reduction driven gear	<b>T2: 25 (2.5, 18.4)</b>
(16) Ball bearing	(35) Snap ring	<b>T3: 70 (7.1, 51.6)</b>
(17) Transfer clutch hub	(36) Ball bearing	<b>T4: 116 (11.8, 85.6)</b>
(18) Transfer clutch plate	(37) Shim	
(19) Driven plate No. 3.	(38) Gasket	

---

# General Description

## AUTOMATIC TRANSMISSION

### 10. TRANSMISSION CONTROL DEVICE & PARKING SUPPORT



(1)	Bracket	(10)	Parking pawl shaft
(2)	Floating bracket	(11)	Return spring
(3)	AT main case	(12)	Parking pawl
(4)	Range select lever	(13)	Ball bearing
(5)	Straight pin	(14)	Snap ring
(6)	Detent spring	(15)	Parking gear
(7)	Manual plate	(16)	Reduction driven gear
(8)	Parking rod	(17)	Ball bearing
(9)	Parking support actuator	(18)	Gasket

#### Tightening torque:N·m (kgf·m, ft·lb)

T1: 6 (0.6, 4.4)


T2: 7 (0.7, 5.2)

T3: 18 (1.8, 13.3)

T4: 25 (2.5, 18.4)

T5: <Ref. to 5AT-76, Parking Pawl.>

### 11. TRANSMISSION CONTROL MODULE



AT-05557

(1) Transmission control module  
(TCM)

(2) Relay


***Tightening torque:N·m (kgf·m, ft·lb)***

***T: 7.5 (0.8, 5.5)***

# General Description

## AUTOMATIC TRANSMISSION

### 12. TRANSMISSION MOUNTING



(1) Rear cushion rubber

(2) Crossmember

(3) Stopper

(4) Transmission main mounting bracket (RH)

(5) Transmission main mounting bracket (LH)

**Tightening torque: N·m (kgf·m, ft·lb)**

**T1: 35 (3.6, 25.8)**

**T2: 40 (4.1, 29.5)**

**T3: 45 (4.6, 33.2)**



**T4: 75 (7.6, 55.3)**

### C: CAUTION

- Wear appropriate work clothing, including a cap, protective goggles and protective shoes when performing any work.
- Remove contamination including dirt and corrosion before removal, installation or disassembly.
- Keep the disassembled parts in order and protect them from dust and dirt.
- Until the oil pan is removed, do not place with the oil pan side facing up to prevent foreign matter from entering the valve body.
- Before removal, installation or disassembly, be sure to clarify the failure. Avoid unnecessary removal, disassembly and replacement.
- When disassembling the case and other light alloy parts, disassemble them by slightly tapping with a plastic hammer. Do not pry apart with screwdrivers or other tools.
- Vehicle components are extremely hot after driving. Be wary of receiving burns from heated parts.
- Use SUBARU genuine gear oil, grease or equivalent. Do not mix them of different grades or manufacturers.
- Be sure to tighten bolts and nuts to the specified torque.
- Place shop jacks or rigid racks at the specified points.
- Apply gear oil onto sliding or revolving surfaces before installation.
- Replace deformed or damaged snap rings with new parts.
- Before installing O-rings or oil seals, apply sufficient amount of ATF fluid to avoid damage and deformation.
- Be careful not to incorrectly install or fail to install O-rings, snap rings and other such parts.
- Before securing a part on a vise, place cushioning material such as wood blocks, aluminum plate, or cloth between the part and the vise.
- Avoid damaging the mating surface of the case.
- Before applying liquid gasket, completely remove the old liquid gasket.






### D: PREPARATION TOOL

#### 1. SPECIAL TOOL

ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
 ST-498575400	498575400	OIL PRESSURE GAUGE ASSY	Used for measuring oil pressure.
 ST-498897200	498897200	OIL PRESSURE ADAPTER	Used together with oil pump cover installed on when measuring line pressure.





## General Description

### AUTOMATIC TRANSMISSION

ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
 ST-498897800	498897800	OIL PRESSURE ADAPTER SET	Used for measuring transfer clutch pressure.
 ST-498277200	498277200	STOPPER SET	<ul style="list-style-type: none"> <li>Used for removing and installing automatic transmission assembly to engine.</li> <li>Used for preventing the torque converter from dropping off.</li> </ul>
 ST-398527700	398527700	PULLER ASSY	<ul style="list-style-type: none"> <li>Used for removing the extension case roller bearing.</li> <li>Used for removing the extension oil seal.</li> <li>Used for removing the front differential side retainer bearing outer race.</li> <li>Used for removing the front differential side retainer oil seal.</li> </ul>
 ST-498057300	498057300	INSTALLER	Used for installing the extension oil seal.
 ST-498077000	498077000	REMOVER	Used for removing the differential taper roller bearing.






## General Description

AUTOMATIC TRANSMISSION

ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
	18658AA020 (Newly adopted tool) ST18658AA020	WRENCH COMPL RETAINER	<ul style="list-style-type: none"> <li>Used for removing and installing the differential side retainer.</li> <li>Existing SST (18630AA010) with the handle removed. Use together with a commercially sold spinner handle.</li> <li>WRENCH COMPL RETAINER (18630AA010) can also be used.</li> </ul>
	398487700	DRIFT	Used for installing the front differential taper roller bearing.
	498255400 ST-498255400	PLATE	Used for measuring the backlash of hypoid gear.
	498247001 ST-498247001	MAGNET BASE	<ul style="list-style-type: none"> <li>Used for measuring the gear backlash.</li> <li>Used together with DIAL GAUGE (498247100).</li> </ul>
	498247100 ST-498247100	DIAL GAUGE	<ul style="list-style-type: none"> <li>Used for measuring the gear backlash.</li> <li>Used together with MAGNET BASE (498247001).</li> </ul>






## General Description

### AUTOMATIC TRANSMISSION

ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
	498517000	REPLACER	Used for removing the front roller bearing.
	499787700	WRENCH	Used for removing and installing the drive pinion lock nut.
	398643600	GAUGE	Used for measuring total end play, extension end play and drive pinion height.
	398744300	PISTON GUIDE	Used for measuring height from mating surface of the main case to pressure plate.
	499737100	PULLER SET	Used for removing the reduction driven gear assembly.





## General Description

AUTOMATIC TRANSMISSION

ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
	498077600	REMOVER	Used for removing the ball bearing.
	18667AA010	HOLDER	<ul style="list-style-type: none"> <li>Used for removing and installing the drive pinion lock nut.</li> <li>Used as a handle to rotate gear when checking tooth contact.</li> </ul>
	1B022XU0	SUBARU SELECT MONITOR III KIT	Used for troubleshooting the electrical system.
	18675AA000	DIFFERENTIAL SIDE OIL SEAL INSTALLER	Used for installing the differential side retainer oil seal.
	18654AA000	INSTALLER	Used for removing and installing the ball bearing.






## General Description

### AUTOMATIC TRANSMISSION

ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
	28399SA010	OIL SEAL PROTECTOR	Used for protecting oil seal when installing front drive shaft.
	18763AA000	COMPRESSOR SHAFT	Used for disassembling multi-plate clutch for shift transmission.
	18765AA000	COMPRESSOR SUPPORT	Used for disassembling multi-plate clutch for shift transmission.
	18676AA020	TORX® WRENCH	Used for disassembling torque converter case.
	18854AA000	ANGLE GAUGE	Used for tightening parking support.






## General Description

AUTOMATIC TRANSMISSION

ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
	498077300	REMOVER	Used for removing ball bearing of reduction driven gear.
	499587100	OIL SEAL INSTALLER	Used for installing the oil seal.
	499787500	ADAPTER	Used for removing and installing drive pinion lock nut.
	499575400	GAUGE	Used for measuring the height of total end play.
	18762AA000	COMPRESSOR SPECIAL TOOL	Used for disassembling multi-plate clutch for shift transmission.




## General Description

### AUTOMATIC TRANSMISSION

ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
	499755602	PRESS	Used for installing the parking gear.
	18680AA010	GEAR HOLDER	Used for removing reduction driven gear assembly. (2-piece set)
	18766AA000	SUPPORT PULLER	Used for removing reduction driven gear assembly.
	18767AA000	REMOVER	<ul style="list-style-type: none"> <li>Used to pull out the parking gear.</li> <li>Used to pull out the bearing from the VTD assembly.</li> </ul>
	41099AJ010 (Newly adopted tool)	SPECIAL TOOL H6	<ul style="list-style-type: none"> <li>Used for removing and installing transmission.</li> <li>For H6 engine.</li> </ul>

# General Description

AUTOMATIC TRANSMISSION

ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
	18360AA020 (Newly adopted tool) ST18360AA020	HANGER	<ul style="list-style-type: none"> <li>Used for removing and installing transmission.</li> <li>For H6 engine.</li> </ul>
	99099AJ000 (Newly adopted tool) ST99099AJ000	SPECIAL TOOL ENGINE HANGER	<ul style="list-style-type: none"> <li>Used for removing and installing transmission. (Weight of 350 kg (772 lb) is supported)</li> <li>Used together with SPECIAL TOOL CHAIN BALANCER (99099AJ010) and sling chain (general tool).</li> </ul>
	99099AJ010 (Newly adopted tool) ST99099AJ010	SPECIAL TOOL CHAIN BALANCER	<ul style="list-style-type: none"> <li>Used for removing and installing transmission. (Weight of 350 kg (772 lb) is supported)</li> <li>Used together with SPECIAL TOOL ENGINE HANGER (99099AJ000) and sling chain (general tool).</li> <li>Used to hang the engine while balancing it with the sling chain inserted in this tool.</li> </ul>

## 2. GENERAL TOOL

TOOL NAME	REMARKS
Depth gauge	Used for measuring the transmission end play.
Thickness gauge	Used for measuring clearance of the clutch, brake and oil pump.
Micrometer	Used for measuring thickness of the drive pinion.
Spring scale	Used for measuring the starting torque of the drive pinion.
Circuit tester	Used for measuring resistance and voltage.
TORX® T70	Used for removing and installing differential gear oil drain plug.
Snap ring pliers	Used for removing and installing each snap ring.
Sling chain	Used for removing and installing transmission. <ul style="list-style-type: none"> <li>Length: 0.8 — 1 m (2.6 — 3.3 ft)</li> <li>Load capacity: 1.2 t (2646 lb) or more</li> <li>Diameter: 6 mm (0.24 in) or 6.3 mm (0.25 in)</li> <li>Chain external width: 23.5 mm (0.93 in) or less</li> <li>Chain internal width: 8.5 mm (0.33 in) or more</li> </ul>
Screw shackle	Used for removing and installing transmission. <ul style="list-style-type: none"> <li>Load capacity: 250 kg (551 lb) or more</li> <li>Use two pieces.</li> </ul>