

Read Diagnostic Trouble Code (DTC)

HVAC SYSTEM (AUTO A/C) (DIAGNOSTICS)

9. Read Diagnostic Trouble Code (DTC)

A: OPERATION

For details of operation procedures, refer to “PC application help for Subaru Select Monitor”.