


# General Description

## AIRBAG SYSTEM (DIAGNOSTICS)


### 3. General Description

#### A: CAUTION


- When servicing a vehicle, be sure to turn the ignition switch to OFF, disconnect the ground cable from battery, and wait for more than 20 seconds before starting work.
- The airbag system is fitted with a backup power source. After disconnecting the battery ground cable, the airbag may deploy if you do not wait for more than 20 seconds before starting the service of airbag system.




- If sensors, airbag module, airbag control module, pretensioner or harness is deformed or damaged, replace with new part.




- Do not use the airbag system and pretensioners on other vehicles. When replacing parts, be sure to replace them with new ones.
- When checking the airbag system, be sure to use a digital circuit tester. Use of an analog circuit tester may cause the airbag to activate erroneously due to a minimal current inside tester.



- When checking, use a test harness (1). Damage to connector terminal causes malfunction. Do not directly put the tester probe on airbag connector terminal.




- Do not drop the airbag system parts, or keep them at high temperature over 93°C (199°F), or let water, oil or grease get on them; the internal parts may be damaged and reliability greatly lowered.




## General Description

### AIRBAG SYSTEM (DIAGNOSTICS)


- If damage, open circuit or rust is found on airbag system wire harness, do not use a soldering equipment to repair. Replace the faulty harness with a new genuine part.




- Install the wire harness securely with the specified clips to avoid interference or tangled with other parts.




- Do not allow water or oil to come in contact with the connector terminals. Also do not touch the connector terminals.




- Either of the airbag modules for driver's, passenger's, side or curtain, or the pretensioner must not be disassembled.



- The airbag module cannot be used again if deployed once.
- After removal, keep the airbag module with the pad side facing upward on a dry, clean and flat surface away from heat, light sources, moisture and dust.




- Do not check continuity of the airbag modules for driver's side, passenger's side and curtain, or the pretensioner.



## General Description


### AIRBAG SYSTEM (DIAGNOSTICS)

- The removed front seat with airbag module must be kept at least 200 mm (8 in) away from walls and other objects.



(1) 200 mm (8 in) or more

- When painting or performing sheet metal work on the front part of the vehicle, including the front wheel apron, front fender and front side frame, remove the front sub sensors and wire harness of airbag system.
- When painting or performing sheet metal work on the side of the vehicle, including the side sill, center pillar and front and rear doors, remove the side airbag sensors and wire harness of the airbag system.








- Do not discard undeployed airbag module. They could easily cause a serious accident if accidentally deployed.

# General Description






## AIRBAG SYSTEM (DIAGNOSTICS)

- When storing a removed airbag module, do not place any objects on it or pile them up. If the airbag inflates for some reason when it is placed with its pad side facing downward or under any object, a serious accident may result.

(1)



(2)



AB-00130

(1) Driver's airbag module

(2) Passenger's airbag module

# General Description

## AIRBAG SYSTEM (DIAGNOSTICS)

### B: INSPECTION

Measure the battery voltage and check electrolyte.

**Standard voltage: 12 V**


**Specific gravity: Above 1.260**

### C: PREPARATION TOOL

#### CAUTION:

To measure the voltage and resistance of airbag system component, be sure to use the specified test harness.


#### 1. SPECIAL TOOL


ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
 ST18482AA010	18482AA010	CARTRIDGE	Troubleshooting for the electrical system.
 ST22771AA030	22771AA030	SUBARU SELECT MONITOR KIT	Troubleshooting for the electrical system.

# General Description

## AIRBAG SYSTEM (DIAGNOSTICS)

- TEST HARNESS D


ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
 ST98299AG060	98299AG060	TEST HARNESS D	Used when measuring voltage and resistance of the front seat belt buckle switch.




# General Description

## AIRBAG SYSTEM (DIAGNOSTICS)

- TEST HARNESS F


ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
 ST98299FC010	98299FC010	TEST HARNESS F	Used when measuring voltage and resistance of airbag module harnesses.




# General Description

## AIRBAG SYSTEM (DIAGNOSTICS)

- TEST HARNESS H


ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
 ST98299FA030	98299FA030	TEST HARNESS H	Used when measuring voltage and resistance of front sub sensor.




# General Description

## AIRBAG SYSTEM (DIAGNOSTICS)

- TEST HARNESS N


ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
 ST98299SA000	98299SA000	TEST HARNESS N	Used when measuring voltage and resistance of driver's airbag module and seat belt pretensioner.




# General Description

## AIRBAG SYSTEM (DIAGNOSTICS)

- TEST HARNESS P


ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
 ST98299SA020	98299SA020	TEST HARNESS P	Used when measuring voltage and resistance of driver's airbag module harness and passenger's airbag module harness.




# General Description

## AIRBAG SYSTEM (DIAGNOSTICS)

- TEST HARNESS Q


ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
 ST98299SA040	98299SA040	TEST HARNESS Q	Used when measuring voltage and resistance of driver's airbag module.



## General Description


### AIRBAG SYSTEM (DIAGNOSTICS)

- TEST HARNESS U

ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
	98299AG000 ST98299AG000	TEST HARNESS U	Used when measuring voltage and resistance of airbag control module.

# General Description

## AIRBAG SYSTEM (DIAGNOSTICS)





AB-00930

# General Description

## AIRBAG SYSTEM (DIAGNOSTICS)

### • TEST HARNESS V


ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
 ST98299AG010	98299AG010	TEST HARNESS V	Used when measuring voltage and resistance of side airbag sensor and curtain airbag sensor.




# General Description

## AIRBAG SYSTEM (DIAGNOSTICS)

- TEST HARNESS Y

ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
 ST98299AG040	28299AG040	TEST HARNESS Y	Used for diagnosing a failure of the seat belt buckle switch.





AB-01069

# General Description

AIRBAG SYSTEM (DIAGNOSTICS)

- TEST HARNESS AB


ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
 ST98299XA000	98299XA000	TEST HARNESS AB	Used when measuring voltage and resistance of occupant detection system.




# General Description

## AIRBAG SYSTEM (DIAGNOSTICS)

- TEST HARNESS AC


ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
 ST98299XA010	98299XA010	TEST HARNESS AC	Used for diagnosing a failure of the seat belt tension sensor.




# General Description

AIRBAG SYSTEM (DIAGNOSTICS)

- TEST HARNESS AD

ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
 ST98299XA020	98299XA020	TEST HARNESS AD	Used when measuring voltage and resistance of seat belt tension sensor.





OD-00028

# General Description

## AIRBAG SYSTEM (DIAGNOSTICS)

- TEST HARNESS AE


ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
 ST98299XA030	98299XA030	TEST HARNESS AE	<ul style="list-style-type: none"><li>Used for diagnosing a failure of the seat belt buckle switch.</li><li>Used together with the test harness Y.</li></ul>




# General Description

AIRBAG SYSTEM (DIAGNOSTICS)

## • AIRBAG RESISTOR

ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
 ST98299PA040	98299PA040	AIRBAG RESISTOR	Used in replacement of airbag module for which resistance value is same as airbag module.



## 2. GENERAL TOOL

TOOL NAME	REMARKS
Circuit tester	Used for measuring resistance, voltage and current.
Oscilloscope	Used for measuring the sensor.