


8. Warning Box

A: REMOVAL

- 1) Disconnect the ground cable from battery.
- 2) Remove the upper grille. <Ref. to AC-46, REMOVAL, Air Vent Grille.>
- 3) Remove the screws of warning box (1) and pull out the warning box.



- 4) Disconnect the connector in the rear side of warning box to remove the warning box.

B: INSTALLATION

Install in the reverse order of removal.

CAUTION:

- Make sure the electrical connector is connected securely.
- Make sure that each indicator operates normally.

Warning Box

INSTRUMENTATION/DRIVER INFO
