


### 5. Yaw Rate & Lateral G Sensor

#### A: REMOVAL

- 1) Disconnect the ground cable from the battery.
- 2) Remove the console box.  
<Ref. to EI-38, Console Box.>
- 3) Disconnect the connector from the yaw rate & G sensor.
- 4) Remove the yaw rate & G sensor.

#### CAUTION:

**Do not drop or bump the yaw rate & G sensor.**




#### B: INSTALLATION

Install in the reverse order of removal.

#### NOTE:

Install the yaw rate & G sensor to the body while pointing the arrow mark on the sensor to the front of the vehicle.



#### Tightening torque:

**7.5 N·m (0.76 kgf-m, 5.5 ft-lb)**

#### CAUTION:

After completion of installation, set the following two positions.

- Positioning to the center of steering angle sensor
- Positioning of the yaw rate & lateral G sensors to zero.

The above procedure is required VDCCM&H/U to identify the vehicle position afterward. For the setting procedures of the 2 steps above, refer to "VDC Control Module & Hydraulic Control Unit (VDCCM&H/U)". <Ref. to VDC-11, ADJUSTMENT, VDC Control Module & Hydraulic Control Unit (VDCCM&H/U).>