


2. Tire

A: INSPECTION

- 1) Take stones, glass, nails etc. out of the tread groove.
- 2) Replace tires in the following cases.


CAUTION:

- When replacing a tire, make sure to use only tires of the same size, construction and load range as originally installed.
- Use a tire changer when removing the tire from the wheel.
- On models equipped with tire pressure monitoring systems, do not use the bead breaker in a 90° area centered on the transmitter to prevent damaging the transmitter.



(1) Transmitter
 (2) 90° (use of a bead breaker is prohibited in this area.)


- To prevent damaging the transmitter, set the tire changer boom in the position as shown in the figure.



(1) Transmitter
 (2) Turn table rotation direction
 (3) 90°
 (4) Tire changer boom

- (1) If large cracks on side wall, damage or cracks on the tread is found.

- (2) When the "tread wear indicator" appears as a solid band across the tread.




(1) Tread wear indicator
 (2) Tire tread

- 3) When a crack on tire valve is found, replace the tire valve.

1. TIRE ROTATION

Rotate tires periodically (12,500 km/7,500 miles) as shown in the figure, in order to prevent them from uneven wear and to prolong their life.



NOTE:

Vehicles equipped with tire pressure monitoring systems will require re-registration of transmitter ID. <Ref. to TPM(diag)-9, REGISTER TRANSMITTER ID, OPERATION, Subaru Select Monitor.>